

フロントサラウンドシステム

ESB-1090

インストールガイド

JA

本書ではセットアップファイルを使用してモードを詳細に設定する方法について説明します。
セットアップファイルを使用せずにモードを設定する方法については「ESB-1090 取扱説明書」をお読みください。

手順 1. セットアップファイルの作成

次のものを用意してください。

- ・ セットアップファイル作成ツール（名称：ESB-1090_Create_SetupFile.xlsm）
- ・ （中身が空の）USB メモリー

1-1. セットアップファイル作成ツールを開く

次の画面が表示されます。

	A	B	C	D	E	F	G
1	Conference Mode / Hotel Mode / Education Mode setup file for ESB-1090 rev 1.0						
2	Note: Select or change values only in the cells colored with 						
3	Model	Description	Range	Value	Command	Parameter	Notes
4	ESB-1090						
5	Mode Setting	Choose Conference Mode or Hotel Mode or Education Mode	[Select from the list]	Conference Mode	CONFERENCE	1	
7	Auto Power Off	Enabling/disabling Auto Power Off function	[Select from the list]	DISABLE	AUTOPOWER	DISABLE	
9	Turn on Volume	Setup a volume level when the unit turns on. This level should be set to no more than MAX Volume at most	1 - 50 "0" = function disabled	20	TONVOLUME	20	When "0", this function is disabled. Change the value in D9 cell
11	MAX Volume	Setup the max volume. This level needs to be set at least equal to Turn on Volume or higher	1 - 50	50	MAXVOLUME	50	Change the value in D11 cell
13	Key Pattern	Setup the operation specification when pressing the main unit key	[Select from the list]	Key Pattern 2	KEY	2	Key Pattern 1: Enable Volume keys. Key Pattern 2: Disable all keys.
15	Power Back Up	Enabling/disabling to memory the power on/off status right before AC power is unplugged and to get it back to the last status	[Select from the list]	DISABLE	POWERBU	DISABLE	
17	Bluetooth Function	Enabling/disabling Bluetooth function	[Select from the list]	DISABLE	BLUETOOTH	DISABLE	
19	Bluetooth Name	Rename the Bluetooth Name as needed. If there's no texts specified here, the default name is assigned	Under 13 characters with ASCII codes (1-byte character sets)	---	---	---	This setup is invalid when Bluetooth Function is disabled. Change D19 cell to modify the name.
20	Turn on Input	Setup a default input when turned on	[Select from the list]	HDMI	TONINPUT	HDMI	
25	Network Control	Enabling/disabling Network Control function	[Select from the list]	ENABLE	NETCTL	ENABLE	
27	Setup file contents --- texts below here to be output to a text file. Do not modify this cell.						
28	//ESB-1090 Setup File (rev 1.0)						
31	CONFERENCE 1						
32	AUTOPOWER DISABLE						
33	TONVOLUME 20						
34	MAXVOLUME 50						
35	KEY 2						
36	POWERBU DISABLE						
37	BLUETOOTH DISABLE						
38	TONINPUT HDMI						
39	NETCTL ENABLE						
40							
41							
42							
43							
44							
45							
46							
47							
48							
49							
50							
51							
52							
53							
54							
55							

Output file name: demo_0000.txt

Create a Setup Text File

1-2. 各項目の記載内容を確認し、必要に応じて [Value] (D 列) を変更する

	A	B	C	D
1	Conference Mode / Hotel Mode / Education Mode setup file for ESB-10	rev 1.0		
2	Note: Select or change values only in the cells colored with 			
3	Model	Description	Range	Value
4	ESB-1090			
①	5 Mode Setting	Choose Conference Mode or Hotel Mode or Education Mode	[Select from the list]	Conference Mode
②	7 Auto Power Off	Enabling/disabling Auto Power Off function	[Select from the list]	DISABLE
③	9 Turn on Volume	Setup a volume level when the unit turns on. This level should be set to no more than MAX Volume at most	1 - 50 "0" = function disabled	20
④	11 MAX Volume	Setup the max volume. This level needs to be set at least equal to Turn on Volume or higher	1 - 50	50
⑤	13 Key Pattern	Setup the operation specification when pressing the main unit key	[Select from the list]	Key Pattern 2
⑥	15 Power Back Up	Enabling/disabling to memory the power on/off status right before AC power is unplugged and to get it back to the last status	[Select from the list]	DISABLE
⑦	17 Bluetooth Function	Enabling/disabling Bluetooth function	[Select from the list]	DISABLE
⑧	19 Bluetooth Name	Rename the Bluetooth Name as needed. If there's no texts specified here, the default name is assigned	Under 13 characters with ASCII codes (1-byte character sets)	---
⑨	21 Turn on Input	Setup a default input when turned on	[Select from the list]	HDMI
⑩	23 Network Control	Enabling/disabling Network Control function	[Select from the list]	ENABLE

① [Mode Setting]

本機のモードを設定できます。

② [Auto Power Off]

自動スタンバイ機能（本機の電源を自動でオフにする機能）の有効 / 無効を設定できます。この機能が有効のとき、次のどちらかの条件が満たされると本機の電源が自動でオフになります。

- ・ 本機が操作されないまま 8 時間が経過
- ・ 本機が操作されないまま、かつ本機への音声信号の入力がないまま 10 分間が経過

③ [Turn on Volume]

本機の電源をオンにしたときのスピーカーの音量を設定できます。1 から 50 までの整数を入力してください。

なお、0 を入力すると、この項目の設定が無効になります。

④ [MAX Volume]

スピーカーの最大音量を設定できます。1 から 50 までの整数を入力してください。

必ず ③ [Turn on Volume] よりも大きい数を入力してください。

⑤ [Key Pattern]

[Key Pattern1] を選択するとタッチパネルの音量（+）ボタン / 音量（-）ボタンによる操作を有効に、電源ボタン / 入力元設定ボタンによる操作を無効にできます。[Key Pattern2] を選択するとタッチパネルのすべてのボタンによる操作を無効にできます。[Key Pattern3] を選択するとタッチパネルのすべてのボタンによる操作を有効にできます。

6 [Power Back Up]

パワーバックアップ機能（本機の電源の状態を本機自体が記録する機能）の有効 / 無効を設定できます。電源プラグがコンセントから抜けると本機は起動を停止します。（電源プラグをコンセントに差し込んで）再起動させるときの本機の電源の状態は、この機能が有効か無効か、および本機がどのモードかによって変わります。

・ パワーバックアップ機能が有効のとき

- （起動停止前の）本機の電源が「オン」 → （モードに関係なく）再起動時の本機の電源は「オン」
- （起動停止前の）本機の電源が「オフ」 → （モードに関係なく）再起動時の本機の電源は「オフ」

・ パワーバックアップ機能が無効のとき

- 本機が Conference モード → （起動停止前の状態に関係なく）再起動時の本機の電源は「オン」
- 本機が Hotel モード → （起動停止前の状態に関係なく）再起動時の本機の電源は「オフ」
- 本機が Education モード → （起動停止前の状態に関係なく）再起動時の本機の電源は「オフ」

7 [Bluetooth Function]

Bluetooth® 機能の有効 / 無効を設定できます。

8 [Bluetooth Name]

Bluetooth の名称を設定できます。13 文字以下の ASCII 文字を入力してください。

9 [Turn on Input]

本機の電源をオンにしたときの音声信号の入力元を設定できます。

10 [Network Control]

ネットワークコントロール機能（本機を有線ネットワーク経由で遠隔操作する機能）の有効 / 無効を設定できます。

1-3. [Create a Setup Text File] ボタンをクリックする

セットアップファイルが作成され、セットアップファイル作成ツールと同じフォルダに保存されます。

お知らせ 出力ファイル名について

- ・ 出力ファイル名は “demo_****.txt” とする必要があります。
“****” の部分は変更可能です。
- ・ **** は次の半角文字を使用して、64 文字以内にする必要があります。
大文字：[A-Z]
小文字：[a-z]
数字： [0-9]
記号： !#\$%&'()+,-.;:=@[]^_`{}~
スペース

1-4. セットアップファイルを USB メモリーに保存する

USB メモリーには作成したセットアップファイルだけを保存してください。

手順 2. 設定内容のインストール

2-1. リモコンの電源ボタンを押して本機の電源をオフにする

2-2. リモコンのボタンを次の順に押す

“MUSIC ボタンを 1 回” > “VOLUME (－) ボタンを 2 回” > “消音ボタンを 1 回”

本機の電源がオンになります。

2-3. リモコンの電源ボタンを押して本機の電源をオフにする

2-4. USB メモリーを本機背面の UPDATE ONLY 端子に差し込む

2-5. リモコンのボタンを次の順に押す

“BASS EXT ボタンを 1 回” > “VOLUME (+) ボタンを 2 回” > “消音ボタンを 1 回”

手順は以上です。設定が完了すると本機の電源がオンになります。

Yamaha Global Site
U.S.A. and Canada
<https://uc.yamaha.com/>
Other countries
<https://www.yamaha.com/>

Yamaha Downloads
U.S.A. and Canada
<https://uc.yamaha.com/support/>
Other countries
<https://download.yamaha.com/>

Manual Development Group
© 2021 Yamaha Corporation
2021年10月発行
IP-B0