

## Speaker Options Compatibility Chart

	BWS20-120	BWS20-190	BWS50-190	BWS50-260	BWS251-300	BWS251-400	BCS20-150	BCS20-210	BCS251	BBS251	BAS-10	BMS-10A
IF2208(W)	—	—	—	—	●	●	—	—	●	●	—	—
IF2108(W)	—	—	—	—	●	●	—	—	●	●	—	—
IF2205(W)	—	—	—	—	●	●	—	—	●	●	—	—
CBR15	—	—	—	—	●	●	—	—	●	●	—	—
CBR12	—	—	—	—	●	●	—	—	●	●	—	—
CBR10	—	—	—	—	●	●	—	—	●	●	—	—
MSP7 STUDIO	—	—	● <sup>*1</sup>	●	—	—	—	—	—	—	—	—
MSP5 STUDIO	—	—	—	—	—	—	●	●	—	—	—	—
MSP3	● <sup>*1</sup>	●	—	—	—	—	●	●	—	—	●	●
DBR15	—	—	—	—	●	●	—	—	●	●	—	—
DBR12	—	—	—	—	●	●	—	—	●	●	—	—
DBR10	—	—	—	—	●	●	—	—	●	●	—	—
MSR100	—	—	● <sup>*1</sup>	●	●	●	—	—	●	●	—	—
MS101III	● <sup>*1</sup>	●	—	—	—	—	●	●	—	—	●	●
VXS8(W)	—	—	—	—	—	—	●	●	—	—	—	—
VXS5(W)	●	●	—	—	—	—	●	●	—	—	—	—
S55	● <sup>*1</sup>	● <sup>*1</sup>	—	—	—	—	●	●	—	—	—	—
S15(W)	● <sup>*1</sup>	●	—	—	—	—	●	●	—	—	●	●
C112VA	—	—	● <sup>*2</sup>	● <sup>*3</sup>	●	●	—	—	●	●	—	—
HS8I(W)	—	—	● <sup>*2</sup>	● <sup>*3</sup>	●	●	—	—	●	●	—	—
HS7I(W)	—	—	—	—	●	●	—	—	●	●	—	—
HS5I(W)	● <sup>*1</sup>	● <sup>*3</sup>	—	—	—	—	●	●	—	—	—	—
STAGEPAS 600i	—	—	—	—	—	—	—	—	—	—	—	● <sup>*4</sup>
STAGEPAS 400i	—	—	—	—	—	—	—	—	—	—	—	● <sup>*4</sup>

\*1 Recommend to use for Ceiling mounted.

\*2 Ceiling mounted only.

\*3 When Wall mounted, the tilt angle is zero.

\*4 Mixer