

# **Previous RM-TT Firmware** **version information**

## **V1.7.0**

### **Specification Changes**

- Changed the initial value (Low) of the AGC (Auto Gain Control) parameter to High.

### **Improvements**

- Improved the operation of the echo canceller.

## **V1.5.0**

### **New Functions**

- When RM-TT and RM-CR are used in combination, it is now possible to change the color of the status indicator of RM-TT when there is no call. RM-CR and the Web GUI "RM-CR Device Manager" are required to make this change.

## **V1.2.0**

### **New Functions**

- You can now use the Web GUI "RM-TT Device Manager."
- Added a push-to-talk function that enables the microphone only while the button is pressed.
- Added a mute group function to link microphone muting for each group. It can be used in an environment combined with the RM-CR.
- Added a function to light up the microphone's LED according to the directionality setting. It can be used for the three cardioid types and the bidirectional type.
- Now supports SNMP (Simple Network Management Protocol), a remote management protocol.