

List of remote control codes
Liste des codes de commande
Liste der Fernbedienungs-codes
Lista över fjärrstyrningskoder
Elenco dei codici di telecomando
Lista de códigos de mando a distancia

TV

A.R. Systems	0320
Acme	0342
Acura	0323, 0343
ADC	0337
Admiral	0054, 0178, 0336, 0337, 0339, 0346, 0347
Advent	0158
Adventura	0057
Adyson	0277, 0282, 0342
Agashi	0277, 0282
Agazi	0337
Aiko	0277, 0282, 0320, 0323, 0342, 0343
Aim	0320
Aiwa	0078, 0379
Akai	0050, 0055, 0109, 0159, 0181, 0277, 0282, 0320, 0323, 0340, 0343, 0349, 0350
Akiba	0320, 0340
Akura	0320, 0323, 0337, 0340
Alaron	0277
Alba	0161, 0277, 0320, 0323, 0340, 0342, 0343, 0344, 0349, 0351, 0372, 0382
Albatron	0140
Alcyon	0171
Alleron	0059
Allorgan	0282
Allstar	0320, 0350
America Action	0179
AMOi	0276
Amplivision	0161, 0282, 0321, 0342
Amstrad	0320, 0323, 0337, 0340, 0343
Amtron	0058

Anam	0179, 0343
Anam National	0052, 0058
Anglo	0323, 0343
Anitech	0171, 0320, 0323, 0337, 0343
Ansonic	0161, 0168, 0320, 0323, 0341, 0343
AOC	0008, 0026, 0050, 0053
Apex	0039, 0111, 0217
Arcam	0277, 0282
Arcam Delta	0342
Aristona	0320, 0349, 0350
Arthur Martin	0321
ASA	0339, 0347
Asberg	0171, 0320, 0350
Astra	0343
Asuka	0277, 0282, 0337, 0340, 0342
Atlantic	0277, 0320, 0342, 0349, 0350
Atori	0323, 0343
Auchan	0321
Audiosonic	0161, 0282, 0320, 0340, 0342, 0343, 0349, 0350
AudioTon	0161, 0282, 0342
Audiovox	0058, 0179, 0194
Ausind	0171
Autovox	0171, 0282, 0337, 0339, 0342
Aventura	0051
Awa	0277, 0282
Axion	0156
Baird	0282
Bang & Olufsen	0180, 0339
Basic Line	0282, 0320, 0323, 0340, 0343, 0350
Bastide	0282, 0342
Baur	0320, 0349

Lijst met afstandsbedieningscodes
Liste over fjernbetjeningskoder
Liste over fjernkontrollkoder
Список кодов дистанционного управления
遥控器代码列表
리모콘코드목록

Bazin	0282
Beko	0161, 0269, 0294, 0302, 0311, 0320, 0328, 0351
Belcor	0008
Bell & Howell	0019, 0054
Benq	0097, 0242, 0361
Beon	0320, 0349, 0350
Best	0161
Bestar	0161, 0320, 0350
BGH	0400
Binatone	0282, 0342
Blue Sky	0320, 0340
Blue Star	0348
Boots	0282, 0342
BPL	0320, 0348
Bradford	0058, 0179
Brandt	0322, 0345
Brilliant	0182
Brinkmann	0320
Brionvega	0320, 0339, 0349, 0350
Britannia	0277, 0282, 0342
Brockwood	0008
Broksonic	0109, 0179
Bruns	0339
BTC	0340
Bush	0269, 0282, 0283, 0304, 0320, 0323, 0328, 0332, 0340, 0343, 0344, 0346, 0348, 0349, 0350, 0372, 0382, 0463, 0470, 0472
byd:sign	0093
Candle	0008, 0026, 0050, 0057
Capsonic	0337
Carena	0320
Carnivale	0050
Carrefour	0344
Carver	0010
Cascade	0320, 0323, 0343

Casio	0367
Cathay	0320, 0349, 0350
CCE	0183, 0282
Celebrity	0055, 0107
Celera	0039
Centurion	0320, 0349, 0350
Century	0339
CGE	0161, 0171
Changhong	0039
Chimei	0273
Cimline	0323, 0343
Citizen	0007, 0008, 0026, 0050, 0058
City	0323, 0343
Clarion	0179
Clarivox	0349
Clatronic	0161, 0171, 0282, 0320, 0323, 0337, 0340, 0342, 0343, 0350, 0351
CMS	0277
CMS Hightec	0282
Coby	0197
Colortyme	0008, 0026
Commercial Solutions	0021
Concerto	0008, 0026
Concorde	0323, 0343
Condor	0161, 0277, 0320, 0323, 0342, 0350, 0351
Contec	0179, 0277, 0323, 0342, 0343, 0344
Contec/Cony	0012, 0058
Continental Edison	0345
Cosmel	0323, 0343
Craig	0058, 0179
Crosley	0010, 0037, 0171, 0339

Crown	0058, 0161, 0171, 0179, 0320, 0323, 0343, 0349, 0350, 0351	Elcit	0339	Frontech	0282, 0323, 0337, 0343, 0346, 0347	Grunpy	0058, 0059, 0179
CS Electronics	0277, 0340, 0342	Electa	0348	Fujitsu	0059, 0069, 0074, 0075, 0282	Haier	0157, 0233
CTC Clatronic	0341	ELECTRO TECH	0343	Fujitsu General	0282	Halifax	0277, 0282, 0337, 0342
CTX	0205	Electroband	0055, 0107	Fujitsu Siemens	0504, 0505, 0507, 0510, 0511	Hallmark	0008, 0026, 0031
Curtis Mathes	0007, 0008, 0010, 0019, 0021, 0026, 0049, 0050, 0178	Electrograph	0176	Funai	0051, 0058, 0059, 0112, 0113, 0115, 0118, 0119, 0179, 0337, 0488, 0489	Hampton	0277, 0282, 0342
CXC	0058, 0179	Electrohomet	0008, 0026, 0052, 0055	Futurtech	0058, 0179	Hanseatic	0161, 0168, 0282, 0320, 0323, 0342, 0343, 0344, 0349, 0350
Cybertron	0340	Element	0230	Galaxi	0320, 0351	Hantarex	0320, 0323, 0343
Cytron	0152	Elin	0277, 0320, 0323, 0342, 0349, 0350	Galaxis	0161, 0320	Hantor	0320
Daewoo	0007, 0008, 0026, 0037, 0053, 0167, 0266, 0275, 0277, 0282, 0315, 0320, 0323, 0331, 0335, 0342, 0343, 0350, 0381, 0465	Elite	0320, 0340, 0350	Gateway	0176, 0177, 0241	Harman/Kardon	0010
Dainichi	0277, 0340	Elman	0341	GBC	0323, 0343, 0344	Harvard	0058, 0179
Dansai	0277, 0282, 0320, 0337, 0349, 0350	Elta	0277, 0323, 0343	GE	0008, 0021, 0023, 0026, 0027, 0031, 0034, 0049, 0052, 0056, 0209	Harwood	0320, 0323
Dantax	0161, 0349	Emerson	0000, 0007, 0008, 0012, 0013, 0019, 0026, 0031, 0037, 0051, 0058, 0059, 0161, 0179, 0320, 0339	Geant Casino	0321	Havermy	0178
Dawa	0320	Emprex	0154	GEC	0282, 0320, 0342, 0347, 0349, 0350	HCM	0282, 0320, 0323, 0337, 0342, 0343, 0348
Daytron	0007, 0008, 0026, 0323, 0343	Envision	0008, 0026, 0050	Geloso	0323, 0343, 0346	Hema	0282, 0323
De Graaf	0346	Epson	0155, 0206, 0359	General Technic	0323, 0343	Hewlett Packard	0192
Decca	0282, 0320, 0342, 0349, 0350	Erres	0320, 0349, 0350	Genexxa	0320, 0340, 0347, 0350	Higashi	0277
Dell	0145, 0245	ESA	0051	GFM	0128, 0227	HiLine	0320
Denver	0358, 0362	ESC	0282	Giant	0282	Hinari	0320, 0323, 0340, 0343, 0344, 0349, 0350
Desmet	0320, 0349, 0350	Etron	0343	Gibraltar	0008, 0030, 0050, 0062	Hisawa	0321, 0340, 0348
Diamant	0320	Eurofeel	0282	GoldHand	0277	Hisense	0247
Diamond	0277	Euro-Feel	0337	Goldline	0320	Hitachi	0008, 0012, 0026, 0066, 0084, 0092, 0093, 0120, 0172, 0173, 0255, 0270, 0271, 0282, 0320, 0335, 0338, 0342, 0344, 0346, 0347, 0365, 0382, 0448, 0456, 0467, 0482, 0484, 0487
DiamondVision	0135, 0143	Euroline	0349	GoldStar	0007, 0008, 0012, 0026, 0031, 0050, 0053, 0161, 0277, 0282, 0320, 0323, 0342, 0343, 0346, 0349, 0350	Hornophon	0320, 0350
Dimensia	0049	Euroman	0161, 0277, 0282	Goodmans	0246, 0272, 0282, 0320, 0323, 0337, 0343, 0344, 0349, 0350, 0462, 0473, 0477	Hoshai	0340
Disney	0219	Euromann	0320, 0337, 0342, 0350	Gorenje	0161, 0351	Huanyu	0277, 0342
Dixi	0282, 0320, 0323, 0343, 0349, 0350	Europhon	0277, 0282, 0320, 0341, 0342, 0350	GPM	0340	Hygashi	0277, 0282, 0342
Dream Vision	0461, 0498	Expert	0321	GPX	0129	Hyper	0277, 0282, 0323, 0342, 0343
DTS	0323, 0343	Exquisit	0320	Gradiente	0240	Hypson	0282, 0320, 0321, 0337, 0342, 0348, 0349, 0350
Dual	0282, 0320, 0342	Fenner	0323, 0343	Graetz	0347	Hyundai	0141
Dual-Tec	0342, 0343	Ferguson	0322, 0345, 0349	Granada	0171, 0282, 0320, 0321, 0342, 0344, 0346, 0349, 0350	Iberia	0320
Dumont	0008, 0030, 0062, 0282, 0339, 0341, 0342	Fidelity	0277, 0320, 0342, 0346	Grandin	0340, 0343, 0348, 0349	ICE	0277, 0282, 0320, 0323, 0337, 0340, 0342, 0343, 0350
Durabrand	0031, 0051, 0179, 0215	Filsai	0282	Gronic	0282	ICeS	0277
Dux	0349	Finlandia	0346	Grundig	0160, 0161, 0171, 0310, 0320	Ilo	0148, 0153
Dwin	0178	Finlux	0171, 0282, 0320, 0339, 0341, 0342, 0349, 0350			IMA	0058
Dynatron	0320, 0349, 0350	FIRST LINE	0342, 0343, 0350			Imperial	0161, 0171, 0320, 0347, 0350, 0351
Dynex	0228, 0231	Firstline	0277, 0282, 0320, 0323				
EIZO	0509	Fisher	0019, 0161, 0282, 0339, 0342, 0344, 0351				
Elbe	0161, 0168, 0282, 0320	Flint	0320, 0350				
		Formenti	0171, 0277, 0336, 0339, 0342, 0349				
		Formenti/Phoenix	0277				
		Fortress	0336, 0339				
		Fraba	0161, 0320				
		Friac	0161				

Indiana	0320, 0349, 0350	Kingsley	0277, 0342	Magnavox	0008, 0009, 0010, 0013,	Motion	0171
Infinity	0010	KLH	0039		0026, 0032, 0033, 0048,	Motorola	0052, 0178
InFocus	0250, 0327, 0363, 0479,	Kloss Novabeam	0057, 0058		0050, 0128, 0211, 0212,	MTC	0008, 0026, 0050, 0053,
	0508	Kneissel	0161, 0168, 0320		0224, 0226, 0239		0161, 0277
Ingelen	0347	Kolster	0320, 0350	Magnum	0337, 0343	Multi System	0349
Ingersol	0323, 0343	Konka	0340	Majestic	0054	Multitech	0058, 0161, 0179, 0183,
Initial	0153	Korpel	0320, 0349, 0350	Mandor	0337		0277, 0282, 0320, 0323,
Inno Hit	0171, 0282, 0320, 0323,	Korting	0161, 0339	Manesth	0282, 0320, 0337, 0342,		0341, 0342, 0343, 0344,
	0340, 0342, 0343, 0349,	Kosmos	0320		0349, 0350		0346, 0349
	0350	Koyoda	0343	Marantz	0008, 0010, 0026, 0050,	Murphy	0277, 0342
Innovation	0337, 0343	KTV	0007, 0050, 0058, 0179,		0204, 0320, 0349, 0350	NAD	0026, 0031, 0111
Insighia	0131, 0228, 0236, 0238		0183, 0282, 0342	Marelli	0339	Naonis	0346
Inteq	0030	Kyoto	0277, 0282	Mark	0277, 0282, 0320, 0323,	NEC	0008, 0026, 0050, 0052,
Interactive	0161	Lasat	0161		0349, 0350		0053, 0072, 0103, 0282,
Interbuy	0323, 0343	Lenco	0323, 0343	Masuda	0282		0344
Interfunk	0161, 0320, 0339, 0347,	Lenoir	0323, 0342, 0343	Matsui	0282, 0320, 0323, 0342,	Neckermann	0161, 0282, 0320, 0339,
	0349, 0350	Leyco	0320, 0337, 0349, 0350		0343, 0344, 0346, 0349,		0342, 0346, 0349, 0350,
International	0277	LG	0031, 0053, 0066, 0116,		0350, 0455		0351
Intervision	0161, 0282, 0320, 0337,		0117, 0140, 0161, 0164,	Matsushita	0017	NEI	0320, 0349, 0350
	0341, 0342		0175, 0195, 0269, 0277,	Maxent	0147, 0176	Net-TV	0176
Irradio	0171, 0320, 0323, 0340,		0282, 0300, 0309, 0317,	Mediator	0320, 0349, 0350	Neufunk	0320, 0323
	0343, 0349, 0350		0320, 0323, 0328, 0342,	Medion	0320, 0337, 0343	New Tech	0343, 0350
Isukai	0320, 0340		0343, 0346, 0349, 0350,	Megapower	0140	New World	0340
ITC	0282, 0342		0366, 0368, 0377, 0466,	Megatron	0026, 0031	NewTech	0282, 0320, 0323
ITS	0277, 0320, 0340, 0348,		0471, 0478	MElectronic	0277, 0282, 0320, 0323	Nicamagic	0277, 0342
	0350	LG/GoldStar	0164	Melvox	0321	Nikkai	0277, 0282, 0320, 0323,
ITT	0343, 0347	Liesenk	0349	Memorex	0019, 0026, 0031, 0053,		0337, 0340, 0342, 0349,
ITV	0320, 0343, 0349	Liesenkotter	0320		0054, 0137, 0215, 0323,		0350
Janeil	0057	Life	0337, 0343		0343	Nikko	0026, 0031, 0050
JBL	0010	Lifetec	0320, 0323, 0337, 0343	Memphis	0323, 0343	Noblisko	0171, 0277, 0341, 0342
JC Penney	0007, 0008, 0026, 0027,	Lloyds	0323	Mercury	0320, 0323	Nokia	0347
	0049, 0053, 0056	Loewe	0161, 0168, 0265, 0320,	Metz	0339	Norcent	0201
JCB	0055, 0107		0330, 0352	MGA	0008, 0026, 0031, 0050,	Nordic	0282
Jensen	0008, 0026	Loewe Opta	0339, 0349, 0350		0053	Nordmende	0339, 0345, 0347, 0350
JVC	0012, 0014, 0015, 0056,	Logik	0054	Micromaxx	0337, 0343	Nordvision	0349
	0064, 0065, 0067, 0169,	Luma	0320, 0323, 0346, 0349	Microstar	0337, 0343	Novatronic	0320
	0174, 0297, 0314, 0344,	Lumatron	0282, 0320, 0346, 0349,	Midland	0007, 0021, 0023, 0027,	Oceanic	0321, 0347
	0350, 0375		0350		0030, 0056, 0062	Okano	0161, 0320, 0351
Kaisui	0277, 0282, 0320, 0323,	Lux May	0350	Minerva	0171	Olevia	0102, 0199, 0200, 0207,
	0340, 0342, 0343, 0348	Luxman	0008, 0026	Minoka	0320, 0350		0222
Kamosonic	0342	Luxor	0282, 0342, 0346	Mintek	0153	ONCEAS	0342
Kamp	0277, 0342	LXI	0010, 0019, 0021, 0026,	Mitsubishi	0008, 0026, 0031, 0053,	Onwa	0058, 0179
Kapsch	0347		0027, 0031, 0049, 0111		0066, 0084, 0093, 0098,	Opera	0320
Karcher	0161, 0320, 0342, 0343,	M Electronic	0342, 0343, 0345, 0347,		0150, 0178, 0289, 0320,	Oppo	0130
	0349		0349, 0350		0339, 0344, 0350, 0376	Optimus	0017, 0019
Kawasho	0008, 0026, 0055, 0277	MAG	0096	Mivar	0161, 0168, 0171, 0277,	Optoma	0144
KEC	0179	Magnadyne	0339, 0341, 0349		0282, 0342	Optonica	0178
Kendo	0161, 0320, 0341, 0346	Magnafon	0171, 0277, 0341, 0342	Monivision	0140	Orbit	0320, 0350
Kenwood	0008, 0026, 0050			Montgomery Ward			
KIC	0282				0054		

Orion	0043, 0146, 0283, 0320, 0323, 0328, 0343, 0349, 0350	Phonola	0277, 0320, 0339, 0349, 0350	RCA	0008, 0021, 0024, 0025, 0026, 0027, 0042, 0049, 0052, 0053, 0063, 0136, 0225	Schneider	0282, 0316, 0318, 0320, 0333, 0340, 0342, 0349, 0350, 0382
Orline	0320	Pilot	0007, 0008, 0050	Realistic	0019, 0031, 0050, 0179	Scotch	0026, 0031
Osaki	0282, 0320, 0337, 0340, 0342	Pioneer	0008, 0026, 0094, 0095, 0161, 0320, 0345, 0347, 0349, 0350, 0458, 0480	Recor	0320	Scott	0008, 0012, 0026, 0031, 0058, 0059, 0149, 0179
Oso	0340	Plantron	0320, 0323, 0337, 0350	Redstar	0320	Sears	0008, 0010, 0019, 0021, 0026, 0027, 0031, 0049, 0051, 0059, 0111
Otto Versand	0282, 0320, 0336, 0342, 0344, 0348, 0349, 0350	Playsonic	0282	Reflex	0320	SEG	0277, 0282, 0320, 0323, 0337, 0341, 0342, 0344, 0349, 0382
Pael	0277, 0342	Polaroid	0039, 0142, 0202, 0234	Revox	0161, 0320, 0349, 0350	SEI	0320
Palladium	0161, 0282, 0320, 0342, 0351	Poppy	0323, 0343	Rex	0337, 0346, 0347	SEI-Sinudyne	0339, 0341, 0347
Palsonic	0282	Portland	0007, 0008, 0026, 0053	RFT	0161, 0168, 0339	Seleco	0344, 0346, 0347
Panama	0277, 0282, 0320, 0323, 0337, 0342, 0343	Prandoni-Prince	0171, 0346	Rhapsody	0277	Sencora	0323, 0343
Panasonic	0016, 0017, 0020, 0022, 0023, 0035, 0052, 0056, 0084, 0085, 0133, 0163, 0193, 0284, 0286, 0290, 0292, 0320, 0325, 0347, 0356, 0483, 0485, 0490	Precision	0282, 0342	R-Line	0320, 0349, 0350	Sentra	0323
Panavision	0320	Prima	0157, 0243, 0323, 0343, 0347	Roadstar	0323, 0337, 0340, 0343	Serino	0277
Pathe Cinema	0161, 0168, 0277, 0321, 0342	Princeton	0140	Robotron	0339	Sharp	0000, 0001, 0002, 0003, 0007, 0008, 0012, 0026, 0060, 0088, 0089, 0091, 0138, 0165, 0170, 0178, 0198, 0229, 0262, 0278, 0279, 0291, 0308, 0312, 0336, 0344, 0354, 0370, 0449, 0450, 0451, 0464, 0474, 0476, 0481
Pausa	0323, 0343	Prism	0023, 0056	Rowa	0277, 0282, 0400, 0403, 0494	Sheng Chia	0178
Penney	0021, 0023, 0031, 0050, 0111	Profex	0323, 0343	Royal Lux	0161	Shogun	0008
Perdio	0277, 0320	Profi-Tronic	0320, 0350	RTF	0339	Siarem	0320, 0339, 0341
Perfekt	0320	Proline	0320, 0350	Runco	0030, 0050, 0062	Sierra	0320, 0350
Philco	0008, 0009, 0010, 0012, 0026, 0050, 0052, 0053, 0161, 0171, 0320, 0339	Proscan	0021, 0027, 0049	Saba	0298, 0322, 0339, 0345, 0347	Siesta	0161
Philharmonic	0282, 0342	Prosonic	0161, 0277, 0282, 0320, 0342, 0349	Saisho	0282, 0323, 0337, 0342, 0343	Signature	0054
Philips	0008, 0009, 0010, 0011, 0012, 0032, 0048, 0049, 0052, 0122, 0128, 0134, 0186, 0187, 0213, 0221, 0224, 0226, 0239, 0256, 0257, 0259, 0261, 0263, 0267, 0280, 0281, 0287, 0296, 0299, 0301, 0303, 0305, 0313, 0319, 0320, 0324, 0333, 0339, 0342, 0349, 0350, 0353, 0357, 0360, 0380, 0383, 0452, 0459, 0460	Protech	0282, 0337, 0341, 0342, 0343, 0349, 0350	Salora	0346, 0347	Silva	0277
Philips Magnavox	0011, 0032, 0033	Proton	0008, 0012, 0026, 0031	Sambers	0171, 0341	Silver	0344
Phoenix	0161, 0277, 0320, 0339, 0349, 0350	Protron	0196	Sampo	0007, 0008, 0026, 0050, 0176, 0400	Singer	0321, 0339, 0341
		PROVIEW	0096, 0246	Samsung	0004, 0005, 0006, 0007, 0008, 0012, 0026, 0031, 0036, 0050, 0053, 0076, 0077, 0079, 0114, 0124, 0125, 0126, 0127, 0139, 0161, 0183, 0185, 0190, 0191, 0258, 0264, 0277, 0282, 0320, 0323, 0334, 0337, 0342, 0343, 0349, 0350, 0351, 0373, 0453, 0468	Sinudyne	0320, 0339, 0341, 0349
		Provision	0320, 0349	Sandra	0277, 0282, 0342	Skantic	0347
		Pulsar	0008, 0030, 0062	Sansui	0043, 0109, 0320, 0350, 0400	Skyworth	0402, 0492, 0493, 0495
		Pye	0256, 0320, 0349, 0350, 0378	Sanyo	0008, 0019, 0068, 0070, 0071, 0099, 0161, 0168, 0223, 0237, 0277, 0282, 0288, 0295, 0323, 0342, 0344, 0369, 0469	Sonitron	0161, 0282
		Pymi	0323, 0343	Sceptre	0235, 0244	Sonoko	0282, 0320, 0323, 0337, 0342, 0343, 0349, 0350
		Quandra Vision	0321	Schaub Lorenz	0347	Sontec	0161, 0320, 0349, 0350
		Quasar	0017, 0023, 0052, 0056				
		Quelle	0282, 0320, 0337, 0342, 0349, 0350				
		Questa	0344				
		Radialva	0320				
		RadioShack	0019, 0021, 0031, 0050, 0179, 0320				
		RadioShack/Realistic	0007, 0008, 0012, 0026, 0049, 0058				
		Radiola	0282, 0320, 0349, 0350				
		Radiomarelli	0320, 0339				
		Radiotone	0161, 0320, 0323, 0350				
		Rank	0344				

Sony	0038, 0044, 0045, 0047, 0055, 0090, 0104, 0105, 0107, 0110, 0123, 0184, 0220, 0248, 0249, 0251, 0252, 0254, 0326, 0343, 0344, 0371, 0374, 0457, 0475, 0486	TCL	0400, 0401, 0403, 0406, 0494	Triumph	0320	Yamaha	0008, 0026, 0050, 0053, 0080, 0081, 0082, 0083, 0086, 0087
Sound & Vision	0340, 0341	Teac	0282, 0320, 0400	Uher	0161, 0171, 0320, 0347, 0350	Yamishi	0282, 0320
Soundesign	0008, 0026, 0031, 0058, 0059, 0179	Tec	0282, 0323, 0342, 0343	Ultravox	0277, 0320, 0339, 0341, 0342	Yokan	0320
Soundwave	0320, 0349, 0350	Technics	0017, 0023, 0056	Unic Line	0320	Yoko	0161, 0277, 0282, 0320, 0323, 0337, 0340, 0342, 0343, 0349, 0350
Squareview	0051	TechniSat	0274, 0496, 0497, 0499	United	0349	Yorx	0340
SSS	0008, 0058, 0179	Techwood	0008, 0023, 0026, 0056	Univox	0320	Zanussi	0282, 0346
Standard	0282, 0320, 0323, 0340, 0342, 0343, 0350	TEDELEX	0282	Vector Research	0050	Zenith	0008, 0028, 0029, 0030, 0031, 0054, 0061, 0062
Starlite	0058, 0179, 0320, 0323, 0349	Teknika	0007, 0008, 0010, 0012, 0026, 0053, 0054, 0058, 0059, 0179	Vestel	0282, 0320, 0346, 0347, 0349, 0350, 0351		
Stenway	0348	Teleavia	0345	Vexa	0320, 0323, 0343, 0349		
Stern	0346, 0347	Telecor	0282, 0320	Victor	0015, 0344, 0350	VCR	
Strato	0320, 0323	Telefunken	0320, 0322, 0345, 0350	VIDEOLÓGIC	0277	ABS	1016
Stylandia	0282	Telegazi	0320	Videologique	0277, 0282, 0340, 0342	Adventura	1069
Sunkai	0343	Telemeister	0320	VideoSystem	0320, 0350	Adyson	1008
Sunstar	0320, 0323	Telesonic	0320	Videotechnic	0277, 0282	Aiwa	1024, 1026, 1027, 1069
Sunwood	0320, 0323, 0343, 0350	Telestari	0320	Vidtekron	0010	Akai	1021, 1027
Superla	0277, 0282, 0342	Teletech	0320, 0323, 0343, 0349	Vidtech	0008, 0026, 0031, 0053	Akiba	1008, 1029
Superscan	0013, 0178	Teleton	0282, 0342	Viewsonic	0176, 0203, 0232, 0364	Akura	1008, 1027, 1029
SuperTech	0277, 0320, 0323	Televideon	0277	Viking	0057	Alba	1008, 1009, 1024, 1025, 1029, 1030
Supra	0323, 0343	Televiso	0321	Visiola	0277, 0342	Alienware	1016
Supre-Macy	0057	Tensai	0282, 0320, 0323, 0340, 0343, 0350	Vision	0282, 0320, 0350	Ambassador	1030
Supreme	0055, 0107	Tesmet	0350	Vizio	0008, 0177, 0218, 0242, 0500, 0501, 0502, 0503, 0506	American High	1068
Susumu	0340	Tevion	0337, 0343	Vortec	0320, 0349, 0350	Amstrad	1008, 1009, 1026
Sutron	0323, 0343	Texet	0277, 0282, 0323, 0342	Voxson	0171, 0320, 0339, 0346, 0347, 0350	Anitech	1008, 1029
SVA	0151	Thomson	0162, 0188, 0189, 0285, 0320, 0322, 0342, 0345, 0350	Waltham	0282, 0320, 0342	Apex	1088
Sydney	0277, 0282, 0342	Thorn	0320, 0349	Wards	0008, 0009, 0010, 0026, 0031, 0048, 0049, 0050, 0053, 0054, 0059	ASA	1028, 1031
Sylvania	0008, 0009, 0010, 0011, 0013, 0026, 0048, 0050, 0051, 0128, 0227, 0253	TMK	0008, 0026, 0031	Watson	0320, 0349, 0350	Asha	1070
Symphonic	0051, 0058, 0062, 0128, 0179, 0215	TNCi	0030	Watt Radio	0277, 0341, 0342	Asuka	1008, 1026, 1028, 1029, 1031
Syntax	0199	Tokai	0282, 0320, 0350	Waycon	0111	Audio Dynamics	1064
Syntax-Brilliant	0199	Tokyo	0277, 0342	Wega	0320, 0339, 0344	Audiosonic	1009
Sysline	0349	Tomashi	0348	Wegavox	0323	Audiovox	1071
Sytong	0277	Toshiba	0018, 0019, 0040, 0041, 0046, 0073, 0100, 0103, 0108, 0109, 0111, 0121, 0132, 0166, 0208, 0210, 0214, 0217, 0260, 0268, 0282, 0283, 0293, 0304, 0306, 0307, 0329, 0344, 0355, 0454, 0491	Weltblick	0282, 0320, 0349, 0350	Baird	1009, 1025, 1026, 1027
Tandy	0178, 0282, 0336, 0340, 0342, 0347	Totevision	0007	Westinghouse	0107, 0216, 0220	Bang & Olufsen	1017
Tashiko	0277, 0282, 0342, 0344, 0346	Towada	0282, 0347	White Westinghouse	0037, 0090, 0277, 0320, 0341, 0342, 0349	Basic Line	1008, 1009, 1024, 1025, 1029, 1030
Tatung	0052, 0177, 0282, 0320, 0342, 0349, 0350	Trakton	0282	Wincom	0101, 0106	Baur	1028
TCM	0337, 0343	Trans Continens	0282, 0320	Xrypton	0320	Beaumarck	1070
		Transtec	0277			Bell & Howell	1065
		Trident	0282			Bestar	1009, 1025, 1030
						Black Panther Line	1009, 1025
						Blaupunkt	1028
						Bondstec	1008, 1030

Broksonic	1100	Emerson	1008, 1020, 1068, 1069,	Howard Computers	Luxor	1008
Bush	1008, 1009, 1024, 1025, 1029, 1049, 1051, 1063, 1217	ESC	1071	HP	LXI	1071
Calix	1071	Etzuko	1009, 1025	HTS	M Electronic	1026
Candle	1070, 1071	Expressvu	1008, 1029	Hughes	Magnavox	1020, 1068, 1114, 1126
Canon	1068	Ferguson	1018	Hughes Network Systems	Magnin	1071
Cathay	1009	Fidelity	1027		Manesth	1008, 1029
Catron	1030	Finlandia	1008, 1026	Humax	Marantz	1028, 1064, 1065, 1068
CGE	1026, 1027	Finlux	1028	Hush	Mark	1009
Cimline	1008, 1024, 1029	Firstline	1026, 1027, 1028	Hypson	Marta	1071
CineVision	1104	Fisher	1008, 1024, 1029, 1031	iBUYPOWER	Matsui	1024, 1031
Citizen	1070, 1071	Flint	1065	Impego	Matsushita	1068
Clatronic	1008, 1030	Formenti/Phoenix	1024	Imperial	Media Center PC	1016
Colortyme	1064	Frontech	1028	Inno Hit	Mediator	1028
Condor	1009, 1025, 1030	Fuji	1030		Medion	1024
Craig	1070, 1071	Fujitsu	1068	Innovation	MEI	1068
Crown	1008, 1009, 1025, 1029, 1030	Funai	1026	Instant Replay	Memorex	1023, 1026, 1031, 1065, 1068, 1069, 1070, 1071, 1098, 1114
Curtis Mathes	1064, 1068, 1070	Galaxy	1026, 1069	Interbuy	Memphis	1008, 1029
Cybernex	1070	Garrard	1069	Interfunk	MGN Technology	1070
CyberPower	1016	Gateway	1016	Intervision	Micromaxx	1024
Daewoo	1009, 1025, 1030, 1038, 1069, 1223	GBC	1029, 1030	Irradio	Microsoft	1016
Dansai	1008, 1009, 1029	GE	1068, 1070	ITT	Microstar	1024
Dantax	1024	GEC	1028	ITV	Migros	1026
Daytron	1009, 1025	Geloso	1029	JC Penney	Mind	1016
DBX	1064	General	1030		Mitsubishi	1026, 1028, 1079
De Graaf	1028	General Technic	1024	JCL	Motorola	1068
Decca	1026, 1027, 1028	GOI	1018	JVC	MTC	1070
Dell	1016	GoldHand	1008, 1029		Multitech	1008, 1026, 1028, 1029, 1030, 1069, 1070
Denko	1008	Goldstar	1026, 1031, 1064, 1071		Murphy	1026
DiamondVision	1096	Goodmans	1008, 1009, 1025, 1026, 1029, 1030, 1031		NEC	1027, 1064, 1065
DigiFusion	1014	Gradiente	1069	Kaisui	Neckermann	1027, 1028
DIRECTV	1019, 1105, 1110, 1111, 1113, 1116, 1122	Graetz	1027	Karcher	NEI	1028
Dish Network	1018	Granada	1028	Kendo	Nesco	1008, 1029
Dishpro	1018	Grandin	1008, 1009, 1025, 1026, 1029, 1030, 1031	Kenwood	Nikkai	1008, 1009, 1030
Dual	1009, 1027, 1028	Grundig	1028, 1029	Kodak	Nikko	1071
Dumont	1026, 1028	Hanseatic	1009, 1028, 1031	Korpel	Niveus Media	1016
Durabrand	1114	Harley Davidson	1069	Kyoto	Noblex	1070
Dynatech	1069	Harman/Kardon	1064	Lenco	Nokia	1009, 1027
Echostar	1018	Harwood	1008	Leyco	Nordmende	1027
Elbe	1009	HCM	1008, 1029	LG	Northgate	1016
Elcatech	1008	Headquarter	1065		Oceanic	1026, 1027
Electrohome	1071	Hewlett Packard	1016		Okano	1008, 1009, 1024
Electroponic	1071	Hinari	1008, 1009, 1024, 1029	Lifetec	Olympus	1068
Elsay	1008	Hisawa	1024	Linksys	Optimus	1071
Elta	1008, 1009, 1029	Hitachi	1011, 1026, 1027, 1028, 1046, 1062	Lloyd's	Orion	1023, 1024, 1051, 1115, 1217
		HNS	1110	Loewe Opta	Orson	1026
				Logik	Osaki	1008, 1026, 1029, 1031
				Lumatron		

Otto Versand	1028	Runco	1114	Sunwood	1008, 1029	Voodoo	1016
Palladium	1008, 1027, 1029, 1031	Saba	1027	Superscan	1020	Wards	1068, 1069, 1070, 1071
Panasonic	1000, 1022, 1044, 1055, 1068, 1072, 1085, 1090, 1091, 1120, 1121, 1214	Saisho	1024, 1029	Sylvania	1020, 1068, 1069, 1102, 1126	Weltblick	1031
Pathe Marconi	1027	Samsung	1002, 1034, 1041, 1043, 1057, 1060, 1070, 1084, 1110, 1116, 1122, 1124, 1220, 1222	Symphonic	1008, 1069, 1126	XR-1000	1068, 1069
Perdio	1026			Systemax	1016	Yamaha	1064, 1065
Philco	1008, 1068	Samurai	1008, 1030	Tagar Systems	1016	Yamishi	1008, 1029
Philips	1006, 1013, 1028, 1035, 1040, 1045, 1046, 1050, 1058, 1059, 1061, 1068, 1076, 1101, 1110, 1113, 1116, 1117, 1122, 1126, 1210, 1211	Sanky	1114	Taisho	1024	Yokan	1008, 1029
Philips Magnavox	1076	Sansui	1023, 1027, 1106, 1115	Tandberg	1009	Yoko	1008, 1029, 1030, 1031
Phonola	1028	Sanyo	1032, 1065, 1070	Tandy	1065	Zenith	1114
Pilot	1071	Saville	1009	Tashiko	1026, 1071	ZT Group	1016
Pioneer	1028, 1036	SBR	1028	Tatung	1026, 1027, 1028		
Polaroid	1088, 1099	Schaub Lorenz	1026, 1027	TCM	1015, 1024, 1042	DVD	
Portland	1009, 1025, 1030	Schneider	1008, 1009, 1024, 1025, 1026, 1028, 1029, 1030, 1031	Teac	1009, 1069	4Kus	2051
Prinz	1026			Tec	1008, 1009, 1030	Accurian	2142
Profex	1029	Sears	1065, 1068, 1071	Technics	1068	Advent	2155, 2251
Proline	1026	SEG	1008, 1009, 1029	Teknika	1068, 1069, 1071	AEG	2362
Proscan	1019	SEI-Sinudyne	1028	Teleavia	1027	Airis	2364
Prosonic	1009, 1024	Seleco	1027	Telefunken	1027	Aiwa	2322
Pulsar	1114	Sentra	1008, 1030	Teletech	1008, 1009	Akai	2145, 2177, 2179, 2248
Pye	1028, 1102	Sentron	1008, 1029	Tenosal	1008, 1029	Akura	2356
Quarter	1065	Sharp	1003, 1033, 1077, 1107, 1127, 1219	Tensai	1008, 1026, 1029, 1031	Alba	2064, 2165, 2186, 2337, 2346
Quartz	1065	Shintom	1008, 1029	Tevion	1024	Alco	2149
Quasar	1068	Shivaki	1031	Thomson	1005, 1027	Alize	2361
Quelle	1026, 1028	Shogun	1070	Thorn	1027	Allegro	2133
Radialva	1008	Siemens	1031	Tivo	1108, 1110, 1111, 1113, 1117, 1118, 1119, 1122	Amitech	2362
RadioShack	1071	Silva	1031	TMK	1070	Amphion MediaWorks	2195
RadioShack/Realistic	1065, 1068, 1069, 1070, 1071	Silver	1009	Tokai	1008, 1029, 1031	AMW	2195, 2363
Radiola	1028	Singer	1068	Tonsai	1029	Apex	2030, 2124, 2125, 2126, 2127, 2130, 2131
Radix	1071	Sinudyne	1028	Toshiba	1004, 1016, 1027, 1028, 1037, 1049, 1052, 1086, 1087, 1097, 1109, 1112, 1194	Apple	2241
Randex	1071	Solavox	1030			Arrgo	2138
RCA	1019, 1068, 1070, 1075, 1110, 1113, 1122, 1125	Sonic Blue	1022, 1123	Totevision	1070, 1071	Asono	2364
Realistic	1065, 1068, 1069, 1070, 1071	Sonneclair	1008	Touch	1016	Aspire	2152, 2222
ReplayTV	1022, 1123	Sonoko	1009, 1025	Towada	1008, 1029	Astar	2240
Rex	1027	Sontec	1031	Towika	1008, 1029	ATACOM	2364
RFT	1008, 1028, 1030	Sony	1001, 1016, 1048, 1053, 1073, 1074, 1080, 1081, 1082, 1083, 1108, 1118, 1216	TVA	1030	Audiovox	2061, 2149
Ricavision	1016			Uher	1031	Avious	2367
Roadstar	1008, 1009, 1025, 1029, 1031	Stack	1016	UltimateTV	1019	Awa	2363
Royal	1008	Stack 9	1016	Ultravox	1009	Axion	2249
		Standard	1009, 1025	Unitech	1070	Bang & Olufsen	2128
		Stern	1009	United Quick Star	1009, 1025	Baze	2367
		STS	1068	Universum	1026, 1028, 1031	BBK	2364
		Sunkai	1024	Vector Research	1064	Bellagio	2363
		Sunstar	1026	Video Concepts	1064	Best Buy	2359
		Suntronic	1026	Videon	1024	Blaupunkt	2131
				Videosonic	1070	Blue Parade	2157
				Viewsonic	1016		

Boghe	2382	DUNE	2509	Insignia	2002, 2137, 2253	Mecotek	2362
Brainwave	2362	Durabrand	2136	Integra	2157	Medion	2182
Brandt	2148, 2188	DVX	2355	Irradio	2053	Memorex	2028, 2145, 2234
Broksonic	2145, 2146	Easy Home	2359	iSymphony	2246	MiCO	2354, 2382
Bush	2064, 2110, 2170, 2268, 2290, 2346, 2358, 2367, 2383	Eclipse	2354	JBL	2135	Micromaxx	2182
California Audio Labs	2151	E-Dem	2364	JVC	2020, 2096, 2097, 2099, 2100, 2101, 2102, 2103, 2106, 2107, 2160, 2257, 2260, 2262, 2263, 2321, 2324, 2326, 2327, 2343, 2464, 2465, 2468, 2469, 2471	Microsoft	2156
Cambridge Audio	2354	Electrohome	2362			Microstar	2182
CAT	2352, 2353	Elin	2362	Jwin	2198	Minoka	2362
CAVS	2192	Elta	2341, 2361, 2362	Kansai	2360	Minowa	2367
Centrum	2353	Emerson	2129, 2137, 2150	Kawasaki	2149	Mintek	2131, 2245
CGV	2354, 2362	Enterprise	2129	Kenex	2362	Mitsubishi	2003
Changhong	2140	Enzer	2380	Kenwood	2041, 2151, 2348	Mizuda	2358, 2359
Cinetec	2363	Epson	2247	KeyPlug	2362	Monyka	2380
CineVision	2133, 2237	ESA	2137	Kiuro	2362	Mustek	2186
Clatronic	2358, 2367	Finlux	2354, 2362, 2367	Kingavon	2358	Mx Onda	2354
Coby	2031, 2046, 2360	Fintec	2377	Kiss	2380	Mystral	2366
Conia	2383	Fisher	2134	KLH	2131, 2149	Naiko	2362
Continental Edison	2363	Funai	2137	Koda	2358	Nesa	2131
Crown	2362	Gateway	2051	Koss	2013, 2148, 2158	Neufunk	2380
C-Tech	2355	GE	2029, 2131, 2156	KXXD	2359	Nevir	2362
Curtis Mathes	2139	Gericom	2351	Landel	2143	Next Base	2143
CVG	2377	GFM	2226	Lasonic	2132	Nexxtech	2243
CyberHome	2022, 2098, 2138, 2187, 2336	Giec	2382	Lawson	2355	NU-TEC	2383
Cytron	2244	Global Solutions	2355	Lecson	2381	Onkyo	2159, 2368
Daenyx	2363	Global Sphere	2355	Lenco	2358, 2362, 2367	Oopla	2051
Daewoo	2001, 2133, 2276, 2298, 2330, 2362, 2363, 2377	Go Video	2133, 2213	Lenoxx	2136, 2153	Oppo	2196, 2255
Daewoo International	2363	Goodmans	2165, 2280, 2291, 2358, 2371, 2376, 2382	LG	2002, 2033, 2038, 2057, 2129, 2133, 2189, 2191, 2223, 2238, 2270, 2288, 2335, 2373, 2375	Optim	2381
Dalton	2357	GPX	2227	Life	2182	Optimus	2180
Dansai	2362, 2381	Gradiente	2151	Lifetec	2182	Orava	2358
Daytek	2184, 2195, 2363	Graetz	2380	Limit	2355	Orbit	2363
Dayton	2363	Greenhill	2131	Liquid Video	2158	Orion	2073, 2110
DEC	2358	Grundig	2349	Liteon	2043, 2051, 2142	Oritron	2148, 2158
Decca	2362	Grunkel	2362, 2366	Loewe	2320	P&B	2358
Denon	2059, 2151, 2193, 2332	GVG	2377	LogicLab	2355	Pacific	2355
Denver	2356, 2358, 2360, 2370	H&B	2358	Magnavox	2025, 2050, 2137, 2150, 2159, 2224, 2230, 2358	Panasonic	2011, 2024, 2034, 2042, 2058, 2062, 2066, 2067, 2093, 2116, 2117, 2118, 2119, 2120, 2121, 2122, 2123, 2151, 2159, 2164, 2166, 2167, 2172, 2173, 2175, 2209, 2214, 2275, 2277, 2278, 2281, 2282, 2283, 2301, 2374, 2470
Denzel	2380	H_ber	2364			Parasound	2197
Desay	2205	Haaz	2354, 2355	Magnex	2367	peeKTON	2364
Diamond	2354, 2355	Haier	2254	Majestic	2360		
DiamondVision	2225, 2232	Harman/Kardon	2047, 2135	Marantz	2328		
Disney	2010, 2028	HiMAX	2359	Marquant	2362		
DK Digital	2339	Hitachi	2062, 2090, 2115, 2274, 2316, 2359, 2380	Matsui	2148, 2378		
Dmtech	2176	Hiteker	2130	McIntosh	2199		
Dual	2380	Home Tech Industries	2364				
		Hyundai	2366				
		Ilo	2245				
		Initial	2131, 2245				
		Innovation	2182				

Philips	2008, 2012, 2025, 2044, 2050, 2051, 2053, 2060, 2072, 2108, 2111, 2147, 2159, 2163, 2169, 2174, 2181, 2185, 2230, 2261, 2266, 2267, 2286, 2287, 2289, 2295, 2300, 2302, 2317, 2328, 2338, 2342, 2350, 2467	Samsung	2000, 2045, 2077, 2112, 2113, 2114, 2115, 2151, 2200, 2216, 2219, 2228, 2264, 2265, 2271, 2279, 2294, 2303, 2329, 2365	Symphonic	2108, 2230	Yukai	2186
Phonotrend	2367	Sansui	2073, 2145, 2354, 2355, 2362	Synn	2355	Zenith	2002, 2129, 2133, 2159, 2223
Pioneer	2016, 2017, 2018, 2019, 2035, 2092, 2094, 2095, 2109, 2157, 2180, 2190, 2212, 2269, 2272, 2299, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2344, 2345, 2347, 2379	Sanyo	2134, 2145, 2217, 2292	T.D.E. Systems	2366	<hr/>	
Pointer	2362	ScanMagic	2186	Tatung	2001, 2362	Blu-ray Disc	
Polaroid	2125, 2215, 2235	Schaub Lorenz	2362	TCM	2182, 2297	Denon	2452, 2500, 2501
Portland	2362	Schneider	2176	Teac	2149, 2333, 2355, 2383	Hitachi	2460, 2461, 2463
Powerpoint	2363	Scientific Labs	2355	Tec	2356	JVC	2472, 2473, 2475, 2478, 2496, 2499, 2511
Prima	2252	Scott	2161, 2357	Technics	2151	LG	2033, 2456, 2457
Proceed	2130	Seeltech	2364	Technika	2362, 2367	Marantz (US)	2454, 2455
Proscan	2156	SEG	2161, 2355, 2363, 2380	Telefunken	2353	Mitsubishi	2450, 2451
Prosonic	2360, 2377	Sharp	2006, 2040, 2088, 2091, 2182, 2194, 2220, 2221, 2231, 2236, 2293, 2340	Tensai	2362	Onkyo	2504
Protron	2202	Shinsonic	2245	Tevion	2182, 2355, 2357	Panasonic	2011, 2209, 2214, 2476, 2477, 2479
Provision	2358	Sigmatek	2359, 2364	Theta Digital	2157	Philips	2510
Pye	2144	Silva	2356	Thomson	2183, 2188, 2334, 2372	Pioneer	2212, 2506
Qwestar	2148	Singer	2354, 2355	Tokai	2356, 2380	Samsung	2045, 2113, 2498
Raite	2380	Skymaster	2325, 2355	Top Suxess	2364	Sharp	2194, 2220, 2221, 2497, 2502, 2503
RCA	2021, 2029, 2104, 2105, 2131, 2149, 2156, 2157, 2229	Skyworth	2356	Toshiba	2032, 2036, 2037, 2039, 2048, 2049, 2054, 2055, 2072, 2073, 2076, 2078, 2079, 2086, 2145, 2159, 2218, 2233, 2256, 2259, 2296, 2369, 2508	Sony	2075, 2453, 2458, 2459, 2507
RedStar	2356, 2360, 2362	SLM Electronic	2355	TRANScontinents	2363, 2367	Toshiba	2462
Regent	2153	Sonic Blue	2133	Transonic	2367	Yamaha	2064, 2448, 2449, 2474, 2505
Reoc	2355	Sontech	2366	Trio	2362	<hr/>	
Rimax	2361	Sony	2004, 2005, 2007, 2009, 2014, 2015, 2023, 2026, 2027, 2052, 2068, 2069, 2070, 2071, 2074, 2075, 2084, 2085, 2087, 2168, 2171, 2208, 2210, 2211, 2258, 2273, 2284, 2285, 2312, 2313, 2314, 2315, 2318, 2319, 2466	Trutech	2242	DVR	
Rio	2133	Soundmaster	2355	TruVision	2359	Bush	2110
Roadstar	2331, 2358	Soundmax	2355	TSM	2364	Hitachi	2090
Ronin	2363	Spectra	2363	Umax	2361	Panasonic	2066, 2067, 2093, 2116, 2117, 2119, 2120, 2122, 2123
Rotel	2203	Spectroniq	2201	United	2367	Philips	2108, 2111
Rowa	2154, 2383	Standard	2355	Urban Concepts	2159	Pioneer	2016, 2017, 2018, 2019, 2092, 2094, 2095, 2109
Rowsonic	2353	Star Cluster	2355	US Logic	2245	RCA	2105
Saba	2148, 2188	Starmedia	2358, 2364	Venturer	2149	Samsung	2113, 2219
Sabaki	2355	Sungale	2204	Viewmaster	2364	Sharp	2088, 2091
Saivod	2362	Sunkai	2362	Vocopro	2206	Sony	2084, 2085, 2087
Sampo	2141	Superscan	2150	VocoStar	2207	Toshiba	2086
		Supervision	2355	Waitec	2364	Victor	2475
		Sylvania	2012, 2137, 2150, 2178, 2230, 2239	Welltech	2382	Yamaha	2089, 2118
				Westinghouse	2063, 2250		
				Wharfedale	2354, 2355		
				Woxter	2361, 2364		
				Xbox	2156, 2183		
				Xlogic	2355, 2362		
				XMS	2362		
				Xoro	2382		
				Yamada	2051, 2361, 2363		
				Yamaha	2056, 2064, 2065, 2080, 2081, 2082, 2083, 2089, 2118, 2151, 2323		
				Yamakawa	2363, 2380		

DVD Recorder

Aspire	2222
Astar	2240
Broksonic	2146
Go Video	2213
Hitachi	2062
Insignia	2002
Irradio	2053
JVC	2100, 2101, 2106, 2107
LG	2033, 2057, 2223, 2238
Liteon	2043
Panasonic	2011, 2034, 2058, 2062, 2116, 2117, 2119, 2120, 2121, 2123
Philips	2008, 2044, 2050, 2051, 2147
Pioneer	2017, 2035
Pye	2144
Samsung	2000, 2112, 2216
Sansui	2073
Sanyo	2217
Sony	2004, 2005, 2007, 2052, 2068, 2069, 2074, 2208, 2210, 2211
Sylvania	2239
Toshiba	2032, 2036, 2037, 2039, 2049, 2054, 2055, 2076
Yamaha	2056

Cable

ABC	3002, 3003, 3017, 3066, 3067, 3086, 3093, 3119, 3122
ADB	3020
Adelphia	3081
Alcatel	3016
Americast	3124
Amstrad	3022, 3098
Antronix	3065, 3070
Archer	3070
Arcon	3098
AT&T	3095
Axis	3098
Bell South	3124
Cable Vision	3092
Cabletenna	3065
Cabletime	3104

Cableview	3087
Clearmaster	3127
ClearMax	3127
Clyde Cablevision	3105
Colour Voice	3068
Comcast	3084, 3088, 3117
Comcrypt	3107
Comtronics	3069
Contec	3074
Coolmax	3127
COX	3084
Cryptovision	3110
Director	3084
Eastern	3075
Everquest	3123
Fidelity	3098
Filmnet	3107
Filmnet Cablecrypt	3111
Filmnet Comcrypt	3111
Finlux	3097
FIOS	3005
Focus	3126
Foxtel	3022
France Telecom	3100, 3101
Freebox	3023
GC Electronics	3070
GE	3066, 3093
GEC	3105
Gemini	3072, 3123
General Instrument	3017, 3025, 3066, 3084, 3090, 3096, 3117
Goldstar	3120
Gooding	3099
Grundig	3098, 3099
Hamlin	3073, 3078
Hirschmann	3097
Hitachi	3066
HomeChoice	3106
Humax	3021, 3080, 3083
ITT Nokia	3097
Jasco	3123
Jerrold	3017, 3018, 3025, 3066, 3072, 3084, 3090, 3096, 3119, 3123
JVC	3099
Kabel Deutschland	3024, 3027, 3121

Macab	3101
Magnavox	3079
Maspro	3099
Matsui	3099
MegaCable	3117
Memorex	3076, 3122
Minerva	3099
Mnet	3107
Motorola	3025, 3026, 3084, 3088, 3090, 3095, 3117
Movie Time	3077, 3109
Mr Zapp	3101
Multichoice	3107
Multitech	3127
NEC	3064
NET Brazil	3085
Nokia	3097
Noos	3101
NSC	3077
Oak	3074
Pace	3006, 3089, 3121
Palladium	3099
Panasonic	3112, 3118, 3122
Paragon	3122
Philips	3068, 3071, 3079, 3099, 3100, 3101, 3103
Pioneer	3001, 3006, 3094, 3098, 3114, 3116, 3120
Popular Mechanics	3126
Proscan	3066, 3093
Pulsar	3122
PVP Stereo Visual Matrix	3018
Quasar	3122
RadioShack	3123, 3127
RCA	3030, 3031, 3087, 3118
Realistic	3070
Recoton	3126
Regal	3078
Regency	3075
Rembrandt	3066
Runco	3122
Sagem	3101
Samsung	3069, 3089, 3114, 3120
SAT	3098
Scientific Atlanta	3000, 3001, 3002, 3003, 3006, 3028, 3029, 3081, 3086, 3089, 3094, 3095, 3108

Signal	3072, 3123
Signature	3066
Sony	3092, 3125
Sprucer	3118
Standard Component	3115
Starcom	3017, 3072, 3119, 3123
Stargate	3072, 3123
Starquest	3072, 3123
Supercable	3090
Supermax	3127
Tele+1	3107, 3111
TELENET	3004
Telepiu	3107
Thomson	3082, 3091
TIME WARNER	3084
Tocom	3067
Torx	3017
Toshiba	3122
Tristar	3127
Tudi	3102
Tusa	3072, 3123
TV86	3077
Unika	3065, 3070
United Cable	3018, 3119
Universal	3065, 3070
Universum	3097, 3099
V2	3127
Verizon Fios	3007
Videoway	3019
View Star	3074, 3077, 3079
Viewmaster	3127
Vision	3127
Visiopass	3097, 3100, 3101
Vortex View	3127
Wittenberg	3098
Zenith	3113, 3122, 3124
Zentek	3126

Satellite

AB Sat	4216, 4217
AccessHD	4104
ADB	4220
AGS	4216
Akai	4053, 4055
Alba	4001, 4004, 4006, 4007, 4062, 4217
Aldes	4005, 4007, 4010

Allsat	4048, 4053, 4055	Comag	4080, 4081, 4082, 4083, 4086	Emanon	4001	Hinari	4007
Allsonic	4005, 4008, 4024	Commlink	4005	Emme Esse	4008, 4024	Hirschmann	4015, 4024, 4210, 4216, 4218, 4219
Alltech	4217	Comtech	4050	Engel	4217	Hisawa	4013
Alpha	4053	Condor	4008, 4024, 4219	Ep Sat	4006	Hisense	4016
Alpha Digital	4104	Connexions	4014, 4024	EURIEULT	4031	Hitachi	4006, 4114, 4199, 4203
Alphastar	4077	Conrad	4024, 4215, 4218, 4219	Eurodec	4052	Homecast	4084, 4085, 4087
Amitronica	4217	Conrad Electronic	4217, 4219	Europa	4053, 4218, 4219	Houston	4048
Amstrad	4011, 4035, 4217, 4218	Contec	4050	Europhon	4219	HTS	4117
Anglo	4217	Coolsat	4096	Eurosat	4011	Hughes	4064, 4068, 4192, 4194, 4196, 4202
Ankaro	4005, 4008, 4024, 4217	Cosat	4048	Eurosky	4008, 4011, 4215, 4218, 4219, 4024	Hughes Network Systems	4071
Anttron	4001, 4004	Coship	4109	Eurostar	4011, 4215, 4219	Humax	4025, 4030, 4060, 4097
Apollo	4001	Crown	4011	Eutelsat	4217	Huth	4005, 4011, 4012, 4013, 4048, 4050, 4219, 4223
Armstrong	4011, 4053	Daeryung	4014	Exator	4001, 4004	Hypson	4031
Artec	4100	Daewoo	4057, 4217	Expressvuu	4117	Ilo	4016
Asat	4053, 4055	DDC	4007	Fenner	4024, 4212, 4217	Imex	4031
ASLF	4217	Delega	4007	Ferguson	4006, 4052, 4214	Innovation	4008
Astacom	4216	Dew	4050	Fidelity	4218	Insignia	4107
Astra	4009, 4011, 4054, 4217, 4219	Diamond	4051	Finlandia	4006	Intertronic	4011
Astro	4004, 4008, 4010, 4015, 4024, 4213, 4218, 4219	Digiality	4219	Finlux	4006	Intervision	4048, 4219
AudioTon	4004, 4048	Digital Stream	4105	FinnSat	4050, 4052	ITT Nokia	4006
Aurora	4222, 4246	DIRECTV	4056, 4064, 4067, 4068, 4070, 4071, 4074, 4107, 4116, 4119, 4121, 4122, 4123, 4127, 4192, 4193, 4194, 4195, 4196, 4197, 4198, 4199, 4200, 4201, 4202, 4203, 4206, 4207, 4221	Flair Mate	4217	Jerrold	4019
Austar	4222, 4246	Discoverer	4212	Foxtel	4204, 4222, 4244, 4245, 4246, 4247	Johansson	4013
Axiel	4216	Discovery	4216	Freecom	4001, 4049, 4218	JOK	4216
Axis	4008, 4009, 4024, 4050	Diseqc	4216	FTEmaximal	4024, 4217	JSR	4048
BBK	4205	Dish Network	4018, 4065, 4089, 4092, 4094, 4095, 4117	Fuba	4001, 4008, 4014, 4015, 4024, 4055, 4215	JVC	4029, 4065, 4089, 4117
Best	4008, 4024	Dishpro	4018, 4117	Galaxis	4005, 4008, 4009, 4024, 4048, 4050, 4215, 4222, 4246	Kamm	4217
Blaupunkt	4015	Distrisat	4053	GE	4066, 4093, 4111, 4197	Kathrein	4015, 4034, 4042, 4053, 4055, 4063, 4215, 4216, 4217
Blue Sky	4217	Ditristrad	4048	General Instrument	4019, 4073	Kathrein Eurostar	4215
Boca	4011, 4054, 4059, 4217	DNT	4014, 4053, 4055	GMI	4011	Klap	4216
Boston	4216	Drake	4072	GOI	4117	Konig	4219
Brain Wave	4013	DStv	4222, 4246	Goldbox	4213	Kosmos	4049
Broadcast	4012	Dune	4024, 4240, 4242	GoldStar	4049	KR	4004
Broco	4217	Echostar	4014, 4018, 4065, 4089, 4117, 4217	Goodmans	4002, 4006, 4029	Kreiselmeyer	4015
BSkyB	4035, 4041	Einhell	4001, 4005, 4011, 4217, 4218	Goodmind	4111	K-SAT	4217
BT	4216	Elap	4216, 4217	Grandin	4031	Kyostar	4001
Bubu Sat	4217	Elekta	4010	Grothusen	4001, 4049	L&S Electronic	4024
Bush	4006, 4045	Elsat	4217	Grundig	4004, 4006, 4015, 4035, 4211, 4218, 4222, 4246	Lasat	4008, 4010, 4024, 4054, 4212, 4215, 4219
Cambridge	4218	Elta	4001, 4008, 4024, 4048, 4053, 4055	Hänsel & Gretel	4219	Lasonic	4108
Canal Satellite	4213			Hantor	4001, 4013	Lenco	4001, 4024, 4049, 4215, 4217, 4219
Canal+	4213			Hanuri	4010	Leng	4013
CaptiveWorks	4099			Hauppauge	4044	Lennox	4048
Channel Master	4007, 4110			Heliocom	4219	Lenson	4218
Chaparral	4075			Helium	4219		
CHEROKEE	4216						
Chess	4212, 4217						
CityCom	4006, 4215, 4219						
Clatronic	4013						
CNT	4010						

Lexus	4053	Nikko	4011, 4217	Quadral	4005, 4007, 4008, 4216, 4024	Skymaster	4005, 4017, 4022, 4212, 4217
LG	4049, 4103, 4107	Nokia	4006, 4040	Quelle	4015, 4215, 4219	Skymax	4053, 4055
Lifesat	4008, 4024, 4212, 4217	Nordmende	4001, 4006, 4007, 4010, 4052	Quiero	4052	SkySat	4212, 4217, 4218, 4219
Lifetec	4008			RadioShack	4019	Skyvision	4048
Lorenzen	4219	Nova	4222	Radiola	4053, 4055	SM Electronic	4212, 4217
Lorraine	4049	Novis	4013	Radix	4014, 4037	Smart	4215, 4217
Lupus	4008, 4024	Oceanic	4051	Rainbow	4004	Sony	4067, 4070, 4213
Luxor	4218	Octagon	4001, 4004, 4050	RCA	4066, 4093, 4112, 4113, 4116, 4118, 4119, 4197, 4122, 4207	SR	4011, 4054
Lyonnaise	4052	Okano	4011			Star Choice	4019
Macab	4052	Optex	4048	Realistic	4078	Starland	4217
Magnavox	4127, 4101	Optus	4204, 4213, 4222, 4223, 4246	Redpoint	4009	Starring	4013
Manata	4031, 4216, 4217	Orbitech	4001, 4212, 4213, 4218	Redstar	4008, 4024	Start Trak	4001
Manhattan	4006, 4010, 4048, 4216	OSat	4004	RFT	4005, 4053, 4055	Strong	4001, 4004, 4008, 4024, 4049, 4222, 4246
Marantz	4055	Otto Versand	4015	Roadstar	4217	STS	4115
Mascom	4010	Pace	4006, 4015, 4035, 4043, 4047, 4204, 4216, 4243	Roch	4031	STVI	4031
Maspro	4006, 4217			Rover	4024, 4217	Sumida	4011
Matsui	4216	Pacific	4051	Saba	4010, 4215, 4216, 4219	Sunny Sound	4024
Max	4219	Packsat	4216	Sabre	4006	Sunsat	4217
Mediabox	4213	Palcom	4007	Sagem	4023, 4052	Sunstar	4011, 4024, 4054
Mediamarkt	4011	Palladium	4011, 4218	Sakura	4050	Supermax	4223
Mediasat	4009, 4213, 4218	Palsat	4212, 4218	Samsung	4000, 4001, 4003, 4032, 4064, 4069, 4071, 4120, 4123, 4196, 4200	Tandberg	4052
Medion	4008, 4024, 4217	Panasat	4222, 4246			Tandy	4004
Medison	4217	Panasonic	4006, 4035, 4036, 4121, 4124, 4126, 4198, 4221	SAT	4007, 4218	Tantec	4006
Mega	4053, 4055			Sat Cruiser	4223	TCM	4008
Memorex	4127	Panda	4006, 4219	Sat Partner	4001, 4004, 4010, 4013, 4049, 4218	Techniland	4012
Metronic	4001, 4004, 4005, 4010, 4028, 4031, 4217	Pansat	4125			TechniSat	4014, 4021, 4026, 4027, 4038, 4039, 4053, 4212, 4213, 4218
Metz	4015	Patriot	4216	Sat Team	4217	Technology	4222
Micro electronic	4217, 4218, 4219	Paysat	4127	Satcom	4012, 4219	Technosat	4223
Micro Technology	4217	PCT	4110	Satec	4217	Technowelt	4219
MicroGem	4106	Philco	4101	Satelco	4024	Teco	4011, 4054
Micromaxx	4008, 4024	Philips	4006, 4033, 4053, 4055, 4061, 4068, 4071, 4127, 4196, 4201, 4202, 4203, 4206, 4213, 4216	Satford	4012	Telanor	4007
Microstar	4008			Satmaster	4012	Telasat	4215, 4219
Microtec	4217	Phoenix	4050	Satplus	4212	Telecom	4217
Minerva	4015	Phonotrend	4006, 4005, 4048	Schneider	4008, 4212, 4216	Telefunken	4001, 4017, 4216
Mitsubishi	4006, 4015, 4202	Pioneer	4046, 4213	Schwaiger	4051, 4212, 4219	Teleka	4004, 4011, 4014, 4218, 4219
Mitsumi	4054	Polsat	4052	SCS	4215	Telemaster	4010
Morgan's	4011, 4053, 4054, 4055, 4217	Predki	4013	Seemann	4009, 4011, 4014	TELENET	4241
Motorola	4019, 4088, 4090, 4091	Premiere	4048, 4213	SEG	4001, 4008, 4013, 4024	Telesat	4219
Multichoice	4222, 4246	Priesner	4011	Seleco	4048	Telestar	4212, 4213, 4218
Multitec	4212	Primestar	4076	Servi Sat	4031, 4217	Televés	4006, 4218
Muratto	4049	Profile	4216	Siemens	4015	Telewire	4048
Mysat	4217	Promax	4006	Silva	4049	Tempo	4223
Navex	4013	Prosat	4005, 4007	Skantin	4217	Tevion	4008, 4217
Neuhaus	4009, 4048, 4217, 4218, 4219	Proscan	4066, 4093, 4122, 4197	Skardin	4009		
Neusat	4217	Protek	4051	Skinsat	4218		
Next Level	4019	Proton	4016	SKR	4217		
NextWave	4223	Provision	4010	Sky Italia	4204		

Thomson	4006, 4020, 4052, 4058, 4208, 4213, 4215, 4216, 4217, 4219
Thorens	4051
Thorn	4006
Tivax	4104
Tivo	4196
Tokai	4053
Tonna	4006, 4012, 4048, 4217, 4218
Toshiba	4194, 4202, 4203
Triad	4049
Triasat	4218
Triax	4015, 4215, 4217, 4218
Turnsat	4217
Tvonic	4214
Twiner	4031, 4217
UEC	4204, 4222, 4246
Uher	4212
UltimateTV	4070
Uniden	4079, 4127
Unisat	4011, 4050, 4053
Unitor	4013
Universum	4015, 4215, 4219
US Digital	4016
Variosat	4015
Vega	4024
Ventana	4053, 4055
Viewsat	4098
Visiosat	4013, 4048, 4216, 4217
Voom	4019
Vortec	4001
Welltech	4212
WeTeKom	4212, 4218
Wevasat	4006
Wewa	4006
Winersat	4013
Wisi	4006, 4014, 4015, 4218, 4219
Woorisat	4010
Worldsat	4216
Xrypton	4024
XSat	4217
Zehnder	4008, 4209, 4010, 4215, 4024
Zenith	4102, 4107, 4195
Zodiac	4004

CD

Yamaha 5082, 5095, 5114

CD Recorder

Yamaha 5083

MD

Yamaha 5080, 5081, 5086

Tape

Yamaha 5084, 5087

Tuner

Yamaha 5066, 5085, 5088, 5090,
5092

LD

Yamaha 2080

Amplifier

Yamaha 5098

Apple TV

Apple 2241

“Apple TV” is a trademark or registered mark of Apple Inc.