



**YAMAHA**

# PM5D

**DIGITAL MIXING CONSOLE**

## **PM5D / PM5D-RH Owner's Manual**



# FCC INFORMATION (U.S.A.)

## 1. IMPORTANT NOTICE: DO NOT MODIFY THIS UNIT!

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.

**2. IMPORTANT:** When connecting this product to accessories and/or another product use only high quality shielded cables. Cable/s supplied with this product MUST be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.

**3. NOTE:** This product has been tested and found to comply with the requirements listed in FCC Regulations, Part 15 for Class "B" digital devices. Compliance with these requirements provides a reasonable level of assurance that your use of this product in a residential environment will not result in harmful interference with other electronic devices. This equipment generates/uses radio frequencies and, if not installed and used according to the instructions found in the users manual, may cause interference harmful to the operation of other electronic devices. Compliance with FCC regulations does

not guarantee that interference will not occur in all installations. If this product is found to be the source of interference, which can be determined by turning the unit "OFF" and "ON", please try to eliminate the problem by using one of the following measures:

Relocate either this product or the device that is being affected by the interference.

Utilize power outlets that are on different branch (circuit breaker or fuse) circuits or install AC line filter/s.


In the case of radio or TV interference, relocate/reorient the antenna. If the antenna lead-in is 300 ohm ribbon lead, change the lead-in to co-axial type cable.

If these corrective measures do not produce satisfactory results, please contact the local retailer authorized to distribute this type of product. If you can not locate the appropriate retailer, please contact Yamaha Corporation of America, Electronic Service Division, 6600 Orangethorpe Ave, Buena Park, CA90620


The above statements apply ONLY to those products distributed by Yamaha Corporation of America or its subsidiaries.

\* This applies only to products distributed by YAMAHA CORPORATION OF AMERICA.

(class B)



## Explanation of Graphical Symbols



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

The above warning is located on the rear of the unit.

# IMPORTANT SAFETY INSTRUCTIONS

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings.
- 4 Follow all instructions.
- 5 Do not use this apparatus near water.
- 6 Clean only with dry cloth.
- 7 Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9 Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

- 11 Only use attachments/accessories specified by the manufacturer.
- 12 Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 13 Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



## WARNING

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.

**ADVARSEL!**

Lithiumbatteri—Eksplodingsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandoren.

**VARNING**

Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparatillverkaren. Kassera använt batteri enligt fabrikantens instruktion.

**VAROITUS**

Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

(lithium caution)

**NEDERLAND / THE NETHERLANDS**

- Dit apparaat bevat een lithium batterij voor geheugen back-up.
- This apparatus contains a lithium battery for memory back-up.
- Raadpleeg uw leverancier over de verwijdering van de batterij op het moment dat u het apparaat aan het einde van de levensduur afdankt of de volgende Yamaha Service Afdeling:  
Yamaha Music Nederland Service Afdeling  
Kanaalweg 18-G, 3526 KL UTRECHT  
Tel. 030-2828425
- For the removal of the battery at the moment of the disposal at the end of the service life please consult your retailer or Yamaha Service Center as follows:  
Yamaha Music Nederland Service Center  
Address : Kanaalweg 18-G, 3526 KL UTRECHT  
Tel : 030-2828425
- Gooi de batterij niet weg, maar lever hem in als KCA.
- Do not throw away the battery. Instead, hand it in as small chemical waste.

(lithium disposal)

This product contains a high intensity lamp that contains a small amount of mercury. Disposal of this material may be regulated due to environmental considerations. For disposal information in the United States, refer to the Electronic Industries Alliance web site:  
[www.eiae.org](http://www.eiae.org)

\* This applies only to products distributed by YAMAHA CORPORATION OF AMERICA.

(mercury)

# PRECAUTIONS

## PLEASE READ CAREFULLY BEFORE PROCEEDING

\* Please keep this manual in a safe place for future reference.



### WARNING

Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire or other hazards. These precautions include, but are not limited to, the following:

#### Power supply/Power cord

- Use only the specified power supply (PW800W or an equivalent recommended by Yamaha).
- Only use the voltage specified as correct for the device. The required voltage is printed on the name plate of the device.
- Do not place the power cord near heat sources such as heaters or radiators, and do not excessively bend or otherwise damage the cord, place heavy objects on it, or place it in a position where anyone could walk on, trip over, or roll anything over it.

#### Do not open

- Do not open the device or attempt to disassemble the internal parts or modify them in any way. The device contains no user-serviceable parts. If it should appear to be malfunctioning, discontinue use immediately and have it inspected by qualified Yamaha service personnel.

#### Water warning

- Do not expose the device to rain, use it near water or in damp or wet conditions, or place containers on it containing liquids which might spill into any openings.
- Never insert or remove an electric plug with wet hands.

#### If you notice any abnormality

- If the power cord or plug becomes frayed or damaged, or if there is a sudden loss of sound during use of the device, or if any unusual smells or smoke should appear to be caused by it, immediately turn off the power switch, disconnect the electric plug from the outlet, and have the device inspected by qualified Yamaha service personnel.
- If this device or the power supply should be dropped or damaged, immediately turn off the power switch, disconnect the electric plug from the outlet, and have the device inspected by qualified Yamaha service personnel.



### CAUTION

Always follow the basic precautions listed below to avoid the possibility of physical injury to you or others, or damage to the device or other property. These precautions include, but are not limited to, the following:

#### Power supply/Power cord

- Remove the electric plug from the outlet when the device is not to be used for extended periods of time, or during electrical storms.
- When removing the electric plug from the device or an outlet, always hold the plug itself and not the cord. Pulling by the cord can damage it.
- Do not turn the PW800W POWER switch OFF and ON in rapid succession. Doing so can result in excessive current flow that can cause damage. Wait at least 5 seconds before turning the POWER switch ON after it has been turned OFF.

#### Location

- When transporting or moving the device, always use four or more people.
- Before moving the device, remove all connected cables.
- Avoid setting all equalizer controls and faders to their maximum. Depending on the condition of the connected devices, doing so may cause feedback and may damage the speakers.
- Do not expose the device to excessive dust or vibrations, or extreme cold or heat (such as in direct sunlight, near a heater, or in a car during the day) to prevent the possibility of panel disfiguration or damage to the internal components.
- Do not place the device in an unstable position where it might accidentally fall over.
- Do not block the vents. This device has ventilation holes at the front and rear to prevent the internal temperature from rising too high. In particular, do not place the device on its side or upside down, or place it in any poorly-ventilated location, such as a bookcase or closet.
- Do not use the device in the vicinity of a TV, radio, stereo equipment, mobile phone, or other electric devices. Otherwise, the device, TV, or radio may generate noise.

## Connections

- Before connecting the device to other devices, turn off the power for all devices. Before turning the power on or off for all devices, set all volume levels to minimum.

## Handling caution

- Do not insert your fingers or hand in any gaps or openings on the device (vents etc.).
- Avoid inserting or dropping foreign objects (paper, plastic, metal, etc.) into any gaps or openings on the device (vents, etc.) If this happens, turn off the power immediately and unplug the power cord from the AC outlet. Then have the device inspected by qualified Yamaha service personnel.
- Do not use the headphones for a long period of time at a high or uncomfortable volume level, since this can cause permanent hearing loss. If you experience any hearing loss or ringing in the ears, consult a physician.
- Do not rest your weight on the device or place heavy objects on it, and avoid use excessive force on the buttons, switches or connectors.

## Backup battery

- This device has a built-in backup battery. When you unplug the power cord from the AC outlet, the internal data of current scene is retained. However, if the backup battery fully discharges, this data will be lost. When the backup battery is running low, the LCD display indicates "Low Battery!" during operation or "No Battery!" when starting up the system. In this case, have qualified Yamaha service personnel replace the backup battery.

XLR-type connectors are wired as follows (IEC60268 standard): pin 1: ground, pin 2: hot (+), and pin 3: cold (-).

Yamaha cannot be held responsible for damage caused by improper use or modifications to the device, or data that is lost or destroyed.

Always turn the power off when the device is not in use.

The performance of components with moving contacts, such as switches, volume controls, and connectors, deteriorates over time. Consult qualified Yamaha service personnel about replacing defective components.

# Table of Contents — Operating section

<b>1 Introduction</b> .....	<b>10</b>
Thank you .....	10
An overview of the PM5D .....	10
Differences between the PM5D model and the PM5D-RH model .....	11
About the channel structure of the PM5D .....	12
Regarding word clock synchronization .....	12
How this manual is organized .....	13
Conventions in this manual .....	13
<b>2 Top, front, and rear panels</b> .....	<b>14</b>
Top panel .....	14
Rear panel .....	16
Front panel .....	18
<b>3 Basic operation on the PM5D</b> .....	<b>19</b>
About the various types of user interface .....	19
User interface in the display.....	19
DISPLAY ACCESS section .....	20
Data Entry section .....	20
External user interface.....	21
Basic operation .....	22
Click.....	22
Drag .....	22
Drag and drop.....	22
Accessing a desired screen.....	23
Moving the cursor .....	23
Scrolling the screen.....	24
Operating the buttons .....	25
Adjusting the setting of a knob or fader .....	25
Assigning a name .....	26
<b>4 Connections and setup</b> .....	<b>27</b>
Audio connections .....	27
Analog audio connections .....	27
Analog output connections .....	28
Digital input/output connections .....	29
Installing an option card.....	30
Word clock connections and settings.....	31
About word clock .....	31
Selecting the word clock master .....	31
Restoring the current scene to the default state .....	32
<b>5 Input channel operations</b> .....	<b>33</b>
About the input channels .....	33
AD IN section.....	35
Items in the AD IN section .....	35
Controlling the input sensitivity and phantom power (+48V) of the head amp .....	36
INPUT channel strip .....	37
Items in the INPUT channel strip.....	37
ST IN/FX RTN channel strip .....	39
Items in the ST IN/FX RTN channel strip.....	39
FADER FLIP/ENCODER MODE section .....	40
Items in the FADER FLIP/ENCODER MODE section.....	40
Various operations for input channels .....	41
Selecting the function of the encoders.....	41

Exchanging the fader and encoder functions .....	41
Sending a signal from an input channel to the STEREO bus .....	42
Sending the signal from the input channel to a MIX bus .....	43
Enabling/disabling pairing .....	45

## **6 Output channel operations** .....

About the output channels.....	47
MIX section .....	49
Items in the MIX section.....	49
Operations in the MIX section .....	49
STEREO A/B channel strip.....	53
Items in the STEREO A/B channel strip .....	53
Operations in the STEREO A/B channel strip .....	54
MATRIX section.....	55
Items in the MATRIX section.....	55
Operations in the MATRIX section .....	55

## **7 Using the Selected Channel section** .....

About the SELECTED CHANNEL section .....	57
Items in the SELECTED CHANNEL section .....	57
GROUP.....	57
CHANNEL SELECT .....	58
DELAY .....	58
GAIN/ATTENUATION/ $\phi$ (Gain / Attenuation / Phase) .....	59
NOISE GATE .....	59
STEREO.....	60
COMPRESSOR.....	60
HPF (High Pass Filter) .....	61
EQUALIZER.....	61
Operations in the SELECTED CHANNEL section .....	62
Selecting a channel and editing its parameters.....	62
Compressor operations.....	63
Gate operations.....	64
EQ/HPF operations .....	65

## **8 Input Patch / Output Patch operations** .....

Changing the input patch settings.....	66
Changing the output patch settings .....	67
Inserting an external device into a channel .....	69
Connecting an external device for insertion.....	69
Patching the insert-out and insert-in .....	70
Directly outputting the signal of an input channel .....	72

## **9 Grouping and linking** .....

About DCA Groups and Mute Groups.....	73
Items in the ASSIGN MODE section .....	73
Items in the DCA strip .....	73
Using DCA Groups .....	74
Assigning channels to DCA groups.....	74
Controlling DCA groups.....	75
Using mute groups.....	75
Assigning channels to mute groups.....	75
Controlling mute groups .....	76
Using the Mute Safe function .....	76
Using EQ Link and Compressor Link.....	77

## **10 Scene memory.....79**

About scenes .....	79
Items in the SCENE MEMORY section.....	80
Using scene memories.....	81
Storing a scene .....	81
Recalling a scene .....	82
Using PREVIEW mode .....	82
Using the Auto Store function .....	83
Using the Direct Recall function.....	83
Using the Selective Recall function .....	84
Using the Recall Safe function.....	86
Using the Fade function.....	87
Using the Tracking Recall function.....	88
Using the Global Paste function.....	89

## **11 Monitor and Cue.....91**

About the MONITOR and CUE sections.....	91
Using the Monitor function .....	92
Items in the MONITOR section .....	92
Monitoring a signal .....	93
Using the Cue/Solo functions .....	94
Items in the CUE section .....	94
About CUE mode and SOLO mode.....	94
Cue and Solo groups.....	95
Using the Cue function.....	96
Using the Solo function .....	96

## **12 Talkback and Oscillator.....97**

About the TALKBACK/OSCILLATOR sections .....	97
Items in the TALKBACK/OSCILLATOR sections.....	97
Using talkback .....	98
Using the oscillator .....	99

## **13 Meters.....100**

Items in the meter section .....	100
Switching the meter display .....	100
Switching the metering point.....	101
Specifying the metering point for input channels .....	101
Specifying the metering point for output channels.....	101
Viewing the gain reduction of the internal gates and compressors .....	102
Viewing the gain reduction for input channels .....	102
Viewing the gain reduction for output channels.....	102

## **14 Effects .....103**

About the internal effects .....	103
Using an internal effect via a MIX bus.....	104
Inserting an internal effect into a channel.....	105
Basic operations in the effect screen .....	106
Recalling settings from the effect library .....	106
Editing the effect parameters.....	106
Storing settings in the effect library .....	107
Using the Tap Tempo function.....	108
Using the Freeze effect .....	109
Using optional Add-On Effects.....	109

## **15 Graphic EQ..... 110**

Patching the graphic EQ.....	110
Basic graphic EQ operations.....	111
Controlling the graphic EQ from the display .....	111
Controlling the graphic EQ from the DCA section.....	111

## **16 Remote control..... 113**

MIDI on the PM5D .....	113
Using program changes to control events.....	113
Using control changes to control events .....	115
Using the MIDI Remote function.....	117
Assigning MIDI messages to controllers .....	117
Using MIDI remote channels.....	121
Transmitting MIDI events when you switch scenes ...	122
Using GPI (General Purpose Interface) .....	123
Using GPI IN .....	123
Calibrating the GPI IN ports .....	125
Using GPI OUT .....	126

## **17 Using memory cards..... 128**

Using memory cards with the PM5D .....	128
Saving files to a memory card .....	128
Loading files from a memory card.....	130

## **18 Surround pan..... 132**

About surround pan.....	132
Bus configuration and operation in surround mode..	133
About the surround buses .....	133
How the MIX section will operate .....	133
Basic settings for surround buses.....	134
Controlling surround pan.....	135
Notes regarding surround pan .....	137

## **19 Other functions..... 138**

Using the user defined keys.....	138
Items in the USER DEFINED section.....	138
Assigning functions to the User Defined keys.....	138
Executing functions assigned to the User Defined keys...	139
Using the Fader Assign function .....	139
Items in the FADER MODE section.....	139
Assigning channels to DCA faders .....	139
Controlling the channels assigned to DCA faders.....	140
Locking the PM5D (Security functions).....	141
Setting the System Password or Console Password.....	141
Using Parameter Lock or Console Lock.....	142
Using cascade connections .....	143
Making cascade connections .....	143
Basic settings for cascade connection .....	143
Selecting the buses used for cascade connection .....	144
Connecting the PM5D to a computer via USB .....	146
Caution when using the USB TO HOST connector .....	146
Initializing the PM5D's internal memory .....	147
Adjusting the faders and input/output gain (Calibration) .....	147
Calibrating the faders.....	148
Adjusting the analog input gain (PM5D-RH model only) .....	148
Adjusting the output gain.....	148

# Table of Contents — Reference section

<b>Information shown in the display</b> .....	<b>149</b>	<b>Output functions</b> .....	<b>220</b>
Upper part of the display (always visible).....	149	OUTPUT PATCH function.....	220
Main area of the display.....	150	OUTPUT PATCH screen.....	220
Lower part of the display (always visible).....	150	INSERT PATCH screen.....	221
<b>Function menu</b> .....	<b>151</b>	INSERT POINT screen.....	222
<b>Global functions</b> .....	<b>152</b>	OUTPUT PATCH LIBRARY screen.....	223
EFFECT functions.....	152	OUTPUT INSERT function.....	224
EFFECT PARAM (Effect parameter) screen.....	152	INSERT IN MIX 1-24 screen.....	224
EFFECT ASSIGN screen.....	154	INSERT IN MATRIX/STEREO/MONITOR screen.....	224
EFFECT LIBRARY screen.....	155	HA LIBRARY screen.....	225
GEQ function.....	156	OUTPUT EQ function.....	225
GEQ PARAM (GEQ parameter) screen.....	156	EQ PARAM (EQ Parameter) screen.....	225
GEQ ASSIGN screen.....	157	MIX 1-24 screen.....	227
GEQ LIBRARY screen.....	158	MATRIX/STEREO screen.....	227
SCENE function.....	159	OUTPUT EQ LIBRARY screen.....	228
SCENE screen.....	159	OUTPUT COMP function.....	229
EVENT LIST screen.....	161	COMP PARAM (Compressor parameter) screen.....	229
SELECTIVE RECALL screen.....	164	MIX 1-24 screen.....	231
RECALL SAFE screen.....	166	MATRIX/STEREO screen.....	231
FADE TIME screen.....	167	COMP LIBRARY (Compressor library) screen.....	232
TRACKING RECALL screen.....	169	OUTPUT DELAY function.....	233
GLOBAL PASTE screen.....	170	MIX 1-24 screen.....	233
MIDI REMOTE function.....	171	MATRIX/STEREO screen.....	233
MIDI SETUP screen.....	171	OUTPUT DCA/GROUP function.....	234
MIDI PGM CHANGE (MIDI program change) screen ..	173	DCA GROUP ASSIGN screen.....	234
MIDI CTRL CHANGE (MIDI control change) screen ...	174	MUTE GROUP ASSIGN screen.....	235
MIDI REMOTE screen.....	175	EQ LINK ASSIGN screen.....	236
GPI screen.....	177	COMP LINK ASSIGN (Compressor link assign) screen ..	237
FADER START screen.....	179	MATRIX/ST function.....	238
TRANSPORT screen.....	181	MATRIX/ST ROUTING screen.....	238
DME CONTROL screen.....	182	MIX to MATRIX VIEW screen.....	240
UTILITY function.....	186	LCR screen.....	242
PREFERENCE 1/2 screens.....	186	SURR SETUP screen.....	244
USER DEFINE screen.....	189	OUTPUT VIEW function.....	245
SAVE screen.....	192	CH VIEW (Channel view) screen.....	245
LOAD screen.....	195	SIGNAL FLOW screen.....	247
FADER ASSIGN screen.....	197	FADER VIEW screen.....	249
SECURITY screen.....	198	CH COPY (Channel copy) screen.....	249
SYS/W.CLOCK function.....	199	OUTPUT CH LIBRARY screen.....	251
WORD CLOCK screen.....	199		
MIXER SETUP screen.....	200		
CASCADE screen.....	204		
HA (Head Amp) screen.....	206		
OUTPUT PORT ATT (Output port attenuation) screen	207		
DITHER screen.....	207		
HA LIBRARY screen.....	208		
METER function.....	209		
INPUT METER screen.....	209		
OUTPUT METER screen.....	210		
INPUT GR (Input Gain Reduction) screen.....	211		
OUTPUT GR (Output Gain Reduction) screen.....	211		
MON/CUE function.....	212		
TALKBACK screen.....	212		
OSCILLATOR screen.....	213		
2TR I/O screen.....	215		
MONITOR screen.....	216		
CUE/SOLO screen.....	217		



# Operating section

## 1 Introduction

### Thank you

Thank you for purchasing the Yamaha PM5D digital mixing console. In order to take full advantage of the PM5D's superior functionality and enjoy years of trouble-free use, please read this manual before you begin using the product. After you have read the manual, keep it in a safe place.

### An overview of the PM5D

The PM5D is a digital mixing console with the following features.

#### ❑ Full digital SR mixing system

The PM5D is a full-digital SR mixing console that takes advantage of cutting-edge digital audio processing technology. 24-bit linear AD/DA converters are used to deliver up to 110 dB of dynamic range and amazing sound quality. As input channels, it provides 48 monaural channels, four stereo channels, and four stereo channels for effect return. As output channels, it provides 24 MIX channels, eight MATRIX channels, and two STEREO channels. The PM5D can be used in a wide range of applications. You can assign desired channels to be controlled by the eight DCA faders on the panel, and use them as group faders.

#### ❑ PM5D model and PM5D-RH model

In addition to the standard PM5D model that provides manual control of the head amp for each input, the PM5D-RH model is also available, providing programmable control of head amp input sensitivity and phantom power settings. You can choose the model appropriate for your situation and budget.

#### ❑ Cutting-edge user interface

For the input channels and STEREO A/B channels, dedicated channel strips are provided where you can operate the fader, pan, cue, and on/off controls. For MIX channels and MATRIX channels, encoders allow you to control the send level and master level. The PM5D allows quick and intuitive operation just as on an analog mixer. In addition, you can use the SELECTED CHANNEL section to manually control the principal parameters (delay, EQ, gate, compressor) of the desired channel.

#### ❑ Eight effect modules / Twelve graphic EQ modules

Eight high-quality multi-effect modules are built in. Effects such as reverb, delay, multiband compressor, and various modulation effects can be routed via internal buses or inserted into the desired channel. 31-band graphic EQ can also be inserted into any channel or any output.

#### ❑ Scene memories and libraries

Mix parameters and internal effect settings can be stored in memory as up to 500 scenes for immediate recall. Effects, input/output patching, input channel/output channel settings, internal head amp (PM5D-RH model only) or external head amp settings can be stored in various libraries, independently of scenes.

#### ❑ Digital cascade connection

Up to four PM5D units, or one PM5D and one Yamaha DM2000/02R96 unit, can be cascade-connected to share buses in the digital domain. In particular when PM5D units are cascaded together, operations such as scene saving and recall can also be linked. Compatible external devices can also be used as inserts or as extended signal processors via a cascade connection.

#### ❑ Surround panning

Surround pan functionality allows multi-channel playback systems to be used, letting you place the signal of an input channel in two-dimensional space, or move the sound image forward/backward and left/right. 3-1ch, 5.1ch, and 6.1ch surround modes are available.

#### ❑ I/O card expansion

The rear panel provides four slots in which separately sold mini-YGDAI cards can be installed. AD cards, DA cards, or digital I/O cards can be installed in these slots to add inputs and outputs.

#### ❑ Add-On Effects provide additional effect types


Separately sold Add-On Effects packages can be installed to add new effect types for the internal effects. The REV-X reverb effect sold as an Add-On Effect for the DM2000 or 02R96 is included as standard.

# Differences between the PM5D model and the PM5D-RH model


The PM5D is available as the standard PM5D model or as the PM5D-RH model which allows internal head amp settings to be programmed. These models differ as follows.

## PM5D model

- Head amp adjustments (input sensitivity settings, phantom power (+48V) on/off) for the analog inputs (INPUT jacks 1–48, ST IN jacks 1–4) are performed manually, using the controls of the top panel.




- Insert jacks (INSERT IN/OUT jacks) for the monaural analog inputs (INPUT jacks 1–48) are provided on the rear panel, allowing external effect processors to be inserted in the analog domain.
- ST IN jacks 1–4 are only for line level.
- There is no +48V MASTER switch.




## PM5D-RH model

- Head amp adjustments (input sensitivity settings, phantom power (+48V) on/off) for the analog inputs are controlled from within the screen via software. For this reason, the top panel does not have head amp controls; instead, indicators showing the presence or absence of a signal are provided. Head amp settings can be saved in a library and recalled at any time.



- Insert jacks for the analog inputs are not provided.
- ST IN jacks 1–4 support phantom mic levels through line levels. Phantom power can also be supplied to ST IN jacks 1–4.
- The +48V MASTER switch turns all phantom power (+48V) on/off.



## About the channel structure of the PM5D

The PM5D provides the following input channels and output channels.

### □ Input channels

This section processes input signals and sends them to the STEREO bus or MIX buses. There are three types of input channel, as follows.

- **Input channels 1–48**  
These channels are used to process monaural signals. By default, the input signals from the monaural analog input jacks (INPUT jacks 1–48) are assigned to these channels.
- **ST IN channels 1–4**  
These channels are used to process stereo signals. By default, the input signals from the stereo analog input jacks (ST IN jacks 1–4) are assigned to these channels.
- **FX RTN channels 1–4**  
These channels are used mainly to process the return signals (stereo) from the internal effects. By default, the left/right output channels of internal effects 1 through 4 are assigned to these channels.

#### Hint

*Signal assignments to the input channels can be changed as desired.*

### □ Output channels

This section mixes the signals sent from input channels etc., and sends them to the corresponding output jacks or output buses. There are three types of output channel, as follows.

- **MIX channels 1–24**  
These process the signals sent from input channels to MIX buses, and output them from MIX OUT jacks 1 through 24. These channels are used mainly for fold-back or as sends to external effects. The signals of MIX channels 1–24 can also be sent to the STEREO bus or MATRIX buses.
- **MATRIX channels 1–8**  
These process the signals sent from MIX channels or STEREO A/B channels to MATRIX buses, and output them from the MATRIX OUT jacks. This allows MIX channels or STEREO A/B channels to be mixed at the desired balance for output.
- **STEREO A/B channels**  
These process the signals sent from input channels or MIX channels, and output them to STEREO OUT jacks A/B. These channels are used as the main stereo outputs. Normally, the same signal is sent from the STEREO A and B channels. However, it is also possible to use the STEREO B channel as the center channel for three-channel L/C/R playback.

## Regarding word clock synchronization

The signal used to synchronize digital audio signal processing is called “word clock.” Normally, one device transmits a reference word clock signal, and the other devices receive this word clock signal and synchronize to it.

In order to transmit or receive digital audio signals to or from an external device via the PM5D’s digital input/output jacks or via a digital I/O card installed in a slot, the word clock must be synchronized between the devices. Be aware that if the word clock is not synchronized, the signals will not be transmitted correctly, and unpleasant noise will occur.

#### Hint

- For details on synchronizing the word clock of the PM5D and external devices, refer to the explanation of word clock in Operating section “Chapter 4. Connections and setup” (➡ p.31), and to the Reference Section “WORD CLOCK screen” (➡ p.199).
- As an exception, digital signals that are not synchronized with the PM5D can be input via a digital I/O card that contains a sampling rate converter, or via the 2TR IN/OUT DIGITAL jacks.

# How this manual is organized

---

This owner's manual is divided into the following three sections.

## □ Operating section

This section explains the items on the front and rear panels, connections and setup, and how to operate the PM5D's basic functionality. In particular if you have not operated a digital console before, we recommend that you read chapters 2 through 7 first.

## □ Reference section

This section explains the functionality and operation for all of the PM5D's screens. Refer to this section when you want to learn about the items in the screens.

## □ Appendices

This contains various information such as library lists, parameter lists for the internal effects, the MIDI data format, and lists of warning messages and error messages.

## Conventions in this manual

In this manual, non-locking panel switches that you press are called "keys," and those that change their on/off status when you push them in (locking types) are called "switches." Of the control knobs on the panel, those that turn from a minimum value to a maximum value are called "knobs," while those that turn endlessly are called "encoders."


Controls located on the panel are enclosed in square brackets [ ] (e.g., [CUE] key, [PAD] switch) in order to distinguish them from the buttons and knobs displayed in the screen. For some controls, the section name is listed before the [ ] (e.g., CH [ON] key, EQ [FREQUENCY] encoder).

Unless otherwise specified, references to the PM5D apply to both the PM5D model and the PM5D-RH model. If specifications differ between the PM5D model and the PM5D-RH model, such differences will be noted each time they occur.


## 2 Top, front, and rear panels

This chapter explains the names and functions of each part of the PM5D. Details for each section of the top panel are explained in subsequent chapters of this operating section; refer to the appropriate chapter for more information.

### Top panel




(PM5D model)




#### ① AD IN section (PM5D model)

In this section you can adjust the sensitivity of the analog signals being input from the rear panel INPUT jacks 1–48 and ST IN jacks 1–4, and switch pad, insert, and phantom power (+48 V) on/off (➔ p.35).



(PM5D-RH model)





#### ② AD IN section (PM5D-RH model)

This area indicates the presence, peak level, and phantom power (+48V) on/off status of the input signal from rear panel INPUT jacks 1–48 and ST IN jacks 1–4.

#### Hint

For the PM5D-RH model, input sensitivity and phantom power on/off are controlled by operations in the display (➔ p.36).



#### ③ INPUT channel strip section

This section controls the principal parameters for input channels 1–48 (➔ p.37).

#### ④ FADER FLIP/ENCODER MODE section

Here you can select the parameters controlled by the faders/encoders of the INPUT channel strip (③) (➔ p.40).

#### ⑤ MIX section

This section controls the on/off status and send level of the signals sent from input channels to MIX buses, and adjusts the master level of the MIX channels (➔ p.49).

#### ⑥ MATRIX section


This section controls the send level of the signals sent from MIX channels to MATRIX buses, and adjusts the master level of the MATRIX channels (➔ p.55).

#### ⑦ SELECTED CHANNEL section

In this section you can view and control the mix parameters for the currently selected input channel or output channel (➔ p.57).

#### ⑧ Meter section

This section contains peak level meters that indicate the input levels of input channels and the output levels of output channels and cue monitoring, as selected by key operations (➔ p.100).



- ⑮ **CUE/MONITOR section**  
This section selects the monitor source that is output from the MONITOR OUT jacks, and adjusts the levels. This section also determines the cue point and monitoring method that will be used when you press a [CUE] key for a channel (➔ p.91).
- ⑯ **OSCILLATOR/TALKBACK section**  
This section switches the oscillator or talkback on/off, and adjusts the talkback level (➔ p.97).
- ⑰ **DISPLAY ACCESS section**  
This section selects the functions or screen shown in the display (➔ p.20).
- ⑱ **USER DEFINED KEYS sections**  
This section executes the functions that have been assigned to the User Defined keys [1]–[25] (➔ p.138).
- ⑲ **Data entry section**  
This section lets you move the pointer (the arrow displayed in the screen) or cursor (the red frame indicating a selection) in the display and edit the parameter value (➔ p.20).
- ⑳ **ASSIGN MODE section**  
This section lets you assign mute groups and DCA groups for control from the panel (➔ p.73).

### ⑨ Display

This display shows the information you need to operate the PM5D, and lets you make system-wide settings and control mix parameters for input and output channels (➔ p.19).

#### Hint

You can adjust the angle of the display by moving the upper part of the display frame forward or backward.

#### Note

Before moving the PM5D, you must lower the display all the way back until it is fastened in place.

### ⑩ FADER MODE section

Here you can select the combination of channels or DCA groups that will be controlled by the faders of the DCA strip section (⑪) (➔ p.73).

### ⑪ DCA strip section

From this section you can control the channels assigned to DCA groups 1–8 (➔ p.73).

### ⑫ ST IN/FX RTN (Stereo in / Effect return) channel strip section

This section controls the principal parameters of ST IN channels 1–4 or FX RTN channels 1–4 (➔ p.39).


### ⑬ STEREO strip section

This section controls the principal parameters of the STEREO A/B channels (➔ p.53).

### ⑭ SCENE MEMORY section


This section stores/recalls mix parameters as scene memories (➔ p.80). Mute operations for mute groups 1–8 are also performed in this section (➔ p.75).

## Rear panel




### ① INPUT jacks 1–48 (PM5D model)

These are balanced XLR-3-31 type input jacks for inputting analog audio signals from line level devices or microphones. Nominal input level is  $-60$  dBu to  $+10$  dBu.





### ② INSERT IN/OUT jacks 1–48 (PM5D model only)

These are balanced TRS phone type input/output jacks for inserting external effects or dynamics processors etc. into INPUT jacks 1–48. Nominal input/output level is  $+4$  dBu.



### ③ ST IN (Stereo input) jacks 1–4 (PM5D model)

These are balanced XLR-3-31 type input jacks for inputting analog audio signals from line level devices. Nominal input level is  $-34$  dBu to  $+10$  dBu.




### ④ +48V MASTER switch (PM5D-RH model only)

This is the master phantom power ( $+48$ V) switch for INPUT jacks 1–48 and ST IN jacks 1–4. If this switch is off, the  $+48$ V buttons shown in the display are unavailable.


### ⑤ INPUT jacks 1–48 (PM5D-RH model)


These are balanced XLR-3-31 type input jacks for inputting analog audio signals from line level devices or microphones. Nominal input level is  $-62$  dBu to  $+10$  dBu.



### ⑥ ST IN (Stereo input) jacks 1–4 (PM5D-RH model)


These are balanced XLR-3-31 type input jacks for inputting analog audio signals from line level devices or microphones. Nominal input level is  $-62$  dBu to  $+10$  dBu.






### ⑦ MIX OUT jacks

These are XLR-3-32 (balanced) jacks that output the analog signals of MIX channels 1–24. Nominal output level is +4 dBu.




### ⑧ LAMP connector

This is a four-pin female XLR output jack for supplying power to a gooseneck lamp. (These jacks are provided at three locations). The location of these jacks differs between the PM5D model and the PM5D-RH model.



### ⑨ MONITOR OUT jacks

These are XLR-3-32 (balanced) jacks that output the monitor signal selected in the MONITOR section of the top panel. Nominal output level is +4 dBu.




#### Note

Although the various output jacks and 2TR IN ANALOG jacks have a nominal input/output level of +4 dBu (maximum level is +24 dBu), an internal switch allows this to be changed to -2 dBu (maximum level +18 dBu) if necessary. For details, contact your Yamaha dealer.


### ⑩ CUE OUT jacks

These are XLR-3-32 (balanced) jacks that output the cue monitor signal from the channel selected by its [CUE] key. Nominal output level is +4 dBu.




### ⑪ STEREO OUT A/B jacks

These are XLR-3-32 (balanced) jacks that output the analog signals of the STEREO A/B channels. Nominal output level is +4 dBu.




### ⑫ MATRIX OUT jacks

These are XLR-3-32 (balanced) jacks that output the analog signals of MATRIX channels 1–8. Nominal output level is +4 dBu.




### ⑬ DC POWER INPUT connector

This is a connector for connecting the PW800W power supply. Use the dedicated cable included with the PM5D to make the connection.




### ⑭ 2TR IN ANALOG jacks 1/2

These are XLR-3-31 (balanced) jacks that input stereo analog signals from an external source. Nominal input level is +4 dBu.



### ⑮ TIME CODE INPUT jack

This is an XLR-3-31 (balanced) jack that receives SMPTE time code (LTC) from an external source.



### ⑯ TO HOST connector


This is a USB (type B) connector that allows communication with a computer.

### ⑰ GPI connector

This is a D-sub 25-pin female connector that allows communication with a GPI-equipped external device.


- ⑱ **RS422 REMOTE connector**  
This is a D-sub 9-pin female connector for remotely controlling an external device that supports the RS422 protocol.
- ⑲ **HA REMOTE connector**  
This is a D-sub 9-pin male connector for remotely controlling an external head amp device (e.g., Yamaha AD8HR or AD824) that supports a special protocol.
- ⑳ **WORD CLOCK IN connector**  
This is a BNC connector for supplying a word clock from an external device to the PM5D.
- ㉑ **75Ω ON/OFF switch**  
This switch terminates the word clock connection. Normally you will leave this ON. If a device made by another manufacturer is connected and word clock cannot be received correctly, try turning this OFF.
- ㉒ **WORD CLOCK OUT connector**  
This is a BNC connector for supplying a word clock from the PM5D to an external device.
- ㉓ **MIDI IN/THRU/OUT connectors**  
These connectors are used to transmit and receive MIDI messages to and from external MIDI devices. The MIDI IN connector receives messages from an external device, and the MIDI OUT connector transmits messages from the PM5D. Messages received at the MIDI IN connector are retransmitted without change from the MIDI THRU connector.
- ㉔ **2TR OUT DIGITAL (2 track out digital) jacks 1–3**  
These jacks digitally output the signals of the STEREO A/B channels. Two types are provided; AES/EBU (XLR-3-32) jacks (1/2) which output AES/EBU format signals, and a COAXIAL (RCA phono) jack (3) which outputs consumer format signals (IEC60958).
- ㉕ **2TR IN DIGITAL (2 track in digital) jacks 1–3**  
These jacks input digital audio from external devices such as CD players. Two types are provided; AES/EBU (XLR-3-31) jacks (1/2) which receive AES/EBU format signals, and a COAXIAL (RCA phono) jack (3) which receives consumer format signals (IEC60958).

- ㉖ **CASCADE OUT connector**  
This is a D-sub half-pitch 68-pin female connector that can be connected to another PM5D for transmission/reception of control signals and transmission of audio signals.
- ㉗ **CASCADE IN connector**  
This is a D-sub half-pitch 68-pin female connector that can be connected to another PM5D for transmission/reception of control signals and reception of audio signals.



- ⑳ **Fan grille**  
This is an output grille for the fan that cools the interior of the console (two locations). Be careful not to obstruct the fan exhaust.
- ㉑ **SLOT 1–4**  
These slots allow separately sold mini-YGDAI I/O cards to be installed to expand the input/output ports.

## Front panel



- ① **MEMORY CARD slot**  
A memory card inserted in this slot can be used to save/load scene memories or library data. You can use PCMCIA Type II flash ATA cards, or CompactFlash cards inserted into a PC card adaptor.
- ② **MOUSE connector**  
A PS/2 mouse can be connected to this connector and used to perform operations in the display.
- ③ **KEYBOARD connector**  
A PS/2 keyboard can be connected to this connector and used to input text or perform operations in the display.
- ④ **PHONES (Headphone) jack**  
This headphone jack lets you monitor the MONITOR OUT or CUE signals.

This chapter explains the various types of user interface used to operate the PM5D.

## About the various types of user interface

Basic parameters such as mixing and editing the sound of each channel can be controlled by the faders and encoders of the top panel. However to make more detailed settings, you will need to access the appropriate “function” and edit the parameter values in the display. The section below explains the various user interface components shown in the display, and how to use them.

### User interface in the display

The user interface in the PM5D’s display uses the following components.


#### □ Pointer

The arrow shown in the display is called the “pointer.” Use the pointer to select the parameter you want to control next.




#### □ Cursor

The red frame shown in the display is called the “cursor.” If the cursor encloses a parameter on the screen, that parameter is selected for operation.




#### □ Tabs

The screen names shown in the upper left of the display are called “tabs.” Tabs are used to switch between screens within the same function.




#### □ Buttons

Buttons in the display are used to switch parameters on/off or to select one of multiple choices. Buttons that are currently on are displayed in green (some buttons are displayed in red or blue); buttons that are turned off are displayed in gray.



#### □ Knobs/Faders/Boxes

Knobs/faders in the display are used to edit parameter values. The current value is shown in the box. Boxes for which / buttons are displayed at left and right allow you to edit the parameter by using these buttons. (If editing is not possible, the buttons will be gray.)



If you want to assign a name to a channel or scene, input characters, numerals, and symbols into the box.




#### □ Character palette

This is a “virtual” keyboard used to input characters, numerals, and symbols into a text input box.




### □ Scroll bar

If the displayed items are too numerous to fit into a single screen, you can use the scroll bar to view the portion that is not currently displayed.



### DISPLAY ACCESS section

The DISPLAY ACCESS section contains keys that access the desired function or screen in the display.



- ① **Global functions**  
These keys access functions that affect the entire PM5D.
- ② **Output functions**  
These keys access functions that are related to output channels.
- ③ **Input functions**  
These keys access functions that are related to input channels.


When you press the key for the desired function, the screen for that function will appear in the display. By repeatedly pressing a key you can cycle through the screens included in that function.

#### Hint

If you hold down the [SHIFT] key and press a key in the DISPLAY ACCESS section, the screens included in that function will appear in the reverse order (Page Back function). You can also use the Page Back function by holding down a key in the DISPLAY ACCESS section. If you rapidly press a key twice, you will return to the first screen in that function.

### Data Entry section

Controllers used to edit settings and values in the display are gathered into the data entry section.



- ① **[DEC/CANCEL]/[INC/OK] keys**  
Use these keys to increase or decrease the value of the parameter where the cursor is located. If the PM5D has displayed a window asking you to confirm an operation such as recall or store, these buttons can be used instead of the CANCEL button and OK button shown in the window.
- ② **CURSOR [◀]/[▶]/[▲]/[▼] keys**  
These keys are used to move the cursor to the desired parameter.
- ③ **[SHIFT] key**  
This key can be used in conjunction with the CURSOR [◀]/[▶]/[▲]/[▼] keys to move the cursor rapidly, or in conjunction with the [DATA] encoder or [DEC]/[INC] keys to change the parameter value rapidly.  
If you hold down the [SHIFT] key and press the [ENTER] key, the JOB SELECT window will appear, allowing you to set multiple parameters in a single operation. (When you move the cursor to a parameter for which there is a JOB SELECT window, an indication of "Job Select = [SHIFT] + [ENTER]" will appear.)
- ④ **[ENTER] key**  
Use this key to switch a button at the cursor location on/off, or to open a window.
- ⑤ **[DATA] encoder**  
Use this to increase or decrease the value of the parameter where the cursor is located. The parameter value will change more rapidly if you turn the [DATA] encoder while holding down the [SHIFT] key.

### ⑥ Track pad and left/right buttons

These are used to move the pointer or select the desired parameter. To adjust a knob-type parameter in the display, hold down the left button or right track pad button while you operate the track pad.

### ⑦ PHONES (Headphone) jack

This is a stereo phone jack for connecting a set of headphones.

## External user interface

If desired, you can add the following external user interface components.

### □ Mouse

A PS/2 compatible mouse can be connected to the MOUSE connector located on the front panel of the PM5D and used in the same way as the track pad.

### □ Keyboard

A PS/2 compatible keyboard can be connected to the KEYBOARD connector located on the front panel of the PM5D and used in the same way as the character palette in the display to input characters, numerals, and symbols. The numeric key pad of the keyboard can be used to input numerical values or to recall scenes.

Each key (or combination of keys) has the following function.

### Full keyboard

Key	Function
<PageUp>	Same function as the [INS/OK] key of the Data Entry section
<PageDown>	Same function as the [DEC/CANCEL] key of the Data Entry section
<←>, <→>, <↑>, <↓>	Same function as the CURSOR [◀]/[▶]/[▲]/[▼] keys
<Alt> + <PageUp>	Same function as moving the [DATA] encoder clockwise
<Alt> + <PageDown>	Same function as moving the [DATA] encoder counterclockwise
<Enter>	Same function as the [ENTER] key
<Shift>	Same function as the [SHIFT] key
<Ctrl> + <←>, <Ctrl> + <→>	Same function as the [◀] [▶] buttons of the character palette
<Ctrl> + <x>	Copies the text string in the box and clears the copy-source character string (Cut)
<Ctrl> + <c>	Same function as the COPY button of the character palette
<Ctrl> + <v>	Same function as the PASTE button of the character palette
<Insert>	Same function as the INS button of the character palette
<Delete>	Same function as the DEL button of the character palette
<Home>	Moves the input location in the box to the beginning
<End>	Moves the input location in the box to after the last-input character
<BackSpace>	Deletes the preceding character that was input in the box (Backspace)
<Tab>	Switches to the next screen within the same function

Key	Function
<Shift> + <Tab>	Switches to the previous screen within the same function
<Esc>	Accesses the function menu (if the function menu is already displayed, recalls the last-displayed screen)
<Alt> + <0>~<9>	Switch screens within the same function

### Numeric key pad


Key	Function
<0>~<9>	Input a scene number (if the PREFERENCE 1 screen item USE NUMERIC-KEYPAD is on), input numerical values (if off)
<.>	Returns the scene selection number to the number of the scene that was last recalled or stored
<+>	Same function as the [▲] key of the SCENE MEMORY section
<->	Same function as the [▼] key of the SCENE MEMORY section
</>, <*>	Not used
<Enter>	Same function as the [RECALL] key of the SCENE MEMORY section (if the PREFERENCE 1 screen item USE NUMERIC-KEYPAD is on), same function as the [ENTER] key (when off)

## Basic operation

This section explains the basic procedures you can perform in the PM5D's display. In general, you will perform operations in the PM5D's display by combining the operations described here.

### Click

Moving the pointer to a specific parameter in the screen and pressing the left/right track pad button (or the left/right mouse button) is called "clicking." Clicking is mainly used to turn an on-screen button on/off, to move the cursor, or to make fine adjustments to a value.



Using the CURSOR [◀]/[▶]/[▲]/[▼] keys of the data entry section to move the cursor to a desired parameter and then pressing the [ENTER] key is equivalent to clicking. If you are using a PS/2 keyboard, you can perform the same action using the arrow keys and the <Enter> key.

Subsequently in this manual, this operation will simply be called "clicking."

#### Hint


When using the track pad, you can move the pointer to the desired parameter and then tap the track pad to obtain the same result as if you pressed the left button. (This is called the Tapping function.) If you want to use the tapping function, you must enable it in the PREFERENCE 2 screen (UTILITY function) (→ p.188).

#### • Track pad



### Drag

Moving the pointer to a specific parameter in the screen and then holding down the left/right track pad (or mouse) button while moving up/down/left/right is called "dragging." Dragging is used mainly to adjust the value of a knob or fader.



Using the CURSOR [◀]/[▶]/[▲]/[▼] keys of the data entry section to move the cursor to a desired parameter and then turning the [DATA] encoder (or pressing the [DEC/CANCEL]/[INC/OK] keys) is equivalent to dragging. If you are using a PS/2 keyboard, you can perform the same action using the arrow keys and the <PageUp>/<PageDown> keys (or keys that have the same function).

Subsequently in this manual, this operation will simply be called "dragging."

### Drag and drop

Moving the mouse pointer to a specific parameter in the screen, dragging to another location in the screen, and then releasing your finger is called "dragging and dropping." Dragging and dropping is used to copy EQ or compressor settings to another channel. Dragging and dropping cannot be performed using the CURSOR keys or keyboard.

Subsequently in this manual, this operation will be called "dragging and dropping."

## Accessing a desired screen

A desired function/screen can be accessed in the display using either of the following two methods.

### Using the keys of the DISPLAY ACCESS section

- From the keys of the DISPLAY ACCESS section, press the key corresponding to the desired function.

The most recently operated screen for that function will appear.

- If you want to switch to another screen within that function, press the same key you pressed in step 1.

If you repeatedly press a key in the DISPLAY ACCESS section, or hold down the [SHIFT] key of the data entry section and press the same key as in step 1, you will return to the preceding screen of the same function.

### Using buttons within the display

- In any screen, click the function name area located in the upper left of the screen.


When you click the function name area, the function menu screen will appear. This screen is the starting point from which you can access the desired screen via operations in the display.

Click the function name area



- In the function menu screen, click the button corresponding to the desired function.

The most recently operated screen for that function will appear.



- Click a tab in the screen to select the desired screen.

Click a tab



### Hint

By clicking the [BACK] [FORWARD] buttons located below the function name area you can switch backward through the screens that had been previously displayed for at least two seconds (not including the function menu). Up to the eight most recent screens are remembered.

## Moving the cursor


To select a parameter, use the data entry section's controllers or a PS/2 keyboard to move the cursor (the red frame).

### Hint


If you are using a mouse or the track pad, the cursor will move when you click on the button or knob of the desired parameter.

- Use the CURSOR [◀]/[▶]/[▲]/[▼] keys to move the cursor.

The cursor in the display will move in the direction of the key you pressed. However, it will not move if there is no parameter in the direction of that key.




Move to the adjacent grid



- 2 To move quickly to the outer edge of the current window or to a different window, hold down the [SHIFT] key and use the CURSOR [◀]/[▶]/[▲]/[▼] keys.

You will move from the scroll window in which the cursor is currently located, in the direction of the key you pressed.




[SHIFT] key  
+  
CURSOR [▶] key

**Hint**

If the cursor is located on a grid such as in a PATCH screen, turning the [DATA] encoder clockwise will move the cursor toward the right, and turning it counterclockwise will move the cursor toward the left. If you are holding down the [SHIFT] key, turning the [DATA] encoder clockwise will move the cursor downward, and turning it counterclockwise will move the cursor upward.

**Scrolling the screen**

A scroll bar is displayed if there are more items than can be shown in a single screen. To scroll the screen, drag the box shown in the bar.




You can also scroll the screen by clicking the vacant portion of the scroll bar or the ◀/▶ buttons or ◀◀/▶▶ buttons located at the ends of the scroll bar.



Click these buttons to move the scroll bar box step-wise in the direction indicated. Clicking the ◀◀/▶▶ buttons will move in larger steps than clicking the ◀/▶ buttons.

Click in these areas to make the scroll bar box move by a large step in the corresponding direction; the screen will scroll accordingly.

If you move the cursor to the scroll bar and press the [DEC/CANCEL] key or turn the [DATA] encoder counterclockwise, the screen will scroll toward the left (or upward, in the case of vertical scrolling). If you press the [INC/OK] key or turn the [DATA] encoder clockwise, the screen will scroll toward the right (or downward, in the case of vertical scrolling).



**Hint**

If the cursor is located at the scroll bar box, holding down the [SHIFT] key and turning the [DATA] encoder will have the same result as clicking the ◀◀ button or ▶▶ button, depending on the direction in which you turn the encoder.

## Operating the buttons

Buttons in the display are used to switch parameters on/off or to select one of multiple choices.



- 1 Move the pointer to the desired button, and use the left/right buttons of the track pad (or mouse) to click the button.



The button will be switched on/off (or the corresponding button will be selected).

### Hint


You can use the CURSOR [ $\leftarrow$ ]/[ $\rightarrow$ ]/[ $\uparrow$ ]/[ $\downarrow$ ] keys and the [ENTER] key (or the arrow keys and <Enter> key of a PS/2 keyboard) to perform the equivalent operation.

### Hint

When using the track pad, you can also click by tapping the track pad if you have enabled tapping in the PREFERENCE 2 screen (UTILITY function  $\rightarrow$  p.188). In this case, the result will be the same as if you pressed the left button of the track pad (or mouse).

## Adjusting the setting of a knob or fader

Knobs and faders in the display are used to adjust the value of specific parameters.



- 1 Move the pointer to the desired knob/fader, and use the left/right buttons of the track pad (or mouse) to click the knob/fader. The cursor will move to that location.
- 2 To increase or decrease the value in steps of 1, click the right button or left button of the track pad (or mouse). Clicking the right button will raise the value by one step, and clicking the left button will lower the value by one step.
- 3 To raise or lower the value continuously, use the track pad (or mouse) to drag the knob/fader.

The value will change as you drag the knob or fader left/right or up/down. For a parameter whose knob has a wide range of adjustment, holding down the right button of the track pad (or mouse) as you drag will produce a larger range of change than when using the left button.

### Hint

You can also adjust the value by using the [DEC/CANCEL]/[INC/OK] keys, the [DATA] encoder, or the <PageUp>/<PageDown> keys of a PS/2 keyboard. When adjusting a parameter that has a wide range of adjustment, you can increase the rate of change by holding down the [SHIFT] key while you press the [DEC/CANCEL]/[INC/OK] keys (or turn the [DATA] encoder).

## Assigning a name

On the PM5D you can assign a four-character name to each input channel or DCA group, and assign a title to scene and library data when saving it.

For example, the screen shown below is the LIBRARY STORE window that appears when you assign a name to the INPUT EQ library. To input characters in this screen, use the following procedure.



### 1 Use the character palette (or a PS/2 keyboard) to input a character.

When you click the character palette, a character will be input in the box, and the highlighted area will move to the right.



### 2 Input the subsequent characters in the same way.

When inputting characters, you can use the following buttons in the character palette.

<b>INS button</b>	Inserts a space (blank) at the highlighted position. Pressing the <Insert> key of a PS/2 keyboard will produce the same result.
<b>DEL button</b>	Deletes the character at the highlighted position. Pressing the <Delete> key of a PS/2 keyboard will produce the same result.
<b>CLEAR button</b>	Deletes all characters that have been input in the text input box.
<b>◀ ▶ buttons</b>	Move the highlighted area to left or right.
<b>PASTE button</b>	Pastes the character string that was copied to buffer memory by the COPY button. Holding down the <Ctrl> key and pressing the <V> key of a PS/2 keyboard will produce the same result.
<b>COPY button</b>	Copies the character string in the box to a temporary buffer memory. Holding down the <Ctrl> key and pressing the <C> key of a PS/2 keyboard will produce the same result.
<b>CAPS LOCK button</b>	Switches between uppercase and lowercase alphabetical characters. Uppercase characters can be input while this button is on.

#### Note

Copy/paste operations are not possible in some screens. There are also cases in which the paste operation cannot be performed due to the type of character string copied to the buffer memory.

### 3 When you have finished inputting the name, click the STORE button.

The name you input will be stored.

#### Hint

- In general, the same procedure applies in screens where you enter names for scenes or other library items.
- If a PS/2 keyboard is connected, you can use it to enter characters.
- If you move the cursor to the text input box and press the [ENTER] key (or click), the input position will move to that point. If the cursor is located at the text input box, you can step through the available characters by turning the [DATA] encoder. If the cursor is located elsewhere, turning the [DATA] encoder will move the selected position. The [INC]/[DEC] keys move the selected position regardless of where the cursor is located.

#### Note

The number of characters that can be input will depend on the type of data (scene/library) you are saving. You cannot input more than the specified number of characters, or move the highlighted area beyond that range.


# 4 Connections and setup

This chapter explains how to make audio input/output connections, and how to perform the setup required when starting the PM5D for the first time.

## Audio connections

### Analog audio connections


#### PM5D model



INPUT jacks 1–48 are used mainly to connect microphones or monaural line-level devices. ST IN jacks 1–4 are used mainly to connect stereo line-level devices.

Input signal sensitivity, pad on/off, and phantom power (+48V) on/off are controlled from the top panel AD IN section (➔ p.36).

#### PM5D-RH model




INPUT jacks 1–48 and ST IN jacks 1–4 can both be used to connect microphones or line-level devices.

Input signal sensitivity and phantom power (+48V) on/off are controlled from within the display (➔ p.36). However, all phantom power can be switched on/off as a whole by the rear panel [+48V MASTER] switch.

On either model, the default state is for the input signals from INPUT jacks 1–48 to be patched to input channels 1–48 and the input signals from ST IN jacks 1–4 to be patched to the ST IN channels. However, this can be changed if desired. (For details on returning the patching to its default state ➔ p.32)

## Analog output connections




MIX OUT jacks 1–24, MATRIX OUT jacks 1–8, and STEREO OUT A/B jacks respectively output the signal from MIX channels 1–24, MATRIX channels 1–8, and the STEREO A/B channels.

The MONITOR OUT jacks output the monitor signal that is selected in the top panel MONITOR section.

The CUE OUT jacks output the cue monitor signal of the channel that is currently selected by its [CUE] key.

## Digital input/output connections



Use 2TR IN DIGITAL jacks 1–3 to connect digital sources such as CD players or DAT recorders. (To input analog output signals from a CD player or DAT recorder, use 2TR IN ANALOG jacks 1/2.)

Use 2TR OUT DIGITAL jacks 1–3 to send the STEREO A/B channel signals to a DAT recorder or other digital device. By installing separately sold mini-YGDAI I/O cards in slots 1–4 you can add analog input/output jacks to the PM5D or allow connection of digital devices such as digital MTR or HDR units.

The following types of I/O card can be used.

Card type	Model	Number of channels	Digital format	Bit depth
AD card	MY4-AD	4	—	24 bit
	MY8-AD	8		20 bit
	MY8-AD24			24 bit
	MY8-AD96	24 bit		
DA card	MY4-DA	4	—	20 bit
	MY8-DA96	8		24 bit
Digital I/O card	MY8-AE	8	AES/EBU	24 bit
	MY8-AE96			
	MY8-AE96S			
	MY16-AE	16	ADAT	
	MY8-AT	8		
	MY16-AT	16		
	MY8-TD	8	TASCAM	
MY16-TD	16			
CobraNet card	MY16-C	16	CobraNet	24 bit

Refer to the Yamaha Pro Audio global website for the most recent information on I/O cards.

<http://www.yamahaproaudio.com>

### Note

- In order to send or receive digital audio via the 2TR IN DIGITAL jacks, 2TR OUT DIGITAL jacks, or slots 1–4, the word clock data of the respective signals must be synchronized (⇒ p.31).
- In order to assign input signals from the 2TR IN DIGITAL jacks, 2TR IN ANALOG jacks, or slots 1–4 to input channels or ST IN channels, you will need to change the input patching (⇒ p.66).


## Installing an option card

Before installing a card, you must check the Yamaha website to make sure that this device is compatible with this card, and to verify the number of cards that can be installed in conjunction with other Yamaha or third-party cards.


Yamaha website: <http://www.yamahaproaudio.com>

To install an optional mini-YGDAI card, proceed as follows.

- 1 **Make sure that the power is turned off.**
- 2 **Loosen the screws that hold the slot cover in place, and remove the slot cover.**  
Keep the removed slot cover in a safe place.



- 3 **Align the edges of the card with the guard rails inside the slot, and insert the card into the slot.**  
Push the card all the way into the slot so that the connector at the end of the card is correctly mated with the connector inside the slot.



- 4 **Use the screws included with the card to fasten the card in place.**  
Malfunctions or incorrect operation may occur if the card is not fastened.

# Word clock connections and settings

This section explains the word clock settings required in order to send or receive digital audio between the PM5D and an external digital device.

## About word clock

When digital audio signals are being sent or received between multiple devices, the devices must process the audio signals at the matching timing. For example if the audio signal processing is not synchronized, the signals will not be transmitted correctly and unpleasant noise will occur even if both devices are set to the same sampling frequency.


The signal used to synchronize digital audio signal processing is called “word clock.” Normally, one device transmits a reference word clock signal, and the other devices receive this word clock signal and synchronize to it. (The transmitting device is called the “word clock master” and the receiving devices are called “word clock slaves.”)

The word clock can be synchronized between the PM5D and external devices in either of two ways; you can send/receive a word clock signal by itself, or use the clock data that is included in a digital audio signal.

The WORD CLOCK IN/OUT connectors on the rear panel of the PM5D are used to send/receive a word clock signal by itself. In general, word clock connections can be made in either of the following two ways.


### Using daisy-chain connections

In this method, the signal is distributed sequentially; the WORD CLOCK OUT connector of the first device is connected to the WORD CLOCK IN connector of the second device, and so on. Turn ON all of the 75Ω ON/OFF switches. This method is not recommended for large systems.




### Using a word clock distribution box

In this method, a special word clock distribution box is used to distribute the signal from the word clock master to multiple word clock slaves. Turn ON all of the 75Ω ON/OFF switches.




If an external device does not have WORD CLOCK IN/OUT connectors, the clock data included in the digital audio signal is used. In this case, both the digital audio signal and the clock data are sent from the DIGITAL OUT jack of the word clock master to the DIGITAL IN jack of the word clock slave.



### Selecting the word clock master

When digitally connecting the PM5D to an external device, you must select the source that will be the word clock master for the system.

- 1 Repeatedly press the [SYS/W.CLOCK] key of the DISPLAY ACCESS section until the WORD CLOCK screen appears.



In this screen you can select the master clock, and check the input signal synchronization status for each slot or jack.

#### Note

When you switch the word clock source, noise may occur due to loss of synchronization. You must lower the level of your monitoring equipment before you perform the following operation.

Use the MASTER CLOCK SELECT area located in the upper part of the screen to select the master clock source. You can choose one of the following sources.

<b>INT 96, INT 88.2, INT 48, INT 44.1</b>	These settings select the PM5D's internal clock. If you select one of these settings, the PM5D will operate as the word clock master. As necessary, make settings within your external devices so that they will operate as word clock slaves.
<b>W.CLOCK IN</b>	The PM5D will follow the word clock signal being input from the rear panel WORD CLOCK IN connector.
<b>CASCADE IN</b>	The PM5D will follow the clock data being sent from another PM5D connected to the CASCADE IN connector.
<b>2TR IN D1–D3</b>	The PM5D will follow the clock data included in the input signal from 2TR IN DIGITAL jacks 1–3.
<b>SLOT 1–4</b>	The PM5D will follow the clock data included in the input signal from a digital I/O card installed in slots 1–4. (You can select a specific pair of adjacent odd-numbered/even-numbered channels.)

#### Note

Sources for which the  symbol at the left of the button is red (UNLOCK) or yellow (UNKNOWN) cannot be selected, since a valid clock is not being input or the clock cannot be detected.

## 2 In the MASTER CLOCK SELECT area located in the upper part of the screen, click a button to select the desired master clock source.

A window will appear, asking you to confirm that you want to switch the master clock.

## 3 Click the OK button.

The selected word clock master will be enabled. The selected word clock master is remembered even if you turn off the power. As long as the connections have not been changed, you don't have to make this setting again.

#### Note

- If a digital I/O card (such as the MY8-AE96S) that contains a built-in SRC (Sampling Rate Converter) is installed in slots 1–4, you can switch the SRC on/off in groups of two channels. The input signals from channels for which the SRC is turned on do not need to be synchronized with the PM5D's word clock.
- If transferring high sampling rate (88.2 kHz/96 kHz) signals between the PM5D and an external device, you will need to select the transmission method. (For details, refer to p.200)

## Restoring the current scene to the default state


When the PM5D is in its default state, the input signals from INPUT jacks 1–48 are patched to input channels 1–48 and the input signals from ST IN jacks 1–4 are patched to the ST IN channels, and can then be output via the STEREO bus or MIX buses.

However, if the PM5D's internal mix parameter settings (referred to as the "current scene") have been modified, the signal of a specific input may not be sent to an input channel, or the EQ or dynamics processors may be set to produce extreme effects.

To initialize the mix parameters from such a state, proceed as follows.

### 1 Use the SCENE [▲]/[▼] keys of the SCENE MEMORY section to make the scene number indicator show "000".

Scene number "000" is a scene memory containing the default settings.



### 2 Press the [RECALL] key of the SCENE MEMORY section.

Scene number "000" will be loaded, and the current scene will return to the default state.

#### Note

Be aware that when scene number "000" is loaded, the input patch, output patch, internal effect, and HA (Head Amp) settings will also return to their default state. (However, the word clock master selection is not affected.)

# 5 Input channel operations


This chapter explains the functions and operation of each section related to input channels.

## About the input channels

The input channel section processes the signals that are input via the input patch section, and outputs them to the STEREO buses or MIX buses. There are three types of input channel, as follows.


### Input channels 1–48

These channels are used to process monaural signals. When the input patching is in the default state, the input signals from INPUT jacks 1–48 are assigned to these channels.




### ST IN channels 1–4

These channels are used to process stereo signals. When the input patching is in the default state, the input signals from ST IN jacks 1–4 are assigned to these channels.



## FX RTN channels 1–4

These channels are used mainly to process the return signals (stereo) from the internal effects. When the input patching is in the default state, the left/right channels of internal effects 1–4 are assigned to these channels.



- **INPUT PATCH**

This assigns an input signal to the input channel.

- **φ (Phase)**

Switches the phase of the input signal.

- **MS DECODE (Input channels / ST IN channels only)**

Switches MS decode processing on/off when an MS mic is connected.

- **ATT (Attenuator)**

Attenuates/boosts the level of the input signal.

- **HPF (High Pass Filter)**

This is a high pass filter that cuts the region below the specified frequency.

- **4 BAND EQ (4 band equalizer)**

A parametric EQ with four bands; HIGH, HIGH MID, LOW MID, and LOW.

- **GATE (Input channels and ST IN channels only)**

This is a dynamics processor that can be used for gating or ducking.

- **COMP (Compressor) (Input channels and ST IN channels only)**

This is a dynamics processor that can be used as a compressor, expander, or limiter.

- **INPUT DELAY (Input channels and ST IN channels only)**

This delays the input signal. It can be used to make fine adjustments in the relative timing between channels.

- **LEVEL/DCA 1-8**

Adjusts the input level of the effect.

- **ON (On/off)**

Turns the input channel on/off. If off, that channel is muted.

- **PAN**

Adjusts the panning of the signal sent from the input channel to the STEREO bus. If necessary, this pan setting can also be applied to signals sent to two paired MIX buses.

- **LCR (Left/Center/Right)**

Sends the three-channel signal (left/right channels and a center channel) to the STEREO bus.

- **MIX 1-24 (Mix send level 1–24)**

Adjusts the send level of the signal sent from the input channel to MIX buses 1–24. As the position from which the signal is sent to the MIX bus, you can choose from the following; immediately before the 4-band EQ, pre-fader, or post-fader.

- **INSERT (Input channels and ST IN channels only)**

Here you can patch the desired output port and input port to insert-out/insert-in, allowing an external effect processor or other device to be inserted. You can switch the insert-out and insert-in locations.

- **DIRECT OUT (Input channel and ST IN channels only)**

This can be patched to an output port, and the input signal sent directly from that output port.

- **METER**

This meters the level of the input channel. The level detection point can be switched.

### Note


The signal assignments from input patch to input channel can be edited in the INPUT PATCH function INPUT PATCH screen.

To edit the parameters of an input channel, you can either use the panel controllers (e.g., INPUT channel strip, ST IN/FX RTN channel strip, SELECTED CHANNEL section), or access the appropriate screen in the display and edit the parameters in the screen.


# AD IN section

The AD IN section AD-converts the signals that are input from the rear panel INPUT jacks 1–48 and ST IN jacks 1–4, and sends them to the input patch section. The structure of this section differs between the PM5D model and the PM5D-RH model.

## PM5D model




## PM5D-RH model




## Items in the AD IN section

### PM5D model



- ① **[+48V ON/OFF] switch**  
If this switch is on, +48V is supplied to the condenser mic or direct box connected to the INPUT jack 1–48.
- ② **[PAD] switch**  
If this switch is on, the input level is attenuated by 26 dB.
- ③ **[GAIN] knob**  
Adjusts the input sensitivity of the input channel. The range of adjustment is –34 dBu to +10 dBu (when the PAD switch is on) or –60 dBu to –16 dBu (when the PAD switch is off).
- ④ **[PEAK]/[SIGNAL] LED**  
The [SIGNAL] LED will light when the input level reaches 14 dB below nominal level (i.e., 34 dB below clipping level). The [PEAK] indicator will light when the signal reaches 3 dB below clipping level.
- ⑤ **[INSERT ON/OFF] switch**  
This switch enables/disables the INSERT IN/OUT jack located on the rear panel.
- ⑥ **ST IN [GAIN] knob**  
Adjusts the input sensitivity of the ST IN channel. The range of adjustment is –34 dBu to +10 dBu.
- ⑦ **ST IN [PEAK]/ST IN [SIGNAL] LED**  
The ST IN [SIGNAL] LED will light when the input level of the ST IN channel reaches 14 dB below nominal level (34 dB below clipping level). The ST IN [PEAK] indicator will light when the signal reaches 3 dB below clipping level.
- ⑧ **[LAMP DIMMER] knob**  
This adjusts the brightness of the lamp, connected to the LAMP connector.

## PM5D-RH model



## ① [+48V ON/OFF] LED

This LED will light if phantom power (+48V) is being supplied to the corresponding INPUT jacks 1–48 or ST IN jacks 1–4. However, +48V will not be supplied unless the rear panel [+48V MASTER] switch is on.

## ② [PEAK]/[SIGNAL] LED

The [SIGNAL] LED will light when the input level reaches 14 dB below nominal level (i.e., 34 dB below clipping level). The [PEAK] indicator will light when the signal reaches 3 dB below clipping level.

## ③ [LAMP DIMMER] knob

This adjusts the brightness of the lamp connected to the LAMP connector.

On the PM5D-RH model, the AD IN input signal sensitivity and phantom power (+48V) on/off setting for each channel are controlled from within the display. However, the rear panel [+48V MASTER] switch is the phantom power master switch.

### Controlling the input sensitivity and phantom power (+48V) of the head amp

You can adjust the input sensitivity and switch phantom power (+48V) on/off for the signals being input from INPUT jacks 1–48 and ST IN jacks 1–4. These operations are performed differently on the PM5D model and PM5D-RH model.

#### Hint

Even if input channels are paired, head amp settings must be made individually.

## PM5D model


For the PM5D model, head amp settings are made using the controls of the AD IN section of the panel (➔ p.35).

- The input sensitivity is adjusted by the combination of the [GAIN] knob setting and [PAN] switch on/off setting for that jack.
- To supply phantom power (+48V) to an INPUT jack 1–48, turn on the [+48V] switch corresponding to that jack.
- To enable an external device that is inserted into the INSERT IN/OUT jacks, turn on the [INSERT] switch corresponding to that jack.


## PM5D-RH model

On the PM5D-RH model, head amp settings are made by operations within the display.

- 1 Repeatedly press the [SYS/W.CLOCK] key of the DISPLAY ACCESS section until the HA screen appears.



- 2 In the screen, click the INTERNAL HA button. The internal head amp settings for INPUT jacks 1–48 and ST IN jacks 1–4 will be displayed.
- 3 Use the buttons and knobs in the screen to edit the head amp settings.



## ① +48V button

Click this button to switch phantom power (+48V) on/off for that jack.

## ② GAIN knob

Drag this knob to adjust the input sensitivity of that jack in a range of +10 dB to –62 dB.

## ③ GANG button

If this button is on, the input sensitivity of two adjacent odd-numbered/even-numbered channels will change in tandem, maintaining the current offset value.


When making these settings, the LEDs of the AD IN section of the panel will indicate the input signal level and the phantom power (+48V) on/off status.

#### Note


- On the PM5D-RH model, head amp settings can also be made from the HA/INSERT function CH 1-24 screen, CH 25-48 screen, or ST IN/FX RTN screen (➔ p.258).
- Settings for an external head amp device (AD8HR) can also be made from the screen in the same way as for the internal head amps.

# INPUT channel strip

The INPUT channel strip is the section where you can control the principal parameters of the input channels. This section is layered as shown in the following diagram; choose the CH 1-24 layer when you want to control input channels 1–24, or the CH 25-48 layer when you want to control input channels 25–48.



## Items in the INPUT channel strip




- ① **[CH 1-24]/[CH 25-48] keys**  
These keys select the layer (CH 1-24 or CH 25-48) controlled by the INPUT channel strip. The LED of the currently selected layer will light.
- ② **[PRE] key**  
This selects the output location of the signal when send level to MIX bus 1–24 is selected as the encoder function. The pre-fader signal is sent to the corresponding MIX bus if this key is on, and the post-fader signal is sent if this key is off.
- ③ **ENCODER [ON] key**  
This switches the function currently assigned to the encoder on/off. By default, this switches the signal sent from the input channel to MIX buses 1–24 on/off.
- ④ **Encoder**  
According to the selection in the ENCODER MODE section / FADER FLIP section (➔ p.40), this encoder adjusts the send level from the input channel to MIX buses 1–24, the panning of the input channel, or the level of the input channel in the layer that is not currently selected. By default, this adjusts the send level to MIX buses 1–24.
- ⑤ **[SEL] key**  
This selects the input channel that you will control from the SELECTED CHANNEL section or from within the display.
- ⑥ **Name indicator**  
This displays the name that has been assigned to the input channel.
- ⑦ **CH [ON] key**  
Switches the input channel on/off. If this key is off (LED dark), no signal will be sent from that input channel to the STEREO bus or MIX buses.
- ⑧ **Fader**  
This 100 mm fader adjusts the input level of the input channel.
- ⑨ **[CUE] key**  
This key lets you cue-monitor the signal of the input channel.

- ⑩ **[TO ST] LED**  
This LED will light when the signal sent from the input channel to the STEREO bus is on.
- ⑪ **[COMP] LED**  
This indicates the operational status of the compressor for the input channel. This will be dark when the gain reduction amount is 0 dB, dimly lit when it is 0–10 dB, and lit when it is greater than 10 dB.
- ⑫ **[GATE] LED**  
This indicates the operational status of the gate for the input channel. This will be dark when the gain reduction amount is 0 dB, dimly lit when it is 0–30 dB (or 0–10 dB when ducking), and lit when greater than this.
- ⑬ **Meter LEDs**  
This is a six-point LED meter that indicates the input level of the input channel. OVER indicates clipping level, and –6 to –60 indicate the level of the signal relative to clipping level (0 dB). The level detection point can be switched.
- ⑭ **DCA assign LEDs**  
The LED of the DCA group to which that input channel is assigned will light.
- ⑮ **MUTE assign LEDs**  
The LED of the mute group to which that input channel is assigned will light.
- ⑯ **[RCL SAFE]/[MUTE SAFE] LEDs**  
The corresponding LED will light when recall safe or mute safe is enabled for the input channel.


# ST IN/FX RTN channel strip

In this section you can control the ST IN channels and FX RTN channels.

This section is layered as shown in the diagram below; choose the ST IN layer when you want to control the ST IN channels, or the FX RTN layer when you want to control the FX RTN channels.



## Items in the ST IN/FX RTN channel strip



- ① **[ST IN 1-4]/[FX RTN 1-4] keys**  
These keys select the layer that will be controlled by the ST IN/FX RTN channel strip. Press the [ST IN 1-4] key to control ST IN channels 1–4, or press the [FX RTN 1-4] key to control FX RTN channels 1–4.


Items ②–⑯ below are the same as in the INPUT channel strip (▶ p.37). However since FX RTN channels do not have a gate or compressor, the [GATE] LED (⑫) and [COMP] LED (⑪) are not used.

- ② **[PRE] key**
- ③ **ENCODER [ON] key**
- ④ **Encoder**
- ⑤ **[SEL] key**
- ⑥ **Name indicator**
- ⑦ **CH [ON] key**
- ⑧ **Fader**
- ⑨ **[CUE] key**
- ⑩ **[TO ST] LED**
- ⑪ **[COMP] LED**
- ⑫ **[GATE] LED**
- ⑬ **Meter LEDs**
- ⑭ **DCA assign LEDs**
- ⑮ **MUTE assign LEDs**
- ⑯ **[RCL SAFE]/[MUTE SAFE] LEDs**

## FADER FLIP/ENCODER MODE section

In the FADER FLIP/ENCODER MODE section you can change the parameter that is assigned to the encoders, and exchange the parameters assigned to the faders and encoders.

### Items in the FADER FLIP/ENCODER MODE section



- ① **FADER [FLIP] key**  
If this key is on, the parameters controlled by the faders and encoders will be exchanged.
- ② **Encoder mode indicator**  
This indicates the number of the MIX bus (1–24) selected by the MIX SEND SELECT keys (⑥) or the encoder function selected by keys ③–⑤.
- ③ **[PAN] key**  
This key selects pan (balance) as the parameter controlled by the encoders. The encoder mode indicator will indicate “Pn” while this key is on.
- ④ **[GAIN/ATT] key**  
This key selects input sensitivity to the internal head amp (PM5D-RH model only) or external head amp device (AD8HR or AD824) or attenuation immediately after AD conversion as the parameter controlled by the encoders. The encoder mode indicator will indicate “HA” (if input sensitivity to the head amp is selected) or “At” (if attenuator is selected) while this key is on.
- ⑤ **[ALT LAYER] key**  
This key selects “input level of the channel not included in the currently selected layer” as the parameter controlled by the encoders. The encoder mode indicator will indicate “AL” while this key is on.
- ⑥ **MIX SEND SELECT [1]–[24] keys**  
These keys select the MIX bus (1–24) whose send level will be controlled by the encoders. When you press one of these keys, the LED of that key will light, and the encoder mode indicator will show the number of the MIX bus.

#### Hint

*If you turn on any key ③–⑥, the remaining keys will automatically turn off.*

# Various operations for input channels

## Selecting the function of the encoders

When the PM5D is in the default state, the encoders of the INPUT channel strip and ST IN/FX RTN channel strip are assigned to control send levels to MIX buses 1–24. However you can use the various ENCODER MODE keys to select one of the following as the function of the encoders.

Key	Encoder function	Display
MIX SEND SELECT [1]–[24] keys	Send levels to MIX buses 1–24	1–24
[PAN] key	Pan (balance)	Pn
[GAIN/ATT] key	Head amp input sensitivity	HA
[GAIN/ATT] key	Attenuator	At
[ALT LAYER] key	Input level for the currently un-selected layer <sup>1</sup>	AL

\*1. In the INPUT channel strip, the CH 1-24 layer and the CH 25-48 layer are in a “front/rear” relation. In the ST IN/FX RTN channel strip, the ST IN 1-4 layer and the FX RTN 1-4 layer are in a “front/rear” relation.

The currently selected function is shown by the key that is lit and by the encoder mode indicator.

Repeatedly pressing the [PAN] key or [ALT LAYER] key will alternate between the function selected by that key and the MIX bus send level. Repeatedly pressing the [GAIN/ATT] key will alternate between the following three choices; input sensitivity to the internal head amp → attenuator → MIX bus send level.

### Hint


*If the FADER section [FLIP] key is on, the functions controlled by the encoders and faders will be exchanged.*

## Exchanging the fader and encoder functions

You can use the FADER [FLIP] key to exchange the functions assigned to the faders and encoders of the channel strip.


For example with the default setting (FADER [FLIP] key off), the faders control the input channel input levels, and the encoders control the send levels to the MIX buses. If you then press the FADER [FLIP] key to make the LED light, the faders will control the send levels to the MIX buses and the encoders will control the input channel input levels.

Control the send level and on/off status of the signal sent from the channel to the MIX buses



Control the channel input level and on/off status

Control the channel input level and on/off status



Control the send level and on/off status of the signal sent from the channel to the MIX buses

The function assigned to the controls when the [FLIP] key is on (LED lit) will depend on the current encoder mode as follows.

[FLIP] key	Encoder mode	Function of each control			
		Encoder	ENCODER [ON] key	Fader	CH [ON] key
Off	MIX SEND	Send level from channel to MIX bus	On/off status of signal sent from channel to MIX bus	Channel (currently selected layer) input level	Channel (currently selected layer) on/off
	PAN	Pan (balance)	On/off status of signal sent from channel to STEREO bus		
	GAIN/ATT	Head amp input sensitivity / attenuator	No function		
	ALT LAYER	Channel (currently un-selected layer) input level	Channel (currently un-selected layer) on/off		
On	MIX SEND	Channel (currently selected layer) input level	Channel (currently selected layer) on/off	Send level from channel (currently selected layer) to MIX bus	On/off status of signal sent from channel (currently selected layer) to MIX bus
	PAN	—	—	—	—
	ALT LAYER	Send level from channel (currently un-selected layer) to MIX bus	On/off status of signal sent from channel (currently un-selected layer) to MIX bus	Send level from channel (currently selected layer) to MIX bus	On/off status of signal sent from channel (currently selected layer) to MIX bus

### Note


- The DCA channel strip and STEREO A/B channel strip are not affected by the on/off status of the [FLIP] key.
- The Flip function cannot be used if PAN or GAIN/ATT is selected as the encoder mode. If you turn on the [FLIP] key in these modes, MIX SEND will automatically be selected as the encoder mode, and then the fader and encoder parameters will be exchanged.

### Sending a signal from an input channel to the STEREO bus

Here's how to use the INPUT channel strip or ST IN/FX RTN channel strip to send an input channel signal to the STEREO bus. The explanation here uses the example of an input channel, but the procedure is essentially identical when using a ST IN channel or FX RTN channel.

- 1** Make sure that an input source is correctly assigned to the input channel, and that the head amp gain is set appropriately.
- 2** Make sure that the appropriate CH [ON] key is turned on in the INPUT channel strip, and press the [SEL] key for that channel to make it light.


The [SEL] keys are used to select the channel you want to control.



- 3** In the SELECTED CHANNEL section, press the [TO STEREO] key to make it light.

In the SELECTED CHANNEL section you can make detailed parameters settings for the channel currently selected by its [SEL] key. (For details on the SELECTED CHANNEL section ➔ p.57.)

When you turn on the [TO STEREO] key, the signal sent from that input channel to the STEREO bus will be turned on. At this time, the [TO ST] LED of the INPUT channel strip will light.



- 4** Raise the corresponding fader of the INPUT channel strip.

The level of the input signal is shown by the level meter located at the right of the CH [ON] key.


- 5** Turn on the [PAN] key in the ENCODER MODE section.

- 6** Use the encoder in the INPUT channel strip to adjust the pan of the input channel.

**Note**

*If you are sending the signal from a ST IN channel / FX RTN channel to the STEREO bus, you can repeatedly press the [SEL] key to switch between L/R channels, and make pan settings for each channel.*

- 7** In the STEREO A/B channel strip, turn the STEREO A [ON] key and STEREO B [ON] key on (LED lit).



- 8** In the STEREO A/B channel strip, raise the [STEREO A]/[STEREO B] faders.

The signal sent to the stereo bus will be routed through the STEREO A/B channels and output from the STEREO OUT A/B jacks.

## Sending the signal from the input channel to a MIX bus

Signals from input channels or ST IN/FX RTN channels can be sent to the desired MIX bus. This can be done either by specifying the send level sent from all input channels to a specific MIX bus, or by specifying the send level sent from a specific input channel to all MIX buses.

The explanation here uses an input channel as the send-source, but the procedure is the same when using a ST IN channel or FX RTN channel.


### To send signals from all input channels to a specific MIX bus

- 1 Use MIX SEND SELECT [1]–[24] keys of the ENCODER MODE section to select the destination MIX bus.

The selected key will light, and the encoder mode indicator will show the number of the destination MIX bus. In this state, the encoders of the channel strip adjust the send level to the MIX bus. Make sure that the FADER [FLIP] key is dark.

- 2 Turn the encoders of the INPUT channel strip. When MIX SEND is selected as the encoder mode, you can use the encoders of the INPUT channel strip to adjust the level of the signal that is sent to the currently selected MIX bus from the corresponding input channel.

The LEDs around the periphery of the encoder indicate the approximate send level.



- 3 To turn off the signal sent from a specific channel to the MIX bus, press the ENCODER [ON] key for that channel to turn it off. Press the same key once again to turn it back on.

#### Note

If the send-destination MIX bus is set to FIXED mode (➔ p.44), the encoders have no effect; the signal can only be switched on/off by the ENCODER [ON] key.


- 4 In the same way, select a different send-destination MIX bus, and use the encoders of the INPUT channel strip to adjust the send levels to it.

### To send signals from a specific input channel to all MIX buses

- 1 Press a [SEL] key of the INPUT channel strip to select the send-source channel.
- 2 In the MIX section, press the [MIX SEND] key to make it light.

The MIX section lets you control the signals sent to MIX buses 1–24 and the signals output from MIX channels 1–24. (For details, refer to ➔ p.49)

When the [MIX SEND] key is lit, you can use the encoders of the MIX section to control the send levels from the currently selected input channel to MIX buses 1–24.





#### Hint

When the [MIX MASTER] key of the MIX section is lit, you can hold down the [SEL] key of an input channel to make the [MIX SEND] key light (the [MIX MASTER] key will go dark). In this state, you can use the encoders of the MIX section to adjust the send levels from the selected channel to MIX buses 1–24.

- 3 Turn the MIX encoders to adjust the send levels to the MIX buses.

The LEDs around the periphery of the encoder indicate the approximate send level.







- 4 To turn off the signal sent from that channel to a MIX bus, press the MIX [ON] key to turn it off.**  
 Press the MIX [ON] key once again to turn it back on.

**Note**  
 MIX buses can be switched (in units of two adjacent odd-numbered/even-numbered MIX buses) between VARI type (send levels are variable) and FIXED type (send levels are fixed). (For details on switching the type ➔ p.274)

- When sending a signal from an input channel to a VARI type MIX bus



- When sending a signal from an input channel to a FIXED type MIX bus




If the send-destination MIX bus is set to FIXED mode, the MIX encoders have no effect; the signal can only be switched on/off by the MIX [ON] key.

## Enabling/disabling pairing

Monaural input channels can be paired to link their principal parameters. There are two types of pairing; you can use only one type.


- **Horizontal pair mode**

This mode pairs adjacent odd-numbered/even-numbered channels (default setting).



- **Vertical pair mode**

This mode pairs channels of different layers that share the same fader.



**Hint**

Input channels that are paired will have their parameters linked except for head amp, delay, pan, attenuation, and phase.

## Using horizontal pairing

Here's how to enable or defeat pairing for adjacent odd-numbered/even-numbered channels.

- 1 To enable pairing, hold down the [SEL] key of one of the adjacent odd-numbered/even-numbered channels, and press the [SEL] key of the other channel.

The parameters of the channel you pressed first will be copied to the subsequently-pressed channel.

**Hint**

The copy-source channel is determined by the order in which you press the [SEL] keys. For example if you hold down the channel 1 [SEL] key and press the channel 2 [SEL] key, the channel 1 parameters will be copied to channel 2.

- 2 To defeat pairing, hold down the [SEL] key of one of the paired channels and press the [SEL] key of the other channel.

**Note**

If you are unable to enable/defeat pairing by using the above procedure, make sure that PAIR SHORTCUT is turned on in the UTILITY function PREFERENCE 1 screen (→ p.187).

## Using vertical pairing

Here's how to enable or disable pairing for channels of different layers that share the same fader.

- 1 Repeatedly press the [SYS/W.CLOCK] key of the DISPLAY ACCESS section until the MIXER SETUP screen appears.



- 2 Click the VERTICAL PAIR button in the PAIR MODE area to turn it on.

A window will appear, asking you to confirm that you want to change the pair mode.

- 3 Click the OK button.

Now you can use “vertical pair” mode.

When you switch to “vertical pair” mode, new numbers will be assigned to the input channels. For details, refer to p.200.

You can return to “horizontal pair mode” by clicking the HORIZONTAL PAIR button to turn it on.


**Hint**

*When you switch between vertical pair mode and horizontal pair mode, the input channel numbers will change, but the channel names and parameter values will not change.*

---

- 4 Hold down the [SHIFT] key of the data entry section, and press the [SEL] key of one of the channels you want to pair.**

A window will appear, allowing you to select how pairing will be handled.



- 5 Click the appropriate button to choose the source/destination for the parameters that will be copied.**

The channels will be paired as you specify.

**Hint**

*If you click the RESET BOTH button, the parameters of both channels will be reset to their default value.*

---

- 6 To defeat pairing, hold down the [SHIFT] key and press the [SEL] key of one of the channels.**

A window will ask you to confirm that you want to defeat pairing. Click the OK button to defeat pairing.

# 6 Output channel operations

This chapter explains the functions and operation of each section related to output channels.


## About the output channels

Output channels mix the signals sent from input channels etc., and send them to the corresponding output jacks or output buses.

There are three types of output channel, as follows.


### MIX channels 1–24

The signals sent from input channels to MIX buses are sent via these channels to MIX OUT jacks 1–24 or the STEREO/MATRIX buses.




### STEREO A/B channels

The signals sent from input channels or MIX channels are sent via these channels to STEREO OUT jacks A/B.



## MATRIX channels 1–8

The signals sent from MIX channels or STEREO A/B channels to MATRIX buses are sent via these channels to the MATRIX OUT jacks.



- **8 BAND EQ (8 band equalizer) (MIX channels and STEREO A/B channels)**

This is an eight-band (four upper bands + four lower bands) parametric EQ.

- **4 BAND EQ (4 band equalizer) (MATRIX channels)**

This is a four-band (HIGH, HIGH MID, LOW MID, LOW) parametric EQ.

- **COMP (Compressor)**

This is a dynamics processor that can be used as a compressor, expander, or limiter.

- **LEVEL**

This adjusts the output level of the channel.

- **ON (On/off)**

This switches the channel on/off. If this is off, that channel will be muted.

- **OUTPUT DELAY**

This delays the output signal. It can be used to make fine adjustments in the relative timing between channels.

- **OUT ATT. (Output attenuator)**

This attenuates or boosts the level of the channel's output signal.

- **METER**

This meter indicates the output level of the output channel. The level detection point can be switched.

- **MIX to STEREO (MIX channels)**

This is an on/off switch for the signal sent from the MIX channel to the STEREO bus.

- **to MATRIX (MIX channels and STEREO A/B channels)**

This is an on/off switch for the signal sent from the MIX channel to the MATRIX bus.

- **PAN (MIX channels)**

This adjusts the panning of the signal sent from the MIX channel to the STEREO bus.

- **BAL (Balance) (STEREO channels)**

This adjusts the L/R volume balance of the STEREO channel.

- **LCR (Left/Center/Right) (MIX channels)**

This sends the three-channel signal (left/right channels and a center channel) to the STEREO bus.

- **INSERT**

Here you can patch the desired output port and input port to insert-out/insert-in, allowing an external effect processor or other device to be inserted. You can switch the insert-out and insert-in locations.


### Hint

MIX channels 1–24, STEREO A/B channels, and MATRIX channels 1–8 are always connected to MIX OUT jacks 1–24, STEREO OUT jacks A/B, and MATRIX OUT jacks 1–8 respectively. However, you can also make output patch settings to send the signals of these output channels to slots 1–4 or the 2TR OUT DIGITAL jacks.

# MIX section

The MIX section adjusts the send level of the signals sent from input channels to MIX buses, and adjusts the output level of the MIX channels.

## Items in the MIX section



- ① **[TO ST] LED**  
This LED will light when the signal sent from the MIX channel to the STEREO bus is on.
- ② **[TO MTRX] LED**  
This LED will light when the signal sent from the MIX channel to the MATRIX bus is on.
- ③ **DCA group LEDs**  
The LED of the DCA group to which this MIX channel is assigned will light.
- ④ **MIX [PAIR] LED**  
This LED will light if adjacent odd-numbered/even-numbered MIX channels are paired.
- ⑤ **MIX [ON] key**  
If the [MIX SEND] key (⑨) is on, this switches the signal sent from the input channel to the MIX bus on/off. If the [MIX MASTER] key (⑩) is on, this switches the MIX channel on/off.
- ⑥ **MIX encoder**  
If the [MIX SEND] key (⑨) is on, this adjusts the send level to the MIX bus. If the [MIX MASTER] key (⑩) is on, this adjusts the output level of the MIX channel.
- ⑦ **MIX [CUE] key**  
This is used to monitor a MIX channel via the Cue Monitor/Solo function.
- ⑧ **MIX [SEL] key**  
This selects the MIX channel to which operations in the SELECTED CHANNEL section or in the display will apply.
- ⑨ **[MIX SEND] key**
- ⑩ **[MIX MASTER] key**  
These keys switch the operation of the MIX section. When the [MIX SEND] key is on, you can use the con-

trols of the MIX section to edit the send level and on/off status of the signal being sent from the currently selected input channel to the MIX buses. Controls other than ④–⑥ will have no effect.


When the [MIX MASTER] key is on, you can use the controls of the MIX section to edit the output level and on/off status of the MIX channels.

## Operations in the MIX section

### ❑ Sending signals from MIX channels to output jacks

Here's how a signal sent from an input channel to a MIX bus can be sent from the corresponding MIX OUT jack.

- 1 **Make sure that an appropriate signal is being sent from an input channel to the MIX bus.**
- 2 **Press the [MIX MASTER] key in the MIX section.**  
When this key is on, you can use the MIX section to control the signals being sent from the MIX channels to the MIX OUT jacks.
- 3 **Turn on the MIX [ON] key for the MIX channel whose signal you want to output.**
- 4 **Turn the MIX encoder to adjust the output level of the corresponding MIX channel.**  
The signal of the corresponding MIX channel will be sent from the corresponding MIX OUT jack.
- 5 **If you want the meters of the panel to indicate the output level of the MIX channels, press the [MIX/MATRIX] key of the meter section.**  
The output level of the MIX channels will be shown by the [INPUT/MIX] meters.



**Hint**

The detection point (metering point) of the signal levels shown in the meters can be changed if desired. For details, refer to p.101.

### □ Sending signals from MIX channels to MATRIX buses

Here's how a signal sent from an input channel to a MIX bus can be output to a MATRIX bus. This can be done either by specifying the send level sent from all MIX channels to a specific MATRIX bus, or by specifying the send level sent from a specific MIX channel to all MATRIX buses.

#### To send signals from all MIX channels to a specific MATRIX bus

- 1 Make sure that appropriate signals are being sent from input channels to the MIX buses.
- 2 Repeatedly press the [MATRIX/ST] key of the DISPLAY ACCESS section to access the MATRIX/ST ROUTING screen shown below.

#### MATRIX/ST ROUTING



MIX TO MATRIX  
ON/OFF buttons

MIX channels

- 3 Use the left/right scroll bar to display the MIX channel that you want to send to the MATRIX bus, and click the MIX TO MATRIX ON/OFF button to turn it on.

The signal of the corresponding MIX channel is now sent to the MATRIX bus.


**Hint**

You can use the PRE FADER/POST FADER buttons in the MIX TO MATRIX area to change the send point (pre-fader/post-fader) of the signal sent from the MIX channel to the MATRIX bus.

- 4 Press the [MIX MASTER] key in the MIX section.
- 5 Press and hold the MATRIX [SEL] key for the send-destination MATRIX bus.  
All MIX [SEL] keys will blink. As long as you hold down the MATRIX [SEL] key, the MIX encoders 1–24 will respectively adjust the send levels from the MIX channels to the currently selected MATRIX bus.

- 6 Continuing to hold down the MATRIX [SEL] key, turn MIX encoders 1–24 to adjust the level of the signal sent from each MIX channel to the currently selected MATRIX bus.

The LEDs around the periphery of the MIX encoder indicate the approximate level. When you take your hand off the MATRIX [SEL] key, the encoders will revert to their previous function.



Use the encoders of the MIX section to adjust the send levels


**Hint**

You can fix the encoders in the above state by rapidly pressing the MATRIX [SEL] key twice. To return to the previous state, press any MIX [SEL] key or MATRIX [SEL] key.

#### To send from a specific MIX channel to all MATRIX buses

- 1 Make settings so that a signal is sent from the desired MIX channel to a MATRIX bus, as described in steps 1–3 of "To send signals from all MIX channels to a specific MATRIX bus."
- 2 Press the [MIX MASTER] key in the MIX section.
- 3 Press and hold the MIX [SEL] key for the send-source MIX channel.  
All MATRIX [SEL] keys will blink. As long as you continue to hold down the MIX [SEL] key, MATRIX encoders 1–8 will adjust the send levels sent from the selected MIX channel to each MATRIX bus.
- 4 Continuing to hold down the MIX [SEL] key, turn MATRIX encoders 1–8 to adjust the level of the signal sent from the currently selected MIX channel to the MATRIX buses.  
The LEDs around the periphery of the MATRIX encoder indicate the approximate send level. When you take your hand off the MIX [SEL] key, the encoders will revert to their previous function.

Use the encoders of the MATRIX section to adjust the send level



#### Hint

You can fix the encoders in the above state by rapidly pressing the MIX [SEL] key twice. To return to the previous state, press any MIX [SEL] key or MATRIX [SEL] key.

- 5 If you want the meters of the panel to indicate the output level of the MIX channels, press the [MIX/MATRIX] key of the meter section.


#### Hint

The send levels from MIX channels to MATRIX buses can also be edited in the display. For details, refer to p.238.

### ❑ Sending signals from MIX channels to the STEREO bus

Here's how signals sent from input channels to MIX buses can be output to the STEREO bus.

- 1 Make sure that appropriate signals are being sent from input channels to the MIX buses.
- 2 Press the [MIX MASTER] key in the MIX section.
- 3 Turn on the MIX [ON] key for the MIX channels whose signals you want to send to the STEREO bus.
- 4 Press the MIX [SEL] key of the channel whose signal you want to send to the STEREO bus, and turn on the [TO STEREO] key of the SELECTED CHANNEL section.



- 5 To adjust the pan of the signal sent from the MIX channel to the STEREO bus, press the MIX [SEL] key of the desired MIX channel and turn the STEREO [PAN] encoder of the SELECTED CHANNEL section.

- 6 Turn the MIX encoder to adjust the signal level that is sent to the STEREO bus.

#### Hint

You can also switch the output to the STEREO bus on/off and adjust the pan from within the MATRIX/ST ROUTING screen (MATRIX/ST function). If desired, the send position (post fader or post ON key) for the signal sent from the MIX channel to the STEREO bus can also be changed in this screen (► p.239).

- 7 In the STEREO A/B channel strip, turn the STEREO A [ON] key and STEREO B [ON] key on (LED lit).

- 8 In the STEREO A/B channel strip, raise the [STEREO A]/[STEREO B] faders.

The signal sent from the MIX channel to the STEREO bus will be sent from STEREO OUT jacks A/B.

The level of the signal output from the STEREO A/B channels is shown by the [MASTER] meters in the meter section.



### ❑ Pairing MIX channels

Adjacent odd-numbered/even-numbered MIX channels can be paired. If two MIX channels are paired, their parameters (with the exception of pan and delay) will be linked.



- 1 Turn on the [MIX MASTER] key in the MIX section.
- 2 Of the desired two adjacent odd-numbered/even-numbered MIX channels, hold down the MIX [SEL] key of one, and press the MIX [SEL] key of the other. The [PAIR] LED will light, and the MIX channels will be paired. At this time, the parameters of the channel whose MIX [SEL] key you pressed first will be copied to the channel whose MIX [SEL] key you pressed later. For example if you pressed the keys in the order of MIX channel 1 → MIX channel 2, the parameters of MIX channel 1 will be copied to MIX channel 2.
- 3 To defeat pairing, hold down the MIX [SEL] key of one of the paired MIX channels and press the MIX [SEL] key of the other channel. When MIX channels are paired, the signal flow will change as follows.

### Signals sent from an input channel to a VARI type MIX bus

- **If the VARI type MIX bus is not paired**  
When the [MIX SEND] key is on, the MIX encoders will adjust the send level of the signals sent to the corresponding MIX bus from the currently selected input channel.




- **If the VARI type MIX bus is paired**  
When the [MIX SEND] key is on, MIX encoders of odd-numbered channels will adjust the pan of the signal sent to the two MIX buses. MIX encoders of even-numbered channels will adjust the shared send level for the two MIX buses.




### MIX channel output signals


- **If MIX channels are not paired**  
When the [MIX MASTER] key is on, the MIX encoders will adjust the output level of the corresponding MIX channels.




#### MIX CHANNEL



- **If MIX channels are paired**  
When the [MIX MASTER] key is on, the MIX encoders of odd-numbered channels will adjust the volume balance between paired MIX channels. The MIX encoders of even-numbered channels will adjust the shared level of the two paired channels.



#### MIX CHANNEL




#### Hint

MIX channel pairing status and output level/balance settings can also be edited in the CH to MIX screen (➔ p.274) or MATRIX/ST screen (➔ p.238).

# STEREO A/B channel strip

The STEREO A/B channel strip lets you send the signal of the STEREO A/B channels to the MATRIX bus, and adjust the output level of the STEREO A/B channels.

## Items in the STEREO A/B channel strip




- ① **[TO MATRIX] LED**  
This LED will light when the signal sent from the STEREO channel to the MATRIX bus is on.
- ② **[COMP] LED**  
This indicates the operating status of the compressor for the STEREO channel. This will be dark when the gain reduction amount is 0 dB, dimly lit when it is 0–10 dB, and lit when it is greater than 10 dB.
- ③ **STEREO A/B [SEL] key**  
This selects the STEREO A or STEREO B L/R channels for editing in the SELECTED CHANNEL section or display. The L/R channels will alternate each time you press the key.
- ④ **STEREO [MONO] key**  
This switches the STEREO B channel to monaural. The status will alternate between monaural and stereo each time you press the key.
- ⑤ **STEREO [ON] key**  
This switches the STEREO channel on/off. If this key is off (LED dark), no signal will be output from that STEREO channel.
- ⑥ **STEREO fader**  
This 100 mm fader adjusts the output level of the STEREO channel.
- ⑦ **STEREO [CUE] key**  
This is used to monitor the STEREO A/B channel via the Cue Monitor/Solo function.

## Operations in the STEREO A/B channel strip

### □ Sending signals from the STEREO A/B channels to output jacks

Here's how the signals sent from input channels or MIX channels to the STEREO bus can be output from STEREO OUT jacks A/B.

- 1 Make sure that appropriate signals are being sent from the desired channels to the STEREO bus.
- 2 Turn on the STEREO [ON] key of the STEREO A/B channel strip.
- 3 Raise the [STEREO A]/[STEREO B] faders. The signal of the STEREO A/B channels will be output from STEREO OUT jacks A/B. The output level of the STEREO A/B channels is shown by the [MASTER] meters in the meter section.



#### Hint

Normally, the same signal is output from the STEREO A and B channels. However you can also use the STEREO B channel as a Center channel for L/C/R three-channel playback (► p.201, 242).

### □ Sending signals from the STEREO A/B channels to MATRIX buses

Here's how the signal of the STEREO A/B channels can be sent to the MATRIX buses.

- 1 Make sure that an appropriate signal is being input to the STEREO bus.
- 2 Repeatedly press the [MATRIX/ST] key of the DISPLAY ACCESS section to access the MATRIX/ST ROUTING screen.

#### MATRIX/ST ROUTING



MIX TO MATRIX ON/OFF buttons

- 3 Use the left/right scroll bar to display the STEREO A/B channels, and click the MIX TO MATRIX ON/OFF button to turn it on. With these settings, the signal of the STEREO A/B channels will be sent to the MATRIX channels.
- 4 Make sure that the STEREO A/B [ON] keys are turned on in the STEREO A/B channel strip; then hold down the STEREO A [SEL] key or STEREO B [SEL] key. While you continue holding down the key, all MATRIX [SEL] keys will blink. In this condition, you can use the MATRIX encoders to adjust the signal levels sent from the STEREO A or B channel to the MATRIX buses.
- 5 While continuing to hold down the STEREO A [SEL] key or STEREO B [SEL] key, turn MATRIX encoders 1–8 to adjust the signal level sent to the MATRIX buses.

The LEDs around the periphery of the MATRIX encoder indicate the approximate send level. When you take your hand off the STEREO A [SEL] key or STEREO B [SEL] key, the MATRIX encoders will revert to their previous function.


#### Hint

- You can also switch to the above state by rapidly pressing the STEREO A [SEL] key or STEREO B [SEL] key twice. To return to the previous state, press any [SEL] key.
- Send levels from the STEREO A/B channels to the MATRIX buses can also be adjusted from within the display (► p.238).

# MATRIX section

In the MATRIX section you can adjust the send levels from MIX channels to MATRIX buses, and adjust the output level of the MATRIX channels.

## Items in the MATRIX section



- ① **DCA group LEDs**  
The LED of the DCA group to which this MATRIX channel is assigned will light.
- ② **MATRIX [PAIR] LED**  
This LED will light if adjacent odd-numbered/even-numbered MATRIX channels are paired.
- ③ **MATRIX [ON] key**  
This switches the MATRIX channel on/off.
- ④ **MATRIX encoder**  
This adjusts the output level of the MATRIX channel.
- ⑤ **MATRIX [CUE] key**  
This is used to monitor a MATRIX channel via the Cue Monitor/Solo function.
- ⑥ **MATRIX [SEL] key**  
This selects the MATRIX channel to which operations in the SELECTED CHANNEL section or in the display will apply.

## Operations in the MATRIX section

### □ Sending signals from the MATRIX section to output jacks

Here's how the signals sent from MIX channels or STEREO A/B channels to MATRIX buses can be sent to the MATRIX OUT jacks.

- 1 **Make sure that appropriate signals are being sent from the MIX channels or STEREO A/B channels to the MATRIX buses.**


- 2 **In the MATRIX section, press the MATRIX [ON] buttons to turn the desired MATRIX channel(s) on.**

- 3 **Turn the encoders of the MATRIX section to adjust the output level of the MATRIX channels.**

The signals sent to the MATRIX bus(es) will be sent from the corresponding MATRIX OUT jack(s).

- 4 **To check the output level of the MATRIX channels, press the [MIX/MATRIX] key in the meter section.**

The [ST IN/MATRIX] meters will show the output levels.



### Hint

The detection point (metering point) of the signal levels shown in the meters can be changed if desired (➔ p.101).

### □ Pairing the MATRIX section

Adjacent odd-numbered/even-numbered MATRIX channels can be paired if desired. If two channels are paired, their parameters (with the exception of pan and delay) will be linked.

- 1 **In the MATRIX section, hold down the MATRIX [SEL] key for one of two adjacent odd-numbered/even-numbered channels, and press the MATRIX [SEL] key of the other channel.**

The [PAIR] LED will light, and the MATRIX channels will be paired. At this time, the parameters of the channel whose MATRIX [SEL] key you pressed first will be copied to the channel whose MATRIX [SEL] key you pressed later.

For example if you pressed the keys in the order of MATRIX channel 1 → MATRIX channel 2, the parameters of MATRIX channel 1 will be copied to MATRIX channel 2.


- 2 **To defeat pairing, hold down the [SEL] key of one of the paired MATRIX channels and press the [SEL] key of the other MATRIX channel.**

When MATRIX channels are paired, the signal flow will change as follows.

### Signals sent from MIX channels and STEREO A/B channels to MATRIX buses


**If MATRIX channels are not paired**

When you are holding down the [SEL] key of a specific MIX channel or STEREO A/B channel in order to adjust the send levels from that channel to all MATRIX buses, the MATRIX encoders will adjust the send level to the corresponding MATRIX bus.



**If MATRIX channels are paired**

When you are holding down the [SEL] key of a specific MIX channel or STEREO A/B channel in order to adjust the send levels from that channel to all MATRIX buses, the MATRIX encoder of the odd-numbered channel will adjust the pan of the signal sent to the two MATRIX buses. The MATRIX encoder of the even-numbered channel will adjust the send level shared by the two MATRIX buses.




**Hint**

For details on how to send the signal of a specific MIX channel to all MATRIX buses, refer to p.50. For details on how to send the signal from either the STEREO A or B channel to all MATRIX buses, refer to p.54.


### Output signals from MATRIX channels

**If MATRIX channels are not paired**

The MATRIX encoders adjust the output level of the corresponding MATRIX channel.




**MATRIX CHANNEL**




**If MATRIX channels are paired**

MIX encoders of odd-numbered channels adjust the volume balance between paired MATRIX channels. MATRIX encoders of even-numbered channels will adjust the shared level of the two paired channels.



**MATRIX CHANNEL**



**Hint**

You can access the MATRIX/ST ROUTING screen (MATRIX/ST function) to see a list of the MATRIX channels in the display, and edit the pairing and other parameters. For details, refer to p.238 of the Reference section.

# 7 Using the Selected Channel section

This chapter explains how you can use the SELECTED CHANNEL section to control input channels and output channels.

## About the SELECTED CHANNEL section


The SELECTED CHANNEL section lets you edit the mix parameters of the currently selected input channel or output channel; it corresponds to a channel module of a conventional analog mixer.

This section controls the channel that was last selected by pressing its [SEL] key. (In the case of an ST IN channel, FX TRN channel, or STEREO A/B channel, you will select either the L or the R channel.) However, you will be able to edit essentially all of the mix parameters (head amp settings, EQ/compressor/gate settings, output to the STEREO bus, DCA group and mute group assignments, etc.) using panel controls.

## Items in the SELECTED CHANNEL section

### GROUP


Here you can assign the currently selected channel to DCA groups and mute groups. (For details on DCA groups and mute groups ➔ p.74, 75)



- ① **DCA [1]–[8] keys**  
These keys assign the selected channel to DCA groups 1–8. The key LED for the assigned DCA group(s) will light.  
Input channels can use DCA groups 1–8, and output channels can use DCA groups 7/8. For DCA groups 7/8, input channels and output channels can both exist in the same-numbered group.
- ② **MUTE [1]–[8] keys**  
These keys assign the selected channel to mute groups 1–8. The key LED for the assigned mute group(s) will light.  
Mute groups 1–8 allow you to mix input channels and output channels.
- ③ **[RECALL SAFE] key**  
This key switches Recall Safe on/off for the selected channel. If this key is on, the parameters of the corresponding channel will not be affected when a scene is recalled. The applicable parameters can be specified in the RECALL SAFE screen (SCENE function) (➔ p.166).
- ④ **[MUTE SAFE] key**  
This key switches Mute Safe on/off for the selected channel. If this key is on, the corresponding channel will be temporarily excluded from mute groups.
- ⑤ **Level meter**  
This indicates the input/output level of the selected channel.

## CHANNEL SELECT

Here you can select or copy channels.



### ① INPUT/OUTPUT indicators

These indicators show whether an input channel or output channel is selected.

### ② Name indicator

This indicates the name of the selected channel.

### ③ Number indicator

This is the number of the selected channel. For stereo channels (ST IN, FX TRN, STEREO A/B), the number and a character of “L” or “r” will appear, depending on whether the L or R channel is selected. If a channel is paired, the decimal point for the lowest place will light. For a FX RTN channel, the LED for the highest place will light.

Channel	Display
ST IN channel	1L./1r. – 4L./4r.
FX RTN channel	1.L./1.r. – 4.L./4.r.
STEREO A channel	AL./Ar.
STEREO B channel	BL./Br.

### ④ [PASTE] key

### ⑤ [COPY] key

These keys are used to copy and paste channel data. When you press the [COPY] key, the data of the currently selected channel will be copied into a memory buffer; when you press the [PASTE] key, the data in the memory buffer will be pasted into the currently selected channel. You can specify the parameters that will be copied in the INPUT VIEW function CH COPY screen (for input channels) or the OUTPUT VIEW function CH COPY screen (for output channels).

### Note

- If the buffer memory contains no data, or if the data in the buffer memory is of a different type than the selected channel, a warning message will appear and the Paste operation cannot be executed.
- The data in the buffer memory is lost when the power is turned off.

### ⑥ CH [DEC] key


### ⑦ CH [INC] key

The CH [DEC] key decrements the currently selected channel number, and the CH [INC] key increments it.

- Input channels 1–48
- ST IN channels 1L/1R–4L/4R
- FX RTN channels 1L/1R–4L/4R
- MIX channels 1–24
- MATRIX channels 1–8
- STEREO A channel L/R
- STEREO B channel L/R

## DELAY

Here you can edit delay-related parameters for the currently selected channel.



### ① DELAY [TIME] indicator

This indicates the currently specified delay time in msec units. However in the case of one second, the indicator will be “1...”.

### ② DELAY [TIME] encoder


This controls the delay time of the selected channel.

### ③ DELAY [ON] key

This key switches delay on/off for the selected channel.

## GAIN/ATTENUATION/Ø (Gain / Attenuation / Phase)

Here you can edit the head amp, post AD conversion attenuator, and phase parameters for the currently selected channel. This section is available only if an input channel is selected.



### ① A[GAIN/ATT] key

This key selects the parameter that is controlled by the [GAIN/ATT] encoder (②).

- **[GAIN/ATT] key lit (Gain)**  
The encoder adjusts the input sensitivity of the internal head amp patched to the input channel (PM5D-RH only) or of an external head amp that supports the dedicated protocol (Yamaha AD8HR, AD824, etc.). The range of adjustment is +10 to -62.
- **[GAIN/ATT] key dark (Attenuator)**  
The encoder controls the post AD conversion attenuator of the input channel. The range of adjustment is -96 to +24.

#### Note


*Gain cannot be selected for channels to which an internal/external head amp is not patched.*

### ② [GAIN/ATT] encoder


According to the setting of the [GAIN/ATT] key (①), this encoder controls either the input sensitivity of the internal/external head amp patched to the input channel, or the attenuator following AD conversion.

The LEDs around the periphery will change as follows.

- **[GAIN/ATT] key lit (Gain)**



- **[GAIN/ATT] key dark (Attenuator)**




### ③ [Ø] key

This switches the phase of the selected input channel. If this key is on, the phase will be reversed.

## NOISE GATE

Here you can edit noise gate parameters for the selected channel. This section is valid only if an input channel or ST IN channel is selected.



### ① GATE GR meter

This meter indicates the amount of reduction produced by the gate of the selected channel.

### ② GATE [ON] key

Switches the gate on/off for the selected channel.

### ③ GATE [ATTACK] indicator

Indicates the attack time of the gate in msec units.

### ④ GATE [ATTACK] encoder

Specifies the attack time of the gate (the time from when the signal exceeds the threshold until the gate opens).

### ⑤ GATE [HOLD] indicator

Indicates the hold time of the gate in msec units or sec units (the indicator for the displayed unit will light).

### ⑥ GATE [HOLD] encoder

Specifies the hold time of the gate (the time from when the signal falls below the threshold until the gate closes).

### ⑦ GATE [DECAY] indicator

Indicates the decay time of the gate in msec units or sec units.

### ⑧ GATE [DECAY] encoder

Specifies the hold time of the gate (the time over which the gate will close after the hold time has elapsed).

### ⑨ GATE [THRESHOLD] encoder


Specifies the threshold level of the gate (the level at which the gate will open or close). The gate will open when the signal exceeds this level, and will close when the signal falls below this level.

### ⑩ GATE [RANGE] encoder

Specifies the amount of attenuation while the gate is closed.

## STEREO

Here you can switch the on/off status of the signal sent from the selected channel to the STEREO bus, and adjust the pan.



### ① STEREO [PAN] encoder

The function of this encoder depends on the currently selected channel, as follows.

Selected channel	Function
Input channel	
ST IN channel	Adjusts the panning of the signal sent from that channel to the STEREO bus.
FX RTN channel	
MIX channel	
STEREO A/B channels	Adjusts the left/right balance of the signal sent from the STEREO A/B channels.
MATRIX channel	No function.


### ② [TO STEREO] key

The function of this key depends on the currently selected channel, as follows.

Selected channel	Function
Input channel	
ST IN channel	Functions as an on/off switch for the signal sent from that channel to the STEREO bus.
FX RTN channel	
MIX channel	
STEREO A/B channels	No function.
MATRIX channel	

## COMPRESSOR

Here you can edit compressor parameters for the selected channel. This section is available only if a channel other than an FX RTN channel is selected.



### ① COMP GR meter

This meter indicates the amount of reduction produced by the compressor of the selected channel.

### ② COMP [ON] key

Switches the compressor on/off for the selected channel.

### ③ COMP [ATTACK] indicator

Indicates the attack time of the compressor in msec units.

### ④ COMP [ATTACK] encoder

Specifies the attack time of the compressor (the time from when the signal exceeds the threshold level until compression begins).

### ⑤ COMP [RELEASE] indicator

Indicates the release time of the compressor in msec units or sec units (the indicator for the displayed unit will light).

### ⑥ COMP [RELEASE] encoder

Specifies the release time of the compressor (the time from when the signal falls below the threshold level until compression is removed).

### ⑦ COMP [RATIO] indicator

Indicates the compression ratio setting.

### ⑧ COMP [RATIO] encoder

Specifies the compression ratio (the ratio at which the input signal will be compressed when the signal exceeds the threshold level).

### ⑨ COMP [THRESHOLD] encoder


Specifies the threshold level of the compressor (the level at which the compressor will operate). The input signal will start being compressed when the signal exceeds this level; compression will be removed when the signal falls below this level.

### ⑩ COMP [GAIN] encoder

Specifies the gain of the signal that has passed through the compressor.

## HPF (High Pass Filter)

Here you can edit high pass filter parameters for the selected channel. This section is available only if an input channel is selected.



### ① HPF [FREQUENCY] encoder

Specifies the cutoff frequency of the high pass filter.

### ② HPF [FREQUENCY] indicator

Indicates the currently specified high pass filter cutoff frequency, in units of Hz.

### ③ HPF [ON] key

Switches the high pass filter on/off.

## EQUALIZER

Here you can edit equalizer parameters for the selected channel. The equalizer structure differs as follows between input channels and output channels.

### ❑ Input channels

You can use a four-band peak/dip type EQ (HIGH, HIGH MID, LOW MID, LOW). The HIGH band can be switched to an LPF or shelving type; the LOW band can be switched to a shelving type.


### ❑ Output channels

If a MIX channel or STEREO A/B is selected, you can use an eight-band peak/dip type EQ. (Operation is divided into UPPER and LOWER groups of four bands each.) For MATRIX channels, you can use a four-band peak/dip type EQ.

For any output channel, the HIGH band can be switched to shelving or LPF. The LOW band can be switched to shelving or LPF. The LOW band can be switched to shelving or LPF. For MIX channels and STEREO A/B channels, this can be specified for UPPER and LOWER, allowing you to apply shelving or filtering twice.

## Hint

- Input channels also provide an HPF that is independent of the four-band EQ.
- Output channels do not have an independent HPF, but instead allow you to switch the LOW band type to HPF.
- Switching the equalizer type to HPF or LPF can be done in the EQ PARAM screen (➔ p.225)



### ① EQ [ON] key

Switches the equalizer on/off for the selected channel.

### ② EQ [UPPER] key

### ③ EQ [LOWER] key

If a MIX channel or STEREO A/B channel is selected, these keys select the four-band group (UPPER or LOWER) that you will edit. (The LED of the currently selected key will light.)

If any other channel is selected, the LEDs of both keys will be dark.

## Hint

By simultaneously holding down the EQ [UPPER] key and EQ [LOWER] key, you can return the EQ GAIN settings of the selected channel to a flat state.

### ④ EQ [-C] key

If this key is on, the corresponding HIGH band EQ type will be switched to shelving. In this case, the HIGH band EQ [Q] knob will have no function.

- ⑤ **EQ [Q] encoder**  
Adjusts the Q (steepness) of each band. This encoder does nothing for bands whose EQ type is set to shelving, LPF, or HPF.
- ⑥ **EQ [FREQUENCY] encoder**  
Adjusts the center frequency (or cutoff frequency) at which each band will be boosted or cut.
- ⑦ **EQ [FREQUENCY] indicator**  
Indicates the center frequency (or cutoff frequency) at which boost/cut will occur, in units of kHz or Hz. (The indicator for the displayed unit will light.)
- ⑧ **EQ [GAIN] encoder**  
Adjusts the amount of cut/boost for each band.
- ⑨ **[D] key**  
If this key is on, the corresponding LOW band EQ will be switched to shelving type. In this case, the LOW band EQ [Q] knob will have no function.

## Operations in the SELECTED CHANNEL section

### Selecting a channel and editing its parameters

The SELECTED CHANNEL section always controls the channel that was last selected by its [SEL] key.

To select an input channel, press a [SEL] key in the INPUT channel strip or ST IN/FX RTN channel strip. (If necessary, switch the layer before pressing a [SEL] key.) To select an output channel, press a [SEL] key in the MIX section, MATRIX section, or STEREO A/B channel strip.


#### 1 Press a [SEL] key to select the channel you want to control.

The number and name of the currently selected channel is shown in the SELECTED CH area at the lower left of the display, and by the name indicator and number indicator in the SELECTED CHANNEL section.

Number of the selected channel



Name of the selected channel



**Name indicator**  
The name of the selected channel

**Number indicator**  
The number of the selected channel

The number shown in the number indicator is as follows. If a channel is paired, the decimal point for the lowest place will light. For a FX RTN channel, the decimal point for the highest place will light.

Selected channel	Number indicator
Input channels 1–48	1–48
ST IN/FX RTN channels 1–4 (L/R)	1L./1r. – 4L./4r.
MIX channels 1–24	1–24
MATRIX channels 1–8	1–8
STEREO A/B channels (L/R)	AL., Ar., BL., Br.

#### Hint

- In the case of stereo channels (ST IN/FX RTN channels, STEREO A/B channels), you can switch between L/R by pressing the same [SEL] key.
- You can also switch the channel by using the CH [DEC] key / CH [INC] key of the SELECTED CHANNEL section.

#### 2 Use the controls of the SELECTED CHANNEL section to edit the parameters of the selected channel.

When you select a channel in step 1, the parameter values of that channel will be shown by the LEDs and indicators of the SELECTED CHANNEL section. These parameters can be edited using the controls of the SELECTED CHANNEL section.

#### Hint

- Gate, compressor, and EQ/HPF operations are explained in the second half of this chapter; refer to the appropriate section for details.
- For details on DCA group and mute group operations, refer to p.74, 75.
- If you operate a parameter that is selected for AUTO DISPLAY in the PREFERENCE 1 screen, the screen associated with that parameter will appear automatically.

#### 3 In the same way, select other channels and edit their parameters.

## Compressor operations

Here's how you can use the SELECTED CHANNEL section to operate the internal compressor.


### Note

The PM5D provides four types of built-in compressor; COMP (compressor), EXPANDER (expander), COMPANDER H (hard compander), and COMPANDER S (soft compander). These four operate in different ways. This means that if you want to use a compressor, you must load compressor settings of the desired type from the compressor library, and then edit the parameters as desired.

### 1 Press a [SEL] key to select the channel you want to control.

A compressor is available for all channels except for FX RTN channels.

### 2 In the DISPLAY ACCESS section, press the INPUT [GATE/COMP] key (for an input channel) or OUTPUT [COMP] key (for an output channel) several times to access the COMP LIBRARY screen.



RECALL button

Scroll bar

In the COMP LIBRARY screen you can store compressor settings in the library, or recall existing data from the library. The operations described below are the same for the COMP LIBRARY screen of both output channels and input channels.

### 3 Move the cursor to the scroll bar of the library list in the lower right of the screen, and turn the [DATA] encoder to select the library item that you want to load. (The library item selected in the list is highlighted.)

Numbers 001–036 for which an “R” is shown at the right of the list contain read-only preset library items. Numbers 001–004 contain preset library items of different types. It is convenient to use these library items when you want to select a specific type. Preset library items 001–004 are respectively of the following types.

Number	Name	Type
001	Comp	COMP (Compressor)
002	Expand	EXPANDER
003	Compander (H)	COMPANDER H (Hard compander)
004	Compander (S)	COMPANDER S (Soft compander)

### Hint


- The type of the currently selected compressor is shown in the COMP PARAM screen (➔ p.229, 266).
- The COMP LIBRARY screen also provides other library settings suitable for a wide variety of instruments or purposes. Settings you edit can also be stored in the library.
- For a detailed explanation of each type of compressor, refer to the Appendices (➔ p.295).

### 4 After selecting a library item, click the RECALL button located at the lower left of the library list.

The library item you selected in step 3 will be recalled to the channel you selected in step 1.

### 5 In the SELECTED CHANNEL section, press the COMP [ON] key to make the LED light.

The compressor of the selected channel will be activated.



COMP GR meter

COMP [ON] key

### 6 You can use the compressor controls of the SELECTED CHANNEL section to edit the compressor parameters.

The amount of gain reduction produced by the compressor is shown by the COMP GR meter in the SELECTED CHANNEL section.

### Hint

- For details on the function of the compressor controls, refer to p.60.
- More detailed parameters for the compressor (selection of the key-in signal, stereo link on/off, assignment to a compressor link group) can be edited in the COMP PARAM screen of the INPUT GATE/COMP function or the OUTPUT COMP function (➔ p.229, 266).
- You can also cause the COMP PARAM screen to appear automatically when you operate a compressor-related control. This setting is made in the UTILITY function PREFERENCE 1 screen (➔ p.186).

## Gate operations

Here's how you can use the SELECTED CHANNEL section to operate the internal gate.


### Note

The PM5D provides two types of built-in gating; GATE and DUCKING. These operate in different ways. This means that if you want to use a gate, you must load gate settings of the desired type from the gate library, and then edit the parameters as desired.

**1 Press a [SEL] key to select the channel you want to control.**

Gate is available only for input channels or ST IN channels.

**2 In the DISPLAY ACCESS section, press the INPUT [GATE/COMP] key several times to access the GATE LIBRARY screen.**



In the GATE LIBRARY screen you can store gate settings in the library, or recall existing data from the library.

**3 Move the cursor to the scroll bar of the library list in the lower right of the screen, and turn the [DATA] encoder to select the library item that you want to load. (The library item selected in the list is highlighted.)**

Numbers 001–036 for which an “R” is shown at the right of the list contain read-only preset library items. Numbers 001–002 contain preset library items of different types. It is convenient to use these library items when you want to select a specific type. These numbers correspond to the different types as follows.

Number	Name	Type
001	Gate	GATE
002	Ducking	DUCKING

### Hint

- The type of the currently selected gate is shown in the GATE PARAM screen (➔ p.264).
- The GATE LIBRARY screen also provides other library settings suitable for a wide variety of instruments or purposes. You can also save your own settings in the library.
- For a detailed explanation of each type of gate, refer to the Appendices (➔ p.294).

**4 After selecting a library item, click the RECALL button located at the lower left of the library list.**


The library item you selected in step 3 will be recalled to the channel you selected in step 1.

**5 In the SELECTED CHANNEL section, press the GATE [ON] key to make the LED light.**

The gate of the selected channel will be activated.

**6 You can use the gate controls of the SELECTED CHANNEL section to edit the gate parameters.**

The amount of gain reduction produced by the gate is shown by the GATE GR meter in the SELECTED CHANNEL section.



### Hint

- For details on the function of the gate controls, refer to p.59.
- More detailed parameters for the gate (selection of key-in signal, stereo link on/off) can be edited in the INPUT GATE/COMP function GATE PARAM screen (➔ p.264).
- You can also cause the GATE PARAM screen to appear automatically when you operate a gate control. This setting is made in the UTILITY function PREFERENCE 1 screen (➔ p.186).

## EQ/HPF operations

Here's how you can use the SELECTED CHANNEL section to edit the EQ (equalizer) and HPF (High Pass Filter). EQ can be used on all input channels and all output channels. An HPF that is independent of the EQ is provided only for input channels. However even on output channels, you can switch the LOW band type to HPF.


### 1 Press a [SEL] key to select the channel you want to control.

Four-band EQ (HIGH, HIGH MID, LOW MID, LOW) is provided on all input channels and on MATRIX channels.


Eight-band EQ is provided on MIX channels and STEREO A/B channels. (Control is divided into UPPER and LOWER sections of four bands each.)

### 2 In the SELECTED CHANNEL section, make sure that the EQ [ON] key is on.

If you selected a MIX channel or STEREO A/B channel in step 1, use the SELECTED CHANNEL section EQ [UPPER] key or EQ [LOWER] key to select the UPPER or LOWER group of four bands.



### 3 For each band, use the EQ [Q] encoder, EQ [FREQUENCY] encoder, and [GAIN] encoder to edit the steepness, center frequency, and gain respectively.



### Hint

If the input signal of an input channel clips because of EQ boost, make the SELECTED CHANNEL section [GAIN/ATT] key go dark and use the [GAIN/ATT] encoder to lower the level.


### 4 If you want to restore the EQ of the currently operated channel to a flat state, simultaneously hold down the EQ [UPPER] and EQ [LOWER] keys of the SELECTED CHANNEL section.

When you hold down these two keys simultaneously, the boost/cut amount of all bands will be reset to 0 dB.

### 5 If you want to use the HIGH band or LOW band as a shelving-type EQ, turn on the [-C] key or [D] key for the corresponding band.

### 6 If you want to use HPF on an input channel, turn on the HPF [ON] key in the SELECTED CHANNEL section.

Input channels provide an HPF that is independent of the four-band EQ. Use the HPF [ON] key to switch the HPF on/off, and use the HPF [FREQUENCY] encoder to specify the cutoff frequency.



### Hint

- Output channels do not provide an HPF that is independent of the EQ, but you can switch the LOW band type to HPF, or the HIGH band type to LPF. This change is made in the OUTPUT EQ function EQ PARAM screen (➔ p.225).
- For input channels you can switch the HIGH band type to LPF. This change is made in the INPUT EQ function EQ PARAM screen (➔ p.260).

### Hint

- You can cause the associated screen to appear automatically when you operate equalizer or HPF parameters in the SELECTED CHANNEL section. This setting is made in the UTILITY function PREFERENCE 1 screen (➔ p.186).
- In the same way as for compressor or noise gate settings, EQ settings can also be stored to or recalled from a dedicated EQ library. Preset library items suitable for a variety of instruments or situations are also provided.

# 8 Input Patch / Output Patch operations

This chapter explains how to edit the input patch and output patch settings, and how to use insert connections and direct output.

## Changing the input patch settings


The input patch section lets you assign input ports to input channels. In the PM5D's default state, the input patch settings assign the following signals to input channels.

<b>Input channels 1–48</b>	Input signals from INPUT jacks 1–48
<b>ST IN channels 1–4</b>	Input signals from ST IN jacks 1–4 (L/R)
<b>FX RTN channels 1–4</b>	Output signals of internal effects 1–4 (L/R)

However, you will need to edit the input patch settings if you want input signals from an I/O card installed in slots 1–4 or input signals from a 2TR IN DIGITAL jack to be assigned to an input channel. Here's how to do this.

- 1 In the DISPLAY ACCESS section, press the INPUT [PATCH] key several times to access the INPUT PATCH screen.

### INPUT PATCH



The INPUT PATCH screen is where you can patch (assign) input ports (rear panel input jacks or input channels of I/O cards) to input channels.


The horizontal direction of the screen shows the input ports (i.e., patch sources), and the vertical direction of the screen shows the input channels (i.e., patch destinations).

If an input port is patched to an input channel, a  symbol is displayed at the intersecting grid.

- 2 Use the left/right scroll bar to display the patch-source input port.

The horizontal direction of the screen shows the patch source's input port type, ID number, port number, and the number of input channels that are assigned to it. To view input ports that are not currently visible, use the horizontal scroll bar or the [DATA] encoder.

From the top, this shows the input port type and ID number, the port number, and the number of input channels currently assigned.



To patch an input port to an input channel, click this grid to display a  symbol.

Indicates the number of input ports assigned to the input channel.

Indicates the name of the input channel.

Indicates the number of the input channel.

You can select the following input ports.

<b>AD IN 1–48</b>	INPUT jacks 1–48
<b>AD ST IN 1–4</b>	ST IN jacks 1–4 (L/R)
<b>SLOT IN 1–4</b>	Input channels (1–16) of slots 1–4
<b>FX OUT 1–8</b>	Outputs (L/R) of internal effects 1–8
<b>2TR IN D1–D3</b>	2TR IN DIGITAL jacks 1–3 (L/R)
<b>2TR IN A1/A2</b>	2TR IN ANALOG jacks 1/2

- 3 Use the vertical scroll bar to display the patch-destination input channel.


The vertical direction of the screen shows the patch-destination input channels. To see channels that are not currently visible, use the vertical scroll bar. Alternatively, you can hold down the [SHIFT] key and turn the [DATA] encoder.

The following input channels can be selected.

<b>CH 1–48</b>	Input channels 1–48
<b>STIN1L/1R–STIN4L/4R</b>	ST IN channels 1–4 (L/R)
<b>FXRTN1L/1R–FXRTN4L/4R</b>	FX RTN channels 1–4 (L/R)

**4 Click the grid where the desired patch-source and patch-destination intersect.**

The vertical and horizontal red lines indicate the grid position where the cursor is located. The SELECTED PATCH area in the upper left of the screen shows the input port and input channel for the grid at which the cursor is located.



When you click a grid, a window will ask you to confirm that you want to change the patch setting.

**5 Click the OK button in the window.**

The new patch will be finalized, and a “●” symbol will appear at the corresponding grid.

To cancel the patch, click the “●” symbol once again.

**Hint**

- If you want to change the patch directly without having to respond to the confirmation window, go to the UTILITY function PREFERENCE 1 screen and turn PATCH CONFIRMATION off (➔ p.186).
- To move the cursor location rapidly in or out of the grid, hold down the [SHIFT] key and press the CURSOR [◀]/[▶]/[▲]/[▼] keys.

**Note**

You can patch a single input port to multiple input channels, but you cannot patch multiple input ports to a single input channel.

## Changing the output patch settings

In the output patch section you can assign output channels to output ports. The PM5D’s output channels are always connected to the following output jacks.

<b>MIX channels 1–24</b>	MIX OUT jacks 1–24
<b>STEREO A/B channels</b>	STEREO OUT jacks A/B
<b>MATRIX channels 1–8</b>	MATRIX OUT jacks 1–8
<b>Monitor output L/C/R</b>	MONITOR OUT jacks L/R/C

However you can edit the output patch settings so that the signals of these output channels are also sent from other output ports in parallel. Here’s how to do this.

**1 In the DISPLAY ACCESS section, press the OUTPUT [PATCH] key several times to access the OUTPUT PATCH screen.**

**OUTPUT PATCH**




In the OUTPUT PATCH screen you can patch (assign) output channels to output ports. The horizontal direction of the screen shows the output ports (i.e., patch destinations), and the vertical direction of the screen shows the output channels (i.e., patch sources).

When the PM5D is in its default state, MIX channels 1–24, MATRIX channels 1–8, and the STEREO A channel are patched to the output channels of slots 1–4 and the 2TR OUT DIGITAL jacks in addition to the output jacks that are always connected. However, you are free to change this patching.

**2 Use the horizontal scroll bar to display the patch-destination output port.**

The horizontal direction of the screen shows the patch destination’s output port type, ID number, port number, and the number of output channels that are assigned to it.

From the top, this area shows the output port type, ID number, port number, and number of assigned output channels.



To patch an output port to an output channel, click this grid to display a “●” symbol.

Indicates the number of output ports assigned to the output channel.

Indicates the output channel number.

You can select the following output ports.

<b>SLOT OUT 1–4</b>	Output channels (1–16) of an I/O card installed in slots 1–4
<b>FX IN 1–8</b>	Inputs (L/R) of internal effects 1–8
<b>2TR OUT D1/D2</b>	2TR OUT DIGITAL jacks 1–2 (L/R)

**3 Use the vertical scroll bar to display the patch-source output channel.**


The vertical direction of the screen shows the patch-source output channels.

The following output channels can be selected.

<b>MIX 1–24</b>	MIX channels 1–24
<b>MATRIX 1–8</b>	MATRIX channels 1–8
<b>ST AL/AR</b>	STEREO A channel (L/R)
<b>ST BL/BR</b>	STEREO B channel (L/R)
<b>MONITOR L/R/C</b>	Monitor output (L/C/R)
<b>TALKBACK OUT</b>	Talkback output
<b>OSC OUT</b>	Oscillator output

#### 4 Click the grid where the desired patch-source and patch-destination intersect.

The SELECTED PATCH area in the upper left of the screen shows the output port and output channel for the grid at which the cursor is located.



When you click a grid, a window will ask you to confirm that you want to change the patch setting.

#### Hint

*If you want to change the patch directly without having to respond to the confirmation window, go to the UTILITY function PREFERENCE 1 screen and turn PATCH CONFIRMATION off (➔ p. 186).*

#### 5 Click the OK button in the window.

The new patch will be finalized, and a "●" symbol will appear at the corresponding grid. To cancel the patch, click the "●" symbol once again.

#### Note

*You can patch an output channel to more than one output port, but you cannot patch multiple output channels to a single output port.*

# Inserting an external device into a channel


You can insert an effect processor or other external device into the signal route of an input channel or output channel. When doing so, you can specify for each channel the input/output port and insert I/O point that you want to use for insertion.

## Connecting an external device for insertion


When inserting an external device into a desired channel, you can use the rear panel input/output jacks or the input/output jacks of an I/O card installed in a slot as insert-out/insert-in jacks.

The following diagrams show typical examples of insert connections.


Insert connection example ①



Insert connection example ②



Insert connection example ③



If you are inserting an external digital device via a digital I/O card as shown in “Insert connection example ③,” you will need to synchronize the word clock of the PM5D and the external device. Normally, we recommend that you set the external device as a word clock slave, and make it follow the PM5D’s word clock. (For details on how to set your device as a word clock slave, refer to its manual.)

### Hint


For the PM5D model, you can also use the rear panel INSERT IN/OUT jacks to insert an external device into an input signal, as an alternative to the method described above. In this case, the insert I/O point is fixed at immediately before AD conversion. Also, the steps described p.70 will not be necessary.

### Patching the insert-out and insert-in

Here we will explain how to make insert connections, using an example in which an external device connected to an AD/DA card in a slot is inserted into an input channel. However, the procedure is the same when inserting into an output channel, the only difference being that you will be working in a screen for output channels.

- 1 In the DISPLAY ACCESS section, press the INPUT [PATCH] key several times to access the INSERT PATCH screen (INPUT PATCH function) shown below.

In the left side of this screen you can select an output port to use as insert-out, and in the right side of the screen you can select an input port to use as insert-in.



If you want to insert into an output channel, press the OUTPUT [PATCH] key several times to access the OUTPUT PATCH function INSERT PATCH screen.

- 2 In the left side of the screen, click the grid at which the output port connected to your external device intersects the desired channel. The procedure is the same as in the INPUT PATCH screen or OUTPUT PATCH screen. You can select the following output ports.

<b>SLOT OUT 1-4</b>	Output channels of an I/O card installed in slots 1-4
<b>FX IN 1-8</b>	L/R inputs of internal effects 1-8
<b>GEQ IN 1-12</b>	Inputs of GEQ modules 1-12
<b>2TR OUT 1-3</b>	2TR OUT DIGITAL jacks 1-3 (L/R)


**Hint**

If you select GEQ IN at the left side of the screen, the identically-numbered GEQ OUT will be automatically selected at the right side of the screen, inserting the correspondingly-numbered GEQ module into that channel. (For details on using the graphic EQ see p. 110)

- 3 In the right side of the screen, click the grid at which the input port connected to your external device intersects the desired channel. You can select the following input ports.

<b>AD IN 1-48</b>	INPUT jacks 1-48
<b>AD ST IN 1-4</b>	ST IN jacks 1-4 (L/R)
<b>SLOT IN 1-4</b>	Input channels of an I/O card installed in slots 1-4
<b>FX OUT 1-8</b>	Outputs (L/R) of internal effects 1-8
<b>GEQ OUT 1-12</b>	Outputs of GEQ modules 1-12
<b>2TR IN D1-D3</b>	2TR IN DIGITAL jacks 1-3 (L/R)
<b>2TR IN A1/A2</b>	2TR IN ANALOG jacks 1/2 (L/R)

The SELECTED PATCH area shows the channel corresponding to the grid at which the cursor is located. To the right of this are shown the input/output ports patched to insert-out/insert-in for this channel.



**Hint**


To move the cursor rapidly between the grids in the left and right sides of the screen, you can hold down the [SHIFT] key and press the CURSOR [←]/[→] keys.

**Note**

With the steps you have taken so far, the external device has been patched to the insert-out/insert-in of the selected channel. However, please note that the insert connection is not actually enabled until you turn on the INSERT I/O ON/OFF button in the INSERT/DIRECT OUT screen as described below. As an exception to this, the INSERT I/O ON/OFF button is automatically turned on if you patch a GEQ.

- 4 Press the INPUT [PATCH] key several times to access the INSERT/DIRECT OUT POINT screen (INPUT PATCH function) shown below. In the INSERT/DIRECT OUT POINT screen (INPUT PATCH function) you can switch insert on/off for each input channel. In this screen you can also select the insert I/O point (the location at which the external device will be inserted).

### INSERT/DIRECT OUT POINT



If you want to insert into an output channel, press the OUTPUT [PATCH] key several times to access the OUTPUT PATCH function INSERT PATCH screen.

- 5 Select one of the following as the insert I/O point for each channel, and turn on the corresponding button.

<b>PRE EQ</b>	Immediately before the EQ
<b>POST EQ</b>	Immediately after the EQ
<b>PRE DELAY</b>	Immediately before the delay
<b>POST FADER</b>	Immediately after the fader

The selected point is indicated by the graphic in the upper part of the screen.

The INS symbol indicates the insert I/O point for the channel at which the cursor is located.



Select the insert I/O point for each channel.

These are the INSERT I/O ON/OFF buttons that switch insert on/off for each channel.

These indicate the names of the input channels.

These indicate the channel numbers.

- 6 Click the INSERT I/O ON/OFF button for the desired channel to turn it on.

This enables the insert connection for the corresponding channel.


If you selected AD IN as the insert-in, or if you selected a slot to which an external head amp supporting the special protocol (Yamaha AD8HR, AD824) is connected, make head amp settings as necessary (➔ p.36).

# Directly outputting the signal of an input channel

Here's how the signal being input to an input channel or ST IN channel can be output directly from the desired output jack.

- 1 In the DISPLAY ACCESS section, press the INPUT [PATCH] key several times to access the DIRECT OUT PATCH screen (INPUT PATCH function) shown below.

**DIRECT OUT PATCH**



In this screen you can select the output port that will directly output the input signal of an input channel or ST IN channel. You can select the following output ports.

<b>SLOT OUT 1-4</b>	Output channels of an I/O card installed in slots 1-4
<b>2TR OUT D1-D3</b>	2TR OUT DIGITAL jacks 1-3 (L/R)

- 2 Click the grid at which the desired channel and output port intersect.

The procedure is the same as in the INPUT PATCH screen or OUTPUT PATCH screen. The SELECTED PATCH area at the upper left of the screen shows the channel and output port corresponding to the grid at which the cursor is located.

**Note**

With the procedure up to this point, the selected channel and output port are now patched. However, please note that direct output is not actually enabled until you turn on the DIRECT OUT ON/OFF button in the INSERT/DIRECT OUT screen described below.

- 3 Press the INPUT [PATCH] key several times to access the INSERT/DIRECT OUT POINT screen (INPUT PATCH function) shown below.

In the INSERT/DIRECT OUT POINT screen (INPUT PATCH function) you can switch direct output on/off, and select the direct out point (the location from which the signal is taken for direct output).

**INSERT/DIRECT OUT POINT**



- 4 Choose the direct out point for each channel from the following choices, and turn on the appropriate button.

<b>PRE HPF</b>	Immediately before the HPF
<b>PRE EQ</b>	Immediately before the EQ (immediately after the PRE EQ of the INSERT I/O)
<b>PRE FADER</b>	Immediately before the fader
<b>POST ON</b>	Immediately after the [ON] key

The selected point is indicated by the graphic in the upper part of the screen.

The "D" symbol indicates the direct out point for the channel at which the cursor is located



Switch direct out on/off for each channel.

Select the direct out point for each channel.

These indicate the name of the input channels.

These indicate the number of the input channels.

- 5 Click the DIRECT OUT ON/OFF button for the desired channel to turn it on.

This enables direct output for the corresponding channel.

This chapter explains DCA Groups and Mute Groups which let you control the level or muting of multiple channels simultaneously, and EQ Link and Compressor Link which let you link EQ or compressor parameters of multiple channels.

## About DCA Groups and Mute Groups

You can use eight DCA groups and eight mute groups to control multiple channels simultaneously.

DCA groups allow the level of multiple channels to be controlled together by the DCA faders 1–8 of the top panel DCA strip. A single DCA fader will control the level of channels belonging to the same DCA group while maintaining the level difference between the channels. This provides a convenient way in which drum mics can be grouped.


DCA groups 1–6 are for input channels only, but DCA groups 7/8 can be used with both input channels and output channels. Both types of channel can exist in an identically-numbered group.

Mute groups allow multiple channels to be switched on/off simultaneously by the SCENE MEMORY [1]–[8] keys in the SCENE MEMORY section of the top panel. You can use this to cut out multiple channels simultaneously.

Mute groups 1–8 can be used with both input channels and output channels. Both types of channel can exist in an identically-numbered group.

## Items in the ASSIGN MODE section

The ASSIGN MODE section lets you use the panel to assign channels to DCA groups or mute groups.



### ① ASSIGN MODE [DCA] key


This key lets you assign channels to DCA groups 1–8. While this key is blinking, you can use the [CUE] key of each channel to assign that channel to the currently selected DCA group.

### ② ASSIGN MODE [MUTE] key

This key lets you assign channels to mute groups 1–8. While this key is blinking, you can use the [CUE] key of each channel to assign that channel to the currently selected mute group.

## Items in the DCA strip

The DCA strip is where you control DCA groups 1–8.



### ① Name indicator

This indicates the name assigned to each DCA group.

### ② DCA [MUTE] key

This switches DCA group muting on/off. If you turn this key on (LED lit), channels assigned to that DCA group will be muted.

### ③ DCA [NOMINAL] LED

This LED will light when the corresponding DCA fader is at the 0 dB position.

### ④ DCA fader

This fader adjusts the level of the DCA group.

### ⑤ DCA [RCL SAFE] LED

If Recall Safe is enabled for a DCA group, the corresponding LED will light.

⑥ **DCA [CUE] key**

This key is used to cue-monitor all channels assigned to that DCA group.

## Using DCA Groups


Here we explain how to assign channels to DCA groups and use the DCA faders to control them.

### Assigning channels to DCA groups

From the panel, you can assign channels to DCA groups either by selecting a specific channel and specifying the DCA group to which it will belong, or by selecting a specific DCA group and specifying the channels that will belong to that DCA group.

❑ **To select the DCA groups to which a specific channel will belong**

- 1 Press a [SEL] key to select the channel for which you want to make assignments.
- 2 In the **SELECTED CHANNEL** section, press a **DCA [1]–[8]** key to select the DCA group to which the channel will be assigned (you may select more than one DCA group).  
The LEDs will light for DCA [1]–[8] key(s) that are turned on. If an input channel is selected, its corresponding DCA assign LED(s) in the channel strip will also light.



3 **Select the DCA group(s) for other channels in the same way.**

❑ **To select the channels that will belong to a specific DCA group**

- 1 In the **ASSIGN MODE** section, press the **ASSIGN MODE [DCA]** key.  
The **ASSIGN MODE [DCA]** key will blink. The [DCA] key of the **FADER MODE** section will also blink. While this key is blinking, you can use the [CUE] key of each channel to assign that channel to a DCA group.
- 2 Press a **DCA [CUE]** key in the **DCA strip** to select the DCA group (1–8) to which you want to assign channels.
- 3 Press the [CUE] key of input channels / output channels (you may select more than one) to assign them to the selected DCA group.  
If a DCA group 1–6 is selected, you can select only input channels. If a DCA group 7/8 is selected, you can select input channels and output channels. If an input channel is selected, its corresponding DCA assign LED(s) in the channel strip will also light.
- 4 Assign channels to other DCA groups in the same way.
- 5 When you have finished making assignments, press the **ASSIGN MODE** section **ASSIGN MODE [DCA]** key to make its LED go dark. The **FADER MODE** section [DCA] key will also stop blinking, and return to its previous state.

**Hint**


- You can also assign channels to DCA groups from within the display. Input channel DCA assignments are made in the **INPUT DCA/GROUP** function **DCA GROUP ASSIGN** screen (➔ p.271), and output channel DCA assignments are made in the **OUTPUT DCA/GROUP** function **DCA GROUP ASSIGN** screen (➔ p.265).
- DCA group settings are saved as part of the scene.

## Controlling DCA groups

Here's how you can use the DCA strip to control DCA groups.

- 1 In the FADER MODE section, make sure that the FADER MODE [DCA] key LED is lit.

The FADER MODE section selects the function of the DCA strip faders. When the FADER MODE [DCA] key LED is lit, you can use the faders of the DCA strip to control DCA groups 1–8.



- 2 Use the faders of the channel strip to adjust the relative levels between the channels belonging to the DCA group you want to use.
- 3 Operate the DCA fader for the DCA group you want to use.  
The level of the channels assigned to that DCA fader will change while preserving the level differences you established in step 2.
- 4 If you want to mute a DCA group, press the [MUTE] key for that DCA group in the DCA strip.

The [MUTE] key will light, and muting will be turned on for channels belonging to that DCA group (the same state as if the faders were lowered to  $-\infty$  dB). At this time, the name indicator for that DCA group will be dimmed.

### Hint

If desired, you can cause the DCA assign LEDs of the corresponding input channels to blink while the DCA group is muted. To do so, turn on the DCA/MUTE FLASH INDICATE setting in the PREFERENCE 1 screen (UTILITY screen).

- 5 To un-mute a DCA group, press the lit [MUTE] key in the DCA strip.

## Using mute groups

This section explains how to assign channels to mute groups and use the panel keys to control them.


### Assigning channels to mute groups

From the panel, you can assign channels to mute groups either by selecting a specific channel and specifying the mute groups to which that channel will belong, or by selecting a specific mute group and specifying the channels that will belong to that mute group.


- To select the mute groups to which a specific channel will belong

- 1 Press a [SEL] key to select the channel for which you want to make assignments.
- 2 In the SELECTED CHANNEL section, use the MUTE [1]–[8] keys to select the mute group to which the channel will be assigned (you may select more than one mute group).

The LEDs will light for MUTE [1]–[8] key(s) that are turned on. If an input channel is selected, its corresponding mute assign LED(s) in the channel strip will also light.



MUTE [1]–[8] keys



Mute assign LEDs

- 3 Select the mute group(s) for other channels in the same way.

## ❑ To select the channels that will belong to a specific mute group

### 1 In the ASSIGN MODE section, press the ASSIGN MODE [MUTE] key.

The ASSIGN MODE [MUTE] key will blink. In the SCENE MEMORY section, the MUTE MASTER LED will also blink. While this key is blinking, you can use the [CUE] key of each channel to assign that channel to a mute group.

### 2 In the SCENE MEMORY section, use the SCENE MEMORY [1]–[8] keys to select the mute group (1–8) for which you want to make assignments.

While the ASSIGN MODE [MUTE] key is blinking, you can use the SCENE MEMORY [1]–[8] keys to select the mute group for which you will make assignments. Press one of these keys; the LED of that key will blink.

### 3 Press the [CUE] key of input channels / output channels (you may select more than one) to assign them to the selected mute group.

The [CUE] key will light, and that channel will be assigned to the selected mute group.

Both input channels and output channels can be assigned to mute groups 1–8.

### 4 Assign channels to other mute groups in the same way.

### 5 When you have finished making assignments, press the ASSIGN MODE section ASSIGN MODE [MUTE] key to make its LED go dark.

The SCENE MEMORY section MUTE MASTER/DIRECT RECALL LED will also return to its previous state.

#### Hint

- You can also assign channels to mute groups from within the display. Input channel assignments are made in the INPUT DCA/GROUP function MUTE GROUP ASSIGN screen (➔ p.272), and output channel assignments are made in the OUTPUT DCA/GROUP function MUTE GROUP ASSIGN screen (➔ p.235).
- Mute group assignments are saved as part of the scene.

## Controlling mute groups

Here's how you can use the SCENE MEMORY [1]–[8] keys of the SCENE MEMORY section to switch muting on/off for mute groups 1–8.

### 1 Turn on the MUTE MASTER button located in the lower right of the display.

The DIRECT RECALL button and MUTE MASTER button located in the lower right of the display select the function of the SCENE MEMORY [1]–[8] keys.

#### • When the DIRECT RECALL button is on

The SCENE MEMORY [1]–[8] keys will directly recall the scene that is assigned to each key.

#### • When the MUTE MASTER button is on

The SCENE MEMORY [1]–[8] keys will switch muting on/off for mute groups 1–8.



### 2 Press the SCENE MEMORY [1]–[8] key for the mute group you want to mute.

The key LED will light, and all channels belonging to the selected mute group will be muted (the same state as when the [ON] key is turned off). You can turn on more than one key to mute multiple mute groups.

### 3 To un-mute a mute group, press a lit SCENE MEMORY [1]–[8] key.

#### Hint

- The mute group mute on/off status is saved in the scene. However, you can also use the Recall Safe function to exclude the mute group status from scene recall.
- If desired, you can cause the MUTE assign LEDs of the corresponding input channels to blink while the mute group is muted. To do so, turn on the DCA/MUTE FLASH INDICATE setting in the PREFERENCE 1 screen (UTILITY screen).

## Using the Mute Safe function

If necessary, channels belonging to a mute group can be temporarily excluded from mute group operations (Mute Safe).

### 1 Press a [SEL] key to select the channel you want to exclude from mute groups.

### 2 In the SELECTED CHANNEL section, press the [MUTE SAFE] key to make the LED light.

Mute Safe will be enabled for the corresponding channel. (In the case of an input channel, the [MUTE SAFE] LED in the channel strip will light.) In this state, muting an applicable mute group will not affect that channel.

### 3 To defeat Mute Safe, press the SELECTED CHANNEL section [MUTE SAFE] key once again to make the LED go dark.

#### Hint


Mute Safe settings are not saved in the scene. They will remain effective until you manually defeat them.

# Using EQ Link and Compressor Link

EQ Link and Compressor Link are functions that respectively link the EQ parameters or compressor parameters of multiple channels. Editing the EQ or compressor parameters of any channel belonging to a link group will similarly edit the other channels in that link group.


- In the DISPLAY ACCESS section, press the INPUT [DCA/GROUP] key (for an input channel) or OUTPUT [GROUP] key (for an output channel) to access one of the following screens.
  - INPUT DCA/GROUP function EQ LINK ASSIGN screen  
Assign EQ link groups (1–8) for input channels

EQ LINK ASSIGN



- INPUT DCA/GROUP function COMP LINK ASSIGN screen  
Assign compressor link groups (1–8) for input channels

COMP LINK ASSIGN




- OUTPUT DCA/GROUP function EQ LINK ASSIGN screen  
Assign EQ link groups (A–F) for output channels

EQ LINK ASSIGN



- OUTPUT DCA/GROUP function COMP LINK ASSIGN screen  
Assign compressor link groups (A–F) for output channels

COMP LINK ASSIGN



In each screen, the channels (assignment source) are listed horizontally, and the link group number or alphabetical character (assignment destination) are listed vertically.

### Hint

The EQ link groups and compressor link groups are independent for input channels and output channels.

**2 Click the grid at which the desired channel (assignment source) intersects the desired link group (assignment destination).**


A “●” symbol will appear at the corresponding grid. To cancel the assignment, click the “●” symbol once again.

In the case of output channel EQ link groups, MIX channels and STEREO A/B channels can be assigned only to groups A–F, and MATRIX channels can be assigned only to groups G/H. (Unavailable grids are grayed-out.)

If another channel is already assigned to the assignment-destination group, the EQ and compressor parameters of the previously-assigned channel will be copied to the channel that is added later, causing the settings to be the same.

**3 If you want to use the [CUE] key of each channel to assign it to a link group, click the SET BY CUE button for the corresponding link group in the screen to turn it on.**

While the SET BY CUE button is on, you can use the channel [CUE] keys to set or cancel link group assignments.



**Note**

- The SET BY CUE button can be turned on for only one link group.
- When you switch to a different screen, the SET BY CUE button that was turned on will automatically be defeated.

**4 When you have finished making link group assignments, operate the EQ or compressor parameters of a channel belonging to a link group.**

The EQ or compressor parameters of channels belonging to the same link group will follow your editing.

**Hint**

Link group settings are saved as part of the scene.

**Note**

The STEREO LINK button and KEY IN SOURCE settings are not linked even for channels belonging to the same compressor link group.

# 10 Scene memory

This chapter explains how to store and recall the PM5D's mix parameters as “scenes.”

## About scenes

The PM5D can store and recall the current state of its mix parameters as a “scene.” Scenes are assigned a scene number of 000–500. Scene 000 is read-only, and cannot be overwritten. Other scene numbers may be rewritten freely.


A scene contains the settings of the panel controls (except for the TALKBACK section, CUE/MONITOR section, and the AD IN section of the PM5D model) as well as the settings of the functions and screens listed below.

- INPUT function settings
- OUTPUT function settings
- EFFECT PARAM screen settings
- GEQ PARAM screen settings
- SELECTIVE RECALL screen (SCENE function) settings
- FADE TIME screen (SCENE function) settings
- MIXER SETUP screen (SYS/W.CLOCK function) settings
- HA screen (SYS/W.CLOCK function) settings

However, input patch, output patch, and HA (head amp) settings are saved in the corresponding library, and the scene contains only a library number that links to these saved settings.

For example if the input patch, output patch, and HA (head amp) settings have been edited when you store a scene, the changes will be stored in the corresponding library, and the library number of these stored library items will be stored in the scene.

### • Storing a scene




### Hint

You can choose how the changes will be stored in the library; they can either be stored in a new unused library number, or overwritten onto the existing library number (➔ p.81).

When you recall a scene, the input patch, output patch, and HA (head amp) library numbers linked to that scene will be recalled simultaneously.

### • Recalling a scene




For each scene, you can specify whether to enable linking to these libraries (➔ p.159). For example if you turn off linking to the HA library for a certain scene, recalling that scene will not update the HA settings.

### Note

By “head amp settings” we mean settings for the internal head amps of the PM5D-RH model and for an external head amp device that supports the special protocol (e.g., Yamaha AD8HR or AD824). The settings of the AD IN section of the PM5D model are not included.


## Items in the SCENE MEMORY section

The SCENE MEMORY section lets you store and recall mix parameters as scene memories. Mute operations for mute groups 1–8 are also performed in this section.



### ① SCENE MEMORY [1]–[8] keys

The function of these keys will depend on the selection of the DIRECT RECALL button and MUTE MASTER button in the lower right of the display.



- When the **DIRECT RECALL** button is on SCENE MEMORY [1]–[8] keys operate as Direct Recall keys that directly recall the eight scenes assigned to these keys.
  - When the **MUTE MASTER** button is on SCENE MEMORY [1]–[8] keys operate as Mute Master keys that switch muting on/off for mute groups 1–8.
- ② **[DIRECT RECALL]/[MUTE MASTER] indicators**  
These indicators indicate the currently selected function of the SCENE MEMORY [1]–[8] keys (①).

### ③ SCENE MEMORY [PREVIEW] key

This key selects either NORMAL mode or PREVIEW mode as the operation when you recall a scene. PREVIEW mode is selected if this key LED is lit; NORMAL mode is selected if it is dark. Operation will differ as follows according to the selected mode.

#### • NORMAL mode

This mode lets you store and recall scenes as usual. When you recall a scene in this mode, the current scene will be overwritten by the settings of the newly recalled scene.

#### • PREVIEW mode

This mode lets you preview the settings of a scene stored in memory without affecting the signal processing of the current scene. When you recall a scene in this mode, the mix parameter values of that scene will be shown in the PM5D's panel, but the internal signal processing will remain as it was before the recall.

When you operate the panel keys or encoders at this time, the panel display will change but internal signal processing will not be affected. If desired, you can save the edited content in the desired scene number or library number.

### ④ Scene number indicator

This indicator shows the number (000–500) of the scene that is selected for store or recall.

### ⑤ SCENE MEMORY [UNDO] key

This key cancels the most recently-executed scene recall operation. If you have accidentally recalled an unwanted scene, you can press this key to return to the state prior to recalling the scene.

### ⑥ SCENE MEMORY [RECALL] key

This key recalls the scene whose number is shown in the scene number indicator (④).

### ⑦ SCENE MEMORY [▲]/[▼] keys

These keys increment or decrement the number displayed in the scene number indicator (④). However if the SCENE screen BLANK SKIP button is turned on, you will only be able to select numbers in which a scene is actually stored.

### ⑧ SCENE MEMORY [STORE] key

This key stores the current scene into the number shown by the scene number indicator (④).

# Using scene memories

## Storing a scene

Here's how to store the current mix settings (the current scene) into a scene memory.


### Note

Before you continue with the following procedure, make sure that the SCENE MEMORY section SCENE MEMORY [PREVIEW] key is off (dark). (If it is on, turn it off.)

- 1 Use the PM5D's panel controls to set the mix parameters as desired.
- 2 Use the SCENE MEMORY [▲]/[▼] keys to select the store-destination scene number.

When you select a new scene number, the scene number and name shown at the top of the display and the scene number shown in the scene number indicator of the SCENE MEMORY section will blink. This blinking indicates that the settings of the indicated scene differ from the currently-set mix parameters.


Scene number and name will blink



Scene number will blink

- 3 Press the SCENE MEMORY [STORE] key. The SCENE STORE window will appear, allowing you to assign a title to the scene and store it. This window shows the following information.

As the default choice in which edited library settings will be stored when you store a scene, choose either NEW (select an unused library) or OVERWRITE (select the original library).



SCENE TITLE area, where you can rename the scene.

An "EDIT" indicator appears here if the library settings have been modified from the state in which they were last stored.

- 4 Use the SCENE TITLE area to assign a name to the scene. (For details on how to input text → p.26)
- 5 As desired, specify the library numbers in which the input patch, output patch, and HA settings will be stored.

To specify a store-destination library number, scroll the input patch, output patch, or HA library list, and click the desired number. (The number currently selected as the store-destination is highlighted.) The library number you select here is saved as part of the scene.

The default selection of store-destination will depend on the setting in the DEFAULT EDIT LIBRARY NO. area.

- **If the NEW button is on**  
The lowest of the unused library numbers will be selected.
- **If the OVERWRITE button is on**  
The number from which the library was originally recalled will be selected. (If this was a read-only library item, the lowest-numbered unused library number will be selected.)

- 6 Click the STORE button in the window. A message will ask you to confirm the store operation.

- 7 Click the OK button. The current settings will be stored to the scene number you selected in step 2, and the upper part of the screen and the scene number indicators will stop blinking. If any changes have been made to the input patch, output patch, and HA settings used by this scene, they will be stored in the corresponding library number.

## Recalling a scene

Here's how to recall a stored scene from memory.

### Note

Before you continue with the following procedure, make sure that the SCENE MEMORY section SCENE MEMORY [PREVIEW] key is off (dark). (If it is on, turn it off.)

- 1 Use the SCENE MEMORY [▲]/[▼] keys to select the scene number that you want to recall.

When you select a new scene number, the scene number and name shown at the top of the display and the scene number shown in the scene number indicator of the SCENE MEMORY section will blink.

- 2 Press the SCENE MEMORY [RECALL] key.

A message in the display will ask you to confirm the recall operation. When you click the OK button, the scene number you selected in step 1 will be recalled.

If input patch, output patch, and HA libraries are linked to that scene, the correspondingly numbered libraries will also be recalled.

### Hint

If desired, you can disable the link between the scene and these libraries, so that specific libraries will not be updated when you recall that scene.

## Using PREVIEW mode

Preview mode lets you check or edit the settings of a scene stored in memory without affecting the signal processing of the current scene. When you recall a scene in this mode, the settings of the newly recalled scene will appear on the PM5D's panel, but the internal signal processing will remain as it was prior to the recall.

During an actual performance, it can be convenient to use this to check the content of the scene you intend to recall next, or to make minor changes to a scene and then store it.

- 1 In the SCENE MEMORY section, turn on the SCENE MEMORY [PREVIEW] key.

The key LED will light, and the SCENE MEMORY section will operate in PREVIEW mode. At this time, the scene indicator at the top of the display will turn red, and the "PREVIEW" indicator will appear.



While in PREVIEW mode, operating the knobs, encoders, and other controls (except for the TALK-BACK section, CUE/MONITOR section, and the AD IN section of the PM5D model) will not affect the audio signal processing.

- 2 Use the SCENE MEMORY [▲]/[▼] keys to select the scene number that you want to recall.

The scene number will light in the scene number indicator.

- 3 Press the SCENE MEMORY [RECALL] key.

Only the setting values of the scene you selected in step 2 will be loaded and shown in the PM5D's panel LEDs and display. However, the internal signal processing of the system will remain unchanged as it was prior to the Recall operation.

If desired, you can access a specific channel in the SELECTED CHANNEL section, or access a specific screen in the display to examine the values in detail.

- 4 If desired, use the controls of the console to edit the settings.

Operating a panel control in PREVIEW mode will edit the settings of the scene you recalled in step 3, but will not affect the PM5D's internal signal processing.

- 5 If you want to store the changes you made in step 4, select the scene number in which you want to store the scene, and press the SCENE MEMORY [STORE] key.

The settings you edited in step 4 will be stored into memory.

- 6 To return the SCENE MEMORY section to NORMAL mode operation, press the SCENE MEMORY [PREVIEW] key to make the key LED go dark.

### Note


- PREVIEW mode applies to all parameters included in scene memory, all parameters included in the INPUT PATCH and OUTPUT PATCH functions, and HA parameters. PREVIEW mode does not apply to parameters other than these.
- Even while you are in PREVIEW mode, recall operations in the EVENT LIST screen or via MIDI messages will apply to the current scene. While in PREVIEW mode, operations of parameters that can be edited in the USER DEFINED screen will generally apply to PREVIEW mode, not to the current scene.

# Using the Auto Store function

With the PM5D's default settings, pressing the SCENE MEMORY [STORE] key will open the SCENE STORE window where you can name the scene and store it. If you enable the Auto Store function, you can execute the Store operation simply by pressing the SCENE MEMORY [STORE] key twice. Here's the procedure.

- 1 In the DISPLAY ACCESS section, press the [UTILITY] key several times to access the PREFERENCE 1 screen shown below.

The PREFERENCE 1 screen is where you can make various default settings for the PM5D.



- 2 In the STORE/RECALL area at the upper left of the screen, turn on the AUTO STORE button. The Auto Store function is now enabled. When you press the SCENE MEMORY [STORE] key once, the SCENE STORE window will appear as usual; press the key once again to execute the Store operation. If you rapidly press the key twice, the Store operation will be executed before the SCENE STORE window appears.


### Note

Note that if the STORE CONFIRMATION button is turned on in the STORE/RECALL area of this PREFERENCE 1 screen, a window will ask you to confirm the Store operation even if Auto Store is enabled. If you don't want any windows to appear, turn off the STORE CONFIRMATION button as well.

# Using the Direct Recall function

If you assign frequently-used scenes to the SCENE MEMORY [1]–[8] keys of the SCENE MEMORY section, you will be able to recall these scenes with a single keystroke.


- 1 In the DISPLAY ACCESS section, press the [SCENE] key several times to access the SCENE screen shown below.



In the SCENE screen you can use the DIRECT RECALL ASSIGN list shown in the lower middle of the screen to assign scene numbers to the SCENE MEMORY [1]–[8] keys.

- 2 Use the DIRECT RECALL ASSIGN list to assign a scene number to a SCENE MEMORY [1]–[8] key.

Move the cursor to the left-hand field of the DIRECT RECALL ASSIGN list and turn the [DATA] encoder or click the [←] / [→] buttons to select a scene number; the scene name will appear in the field at right.



- 3 Assign scene numbers to other keys in the same way.
- 4 In the KEY MODE area at the right side (or lower right) of the screen, make sure that the DIRECT RECALL button is turned on. (If it is off, click the DIRECT RECALL button.)

When the DIRECT RECALL button is on, the SCENE MEMORY section [DIRECT RECALL] LED will light, and the SCENE MEMORY [1]–[8] keys will operate as Direct Recall keys.

- In the SCENE MEMORY section of the console, press one of the SCENE MEMORY [1]–[8] keys. The LED of the corresponding key will light, and the scene assigned to that key will be recalled.

## Using the Selective Recall function


“Selective Recall” is a function that lets you restrict the parameters or channels that will be updated when you recall a specific scene, or, conversely, specify for each scene parameters or channels that will be excluded from recall operations.

### Hint

As a function similar to Selective Recall, there is also a “Recall Safe” function that lets you select channels and parameters to be excluded from recall operations (→ p.86). However it differs from Selective Recall in that Recall Safe settings apply to all scenes.


- In the DISPLAY ACCESS section, press the [SCENE] key several times to access the SELECTIVE RECALL screen shown below.

SELECTIVE RECALL      SELECTION MODE area




- In the SELECTION MODE area in the upper middle of the screen, choose one of the following two selection modes to specify how the SELECTIVE RECALL screen will operate.
  - SAFE PARAMETER mode**  
Specify channels/parameters that will be excluded from Recall operations.
  - RECALL PARAMETER mode**  
Specify channels/parameters that will be affected by Recall operations.  
When you click a button to change the mode, a confirmation window will appear. Immediately after you switch modes, all channels/parameters will be subject to recall.
- Use the buttons in the screen to select the parameters/channels that will be subject to recall (or excluded from recall).  
The SELECTIVE RECALL screen is divided into three areas. From the left, these areas let you make settings for input channels, output channels, and other parameters. The buttons in the screen correspond to parameters and channels as follows.

### □ Input channels / Output channels



- SAFE ON/OFF RECALL ON/OFF**  
The functions and names of these buttons will depend on the currently-chosen SELECTION MODE.
  - SAFE PARAMETER mode**  
The buttons will function as SAFE ON/OFF buttons to select the channels that will be excluded from Recall.
  - RECALL PARAMETER mode**  
The buttons will function as RECALL ON/OFF buttons to select the channels that will be subject to Recall.
- Parameter matrix grid**  
Here you can select the parameters that will be excluded from (or subject to) Recall. If the ALL button is on, all parameters will be excluded from (or subject to) Recall.
- SET ALL**  
Turns on all buttons for all input channels/output channels or for the corresponding parameter.
- CLEAR ALL**  
Turns off all buttons for all input channels/output channels or for the corresponding parameter.

## ❑ Other parameters



### ① DCA/GEQ/EFFECT

These buttons specify whether DCA groups, GEQ modules, and internal effects will be excluded from (or subject to) Recall.

### ② MUTE MASTER

This button specifies whether the Mute Master key on/off status will be excluded from (or subject to) Recall.

### ③ MIDI REMOTE

These buttons specify whether MIDI remote layers A–D will be excluded from (or subject to) Recall.

### ④ SET ALL

This button turns on all buttons for parameters ①–③.

### ⑤ CLEAR ALL

This button turns off all buttons for parameters ①–③.

## 4 In the upper left of the screen, switch the SELECTIVE RECALL ENABLE/DISABLE button to ENABLE.

When this button is set to ENABLE, the Selective Recall function will apply to subsequently-stored scenes.

## 5 Store the current scene.

The settings of the SELECTIVE RECALL screen will be saved as part of the scene. When you recall this scene, only the selected channels/parameters will be excluded from (or subject to) Recall.


### Note

- If you edit the settings of the SELECTIVE RECALL screen, you must store that scene in order to make your changes effective.
- Recall Safe and Selective Recall can be used together. Channels/parameters excluded from recall operations by either Recall Safe or Selective Recall (or both) will not be recalled.

## Using the Recall Safe function

“Recall Safe” is a function that excludes only specific parameters/channels from Recall operations. This differs from the Selective Recall settings (➔ p.84) made for individual scenes in that Recall Safe settings are common to all scenes.

- 1 In the DISPLAY ACCESS section, press the [SCENE] key several times to access the RECALL SAFE screen shown below.



- 2 Use the buttons in the screen to select the parameters/channels that will be excluded from Recall operations.

The function of the buttons in the screen and the procedures are the same as in the SELECTIVE RECALL screen (when SAFE PARAMETER mode is selected), except for the fact that HA (Head Amp) SAFE ON/OFF button is added as a parameter in the INPUT SAFE PARAMETER area.


The [RCL SAFE] indicator of the channel strip will light for input channels, STEREO A/B channels, and DCA groups for which Recall Safe is turned on.

### Hint

- In the RECALL SAFE screen, clicking the parameter matrix grid will display a “G” symbol with a “G” character in the center. This “G” indicates that the setting is global, and applies to all scenes.
- If desired, you can copy and paste Selective Recall settings from the currently selected scene into the RECALL SAFE screen (➔ p.166).
- If you scroll the scroll bar downward, you will see that the CH column of the SAFE PARAMETERS area shows not only input channels but also input ports. If you set the HA of a certain input port to Recall Safe, the HA of the corresponding channel will also be set to Recall Safe. Even if they are assigned to multiple channels, the HA Recall Safe settings for corresponding input ports/channels will be linked.

- 3 If you want to use the panel to switch Recall Safe on/off for a channel, use the [SEL] key to select a channel and then press the SELECTED CHANNEL section [RECALL SAFE] key to make the key LED light.

Recall Safe will be turned on for the corresponding channel.



### Note

By default, ALL is selected as the parameters that will be excluded from recall. This means that if you turn on Recall Safe from the panel, the Recall Safe setting will affect all parameters of the channel(s) for which it is turned on.

After you have finished making Recall Safe settings and you recall a scene, only the selected channels/parameters will be excluded from the Recall operation.

### Note


Recall Safe and Selective Recall can be used together. Channels/parameters excluded from recall operations by either Recall Safe or Selective Recall (or both) will not be recalled.

# Using the Fade function

“Fade” is a function that smoothly changes fader and pan to their new values over a specified duration when you recall a scene. The settings of the Fade function are made independently for each scene.

- 1** In the DISPLAY ACCESS section, press the [SCENE] key several times to access the FADE TIME screen shown below.

In this screen you can select the channels that will use the Fade function, and specify the fade time and start offset time.



- 2** In the upper left of the screen, click the FADING ENABLE/DISABLE button to select ENABLE.  
When the FADING ENABLE/DISABLE button is set to ENABLE, the Fade function will be enabled for the faders in the current scene.
- 3** In the upper right of the screen, make sure that the FADE TIME button is on.  
The FADE TIME/START OFFSET buttons in the upper right of the screen select the parameter that will be edited in the lower part of the FADE TIME screen. When this button is on, you can specify the fade time (the time over which fader and pan parameters will reach their new value) for each channel.
- 4** In the rows of buttons at the bottom of the screen, click to turn on the buttons of the channels for which you want to enable the Fade function.  
By clicking the SET ALL buttons located at the right of the screen, you can turn on the buttons of all input channels and all DCA groups, or the buttons of all output channels.  
By clicking the CLEAR ALL buttons located at the right of the screen, you can turn off the buttons of all input channels and all DCA groups, or the buttons of all output channels.
- 5** Move the cursor to the box located immediately below each button, and turn the [DATA] encoder to specify the fade time for that channel. (Alternatively, click the [ ] / [ ] buttons at the left and right of the box.)



Fade time

## Hint

If the numerical value is displayed in light blue when you perform the above actions, this indicates that an offset time has been specified for the corresponding channel.

- 6** In the same way, specify the fade time for other channels as well.  
If desired, you can easily copy the fade time setting of a channel to another channel (→ p.167).
- 7** In the upper right of the screen, click the START OFFSET button to turn it on.  
When the START OFFSET button is on, you can specify an offset time for each channel (the time from when the scene is recalled until the fader or pan parameter begins to change).
- 8** As you did in steps 4–6, specify an offset time for each channel.
- 9** If you want to enable the Fade function not only for faders but also for the PAN (BALANCE) parameters of input channels, set the INPUT CH PANNING ENABLE/DISABLE button (located in the upper middle of the screen) to ENABLE.



The FADING ENABLE/DISABLE button and INPUT CH PANNING ENABLE/DISABLE button can be set independently. Use the following two buttons to select the input channels to which this will apply.

- When the ALL INPUT button is on**  
The Fade function will apply to the pan (balance) parameter of all input channels.
  - When the SAME AS FADING button is on**  
The Fade function will apply to the pan (balance) parameters of only the input channels selected in step 4.
- 10** When you have finished making settings, store the scene.  
The settings in the FADE TIME screen are saved independently for each scene. The Fade function will apply when you recall a scene for which this button is set to ENABLE. After recall, the fader and pan (balance) parameter values will begin changing when the specified Start Offset Time has elapsed, and will reach their new values over the specified Fade Time.

10


Scene memory

## Using the Tracking Recall function

“Tracking Recall” is a function that adds a specified offset value to each fader or level value when a scene is recalled. Tracking Recall settings are common to all scenes. For example if the original level of a certain sound source has changed, or if an actor was replaced by an understudy, this function provides a convenient way to adjust the level of that specific channel for all scenes.

- 1 In the DISPLAY ACCESS section, press the [SCENE] key several times to access the TRACKING RECALL screen shown below.

In this screen you can select the channels that will use the Tracking Recall function, and specify the offset value for each channel.




- 2 In the upper left of the screen, click the TRACKING RECALL ENABLE/DISABLE button to make it indicate ENABLE.


When the TRACKING RECALL ENABLE/DISABLE button is set to ENABLE, the Tracking Recall function will be enabled for all scenes.

- 3 Using the buttons of the DISPLAY SELECT area in the upper middle of the screen, select the type of channels for which you want to make settings.

- If the INPUT button is on  
The screen will show the faders of input channels 1–48, ST IN channels 1–4, FX RTN channels 1–4, DCA groups 1–8, and STEREO A/B channels.



- If the OUTPUT button is on  
The screen will show the faders of MIX channels 1–24, MATRIX channels 1–8, DCA groups 7/8, and STEREO A/B channels.




- 4 In the row of buttons above the faders in the screen, click to turn on the buttons of the channels for which you want to enable the Tracking Recall function.

Clicking the SET ALL button located in the upper right of the screen will turn on the buttons of all channels and DCA groups.

Clicking the CLEAR ALL button located in the upper right of the screen will turn off the buttons of all channels and DCA groups.

- 5 To set the offset value for each channel, drag the fader upward or downward for a channel whose button you have turned on.

When you turn on the setting for a channel in step 4, the offset value is set to 0. The offset value can be adjusted in a range of –15 dB to +15 dB. The current value is shown in the box immediately below the fader.



- 6 In the same way, specify the offset value for other channels as well.

- 7 When you have finished making settings, turn on the OFFSET LOCK button located in the upper right of the screen.

When this button is on, the offset values currently specified for the channels will be fixed; this prevents the offset values from being unintentionally changed.

When you recall a new scene in this state, the offset values will be added to the level of each channel when the scene is loaded. (However, the upper and lower level limits will not be exceeded.)

### Note


Channels that are excluded from Recall operations by the Recall Safe or Selective Recall functions will not change even if Tracking Recall is turned on.

# Using the Global Paste function

“Global Paste” is a function that lets you copy and paste settings of the desired channel or parameter from the current scene to scene data in memory (multiple selections are allowed). This is a convenient way in which changes to the current scene can be applied to scenes that have already been stored.

- 1 In the **DISPLAY ACCESS** section, press the **[SCENE]** key several times to access the **GLOBAL PASTE** screen shown below.

In this screen you can select the copy-source channels/parameters and specify the paste-destination scene data.




- 2 Use the buttons in the **PASTE MODE** area to select one of the following as the type of item you want to paste.

<b>INPUT</b>	Input channel parameters
<b>OUTPUT</b>	Output channel parameters
<b>DCA, GEQ, EFFECT</b>	DCA level or mute on/off status, GEQ settings, internal effect settings


- 3 In the **CURRENT SCENE** area, select the copy-source channels or parameters.

The contents shown in the **CURRENT SCENE** area will depend on what you select in the **PASTE MODE** area (1).


- When **PASTE MODE = INPUT**  
Select input channels in the left area, and select parameters in the right area. (For details on the parameters → p.170).



- When **PASTE MODE = OUTPUT**  
Select output channels in the left area, and select parameters in the right area. (For details on the parameters → p.170).



- **When PASTE MODE = DCA, GEQ, EFFECT**  
Select DCA groups, GEQ modules, and internal effects.



**Hint**

In either of these modes, you can click the SET ALL button to turn on all channels, or click the CLEAR ALL button to turn off all channels.

**4 In the DESTINATION SCENE area, select the paste-destination scene(s).**

To select a single scene, click the desired line in the upper half of the list.

To select multiple consecutive scenes, use the upper half of the list to click the scene number at which you want to begin pasting, and use the lower half of the list to click the scene number at which you want to stop pasting.

The order in which the scenes are listed can be changed by clicking one of the buttons at the top of the list; the  button (sort by number), SCENE TITLE button (sort by scene title), or TIME STAMP button (sort by the date on which the scene was saved).

DESTINATION SCENE		
	SCENE TITLE	TIME STAMP
000	Initial Data	R 04/20/2000 08:23:29
001	Openins	04/20/2000 08:23:29
002	ACT1	04/20/2000 07:56:13
003	ACT2	04/20/2000 08:06:05
004	ACT3	04/20/2000 07:57:48
005	Finale	04/20/2000 07:58:02
000	Initial Data	R 04/20/2000 08:23:29
001	Openins	04/20/2000 08:23:29
002	ACT1	04/20/2000 07:56:13
003	ACT2	04/20/2000 08:06:05
004	ACT3	04/20/2000 07:57:48
005	Finale	04/20/2000 07:58:02
006		
007		
008		

**5 Click the PASTE button.**

The selected items of the current scene will be pasted to the scene(s) in memory.

**Note**

- If the parameter settings differ between the copy-source and paste-destination, exception handling may be applied when the data is pasted (→ p.171).
- Only the parameters selected by PASTE MODE will be pasted. Note that even if you selected parameters in the CURRENT SCENE area, they will be excluded from the paste operation if you switch the PASTE MODE.

# 11 Monitor and Cue

This chapter explains the PM5D's Monitor and Cue functions.

## About the MONITOR and CUE sections


The MONITOR section sends the signal selected as the monitor source to the MONITOR OUT jacks. You can select the following signals as the monitor source.

- The input signal from 2TR IN ANALOG jacks 1/2
- The input signal from 2TR IN DIGITAL jacks 1–3
- The output signal of the STEREO A/B channels
- The output signal of the LCR channels
- The output signal of a pre-selected MIX channel 1–24 or MATRIX channel 1–8

The CUE section sends the cue signal of the channel/group selected by a panel [CUE] key to the CUE OUT jacks.

### Hint


If the CUE INTERRUPTION button is turned on in the MONITOR screen (MON/CUE function), the Cue/Solo signal will also be sent from the MONITOR OUT jacks when Cue/Solo is active.



- **MONITOR SELECT**  
Selects the monitor source.
- **MONITOR DELAY**  
Delays the monitor signal.
- **CUE OUT DELAY**  
Delays the cue signal.
- **METER**  
Switches the signal that is shown in the meter section or in the display.
- **DIM (Dimmer)**  
Attenuates the monitor/cue signal by a fixed amount.
- **OUT ATT. (Output attenuator)**  
Attenuates/boosts the monitor/cue signal.
- **ON (On/off)**  
Switches the monitor signal on/off.
- **PHONES LEVEL**  
Adjusts the output level of the top panel and front panel PHONES jacks.
- **MONITOR LEVEL**  
Adjusts the monitor level.
- **CUE OUT LEVEL**  
Adjusts the output level of the cue signal.

## Using the Monitor function

### Items in the MONITOR section



- ① **[2TR IN A1] key**
- ② **[2TR IN A2] key**  
These keys select the input signals of 2TR IN ANALOG jacks 1/2 as the monitor source.
- ③ **[2TR IN D1] key**
- ④ **[2TR IN D2] key**
- ⑤ **[2TR IN D3] key**  
These keys select the input signals of 2TR IN DIGITAL jacks 1–3 as the monitor source.
- ⑥ **[STEREO A] key**
- ⑦ **[STEREO B] key**  
These keys select the output signals of STEREO A/B channels as the monitor source. By simultaneously pressing the [STEREO A] key and [STEREO B] key you can select the LCR channels as the monitor source.
- ⑧ **[DEFINE] key**  
This key selects the output signal of the pre-selected MIX channel 1–24 or MATRIX channel 1–8 as the monitor source. This monitor source selected by this key can be specified in the MONITOR screen (MON/CUE function).

#### Hint

The currently selected source is shown by the lit/dark state of keys ①–⑧.

- ⑨ **MONITOR [LEVEL] knob**  
This knob adjusts the output level of the signal being output from the MONITOR OUT L/R/C jacks.
- ⑩ **MONITOR [ON] key**  
This key turns the monitor output on/off.
- ⑪ **MONITOR [PHONES] knob**  
This analog volume adjusts the output level of the PHONES jacks.
- ⑫ **[MONO] key**  
If this key is on, the monitor output L/R channels will be mixed and output as a monaural signal. The signal will return to stereo when you turn this key off.

## Monitoring a signal

Here we explain how you can use the MONITOR section to monitor the desired source.


### 1 Make sure that your monitor system is connected to the rear panel MONITOR OUT jacks L/R/C.

If you want to monitor through headphones, make sure they are connected to the top panel or front panel PHONES jack.

#### Note

- *MONITOR OUT jack C is a special jack used to monitor the center channel when LCR mode is active. Note that the appropriate signal will not be output from MONITOR OUT jack C unless the LCR channel is selected as the monitor source and the USE AS CENTER BUS button is turned on in the MIXER SETUP screen (SYS/W.CLOCK function) (→ p.201).*
- *Turning on the [CUE] key of even one input channel, output channel, or DCA group will override the settings of the MONITOR section and cause the Cue signal to be output from the MONITOR OUT jacks. Make sure that the CUE section [INPUT]/[DCA]/[OUTPUT] LEDs are not lit.*

### 2 To specify the channel that will be selected by the [DEFINE] key, press the DISPLAY ACCESS section [MON/CUE] key repeatedly to access the MONITOR screen shown below.



### 3 Click a button in the DEFINE area to select the channel that will be monitored when you press the [DEFINE] key.

You can assign more than one channel to the [DEFINE] key. You can choose from the following sources.

<b>MIX 1–MIX24</b>	Output signals of MIX channels 1–24
<b>MATRIX1–MATRIX8</b>	Output signals of MATRIX buses 1–8

#### Hint

The MONITOR screen also lets you make settings for monitor signal delay, insert-out/in, and dimmer (→ p.216).

### 4 Use the keys of the MONITOR section to select the monitor source from the following.

<b>[2TR IN A1]/[2TR IN A2] keys</b>	The input signal from 2TR IN ANALOG jacks 1/2
<b>[2TR IN D1]/[2TR IN D2]/[2TR IN D3] keys</b>	The input signal from 2TR IN DIGITAL jacks 1–3
<b>[STEREO A]/[STEREO B] keys</b>	The output signal of the STEREO A/B channels
<b>[STEREO A] key + [STEREO B] key</b>	The LCR channel output
<b>[DEFINE] key</b>	The signal pre-selected in the MONITOR screen (MON/CUE function)

#### Hint

- *If you select STEREO A/B channel or LCR channel, you can also simultaneously select one other monitor source.*
- *The monitor source can also be selected in the MONITOR screen (MON/CUE function).*

### 5 Press the MONITOR [ON] key to turn it on.

#### Hint


A signal is always output from the PHONES jacks regardless of the on/off state of the MONITOR [ON] key.

### 6 Turn the MONITOR [LEVEL] knob to adjust the monitor level. If you are monitoring through headphones, turn the PHONES [LEVEL] knob to adjust the monitor level.

### 7 If you want to monitor the signal in monaural, turn the MONITOR section's [MONO] key on.

## Using the Cue/Solo functions

### Items in the CUE section



#### ① [INPUT]/[DCA]/[OUTPUT] LEDs

These LEDs indicate the monitoring status. If even one [CUE] key is on, the LED of the group to which that key belongs will light. If a special Cue signal such as KEY IN CUE or EFFECT CUE is active, all three LEDs will light.

#### ② [SOLO] key

This selects how monitoring will occur when you use the [CUE] keys. If this key is on, monitoring will operate in SOLO mode. If this key is off, monitoring will operate in CUE mode.

#### ③ [LAST CUE] key

This selects the mode of operation when more than one [CUE] key is on. Turning the key on selects LAST CUE mode; turning the key off selects MIX CUE mode. When you switch this mode, Cue will be turned off for all channels.

#### ④ CUE [LEVEL] knob

This adjusts the signal level that is sent from the CUE OUT jacks.

#### ⑤ [OUTPUT PFL] key

This switches the location from which the signal is sent to the CUE bus when you turn on the [CUE] key of an output channel (MIX channel, MATRIX channel, STEREO A/B channel). If this key is on, the PFL (pre-fader) signal will be sent. If this key is off, the POST ON (immediately after the [ON] key) signal will be sent.

### About CUE mode and SOLO mode

The PM5D lets you select either SOLO mode or CUE mode when using the [CUE] key to monitor signals. Use the [SOLO] key in the CUE section of the panel to switch the mode.

In CUE mode, holding down the [SOLO] key will switch to SOLO mode; the [CUE] keys of all channels will go dark. Conversely in SOLO mode, pressing the [SOLO] key will immediately switch to CUE mode.

These modes differ as follows.

#### • CUE mode

The cue signals of channels / DCA groups whose [CUE] key is on will be sent via the CUE bus and output from the CUE OUT jacks (Cue function). Choose this method when you want to monitor a signal without affecting other channels. When the PM5D is in the default state, the cue signal can also be monitored from the MONITOR OUT jacks.

#### • SOLO mode

Only the channels / DCA groups whose [CUE] key is on will be output from the MIX/MATRIX/STEREO buses, and other channels / DCA groups will be muted (Solo function). The MONITOR OUT jacks also will output only the signal from these same channels / DCA groups.

#### Note

- If an input channel is soloed, the on/off setting of the output channels will remain unchanged; only the signal of the corresponding input channel will be sent to the buses. If an output channel is soloed, the on/off setting of the input channels will remain unchanged; the signal will be sent only to the corresponding bus.
- If a DCA group is soloed, only the signals of input channels belonging to that DCA group will be output to the corresponding buses. However if output channels are assigned to DCA groups 7/8, signals will be sent only to buses belonging to that DCA group.

#### Hint



If desired, you can exclude specific channels from Solo operations (➔ p.219).

## Cue and Solo groups

The PM5D's cue and solo signals can be categorized into the following four groups.


- **INPUT CUE group**

The cue/solo signals of input channels make up this group. This group becomes active when a [CUE] key of an input channel, ST IN channel, or FX RTN channel is pressed to turn it on.





- **DCA CUE group**

The cue/solo signals of DCA groups make up this group. This group becomes active when a [CUE] key in the DCA strip is pressed to turn it on.



- **OUTPUT CUE group**

The cue/solo signals of output channels make up this group. This group becomes active when a [CUE] key of a MIX channel, MATRIX channel, or STEREO A/B channel is pressed to turn it on.



- **Other CUE group**

This group consists of the cue/solo signals operated by the CUE buttons in the display. This group becomes active when you click to turn on a CUE button in the EFFECT PARAM screen (EFFECT function) or GATE PARAM screen (INPUT GATE/COMP function).



It is not possible to simultaneously turn on Cue between different groups. Normally, the group to which the most recently pressed [CUE] key (CUE button) belongs will take priority, and the [CUE] keys of the previously selected group will be defeated.

However if you have switched cue/solo signal groups in a certain order, the [CUE] key status of the previously selected group will be recovered when you turn off the [CUE] key (CUE button) to defeat the current cue/solo selection.

The [CUE] key status can be recovered for the following combinations of groups.

- OUTPUT CUE group → DCA CUE group
- OUTPUT CUE group → INPUT CUE group
- DCA CUE group → INPUT CUE group
- INPUT CUE / OUTPUT CUE / DCA CUE group → Other CUE group


For example if you switch groups in the order of OUTPUT CUE group → DCA CUE group → INPUT CUE group → Other CUE group, you can then successively defeat the [CUE] keys (CUE buttons) to recover the [CUE] key status of the previously selected group.

## Using the Cue function

This section explains how you can use the [CUE] key of a desired channel or DCA group to monitor the Cue signal.

### Note

If you want the cue/solo signal to be output from the MONITOR OUT jacks as well, access the MONITOR screen (MON/CUE function) and make sure that the CUE INTERRUPTION ON/OFF button is on before you continue with the following procedure (➔ p.217).



- Using the [OUTPUT PFL] key of the CUE section, select one of the following as the output position of the signal sent to the CUE bus when an output channel [CUE] key is pressed.

- PFL ([OUTPUT PFL] key is on)**  
The signal from immediately before the fader will be sent to the CUE bus.
- POST ON ([OUTPUT PFL] key is off)**  
The signal from immediately after the [ON] key will be sent to the CUE bus.

### Hint

The above setting can also be made in the CUE screen (MON/CUE function) (➔ p.217). In this screen you can also specify the output position of the signal sent from input channels and DCA groups to the CUE bus.

- In the CUE section, use the [LAST CUE] key to specify the mode of operation when more than one [CUE] key within the same group is turned on.

- LAST CUE mode ([LAST CUE] key is on)**  
Only the channel/group whose [CUE] key was last turned on will be monitored.
- MIX CUE mode ([LAST CUE] key is off)**  
Channels/groups within the same group whose [CUE] key is turned on will be monitored.

### Note

- [CUE] keys belonging to different groups cannot be turned on simultaneously. The group to which the last-pressed [CUE] key belongs will be turned on, allowing the signals of that group to be monitored.
- If you press the [CUE] key of a paired channel, both channels will be turned on.

- Make sure that the [SOLO] key in the CUE section is turned off.
- Press the [CUE] key of a desired channel or DCA group to turn it on.  
The signal of the corresponding channel will be output from the CUE OUT jacks and the MONITOR OUT jacks.
- To defeat Cue, press the currently-on [CUE] key once again.

### Hint

If you press the [LAST CUE] key to switch from LAST CUE mode to MIX CUE mode (or vice versa), all previously-enabled Cue (Solo) signals will be defeated. For example if you have turned on multiple [CUE] keys in MIX CUE mode, you can quickly turn them all off by pressing the [LAST CUE] key twice.

## Using the Solo function

This section explains how to use the Solo function.

- Use the [LAST CUE] key of the CUE section to specify the mode of operation when a [CUE] key is turned on (LAST CUE mode or MIX CUE mode).

- In the CUE section, press and hold the [SOLO] key.  
When you press and hold the [SOLO] key, the key LED will blink and SOLO mode will be enabled. In SOLO mode, only the signal of the channel or DCA group whose [CUE] key is turned on will be sent to the MIX, MATRIX, and STEREO buses. The same signal can also be monitored from the MONITOR OUT jacks and CUE OUT jacks.

### Hint

If desired, you can exclude specific channels or groups from Solo operations (for details, refer to ➔ p.219).

- Turn on the [CUE] key of a desired channel or DCA group.  
Only the corresponding channel or DCA group will be output to the buses and output jacks; the remaining channels and DCA groups will be muted. The same signal will also be output from the CUE OUT jacks and the MONITOR OUT jacks.

### Note

If you turn on the [CUE] key of an output channel, the signal will be sent only to the corresponding bus.

- To defeat Solo, press the [SOLO] key.  
If you press the [SOLO] key while in SOLO mode, you will immediately return to CUE mode.

### Note

- Normally, the Cue/Solo functions can be operated independently of scene memories.
- Even if you pair a Cued channel, the cue settings will not change in tandem at the moment you pair the channel. The setting will change in tandem when you subsequently switch Cue on/off.


# 12 Talkback and Oscillator

This chapter explains how to use talkback and oscillator.


## About the TALKBACK/OSCILLATOR sections

The TALKBACK and OSCILLATOR sections let you send the signal of a mic connected to the TALKBACK jack or the signal of a test oscillator to the desired output jacks.

Signal flow in the TALKBACK/OSCILLATOR sections is as follows.



### Items in the TALKBACK/OSCILLATOR sections



- ① **TALKBACK jack**  
This is a balanced XLR-3-31 jack to which a talkback mic can be connected. You can make settings in the display to supply +48V phantom power to this jack.
- ② **TALKBACK [LEVEL] knob**  
This adjusts the input level of the mic connected to the TALKBACK jack.
- ③ **TALKBACK [ON] key**  
This switches the talkback signal on/off. When you press and hold the key, talkback will be on as long as you hold down the key. If you press and immediately release the key, talkback will remain on until you press the key once again.  
However if the NEVER LATCH button is turned on in the TALKBACK screen, talkback will be on only while you hold down the key, and will turn off when you release the key; i.e., talkback will not “latch” even if you press and immediately release the key.
- ④ **OSCILLATOR [ON] key**  
This is an on/off switch for the signal sent from the internal oscillator to the specified bus(es).


#### Note

If the OSCILLATOR [ON] key is off, and a screen other than the OSCILLATOR screen (TALKBACK function) is displayed, pressing this key will only display the OSCILLATOR screen; the key will not turn on. When you press the key once again, it will turn on. If the key is on, pressing it once again will turn it off regardless of the screen that is displayed.

## Using talkback

Here's how the talkback signal input from the TALKBACK jack can be sent to the desired bus(es).

- 1 Repeatedly press the [MON/CUE] key of the DISPLAY ACCESS section until the TALKBACK screen appears.



- 2 Turn the TALKBACK [LEVEL] knob to adjust the input sensitivity of the talkback mic.

The meter in the TALKBACK IN area indicates the input level of the mic connected to the TALKBACK jack. If you want phantom power (+48V) to be supplied to the TALKBACK jack, turn on the +48V button located in the TALKBACK IN area.

### Hint

The INPUT TO TALKBACK area also lets you use any INPUT jack 1–48 as a supplementary input for talkback.

- 3 Click a button in the BUS ASSIGN area to specify the bus(es) to which the talkback signal will be sent (multiple selections are allowed).

These buttons correspond to the following buses.

MIX 1–24 buttons	MIX buses 1–24
MATRIX 1–8 buttons	MATRIX buses 1–8
STEREO AL/R	STEREO A bus L/R channels
STEREO BL/R	STEREO B bus L/R channels

### Hint

If desired, the talkback signal can also be output directly from an output channel of slot 1–4 or from 2TR OUT DIGITAL jacks 1–3. To do so, click the PATCH button in the TALKBACK OUT area to access the OUTPUT PATCH screen, and patch talkback to the jack you want to use for direct output.

- 4 To enable talkback, press the TALKBACK [ON] key in the TALKBACK section of the panel to turn it on.

The TALKBACK [ON] key can operate in either of the following two ways, depending on the setting of the NEVER LATCH button in the TALKBACK area.

- If the NEVER LATCH button is off  
Talkback will be switched on/off each time you press the TALKBACK [ON] key (Latched). However if you press and hold down the TALKBACK [ON] key, talkback will remain on only while you continue holding down the key, and will turn off when you release the key (Unlatched).
- If the NEVER LATCH button is on  
Talkback will be on only while you continue holding down the TALKBACK [ON] key, and will turn off when you release the key (Unlatched).


### Hint

- The TALKBACK [ON] key of the panel and the TALKBACK ON/OFF button in the screen are linked. The setting of the NEVER LATCH button also affects both of these. However if the NEVER LATCH button is off, holding down the on-screen TALKBACK ON/OFF button will cause Latched operation.
- When talkback is on, you can use the talkback dimmer to lower the monitor levels other than talkback (➔ p.216).
- You can also assign the talkback function to a user-defined key (➔ p.189).

# Using the oscillator

The PM5D contains a test oscillator. By outputting the oscillator signal to the desired bus you can check the operation of connected devices or test the acoustics of a hall.


- 1 Repeatedly press the [MON/CUE] key of the DISPLAY ACCESS section until the OSCILLATOR screen appears.



- 2 Click a button in the OSC MODE section to select the type of oscillator to output, from the following choices.

<b>SINE WAVE 1CH button</b>	Sine wave x 1 channel
<b>SINE WAVE 2CH button</b>	Sine wave x 2 channels
<b>PINK NOISE button</b>	Pink noise
<b>BURST NOISE button</b>	Burst noise (repeated output of pink noise)

- 3 Use the knobs and buttons of the PARAMETERS area to adjust the oscillator parameters. The parameters that can be adjusted will depend on the type of oscillator you selected in step 2. For example if you selected SINE WAVE 1CH as the oscillator type, the PARAMETERS area will contain the following parameters.



- 4 Click a button in the BUS ASSIGN area to select the oscillator signal output destination from the following choices.

<b>MIX 1–24</b>	MIX buses 1–24
<b>MATRIX1–8</b>	MATRIX buses 1–8
<b>STEREO AL/R</b>	STEREO A bus L/R channels
<b>STEREO BL/R</b>	STEREO B bus L/R channels

### Hint

- If you selected SINE WAVE 2CH as the oscillator type, the L-channel signal of the oscillator will be sent to odd-numbered buses (or the L output jack) and the R-channel signal of the oscillator will be sent to even-numbered buses (or the R output jack).
- You can use the OSC OUT area to directly output the oscillator signal from an output jack or slot (➔ p.214).

- 5 Press the OSCILLATOR [ON] key of the OSCILLATOR section.

The oscillator signal will be sent to the bus you selected in step 4. When you press the key again, the oscillator will turn off.

### Hint

The OSCILLATOR [ON] key of the panel and the OSC ON/OFF button in the screen are linked.

### Note


If the OSCILLATOR [ON] key is off, and a screen other than the OSCILLATOR screen (TALKBACK function) is displayed, pressing this key will only display the OSCILLATOR screen; the key will not turn on. When you press the key once again, it will turn on.

# 13 Meters

This chapter explains meter-related operations.

## Items in the meter section

The meter section shows the input levels of the input channels and the output levels of the output channels.



- ① **INPUT/MIX meters**  
Depending on the key you press, these meters indicate the input levels of input channels 1–24 or 25–48, or the output levels of MIX channels 1–24.
- ② **[CH 1-24/ST IN/FX RTN] key**  
When this key is on, the INPUT/MIX meters indicate the input levels of input channels 1–24 and the ST IN/FX RTN/MATRIX meters indicate the output level of ST IN channels (or FX RTN channels, depending on the FOLLOW INPUT LAYER setting) 1–4.
- ③ **[CH 25-48/FX RTN/ST IN] key**  
When this key is on, the INPUT/MIX meters indicate the input levels of input channels 25–48 and the ST IN/FX RTN/MATRIX meters indicate the output level of FX RTN channels (or ST IN channels, depending on the FOLLOW INPUT LAYER setting) 1–4.
- ④ **[MIX/MASTER] key**  
When this key is on, the INPUT/MIX meters indicate the output levels of MIX channels 1–24 and the ST IN/FX RTN/MATRIX meters indicate the output levels of MATRIX channels 1–8.
- ⑤ **[PEAK HOLD] key**  
Switches the peak hold function on/off for the meter display.
- ⑥ **ST IN/FX RTN/MATRIX meters**  
Depending on the key you press, these meters indicate the output levels of ST IN channels 1–4 or MATRIX channels 1–8.
- ⑦ **MASTER meters**  
These meters always indicate the output levels of the STEREO A/B channels and CUE bus.

## Switching the meter display

You can use the keys of the meter section to specify the channels whose levels will be shown in the INPUT/MIX meters and ST IN/MATRIX meters. The following channels correspond to each key.

Key	[INPUT/MIX] meters	[ST IN/MATRIX] meters
[CH 1-24/ST IN/FX RTN] key	Input channels 1–24	ST channels (or FX RTN channels) 1–4
[CH 25-48/FX RTN/ST IN] key	Input channels 25–48	FX RTN channels (or ST IN channels) 1–4
[MIX/MATRIX] key	MIX channels 1–24	MATRIX channels 1–8

### Hint

- The type of channels shown in the meter section is also shown in the METER SECTION area in the upper right of the display.
- The MASTER meters always indicate the output levels of the STEREO A/B channels and CUE bus.


# Switching the metering point

The metering point for the level meters (i.e., the position at which the level is detected) can be specified separately for input channels and output channels.

## Specifying the metering point for input channels

Here's how to specify the metering point for input channels and ST IN/FX RTN channels.

- 1 In the DISPLAY ACCESS section, repeatedly press the [METER] key to access the INPUT METER screen.



- 2 Click the / buttons at the left and right of the METERING POINT box to choose one of the following metering points.

PRE ATT	Immediately before the attenuator
PRE GATE	Immediately before the internal gate
PRE FADER	Immediately before the fader
POST FADER	Immediately after the fader
POST ON	Immediately after the [ON] key


## Specifying the metering point for output channels

Here's how to specify the metering point for output channels, MONITOR channels, and the CUE bus.

### Hint

The metering point setting for the CUE bus is independent from the other output channels.

- 1 In the DISPLAY ACCESS section, repeatedly press the [METER] key to access the OUTPUT METER screen.



- 2 To specify the metering point for output channels and MONITOR channels, click the / buttons at the left and right of the METERING POINT box to choose one of the following.

PRE EQ	Immediately before the EQ
PRE FADER	Immediately before the fader
POST FADER	Immediately after the fader
POST ON	Immediately after the [ON] key
POST DELAY	Immediately after the internal delay

- 3 To specify the metering point for the CUE bus, click the / buttons at the left and right of the CUE METERING POINT box to choose one of the following.

PRE DELAY	Immediately before the internal delay
POST DELAY	Immediately after the internal delay


## Viewing the gain reduction of the internal gates and compressors

The amount of gain reduction produced by the gates/compressors of the input channels and the amount of gain reduction produced by the compressors of the output channels can be viewed in the display.

### Viewing the gain reduction for input channels

Here's how to view the amount of gain reduction produced by the gates/compressors provided on input channels 1–48 and ST IN channels 1–4.

- 1 In the DISPLAY ACCESS section, repeatedly press the [METER] key to access the INPUT GR screen.




- 2 Click the GATE button or COMP button to select the parameter that will be displayed. For an explanation of the items shown in the screen, refer to the explanation of the INPUT GR screen (➔ p.211) in the Reference section.

### Viewing the gain reduction for output channels

To view the amount of gain reduction produced by the compressors provided on the output channels, repeatedly press the [METER] key of the DISPLAY ACCESS section to access the OUTPUT GR screen.

For an explanation of the items shown in the screen, refer to the explanation of the OUTPUT GR screen (➔ p.211) in the Reference section.



# 14 Effects

This chapter explains the functionality and operation of the PM5D's internal effects.


## About the internal effects

The PM5D contains eight internal effect modules. For each module, you can choose one of 48 effect types (not including Add-On Effects) for the module to use.

### Hint

You can add effect types for the internal effects by installing an optional Add-On Effects package (➔ p.109).

To use an internal effect via send/return, assign the output of a MIX channel to the input of the effect, and assign the output of the effect to an input channel. In this case, the corresponding MIX bus is used as an effect send AUX bus, and the input channel is used as an effect return channel. By default, the L/R outputs of effects 1–4 are assigned to L/R of FX RTN channels 1–4.




Alternatively, you can insert an internal effect into a channel by assigning the input/output of the internal effect to the insert-out/insert-in of the desired channel.



The PM5D's effect types fall into two categories; "stereo effect types" which process the L/R channel input signals independently, and "mix effect types" which mix the two channels before processing the signal.

If signals are assigned to both the L and R inputs of an effect, the way in which the L/R channels are processed will depend on whether a Stereo effect type or a Mix effect type is selected, as follows.

#### • Stereo effect types



#### • Mix effect types



If a signal is assigned to only one input of an effect, it will be processed as mono-in/stereo-out regardless of whether a Stereo effect type or Mix effect type is selected.



## Using an internal effect via a MIX bus

This section explains how to use an internal effect via a MIX bus. As an example, we will choose effect 1 for our operations, assign MIX bus 1 to the effect input, and assign the effect output to FX RTN channels 1/2.

- 1 In the DISPLAY ACCESS section, repeatedly press the INPUT [PAN/ROUTING] key to access the CH to MIX screen.

CH to MIX      Type selection box



- 2 Make sure that the MIX bus 1 type selection box indicates "VARI."

If the box indicates "FIXED," click the / buttons at left and right to change the indication to "VARI"; then press the [ENTER] key (or click inside the box) to finalize the change.


This box selects the operation of the MIX bus (VARI or FIXED). If VARI is selected, the bus send levels will be adjustable.

### Hint

The VARI/FIXED selection is made for two adjacent odd-numbered/even-numbered MIX buses. If the effect input is stereo, it is convenient to pair these two MIX buses.

- 3 In the DISPLAY ACCESS section, repeatedly press the [EFFECT] key to access the EFFECT PARAM screen.

### EFFECT PARAM



- 4 Make sure that the box in the upper left of the screen indicates EFFECT 1.

This box lets you select the effect module that you want to control. If a different effect module is selected, click the / buttons at left and right to select EFFECT 1.

### Hint

You can access the EFFECT ASSIGN screen (EFFECT function) to see all eight effect modules at once while you assign signal routes to the effect inputs and outputs, or operate Bypass and Cue ( p.154).

- 5 In the INPUT area, click the / buttons at the left and right of the L CH box to select MIX 1 (MIX channel 1); then press the [ENTER] key (or click within the box).

This assigns the output of MIX channel 1 to the L input of the effect.

If a signal route is already assigned, a window will appear when you press the [ENTER] key, asking you to confirm the assignment. Click the OK button to confirm the assignment.

If you want to use the effect input in stereo, assign MIX channel 2 to the R CH box in the same way.

- 6 In the OUTPUT area, make sure that the L CH box indicates FX RTN1L and the R CH box indicates FX RTN1R.

The L CH/R CH boxes in the OUTPUT area select the input channels that are assigned to the L/R outputs of the effect.

By default, the L/R outputs of effect 1 are assigned to FX RTN channel 1 (L/R). If different channels are selected, use the / buttons at the left and right of the boxes to select FX RTN1L and FX RTN1R respectively.

- 7 Set the MIX BALANCE knob to about 100.

The MIX BALANCE knob adjusts the balance between the original sound and effect sound included in the output signal from the effect. If this knob is at the 100 (%) position, only the effect sound will be output.

- 8 In the ENCODER MODE section, press the MIX SEND SELECT [1] key to make the encoder mode indicator show "1".

In this state you can use the input channel encoders to adjust the send level from each channel to MIX bus 1.

- 9 Turn the encoders of the INPUT channel strip and ST IN channel strip to adjust the send level of the signal sent from each channel to MIX bus 1.



Don't raise the encoder of the FX RTN channel you are using as the effect return. Doing so will send the output of the effect back to the input, possibly causing oscillation.

### Hint

- The send position of the signals sent from input channels to the MIX bus can be specified for each channel ( p.43).
- As an alternate way to adjust the send level, you can turn on the [MIX SEND] key of the MIX section, then use a [SEL] key to select an input channel and turn the corresponding MIX encoder ( p.43).

- In the MIX section, press the [MIX MASTER] key to turn it on (LED lit).  
When the [MIX MASTER] key is on, you can use the controls of the MIX section to control MIX channels 1–24.
- Press the MIX channel 1 MIX [ON] key to turn it on. Use the MIX encoder of that MIX channel to adjust the master send level of the signal sent to the effect.

- In the FX RTN channel strip, press the FX RTN channel 1 [ON] key to turn it on.
- Use the FX RTN channel 1 fader to adjust the effect return level.


**Hint**

The input/output levels of the effect can be viewed in the meters shown in the EFFECT PARAM screen or EFFECT ASSIGN screen.

## Inserting an internal effect into a channel


You can insert an internal effect into a channel by assigning the input/output of the internal effect to the insert-out/insert-in of the desired channel. As an example, here's how to insert an effect into an input channel.

- In the DISPLAY ACCESS section, repeatedly press the [EFFECT] key to access the EFFECT PARAM screen.



- To select the effect module you want to use, click the [ ] / [ ] buttons at the left and right of the box in the upper left of the screen.
- In the INPUT area, use the [ ] / [ ] buttons at the left and right of the L CH box to select the insert-out of the channel into which you want to insert the effect, and press the [ENTER] key. (If a signal route has already been assigned, a window will ask you to confirm the assignment change.)  
If you are inserting the effect into a stereo channel (or two paired channels), use the R CH box to assign the insert-out for the other channel in the same way.
- In the OUTPUT area, use the [ ] / [ ] buttons at the left and right of the L CH box to select the insert-in assigned to the L output of the effect. If you are inserting the effect into a stereo channel (or two paired channels), use the R CH box to assign the insert-in for the other channel in the same way.

- In the DISPLAY ACCESS section, repeatedly press the INPUT [PATCH] key to access the INSERT/DIRECT OUT POINT screen.



- Turn on the INSERT ON/OFF button for the channel into which you inserted the effect. This enables the effect insertion for the corresponding channel.
- Use the buttons of the INSERT I/O area to specify the insert-out/in point.

**Hint**

For details on the INSERT I/O area, refer to INSERT/DIRECT POINT screen (→ p.256) in the Reference section.

- Turn on the [ON] key for the channel into which you inserted the effect, and use the fader to adjust the input level.
- Access the EFFECT PARAM screen, and drag the MIX BALANCE knob to adjust the balance of the effect sound and original sound.  
The input/output levels of the effect can be viewed in the meters shown in the EFFECT PARAM screen or EFFECT ASSIGN screen.


# Basic operations in the effect screen

This section explains how to store or recall effect library data, and how to edit effect parameters.

## Recalling settings from the effect library


Here's how to recall existing settings from the effect library.

- 1 In the DISPLAY ACCESS section, repeatedly press the [EFFECT] key to access the EFFECT PARAM screen.



**Note**  
You cannot change the currently selected effect type in the EFFECT PARAM screen. To change the effect type, you must recall (load) a library item that uses the desired effect type.

- 2 Click the [LEFT] / [RIGHT] buttons at the left and right of the box in the left side of the screen to select the effect module you want to use, and then click the LIBRARY button. The EFFECT LIBRARY screen will appear, allowing you to recall or store settings in the effect library.



**Hint**  
You can also access this screen by repeatedly pressing the [EFFECT] key. The effect module you are controlling can also be selected in this screen.

- 3 In the library list at the right of the screen, click to select the library item you want to recall

When you click a library item in the library list, that line will be highlighted and move to the center of the list. The effect type of the currently selected library item will be shown above the library list.

- 4 Click the RECALL button.

The selected library item will be loaded into the effect module you chose.

**Hint**


You can click the EDIT button in the upper right of the screen to access the EFFECT PARAM screen for the currently selected effect.

## Editing the effect parameters

Here's how to edit the parameters of an internal effect.

- 1 In the DISPLAY ACCESS section, repeatedly press the [EFFECT] key to access the EFFECT PARAM screen.

The lower part of the screen will show knobs and buttons for editing the parameters of the currently selected effect. The content of the parameters will depend on the type of the currently selected effect.



- 2 Use the box in the upper left of the screen to select the effect module you want to control.
- 3 Use the knobs and buttons in the lower part of the screen to edit the effect parameters. For details on the effect parameters, refer to the Appendices at the end of this manual.


**Hint**

The parameter settings for internal effect modules 1-8 are saved in the scene. The settings of individual effects can also be stored in the effect library independently of scene memory.


## Storing settings in the effect library

Here's how to store effect data parameter settings in the effect library.

- 1 In the DISPLAY ACCESS section, repeatedly press the [EFFECT] key to access the EFFECT PARAM screen.



- 2 Use the box in the upper left of the screen to select the effect module whose settings you want to store, and click the LIBRARY button. The EFFECT LIBRARY screen will appear, allowing you to recall or store settings in the effect library.



"R" (read-only)

- 3 In the library list, choose the store-destination number and click that line.

### Note

Library items for which an "R" (read-only) appears in the right column of the list are factory preset library items. These numbers cannot be overwritten.

- 4 Click the STORE button.

The EFFECT LIBRARY STORE window will appear, allowing you to name the library item you are saving.



- 5 Use the character palette to assign a name to the library item. For details on using the character palette, refer to p.26.
- 6 Click the STORE button. A window will ask you to confirm the Store operation.
- 7 To execute the Store operation, click the OK button.

The data will be stored, and you will return to the previous screen.

If you click the CANCEL button instead of the OK button, the Store operation will be aborted and you will return to the previous screen.

## Using the Tap Tempo function

This section explains how to use the Tap Tempo function. “Tap tempo” is a function that lets you specify the delay time of a effect or the modulation speed of a modulation effect by striking a key at the desired interval.

- 1 From the effect library, recall a library item whose effect type uses a TEMPO parameter (e.g., Delay+ER., Echo, Chorus).

TEMPO is a parameter that specifies a time-related effect parameter (the DELAY parameter of Delay+ER. or Echo, or the FREQ. parameter of Chorus, etc.) in terms of a BPM value or a manual setting. The TEMPO parameter is included in delay-type effects or modulation-type effects, and is shown in the lower left of the EFFECT PARAM screen.

### Hint

For details on the parameters of each effect type, refer to the Appendices at the end of this manual (► p.298).

- 2 In the DISPLAY ACCESS section, repeatedly press the [EFFECT] key to access the EFFECT PARAM screen.

The following illustration shows the screen when the “Delay+ER.” effect type is selected.

### EFFECT PARAM




TAP TEMPO button

- 3 Move the cursor to the TAP TEMPO button, and repeatedly press the [ENTER] key at the desired tempo. (Alternatively, repeatedly click the TAP TEMPO button.)

The average interval (BPM) at which you press the key will be calculated, and that value will be input for the TEMPO parameter.

The average interval will be input  
(the average of a, b, and c)



### Hint

- The Tap Tempo function is valid only for the currently displayed internal effect. However, it is ignored if the selected effect type does not include a TEMPO parameter.
- If the average value is outside the range of 20–300 BPM, it will be ignored.
- If desired, an external switch connected to the GPI connector can be used to operate the Tap Tempo function of the current page (► p.123).

# Using the Freeze effect

Here's how to use the "FREEZE" effect type, which provides the functionality of a simple sampler. When this effect type is selected, you can perform operations in the screen to record (sample) and play back a sound.


- 1** In the EFFECT LIBRARY screen, recall a library item that uses the FREEZE effect type.
- 2** In the DISPLAY ACCESS section, repeatedly press the [EFFECT] key to access the EFFECT PARAM screen.  
If the FREEZE effect type is selected, the lower left of the EFFECT PARAM screen will show a REC button, a PLAY button, and a progress bar.

- 3** To begin recording (sampling), click the REC button and then click the PLAY button.  
The signal being input to the effect will be recorded. The progress bar shows the current recording location. When a fixed time has elapsed, the buttons will automatically turn off.

**Hint**  
You can adjust the parameters in the screen to make detailed settings for recording time, the way in which recording will begin, and the way in which the sample will play back. For more about the parameters, refer to the Appendices at the end of this manual (→ p.305).

- 4** To play back the recorded sample, click the PLAY button.

**Note**  
Once you stop, the sampled content will be erased.



# Using optional Add-On Effects

You can add effect types for the internal effects by installing an optional Add-On Effects package. The installed effect types can be recalled from effect library numbers 049 and following. For details on the installation procedure, refer to the installation guide included with the Add-On Effects package you purchased.

As of August 2004, the following Add-On Effects packages are available for purchase.

- AE011 Channel Strip Package
- AE021 Master Strip Package

However, the Reverb Package sold as an Add-On Effects package for the DM2000 or 02R96 is already included on the PM5D as effect library numbers 046–048.

Other Add-On Effects packages are expected to go on sale in the future, so please check the Yamaha website for the latest information.

Yamaha Pro Audio Website:  
<http://www.yamahaproaudio.com>



# 15 Graphic EQ

The PM5D contains twelve 31-band graphic EQ modules. This chapter explains how to use the graphic EQ.

## Patching the graphic EQ

The twelve GEQ (Graphic EQ) modules built into the PM5D can be inserted into the insert-out/in of the desired channel. As an example, here's how to insert graphic EQ into the STEREO A channel.

- In the DISPLAY ACCESS section, repeatedly press the [GEQ] key to access the GEQ PARAM screen.**  
In this screen you can select a GEQ module, specify the channel into which it will be inserted, and edit its parameters.




- Click the **◀ / ▶** buttons at the left and right of the MODULE box in the upper left of the screen to select the GEQ module you want to operate.
- Click the **◀ / ▶** buttons at the left and right of the INSERT box to select ST AL [INS] (STEREO A L channel insert-in/out) as the channel into which the GEQ module will be inserted, and press the [ENTER] key (or click within the box). You can choose one of the following insert destinations.

INS CH 1–INS CH48	Input channel 1–48 insert in/out
INS STIN1L–INS STIN4R	ST IN channel 1–4 (L/R) insert in/out
INS MIX 1–INS MIX24	MIX channel 1–24 insert in/out
INS MTRX1–INS MTRX8	MATRIX channel 1–8 insert in/out
INS ST AL/INS ST AR	STEREO A channel (L/R) insert in/out
INS ST BL–INS ST BR	STEREO B channel insert in/out
INS MON L–INS MON C	MONITOR channel (L/R/C) insert in/out

If an insert destination is already assigned, a window will appear when you click within the box, asking you to confirm the change. Click the OK button to execute.

- In the upper left of the screen, click the **◀ / ▶** buttons at the left and right of the MODULE box to select another GEQ module, and assign it to ST AR [INS] (STEREO A R channel insert-in) in the same way.
  - Click the GEQ ON/OFF button to turn it on.
- Note**  
When you insert a GEQ, the insert-in for the channel will be enabled automatically.
- In the DISPLAY ACCESS section, repeatedly press the OUTPUT [PATCH] key to access the INSERT POINT screen.



- If desired, change the insert point for the STEREO A channel into which you inserted the graphic EQ.

When you insert a GEQ, the insert-in point for that channel will be enabled automatically.

- Note**
- If you inserted a graphic EQ into an input channel, repeatedly press the INPUT [PATCH] key to access the INSERT/DIRECT OUT POINT screen (INPUT PATCH function), and edit the settings in the same way.
  - You can also insert a graphic EQ into the desired channel's insert-in/out by using the INSERT PATCH screen (INPUT PATCH function and OUTPUT PATCH function).


# Basic graphic EQ operations

There are two ways to control a graphic EQ; using the virtual faders and buttons within the display, or using the DCA faders of the panel.

## Controlling the graphic EQ from the display

Here's how to control the desired GEQ module by using the faders and buttons shown in the GEQ PARAM screen (GEQ function).

- 1 In the DISPLAY ACCESS section, repeatedly press the [GEQ] key to access the GEQ PARAM screen.



- 2 Click the [←] / [→] buttons at the left and right of the MODULE box to select the GEQ module you want to operate.

At this time make sure that the GEQ ON/OFF button is on. Also make sure that the corresponding module is inserted into an appropriate channel, and that insert-in/out is enabled for that channel.

### Hint

- The upper part of the GEQ PARAM screen functions as a spectrum analyzer. If a signal is being input to the corresponding channel, the level of each frequency band is displayed in realtime.
- As an alternate way to select the desired GEQ module, you can use the GEQ ASSIGN screen (GEQ function) (▶ p. 157).

- 3 If desired, use the buttons of the LIMIT area to specify the variable range of the faders.

The LIMIT area lets you select the maximum amount and direction of the change controlled by the faders. You can select  $\pm 15$  dB/ $\pm 12$  dB/ $\pm 6$  dB (both boost and cut directions) or  $-24$  dB (cut only).

- 4 Drag the faders in the lower part of the screen to adjust the amount of boost/cut.

The value of each fader is shown by the box below it.

### Hint

Clicking the EQ FLAT button below the LIMIT area will reset all faders to 0 dB.

## Controlling the graphic EQ from the DCA section

Here's how to control the graphic EQ using the keys and faders of the panel DCA strip. In this case, the corresponding GEQ module is divided into six regions for control.

- 1 In the DISPLAY ACCESS section, repeatedly press the [GEQ] key to access the GEQ PARAM screen.



- 2 Click the [←] / [→] buttons at the left and right of the MODULE box to select the GEQ module you want to operate.

At this time, make sure that the GEQ ON/OFF button is turned on. Also make sure that the corresponding module is inserted into an appropriate channel, and that insert is enabled for that channel.

### Hint

When the GEQ PARAM screen is displayed, pressing the [SEL] key of a channel in which a GEQ module is inserted will recall the corresponding GEQ module in the screen.

- 3 Use the buttons of the LIMIT area to select the maximum amount and direction of the change controlled by the faders.


- 4 In the lower part of the screen, click a button in the ASSIGN TO FADERS area to select the region you will control from the DCA faders. The buttons in the ASSIGN TO FADERS area correspond to the following frequency regions.

A	20.0-100 button	The eight bands 20.0 Hz–100 Hz
B	63.0-315 button	The eight bands 63.0 Hz–315 Hz
C	200-1.00k button	The eight bands 200 Hz–1.00 kHz
D	630-3.15k button	The eight bands 630 Hz–3.15 kHz
E	2.00k-10.0k button	The eight bands 2.00 kHz–10.0 kHz
F	4.00k-20.0k button	The eight bands 4.00 kHz–20.0 kHz

When a button is clicked, you can use the DCA faders to control the faders of that frequency region. The faders of the selected region are indicated by a red line in the center of the fader.

While any of the buttons in the ASSIGN TO FADERS area is on, you can use the FADER MODE section FADER MODE [A]–[F] keys to select the frequency region corresponding to these buttons.

Even if all of the buttons in the ASSIGN TO FADERS area are off, you can hold down the [SHIFT] key and press one of the FADER MODE [A]–[F] keys to select the region to be controlled by the DCA faders.



## 5 Operate DCA faders 1–8.

The corresponding frequency region will be boosted or cut.

### Hint

If the fader of a GEQ module is at the 0 dB position, the [NOMINAL] LED of the DCA fader will light. If it is at other than the 0 dB position, the DCA [MUTE] key will light. While the DCA [MUTE] key is lit, pressing the DCA [MUTE] key will reset the corresponding band to 0 dB.

## 6 If you want to use the DCA faders to control a different region, repeat steps 4–5.

## 7 When you have finished using the DCA faders to control the graphic EQ, either press the FADER MODE [DCA] key or click the OFF button in the ASSIGN TO FADERS area.

When the [DCA] button is on, the FADER MODE keys and the DCA faders will return to their normal state. If you once again want to assign the graphic EQ to the DCA faders, either click a button in the ASSIGN TO FADERS area or hold down the [SHIFT] key and press a FADER MODE [A]–[F] key.

### Hint

- GEQ settings are saved as part of the scene. The settings of a GEQ module can also be saved in the GEQ library. For details, refer to GEQ LIBRARY screen (➔ p.158) in the Reference section.
- When you switch the display to a different screen, the DCA fader assignments will be forcibly defeated, and will no longer function even if you return to the GEQ screen. However if you turn on the AUTO ASSIGN button in the GEQ PARAM screen, the DCA faders will automatically be assigned to the most recently operated region when you access the GEQ PARAM screen.

# 16 Remote control

This chapter explains how you can use MIDI or GPI to control the PM5D's parameters from an external device, or conversely how you can use the PM5D to control external devices.

## MIDI on the PM5D

The PM5D can use MIDI to perform the following operations.

- **Program Change transmission and reception**  
When you execute a specific event (scene/effect library recall) on the PM5D, a program change message of the corresponding number can be transmitted to an external device. Conversely, the corresponding events can be executed when program change messages are received from an external device.
- **Control Change transmission and reception**  
When you execute a specific event (fader/encoder or key operation) on the PM5D, a control change message of the corresponding number can be transmitted to an external device. Conversely, events can be executed when control change messages are received from an external device. This capability can be used to record fader and key operations on a MIDI sequencer or other external device, and play back this data later. System exclusive messages can also be used to transmit or receive bulk data (scene or library content) or parameters.

- **MIDI Remote function**  
You can assign MIDI messages to the controls of the INPUT/ST IN channel strip, and transmit those MIDI messages by operating the controls. This capability can be used for remote control of external MIDI devices such as synthesizers, or to control the parameters of DAW software or a HDR unit.
- **MIDI Event transmission**  
MIDI messages can be registered independently for each scene in scene memory, and transmitted when that scene is recalled.


### Note

For each of the above functions, the MIDI port used to transmit/receive MIDI messages can be selected from the rear panel MIDI IN/OUT connectors, the rear panel USB connector, and an I/O card installed in slots 1 through 4. (If the USB connector or an I/O card is selected, you can additionally choose from ports 1 through 8.) However, MIDI Event transmission is fixed at the MIDI OUT connector.

## Using program changes to control events

The PM5D lets you assign specific events (scene recall / effect library recall) to each MIDI program number, so that the correspondingly-numbered program change message will be transmitted to an external device when you execute that event on the PM5D. Conversely, the corresponding event can be executed when a program change message is received from an external device.

- 1 Connect the MIDI OUT connector of the external device to the PM5D's MIDI IN connector. Connect the MIDI OUT connector of the PM5D to the MIDI IN connector of the external device.



- 2 In the DISPLAY ACCESS section, press the [MIDI/REMOTE] key several times to access the MIDI PGM CHANGE screen shown below.


### MIDI PGM CHANGE



In the MIDI PGM CHANGE screen you can assign events to each program number, select the port at which MIDI messages will be transmitted and received, and select how program changes will be transmitted and received.

- 3** In the PROGRAM CHANGE SETUP area at the left of the screen, you can select the way in which program changes will be transmitted and received, and switch reception and transmission on/off.

The MODE area of PROGRAM CHANGE SETUP lets you choose one of the following as the way in which program changes will be transmitted and received.



- **SINGLE**

If this button is on, program changes will be transmitted/received on a single MIDI channel (Single mode).

- **OMNI ON/OFF**

If this button is on, program changes of all MIDI channels will be received in Single mode (this is unavailable in Multi mode).


- **BANK ON/OFF**

If this button is on, bank select messages will be transmitted and received in Single mode (this is unavailable in Multi mode).

- **MULTI**

If this button is on, program changes will be transmitted/received on multiple MIDI channels (Multi mode). You can use the Tx (transmission) and Rx (reception) buttons to turn program change transmission and reception on/off separately.

- 4** In the MIDI SETUP area at the upper left of the screen, select the port at which program changes will be transmitted/received, and the MIDI channel that will be used for transmission and reception. You have the following choices.



<b>MIDI</b>	The rear panel MIDI IN/OUT connectors
<b>USB</b>	The rear panel USB connector
<b>SLOT 1-4</b>	An I/O card installed in rear panel slot 1-4

Click the / buttons at the left and right of the Tx box (transmission) or Rx box (reception) to change the setting, and press the [ENTER] key (or click within the box) to finalize the setting. If you select USB or SLOT 1-4, use the box at the right to specify the port number (1-8) as well.


If SINGLE (single mode) is selected as the program change transmission/reception mode, use the MIDI CH field to select the MIDI transmit channel and MIDI receive channel.

**Hint**

The MIDI port and MIDI channel used for program change transmission/reception can also be specified from the MIDI SETUP screen (➔ p.171).

- 5** In the list at the right side of the screen, display the MIDI channel (bank) and program number to which you want to assign an event, and click that line.

This list lets you select the event (scene recall / effect library recall) assigned to each program number.



The list contains the following columns.

- **CH/BANK (Channel/Bank)**

In Multi mode, or in Single mode when the BANK ON/OFF button is off, the value in this column indicates the MIDI channel on which program changes are transmitted and received.

In Single mode when the BANK ON/OFF button is on, the value in this column indicates the bank number.

- **PGM No. (Program number)**

Indicates the program number 1-128.


- **LIBRARY NAME**

In this column you can view/select the type and the number of the event assigned to each channel (bank)/program number.

Use the scroll bar at the right to display the desired channel (bank) and program number, and click that line; the line you click will move to the center and will be highlighted.

- 6** Click the button in the LIBRARY NAME column of the currently selected line to open the MIDI PGM CHANGE window.

In this window you can select the type of event (a scene, or a library item for effect 1-8) and its number.



Event type                      Scene/library number

In the list at the left, select the type of event. In the list at the right, select the scene/library number that will be recalled. The following types of event can be selected in the list at the left.

<b>NO ASSIGN</b>	No event is assigned
<b>SCENE</b>	Scene memory recall
<b>EFFECT 1-8</b>	Recall an effect library item into an internal effect module 1-8

- When you have finished making settings, click the OK button in the MIDI PGM CHANGE window.
- Assign events to other program numbers in the same way.

With these settings, executing the specified event on the PM5D will cause a program change (or bank select + program change) message to be transmitted to the external device.

When an external device transmits a program change (or bank select + program change) message on the appropriate channel, the event assigned to that program number will be executed.

#### Hint

- You can use the CLEAR button above the list to erase all assignments to program numbers. The PRESET button will return all program number assignments to their default state.
- The contents of the program change table are not saved in the scene. If desired, you can save this data on a memory card as a MIDI PGM TABLE.

#### Note

If more than one program number is assigned to a single scene, only the lowest-numbered program change will be transmitted in Single mode, and in Multi mode the lowest-numbered program change for each channel will be transmitted.

## Using control changes to control events


You can use MIDI control change messages to control specified events (fader/encoder operations, key on/off operations etc.) on the PM5D. This capability can be used to record fader and key operations on a MIDI sequencer or other external device, and play back this data later.

You can use control changes to control events in either of the following two ways.

- Using control change numbers 1-119**  
This method uses the common variety of control change messages. You can freely assign an event to each control number.
- Using NRPN (Non Registered Parameter Number)**  
This method uses a special type of control change messages called NRPN. NRPN uses control change numbers 99 and 98 to specify the MSB (Most Significant Byte) and LSB (Least Significant Byte) of the parameter number, and subsequently-transmitted control change messages of control change number 6 (or 6 and 38) to specify the value of that parameter.  
The event specified by each combination of MSB and LSB is fixed.

- Connect the MIDI OUT connector of the external device to the PM5D's MIDI IN connector. Connect the MIDI OUT connector of the PM5D to the MIDI IN connector of the external device.

- In the DISPLAY ACCESS section, press the [MIDI/REMOTE] key several times to access the MIDI CTRL CHANGE screen shown below.



In the MIDI CTRL CHANGE screen you can select the port used to transmit/receive MIDI messages, and how control changes will be transmitted and received. If control change 1-119 is selected as the transmission/reception method, you can assign the desired event to each control number.

- In the CONTROL CHANGE SETUP area at the left of the screen, you can select the way in which control changes will be transmitted and received, and switch reception and transmission on/off.

The MODE area of CONTROL CHANGE SETUP lets you choose one of the following as the way in which control changes will be transmitted and received.



<b>NRPN</b>	If this button is on, PM5D parameters will be transmitted/received as NRPN messages.
<b>TABLE [SINGLE]</b>	If this button is on, PM5D parameters will be transmitted/received as control change messages on a single MIDI channel according to the assignments in the list at the right side of the screen.
<b>TABLE [MULTI]</b>	If this button is on, PM5D parameters will be transmitted/received as control change messages on multiple MIDI channels according to the assignments in the list at the right side of the screen.

You can use the buttons in the Tx (transmission) area and Rx (reception) area to turn control change transmission/reception on/off.

- In the MIDI SETUP area at the upper left of the screen, select the port used to transmit/receive control changes, and the MIDI channel used for transmission and reception.

In MIDI SETUP, the MIDI PORT settings let you select the port used for MIDI control change transmission/reception; you have the following choices.



<b>MIDI</b>	The rear panel MIDI IN/OUT connectors
<b>USB</b>	The rear panel USB connector
<b>SLOT 1-4</b>	An I/O card installed in rear panel slot 1-4

Click the [←] / [→] buttons at the left and right of the Tx box (transmission) or Rx box (reception) to change the setting, and press the [ENTER] key to finalize the setting. If you select USB or SLOT 1-4, use the box at the right to specify the port number (1-8) as well.

If TABLE [SINGLE] or NRPN are selected as the control change transmission/reception method, use MIDI CH field to choose the MIDI channel used for transmission and reception.

**Hint**

The MIDI port and MIDI channel used for control change transmission/reception can also be specified from the MIDI SETUP screen (→ p.171).

- If TABLE [SINGLE] or TABLE [MULTI] are selected as the control change transmission/reception method, use the list in the right of the screen to display the MIDI channel and control number to which you want to assign an event, and click that line.

In this list you can select the event (fader/encoder operation, key operation, etc.) that will be assigned to each control number. The list contains the following columns.


- CH (Channel)**  
Indicates the MIDI channel on which the control change is transmitted/received.

**Note**

You can use this column to specify multiple MIDI channels even if TABLE [SINGLE] is selected as the transmission/reception method. However in actuality, only the MIDI transmit/receive channel selected in the MIDI SETUP field will be valid.

- CTRL No. (Control number)**  
Indicates the control number 1-119. You cannot make settings for numbers 0, 32, or 96-101.
- CTRL CHANGE EVENT (Library name)**  
Indicates/selects the type of event assigned to the corresponding channel / control number.  
Use the scroll bar at the right to display the desired channel and control number, and click that line; the line you click will move to the center and will be highlighted.

- Click the [↵] button in the CTRL CHANGE EVENT column of the currently selected line to open the MIDI CTRL CHANGE window, and specify the parameter that you want to assign. In this window you can specify the parameter in three levels (mode, parameters 1/2).



- When you have finished making settings, click the OK button in the MIDI CTRL CHANGE window.

- Assign events to other control numbers in the same way.

When you operate the parameters you assigned on the PM5D, control change messages will be transmitted to external devices.

Similarly, if the corresponding control change messages are sent from an external device on the appropriate channel, the parameters assigned to those control numbers will change.


## Hint

- You can use the CLEAR button above the list to erase all assignments to control numbers. The PRESET button will return all control number assignments to their default state.
- The contents of the control change table are not saved in the scene. If desired, you can save this data on a memory card as a MIDI CTRL TABLE.

## Using the MIDI Remote function

“MIDI Remote” allows you to assign MIDI messages to the controllers (faders, encoders, CH [ON] keys, ENCODER [ON] keys) of the INPUT/ST IN channel strips so that these MIDI messages will be transmitted when you operate these controllers. This capability can be used for remote control of external MIDI devices such as synthesizers, or to control the parameters of DAW software or a HDR unit.

While the MIDI Remote function is active, INPUT channel strip 1–24 functions as MIDI remote channels 1–24, and ST IN channel strip 1–4 functions as MIDI remote channels 25–28.



To each controller you can assign a MIDI message consisting of up to sixteen bytes of hexadecimal data. If desired, you can specify that a value within the message varies according to the movement of the controller.

### Assigning MIDI messages to controllers


Here’s how to specify the MIDI port used by the MIDI Remote function, and assign a MIDI message to the desired MIDI remote channel.

- 1 In the DISPLAY ACCESS section, press the [MIDI/REMOTE] key several times to access the MIDI SETUP screen shown below.

#### MIDI SETUP




- 2 In the MIDI REMOTE area at the right of the screen, select one of the following as the port from which MIDI messages will be output for each of the four MIDI Remote banks (BANK A–D).




MIDI	The rear panel MIDI OUT connector
USB	The rear panel USB connector
SLOT 1–4	An I/O card installed in rear panel slot 1–4

Click the / buttons at the left and right of each box to change the setting, and press the [ENTER] key (or click within the box) to finalize the setting. If you select USB or SLOT 1–4, use the box at the right to specify the port number (1–8) as well.

- In the DISPLAY ACCESS section, press the [MIDI/REMOTE] key several times to access the MIDI REMOTE screen shown below.



- In the BANK SELECT area at the upper right of the screen, use the A–D buttons to select the bank you want to use. The bank name is displayed above buttons A–D. You can change the name by clicking the button at the left of the bank name.




- In the upper left of the screen, set the TRANSMIT ENABLE/DISABLE button to ENABLE. Transmission will be enabled for the selected bank. (You can enable/disable transmission for each of the four banks.)
- Use the channel select area at the left of the screen to select the MIDI remote channel to which you want to assign a MIDI message. These buttons correspond to the following channel strips.

REMOTE CH 1–24	INPUT channel strip 1–24
REMOTE CH 25–28	ST IN channel strip 1–4

When you click the [L] / [R] buttons at the left and right of the box, the corresponding name is displayed in the box at the right. You can change the name of the MIDI remote channel by clicking the [L] button of the box at right.

- Use the MIDI message boxes in the lower part of the screen to specify a MIDI message for each controller of the channel. The lower part of the MIDI REMOTE screen contains MIDI message boxes that let you assign a MIDI message to the ENCODER [ON] key, encoder, CH [ON] key, and fader.



You can assign a MIDI message to a controller in any of the following three ways.

- Directly inputting hexadecimal values**  
In this method you directly input the message as hexadecimal values. To use this method, click the [L] button at the left edge of the desired MIDI message box to open the MIDI REMOTE SETUP window.




In this window you can input a message by clicking the desired input box to select it (the box will be highlighted) and turning the [DATA] encoder. You can use the [INC]/[DEC] keys to move the selected position. You can input the following values.

Value	Available assignments	Content
00(H)–FF(H)	All	The MIDI message that is transmitted (hexadecimal).
END	All	Indicates the end of the MIDI message. When you operate the corresponding controller, the MIDI message from the beginning until immediately before END will be transmitted.
SW	All	Indicates the on/off status of the encoder [ON] key or the channel [ON] key. A value of 7F(H) is transmitted when the key turns on, and a value of 00(H) is transmitted when the key turns off. If this is assigned to an encoder or fader, the current value of the key will be transmitted when the encoder or fader is operated.
ENC	ENCODER ON/ ENCODER	Indicates the current position of the encoder. If assigned to an encoder, a value of 00–7F(H) is transmitted when the encoder is operated. If assigned to an encoder [ON] key, the current value of the encoder is transmitted when the key is switched on.
FAD	CH ON/ FADER	Indicates the current position of the fader. If the message is assigned to a fader, this value is transmitted as a value of 00–7F(H) when the fader is operated. If assigned to a CH [ON] key, the current value of the fader is transmitted when the key is switched on.

If you set a value to SW, ENC, or FAD, that value will be linked to the state of the controller. For example if you have made settings as shown in the following screen, the last value will be linked with the fader position, and will change in the range of 0–127.




When you click a box in which a hexadecimal value has been input, the range of values that can be interpreted as a valid MIDI message (including that box) will turn red. The lower part of the screen shows the MIDI channel (MIDI CH), message type (TYPE), and data values (DATA 1, DATA 2) for this MIDI message, letting you verify that the appropriate MIDI message has been input.



You can use the following buttons to input or edit the message in this window.

	Move the highlighted area to left or right.
<b>INS button</b>	Inserts a space (blank) at the highlighted position. Pressing the <Insert> key of a PS/2 keyboard will produce the same result.
<b>DEL button</b>	Deletes the character at the highlighted position. Pressing the <Delete> key of a PS/2 keyboard will produce the same result.
<b>CLEAR button</b>	Erases the entire message that was input in the MIDI message input boxes.
<b>PASTE button</b>	Pastes the message that was copied to buffer memory by the COPY button.
<b>COPY button</b>	Copies the message from the MIDI message input box to temporary buffer memory. Use this in conjunction with the PASTE button to copy a message from one controller to another bank or controller.

When you have finished inputting data in the MIDI REMOTE SETUP window, click the OK button. The hexadecimal values will be input in the MIDI message box of the MIDI REMOTE screen.




Hexadecimal values that were input

## ② Specifying the type of message

In this method you specify the desired MIDI channel, type of message, and data value; these will be converted into the appropriate hexadecimal values. Access the MIDI REMOTE SETUP window in the same way as for method ①, and click the first box into which you want to input data.

Next, click the / buttons at the left and right of the TYPE box to select the type of message.



Type of message


Then use the MIDI CH, DATA 1, and DATA 2 boxes to specify the MIDI channel and various values. The values that can be selected in the MIDI CH, DATA 1, and DATA 2 boxes will depend on the type of message you selected first.

TYPE	MIDI CH	DATA 1	DATA 2
NOTE OFF	1–16	Note number (0–127)	Note-off velocity (0–127)
NOTE ON			Note-on velocity (0–127)
KEY PRESSURE			Pressure value (0–127)
CONTROL CHANGE		Control number (0–127)	Controller value (0–127)
PROGRAM CHANGE		Program number	—
CHANNEL PRESSURE		Pressure value (0–127)	—
PITCH BEND	Pitch bend MSB (0–127)	Pitch bend LSB (0–127)	—
EXCLUSIVE MESSAGE	—	—	—

If you set the DATA 1 or DATA 2 value to SWITCH, ENCODER (available only for encoders), or FADER (available only for faders), that value will be linked with the state of the controller.

When you have specified all of the values, click the “↑ ENTER” button in the screen; the hexadecimal values for that message will be input in the input box of the MIDI REMOTE SETUP window. As necessary, you can edit the message by clicking an input box and turning the [DATA] encoder.

Hexadecimal values that were input



### ③ Using the LEARN button

The LEARN button lets you assign a MIDI message to a controller by receiving that message from an external device. To use the Learn function, go to the MIDI REMOTE screen and click the LEARN button in for the controller to which you want to assign a message.



#### Note

- Only one LEARN button can be turned on simultaneously.
- The LEARN button is valid only for the MIDI remote channel that is currently selected. Also, you cannot change the MIDI remote channel while this button is on.
- The LEARN button is turned off automatically when you switch to a different screen.

If a MIDI message is received at a MIDI port available for the current bank while the LEARN button is on, the received message will be input to the MIDI input box. The following screen shows an example of when the modulation wheel (control change #1) of a synthesizer is operated.



#### Hint

- MIDI messages assigned using the LEARN button can be a maximum of 16 bytes long (the 17th and subsequent bytes are discarded). If the message is less than 16 bytes long, END will be placed immediately after the last data value.
- If a control change is received, the third byte will automatically be replaced by FAD (if the assignment destination is a fader), ENC (if the assignment destination is an encoder), or SW (if the assignment destination is an encoder [ON] or CH [ON] key).
- If multiple messages are received while the LEARN button is on, the last-received message will be used. If the status byte is omitted from the last message, the appropriate status byte will be supplied.

### 8 Assign messages to other MIDI remote channels or other banks in the same way.

If a specific byte is set to “SW” for the ENCODER [ON] key or CH [ON] key, use the LATCH button to select one of the following behaviors.

- **If the LATCH button is on**  
The on/off status will change each time you press the key (Latched). If you press the key from the Off state, a MIDI message with 7F(H) as the SW value will be transmitted, and when you press the same key once again a MIDI message with 00(H) as the SW value will be transmitted.
- **If the LATCH button is off**  
The switch will be on only while you are holding it down, and will turn off when you release it (Unlatched). The moment you press the key, a MIDI message with 7F(H) as the SW value will be transmitted; the moment you release the key, a MIDI message with a SW value of 00(H) will be transmitted.

If a specific byte is set to “ENC” (or “FAD”) for the ENCODER [ON] key or CH [ON] key, use the LATCH button to select one of the following behaviors.

- **If the LATCH button is on**  
If you press the key from the Off state, a MIDI message with the current value of the encoder (or fader) as the ENC (or FAD) value will be transmitted, and when you press the same key once again a MIDI message with 00(H) as the ENC (or FAD) value will be transmitted.
- **If the LATCH button is off**  
The moment you press the key, a MIDI message with the current value of the encoder (or fader) as the ENC (or FAD) value will be transmitted, and the moment you release the key a MIDI message with 00(H) as the ENC (or FAD) value will be transmitted.


#### Note

If SW/ENC/FAD are not specified as the last byte of the MIDI message, the same MIDI message will be transmitted when the key is turned on or off. (The same message will be transmitted when the key is turned off.)

## Using MIDI remote channels

Here's how to recall banks A–D to which you assigned MIDI messages, and operate MIDI remote channels.

- 1 In the DISPLAY ACCESS section, press the [MIDI/REMOTE] key several times to access the following MIDI REMOTE screen.



- 2 In the BANK SELECT area at the upper right of the screen, use the A–D buttons to select the bank you want to use.
- 3 In the upper middle of the screen, use the ASSIGN TO CH STRIP SECTION buttons to select the MIDI remote channel you want to control. (Multiple simultaneous selections are allowed.)




<b>INPUT CH</b>	INPUT channel strip 1–24
<b>STIN/FXRTN</b>	ST IN/FX RTN channel strip 1–4

This setting applies to all four banks.

Turning on a button will enable the MIDI Remote function; the corresponding channel strip will function as MIDI remote channels. (The usual function of the controllers will be disabled.)

At this time, the lower part of the display will indicate “REMOTE” in the encoder/fader mode area. The INPUT CH layer and ST IN/FX RTN layer indications will change to the corresponding MIDI remote channel.



- 4 Operate the appropriate channel strip. MIDI messages will be transmitted from the corresponding MIDI port.

- 5 To disable the MIDI Remote function, turn off the ASSIGN TO CH STRIP SECTION buttons.

### Note


- When the MIDI Remote function is enabled, the controllers will return to their normal state if you switch to another screen. However when you come back to the MIDI REMOTE screen, the remote function of the controllers will be enabled.
- The controller values during MIDI Remote operation are included in the scene data. This means that when you recall a scene, the controller values will change and MIDI messages will be transmitted. Recall Safe settings can also be applied to the MIDI Remote function

# Transmitting MIDI events when you switch scenes

You can register a desired MIDI message for each scene in scene memory so that this message will be transmitted from the MIDI OUT connector when you recall the scene. For example you can use this to switch programs on an external MIDI-compatible effect processor when the scene changes.

- 1 Connect the MIDI OUT connector of the PM5D to the MIDI IN connector of the external device.
- 2 In the DISPLAY ACCESS section, press the [SCENE] key several times to access the SCENE screen shown below.

**SCENE**




- 3 Scroll the scene list upward or downward to select the scene number for which you want to assign a MIDI event.
- 4 Scroll the scene list toward the right to display the MIDI EVENT column.



MIDI EVENT column

In the MIDI EVENT column you will input the MIDI message that will be transmitted when you recall that scene.


- 5 Click the button at the left edge of the MIDI EVENT column to open the MIDI EVENT SETUP window.



- 6 Use the MIDI EVENT SETUP window to specify the MIDI message that will be linked with that scene.

The procedure for specifying a MIDI message in the MIDI EVENT SETUP window is the same as in the MIDI REMOTE screen MIDI REMOTE SETUP window, with the exceptions that you cannot select FAD, ENC, or SW for the DATA 1/DATA 2 boxes, and that there is no LEARN button. (For details, refer to p.118) When you have finished making settings, click the OK button in the MIDI EVENT SETUP window.

- 7 Click the Tx ON/OFF column located at the right of the MIDI EVENT column to turn it on. The MIDI event linked to the corresponding scene is now enabled.




- 8 In the same way, specify MIDI events for other scene numbers.
- 9 Recall a scene to which a MIDI event is linked. The MIDI message will be transmitted from the specified MIDI port.

# Using GPI (General Purpose Interface)

The GPI connector on the rear panel can be used as a GPI (General Purpose Interface) input/output connector. This connector provides four GPI IN ports and twelve GPI OUT ports. For example you can use an external switch or joystick to control the PM5D's parameters, or conversely use the PM5D's keys and faders to send control signals to an external device.

The following diagram is an example of an external circuit that can operate GPI via the GPI connector. (For specifications of the GPI connector pins, refer to the Appendices p.348 and p.355 at the end of the manual.)




This circuit uses four switches (GPI 1–GPI 4) to switch the GPI IN ports between active and inactive. If the polarity of a GPI OUT port is set to Low Active, and you operate the PM5D to make the GPI OUT port Active, the corresponding LED in the above circuit (GPO 1–GPO 12) will light. (If the polarity of the GPI OUT port is High Active, the LED will go dark.)

## Using GPI IN

You can use the GPI IN ports of the GPI connector to control PM5D parameters from an external device. For example you can use an external switch to turn the PM5D's talkback on/off or to operate its Tap Tempo function, or you can use a joystick to control surround panning.


- 1 Connect an external device to the PM5D's GPI connector.
- 2 In the DISPLAY ACCESS section, press the [MIDI/REMOTE] key several times to access the GPI screen shown below.



In this screen, the upper list is used to make GPI IN settings and the lower list is used to make GPI OUT settings.

- 3 In the POLARITY column of the GPI IN list, select the polarity of each GPI IN port. You can select one of the following as the polarity for a GPI IN port.
  - **L** (Low active)  
When controlling an on/off switch-type parameter, the port will become active when the switch is grounded. When controlling a continuously-variable parameter, that parameter will be at its maximum value when the voltage is at low level (by default, 0V), and at its minimum value when the voltage is at high level (by default, approximately 5V).
  - **H** (High active)  
When controlling an on/off switch-type parameter, the port will be active when the switch is opened or when a high-level voltage is input.

When controlling a continuously-variable parameter, that parameter will be at its minimum value when the voltage is at low level, and at its maximum value when the voltage is at high level.




While the GPI screen is displayed, the GPI IN status column of the GPI IN area will show a yellow bar graph to indicate the approximate value of the voltage being input to each port. (If the bar is not shown, the voltage is grounded; if the bar is displayed all the way to the right edge, the voltage is at high level.)

**Hint**

The voltage value at which the PM5D detects High or Low level can be adjusted to suit the external controller (except for external switches) you are using (➔ p. 125).

- At the left edge of the FUNCTION column, click the button to open the GPI IN PORT ASSIGN window.



In the GPI IN PORT ASSIGN window you can select the PM5D function that will be controlled by each GPI IN port.

Use the FUNCTION column to select the type of function, and use the PARAMETER column to select the optional parameters. You can select the following functions and parameters.

FUNCTION	PARAMETER	PM5D operation
NO ASSIGN	—	No assignment
MONITOR	DIMMER ON	Switches the Dimmer function on/off
	SOURCE = [monitor source name]	Switches the monitor source
	MONO ON	Switches the Monitor section [MONO] key on

FUNCTION	PARAMETER	PM5D operation
TALK-BACK ON	LATCH	Switches the Talkback function on/off (latched operation)
	UNLATCH	Switches the Talkback function on/off (unlatched operation)
CH ON-LATCH	[channel name]	Switches the channel on/off (latched operation)
CH ON-UNLATCH	[channel name]	Switches the channel on/off (unlatched operation)
FADER LEVEL	[channel name]	Modifies the fader value (LEVEL parameter) according to the voltage
SURROUND PAN	FRONT-REAR PAN [SEL]	Modifies the surround panning (front/rear) of the selected channel according to the voltage
	LEFT-RIGHT PAN [SEL]	Modifies the surround panning (left/right) of the selected channel according to the voltage
	FRONT-REAR PAN [ODD]	Modifies the surround panning (front/rear) of the selected odd-numbered channel according to the voltage
	LEFT-RIGHT PAN [ODD]	Modifies the surround panning (left/right) of the selected odd-numbered channel according to the voltage
	FRONT-REAR PAN [EVEN]	Modifies the surround panning (front/rear) of the selected even-numbered channel according to the voltage
	LEFT-RIGHT PAN [EVEN]	Modifies the surround panning (left/right) of the selected even-numbered channel according to the voltage
USER DEFINED KEY FUNCTION	[User Defined key bank / key number]	While the external input is active, executes the same operation as when the selected User Defined key is pressed
USER DEFINED KEY LED	[User Defined key bank / key number]	While the external input is active, lights the LED of the selected User Defined key
PEAK HOLD ON		Switches the Peak Hold function on/off
OSCILLATOR ON	—	Switches the Oscillator on/off
SOLO ON		Switches the Solo function on/off

After you have specified the function and parameter, click the OK button.

**Note**

- If latched operation is selected, the port will change between active/inactive each time a trigger is input from an external switch. In this case, we recommend that you use a non-locking type of external switch.
- If unlatched operation is selected, the port will be active only while the signal from the external switch stays at high level or low level. In this case, we recommend that you use either a non-locking or a locking type of external switch as appropriate for your situation.

### 5 Specify the function and parameter for other GPI IN ports in the same way.

With these settings when you operate an external device to make the GPI IN port active, the corresponding PM5D function will be executed. (If a continuously-variable parameter is assigned, the parameter value will vary according to the change in voltage.)

#### Hint

*The settings in the GPI screen apply to all scenes. These settings can also be saved on a memory card as SETUP data.*

## Calibrating the GPI IN ports


If necessary, the voltage values at which the PM5D detects Low and High levels can be adjusted appropriately for the voltage of the signals being input from the GPI IN port.

You can use this to set the variable range of a PM5D parameter to match the range of voltage change produced by a continuously-variable controller (such as a joystick).

- 1 Connect an external device to the PM5D's GPI connector.
- 2 In the DISPLAY ACCESS section, press the [MIDI/REMOTE] key several times to access the GPI screen.
- 3 In the GPI IN MONITOR area at the upper right of the screen, select the GPI IN port that you want to calibrate.

If you are calibrating a two-dimensional controller such as a joystick, click the ◀ / ▶ buttons at the left and right of the X-AXIS and Y-AXIS fields to specify the two GPI IN ports.

If you are calibrating only one GPI IN port, set one of them to "----" (no assignment).



When you specify a GPI IN port, the voltage from that GPI IN port is indicated by a yellow ☉ symbol in the GPI IN monitor area. In this case, the horizontal position (X-axis) corresponds to the voltage of the GPI IN port selected in the X-AXIS field, and the vertical position (Y-axis) corresponds to the voltage of the GPI IN port selected in the Y-AXIS field.

The red line (or red square) displayed in the GPI IN monitor area indicates the range between High level and Low level for the GPI IN ports corresponding to the Y-axis and X-axis.

#### Hint

*If necessary, you can click the REVERSE button to invert the Low level and High level of the input signal. (The result is the same as switching the POLARITY setting of the GPI IN port.)*

### 4 Turn on the CALIBRATION button.

The red line (or red square) in the GPI IN monitor area will temporarily disappear, and only the yellow ☉ symbol will remain.

### 5 If you are calibrating only one GPI IN port, vary the voltage of the signal being input to the GPI IN port specified in step 3 from the maximum value to the minimum value.

The yellow ☉ symbol will move up/down or left/right as the voltage changes. The red line will extend according to this change, and the maximum and minimum voltage values for the corresponding GPI IN port will be stored.

### 6 If you are calibrating a joystick, move the joystick through a 360-degree path.

The yellow ☉ symbol will rotate. The red square will broaden accordingly, and the maximum and minimum voltage values of the GPI IN ports corresponding to the X-axis and Y-axis will be stored.

### 7 Turn off the CALIBRATION button.

The maximum and minimum voltage values detected will be remembered as the reference values for the High and Low levels. (When controlling a continuously variable parameter, the maximum value and minimum value of that parameter will be aligned with these reference values.)

#### Hint

*The results of calibration apply to all scenes. They are also preserved even when the PM5D is powered-off.*


## Using GPI OUT

Here's how you can use the GPI OUT ports of the GPI connector to control an external device from the PM5D's faders or keys.

- 1 To the PM5D's GPI connector, connect the external device that you want to control from the PM5D.
- 2 In the DISPLAY ACCESS section, press the [MIDI/REMOTE] key several times to access the GPI screen.
- 3 In the POLARITY column of the GPI OUT area, select the polarity of the signal that is output from each GPI OUT port.

The POLARITY column of the GPI OUT area selects one of the following two settings as the polarity of the signal that is output when the GPI OUT port becomes active.

-  (Low active)  
Grounded when the GPI OUT port is active.
-  (High active)  
Open when the GPI OUT port is active.



- 4 In the GPI OUT area, use the FADER START, USER DEFINED KEYS, and TALLY columns to select the PM5D function for GPI OUT ports 1 through 12.

When an operation selected here is executed on the PM5D, the corresponding GPI OUT port will become active, and a control signal will be output.

For each GPI OUT port you can select the following three functions (multiple selections are allowed).


### □ FADER START

A fader operation on the PM5D will be the trigger for outputting a signal from the GPI OUT port.

To edit the setting, click the  button at the left to open the GPI OUT PORT ASSIGN window, and select the fader mode (trigger detection method) and channel. You can select the following fader modes.

- **FADER START**  
A control signal (trigger signal) 250 msec long will be output when the fader of the selected channel moves from  $-60$  dB or below to above  $-60$  dB.
- **FADER STOP**  
A control signal (trigger signal) 250 msec long will be output when the fader of the selected channel reaches  $-\infty$  dB.
- **FADER TALLY**  
A control signal will be output when the fader of the selected channel moves from  $-60$  dB or below to above  $-60$  dB. This control signal will be held until the fader reaches  $-\infty$  dB (or until that GPI OUT port receives a different trigger).

The following illustration shows how the output signal from the GPI OUT port changes when you operate a fader in each of the fader modes. (This illustration shows operation when  is selected as the POLARITY of the GPI OUT port. If POLARITY is , the polarity of the output signal will be the opposite.)



### Note

When the voltage is at High level, the output signal of the port will be open. If the receiving device requires High level, it can be taken from the +5 power supply pin. However in this case there is a limitation on the current flow; for details, refer to the Appendices at the end of this manual.

## ❑ USER DEFINED KEYS

Operation of a User Defined key on the PM5D will be the trigger for outputting a signal from the GPI OUT port.

To edit the setting, click the  button at the left to open the GPI OUT PORT ASSIGN window; from the list, select the User Defined key bank (A–D) and number (1–25), and choose the trigger mode (how the trigger will operate when the key is pressed). You can choose one of the following trigger modes.


- **LATCH**

Alternate between active and inactive each time the key is pressed.

- **UNLATCH**

Active only while the key remains pressed.

The following illustration shows how the output signal from the GPI OUT port changes when you operate a User Defined key in each of the trigger modes. (This illustration shows operation when  is selected as the POLARITY of the GPI OUT port. If POLARITY is , the polarity of the output signal will be the opposite.)



## ❑ TALLY (other)

Other operations on the PM5D will be the trigger for outputting a signal from the GPI OUT port. When the corresponding operation is executed on the PM5D, a control signal will be output. This control signal will be held until you defeat the above operation (or until that GPI OUT port receives a different trigger).

To edit the settings, click the  button at the left to open the GPI OUT PORT ASSIGN window, and select one of the following functions.

Function	PM5D operation
<b>NO ASSIGN</b>	No assignment
<b>POWER ON</b>	The PM5D's power is turned on
<b>SOLO ON</b>	[SOLO] key is turned on
<b>GPI IN 1 FUNCTION</b>	The function assigned to GPI IN port 1 becomes active
<b>GPI IN 2 FUNCTION</b>	The function assigned to GPI IN port 2 becomes active
<b>GPI IN 3 FUNCTION</b>	The function assigned to GPI IN port 3 becomes active
<b>GPI IN 4 FUNCTION</b>	The function assigned to GPI IN port 4 becomes active
<b>PREVIEW ON</b>	SCENE MEMORY section [PREVIEW] key is turned on
<b>CUE ON [INPUT ONLY]</b>	Input channel [CUE] key is turned on
<b>CUE ON [DCA ONLY]</b>	DCA [CUE] key is turned on
<b>CUE ON [OUTPUT ONLY]</b>	Output channel [CUE] key is turned on
<b>CUE ON</b>	Any [CUE] key is turned on

## 5 Make settings for other GPI OUT ports in the same way.

With these settings, executing an operation assigned to the GPI OUT port will output a control signal according to the POLARITY setting.

You can use the TEST buttons in the GPI OUT area to check the operation of the GPI OUT ports. When a TEST button is on, the corresponding GPI OUT port will become active, and a control signal will be output.


The GPI OUT status column indicates the status of the output signal of the corresponding port. The characters L/H indicate the Low or High level of the signal. The background color is yellow when active, and gray when inactive.

# 17 Using memory cards

This chapter explains how to save/load PM5D internal data using a memory card.

## Using memory cards with the PM5D

You can insert a commercially available memory card into the memory card slot located on the front panel of the PM5D, and use it to save or load various types of data.



You can use PCMCIA Type II PC flash ATA cards, or CompactFlash media inserted in a PC card adaptor. (In either case, media with a power supply voltage of 3.3V or 5V is supported.) Normally, these cards are sold in an already-formatted state. This means that you won't need to format them before using them with the PM5D. If you do need to format a card, use a computer or other external device to format the card in FAT16 format.


### Note

Operation is not guaranteed for any type of media other than described above.

## Saving files to a memory card

Here's how to save individual items of data (or all data) from the PM5D onto a memory card.

- 1 Insert the memory card into the memory card slot located on the front panel of the PM5D. You may insert or remove cards while the PM5D is powered-on.
- 2 In the DISPLAY ACCESS section, repeatedly press the [UTILITY] key to access the SAVE screen.



In the left side of the SAVE screen you can select the save mode and the item(s) that will be saved. The file list in the right side of the screen contains four columns; FILE NAME, TYPE, DATE/SIZE, and COMMENT. This list shows the files and directories on the memory card. (To see the COMMENT column, scroll the list toward the right.)

- 3 In the MODE area, click the BASIC button to select BASIC as the save mode. If BASIC mode is selected, you can choose the desired item (or all items) and save them to a memory card.

### Hint

The other save modes provided are ADVANCED mode which lets you save scene memories or libraries under different numbers, and CSV EXPORT mode which lets you save the names of scene memories or libraries as a CSV format file. For details, refer to the Reference section (➔ p. 193).

- 4 Use the buttons below the MODE area to select the item you want to save. The item whose button is turned on is selected for saving. (You can turn on only one button.) By clicking the ALL DATA button you can select all items at once. These buttons correspond to the following items.

Button	Content
ALL DATA	All items, and the contents of the current scene
SCENE MEMORY	Contents of scene memory
LINKED LIBRARY	Libraries linked to the scene (available only if the SCENE MEMORY button is on)
HA	Contents of the HA library
INPUT PATCH	Contents of the input patch library
OUTPUT PATCH	Contents of the output patch library
INPUT CH	Contents of the input channel library
OUTPUT CH	Contents of the output channel library
INPUT EQ	Contents of the input EQ library
OUTPUT EQ	Contents of the output EQ library
GATE	Contents of the gate library
COMP	Contents of the compressor library
EFFECT	Contents of the effect library


Button	Content
GEQ	Contents of the GEQ library
SETUP	Various settings not saved in a scene
USER DEFINED KEY	User Defined key settings
DCA FADER MODE	DCA fader mode settings
MIDI REMOTE	MIDI remote settings
MIDI PGM TABLE	Contents of the list in the MIDI PGM CHANGE screen
MIDI CTRL TABLE	Contents of the list in the MIDI CTRL CHANGE screen
EVENT LIST	Contents of the list in the EVENT LIST screen

If you select the SCENE MEMORY, HA, INPUT PATCH, or OUTPUT PATCH items, you can specify the starting number and ending number so that only the desired range of scenes or library items will be saved. The LINKED LIBRARY button is available only if the SCENE MEMORY button is on.

#### Hint

The TOTAL SIZE field at the bottom of the MODE area indicates the file size for the selected item(s). The available capacity of the inserted memory card is shown below the file list.

- If you selected scenes or libraries for saving, use the boxes at the right of the button to specify the starting number and ending number.



- As necessary, use the file list to select the directory (folder) in which you will save the data.

If the file list contains a directory below the current level, the TYPE column will indicate "[DIR]."

EVENTPA1	ALL	03/06/2004 04:01:06	196KB
EVENTPA2	ALL	03/06/2004 04:01:44	196KB
HALLSET1	ALL	03/06/2004 04:02:02	196KB
HALLSET2	ALL	03/06/2004 04:02:20	196KB
SETTINGS	[DIR]	03/06/2004 04:03:10	

A directory below the current level

To move to a lower directory, click the directory line to select it (that line will move to the center of the list), and click the directory name shown in the FILE NAME column.

If the file list contains a directory above the current level, it will be shown as "." in the FILE NAME column and "[DIR]" in the TYPE column.

A directory above the current level

..	[DIR]	03/06/2004 04:03:10	
LIVESET1	ALL	03/06/2004 04:02:02	196KB
LIVESET2	ALL	03/06/2004 04:02:20	196KB

To move to a higher directory, click the directory line to select it (that line will move to the center of the list), and click the "." shown in the FILE NAME column.

#### Hint

- The directory currently selected as the save destination is also shown in the FILE PATH field above the list
- If you want to create a new directory in the current location, click the MAKE DIR button below the file list.

#### Note

- The file list can display only up to one hundred items.
- Saving is not possible if the FILE PATH field exceeds 60 characters (including the filename extension).

- After specifying the item to be saved and the save-destination directory, click the SAVE button.

The FILE NAME EDIT window will appear, allowing you to assign a name to the data that will be saved.



- Use the character palette to input a filename, and click the OK button.

A window will ask you to confirm the Save operation.

#### Note

- When assigning a name to a file on a memory card, lowercase alphabetical characters and some symbols in the character palette cannot be used.
- If you paste text copied from another character palette when inputting the file name, all lowercase alphabetical characters will be converted to uppercase.

**9 To execute the Save operation, click the OK button.**

A window will appear, indicating the progress of the Save operation. When saving is completed, the previous screen will reappear. If you click the CANCEL button instead of the OK button, the Save operation will be aborted and you will return to the previous screen.




Do not insert or remove the memory card while it is being accessed. A BUSY indicator at the upper right of the display will light while the card is being accessed.

## Loading files from a memory card

Here's how to load data from a memory card into the PM5D.

- 1 Insert the memory card containing the data you want to load into the memory card slot located on the front panel of the PM5D.**
- 2 In the DISPLAY ACCESS section, repeatedly press the [UTILITY] key to access the LOAD screen.**



The file list shows the following information.

- **FILE NAME column**  
This column shows the names of the files saved on the memory card. If a directory is selected, the directory name is shown.
- **TYPE column**  
This column shows the content that was saved. The indication in the TYPE column will be one of the following.

<b>ALL</b>	A file in which all items were saved
<b>[DIR]</b>	A directory
<b>UNKNOWN</b>	A file that cannot be loaded by the PM5D
<b>Other</b>	A file in which a specific item was saved

**Hint**

For scene memory data, the type can be either "SCENE" in which only scene memory data is saved, and "SCENE+LIB" in which linked libraries are included.

- 3 As necessary, use the file list to specify the load-source directory.**  
Navigation between directories is the same as in the file list of the SAVE screen (➔ p.129). The currently selected directory is also shown in the FILE PATH field above the list
- 4 In the file list, click the line showing the file you want to load.**  
That file will move to the center of the list, and will be highlighted.

EVENTPA1	ALL	03/06/2004	04:01:06	196KB
EVENTPA2	ALL	03/06/2004	04:01:44	196KB
HALLSET1	ALL	03/06/2004	04:02:02	196KB
HALLSET2	ALL	03/06/2004	04:02:20	196KB
SETTINGS	[DIR]	03/06/2004	04:03:10	

FILE NAME column      TYPE column      DATE/SIZE column

- **DATE/SIZE column**  
This shows the date on which the file was last saved, and its size. If a directory is selected, only the date is shown.
- **COMMENT column**  
This shows the comment assigned when the file was saved. To input a comment, scroll the file list horizontally and click the COMMENT column for the currently selected file.

**Hint**

By clicking the headings at the top of the list, you can sort the list in ascending or descending order of that item. The text of the currently selected button will turn red, and an arrow indicating ascending (↑) or descending (↓) order will appear.

**5 In the MODE area, click the BASIC button to select BASIC as the loading mode.**

Similarly to the Save mode in the SAVE screen, you can choose either BASIC, ADVANCED, or CSV IMPORT as the Load mode. If BASIC mode is selected, the item buttons appropriate for the currently selected file will turn on.

**Hint**

- If **ADVANCED** mode is selected, you can specify the range of scenes or library numbers that will be loaded from a scene memory and/or library file saved in BASIC mode or ADVANCED mode.
- If **CSV IMPORT** is selected, you can load CSV files that were saved in CSV EXPORT mode. For details on each mode, refer to the Reference section (➔ p.193).

## Note

---

- If you select a directory in the file list, the Load mode will automatically switch to CSV IMPORT, and the screen will indicate whether that directory contains any CSV files. If you subsequently select any file readable by the PM5D other than a CSV file, the mode will automatically switch to BASIC.
  - If the type of file to be loaded is ALL DATA, the entire contents of the PM5D's scene memories and libraries will be rewritten. Before loading, make sure you are not accidentally overwriting important scenes or library data.
- 

**6** When loading scenes or libraries, you can click the  /  buttons at the left and right of the boxes beside each button to select the scene or library numbers that will be loaded.

**7** Click the LOAD button.

A window will ask you to confirm the Load operation.

**8** To execute the Load operation, click the OK button.

A window will appear, indicating the progress of the Load operation. When loading is completed, the previous screen will reappear.

If you click the CANCEL button instead of the OK button, the Load operation will be aborted and you will return to the previous screen.



---

*Do not insert or remove the memory card while it is being accessed. A BUSY indicator at the upper right of the display will light while the card is being accessed.*

---

# 18 Surround pan

This chapter explains how to use the surround pan functionality.


## About surround pan

“Surround pan” is functionality that, when used with a multi-channel playback system, lets you place the signal of an input channel in two-dimensional space or move the sound image between front/back and left/right. (To move the surround pan image, you can use the mouse, the CURSOR [◀]/[▶]/[▲]/[▼] keys, or the MIX encoders etc.)

The PM5D lets you choose from the following three surround modes, depending on the number of channels in your surround environment.


- **3-1ch**

This mode uses four channels; left and right front, front center, and rear (surround).




- **5.1ch**

This mode uses six channels; left and right front, left and right rear, front center, and subwoofer.



- **6.1ch**

This mode uses seven channels; 5.1ch with the addition of rear center.



### Hint

The surround mode can be selected in the MIXER SETUP screen (SYS/W.CLOCK function) or SURR SETUP screen (MATRIX/ST function).

# Bus configuration and operation in surround mode

When any of the three surround modes (3-1ch, 5.1ch, 6.1ch) are selected, the PM5D's bus configuration and operation will change as follows.

## About the surround buses

While a surround mode is selected, MIX buses 1–8 or MIX buses 9–16 can be used as surround buses. (The choice of whether to use MIX buses 1–8 or MIX buses 9–16 is made in the MATRIX/ST function SURR SETUP screen.)


When you switch the surround mode, the following surround channels will be assigned by default to each of the MIX buses. (You are free to change these assignments subsequently.)

Surround mode MIX bus	3-1ch	5.1ch	6.1ch
MIX bus 1/9	L (Front L)		
MIX bus 2/10	R (Front R)		
MIX bus 3/11	C (Center)	Ls (Rear L)	
MIX bus 4/12	S (Surround)	Rs (Rear R)	
MIX bus 5/13	C (Center)		
MIX bus 6/14		LFE (Subwoofer)	Bs (Rear center)
MIX bus 7/15			LFE (Subwoofer)
MIX bus 8/16			

### Note

MIX buses shaded in gray in this table can be used as conventional MIX buses. However in 6.1ch mode, the MIX 8/16 bus will operate only as FIXED type.


For example when the surround mode is 6.1ch and you have chosen MIX 1–8 to use as the surround buses, the surround pan signal flow will be as follows.



## How the MIX section will operate

When a surround mode is selected, the MIX encoders allocated to surround buses will operate differently than normal. For example if MIX buses 1–8 are being used as surround buses, you can use MIX encoders 1–8 of the MIX section to edit the following parameters.

### ❑ If the MIX section [MIX SEND] key is on




- ① **L ↔ R**  
Moves the surround pan of the selected channel between left and right.
- ② **F ↔ R**  
Moves the surround pan of the selected channel between front and rear.
- ③ **Front divergence (5.1ch and 6.1ch modes only)**  
Adjusts the front divergence (the proportion at which a signal panned to the center will be sent to the front center bus and to the front LR buses) of the selected channel. Front divergence (the DIV F parameter) can be adjusted if 6.1ch mode is being used.
- ④ **Rear divergence (6.1ch mode only)**  
Adjusts the rear divergence (the proportion at which a signal panned to the rear will be sent to the rear center bus and to the rear LR buses) of the selected channel.
- ⑤ **LFE (5.1ch and 6.1ch modes only)**  
Adjusts the send level of the signal sent from the selected channel to the LFE (Low Frequency Effects) bus.

### Hint

- For details on each of the surround pan parameters, refer to SURR PARAM screen (➔ p.283) in the Reference section.
- If MIX buses 9–16 are being used as surround buses, you can use MIX encoders 9–16 to perform the above operations.

- If the MIX section [MIX MASTER] key is on




- ① **Output level**  
The encoders adjust the output level of each surround channel.

## Basic settings for surround buses

Here's how to choose either 3-1ch, 5.1ch, or 6.1ch as the surround mode, and make settings for the MIX buses you will use as surround buses.

- 1 According to the surround mode you intend to use, connect an appropriate playback system to MIX OUT jacks 1–8 or MIX OUT jacks 9–16.
- 2 In the DISPLAY ACCESS section, repeatedly press the [MATRIX/ST] key to access the SURR SETUP screen.

In order to use a surround mode, you will first choose a surround mode, and then specify the MIX buses that will be the surround output destinations.



- 3 Click a button in the SURROUND MODE area to select the desired surround mode.  
When you click a button a window will appear, asking you to confirm that you want to switch the surround mode.

Click the OK button to enable the surround mode you selected. For example if you switch to 6.1ch mode, the screen display will change as follows.



- 4 In the SURROUND BUS ALLOCATION area, press the MIX 1-8 button or the MIX 9-16 button to select the MIX buses you want to use as surround buses.

You can select either MIX buses 1–8 or MIX buses 9–16. When you click a button a window will appear, asking you to confirm that you want to change the MIX bus allocation.

When you click the OK button, the selected MIX buses will be allocated as surround buses, and will be assigned to surround channels according to the current surround mode.

- 5 If you want to change the surround channel assignments, click the [ ] / [ ] buttons at the left and right of each field in the bus assign area, and press the [ENTER] key (or click within the box) to confirm the setting.

When the setting is confirmed, the previously-selected bus and the newly-assigned bus will be exchanged.

### Hint

You can initialize the surround channel assignments by clicking the INIT button located at the right of the bus assign area.

- 6 Use the knobs and buttons in the lower part of the screen to adjust the volume, delay, on/off status, and cue for each surround channel.  
For details on these knobs and buttons, refer to SURR PARAM screen (➔ p.283) in the Reference section.
- 7 In the MIX section, make the [MIX MASTER] key light, and turn on the MIX [ON] keys of all MIX buses that will be used as surround buses.  
The signal of each surround bus is now sent from the corresponding MIX OUT jack.

## Controlling surround pan


Here's how to control surround pan for two adjacent input channels (or ST IN/FX RTN channels L and R).

### Note

- Before you continue with the following procedure, you must select the desired surround mode and connect MIX OUT jacks 1–8 or MIX OUT jacks 9–16 to an appropriate playback system, as described in “Basic settings for surround buses” (➔ p.134).
- If you use 5.1ch or 6.1ch surround mode, connect the LFE (Low Frequency Effects) channel signal to a dedicated subwoofer for the low frequencies. However, simply switching the surround mode does not change the EQ (filter) settings. As necessary, use the EQ (LPF) of the MIX channel assigned to the LFE channel to cut the high-frequency portion of the signal according to the frequency response of the subwoofer you are using.

- 1 In the DISPLAY ACCESS section, repeatedly press the [PAN/ROUTING] key to access the SURR PARAM screen (PAN/ROUTING function).

The SURR PARAM screen always shows surround pan settings for two channels.



- 2 Use the channel selection area to select the input channels whose surround pan settings you want to edit.

Two adjacent odd-numbered/even-numbered channels (or ST IN/FX RTN channels L and R) will be displayed.

- 3 Use the SURROUND BUS ON/OFF buttons located around the surround pan grid to select the surround buses to which the input channel will be sent.

The SURROUND BUS ON/OFF buttons are on/off switches for the signal sent from the input channel to each surround bus.

### Hint

You can do the same thing by pressing a [SEL] key to select an input channel, making the MIX section [MIX SEND] key light, and then turning on the MIX [ON] key for the desired surround buses.

- 4 Use any of the following methods to adjust the surround pan of the selected channel.

- Using the mouse or track pad

Move the pointer into the surround pan grid of the channel you want to control, and drag the yellow O symbol forward/backward/left/right. (The symbol will turn red while you are dragging it.) Alternatively, you can click a desired location within the surround pan grid to move the surround pan to that location.

- Using the pan buttons around the surround pan area

If you want to quickly move the channel signal to the location of a speaker, click one of the pan buttons (e.g., L, R, C) shown around the edge of the surround pan grid.

- Using the CURSOR [◀]/[▶]/[▲]/[▼] keys

Move the cursor to the surround pan grid and press the [ENTER] key; the O symbol will turn red.

In this condition, you can use the CURSOR [◀]/[▶] keys to move surround pan left/right, or the CURSOR [▲]/[▼] keys to move it forward/backward, in a range of eight steps. By performing this operation while holding down the [SHIFT] key, you can quickly move surround pan in a range of 32 steps. To finalize the surround pan adjustment, press the [ENTER] key once again.

• **Using the MIX encoders**

If you turn on the [MIX SEND] key of the MIX section, you can use MIX encoders 1 or 9 to adjust the left/right position of the input channel, and MIX encoders 2 or 10 to adjust the front/rear position. The SURR PARAM screen MIX SECTION ASSIGNMENT area shows the parameters assigned to each MIX encoder.

• **Using MIDI control changes or GPI**

If you assign surround pan parameters to MIDI control changes or GPI, you can use an external device to control surround pan. For details, refer to MIDI CTRL CHANGE screen (➔ p.174) and GPI screen (➔ p.177) in the Reference section.

**5 If you want surround pan operations to be linked for two adjacent channels, turn on the STEREO LINK button, and use the box at right to select the link pattern.**

When you turn on the STEREO LINK button, surround pan will be linked for the two channels shown in the SURR PARAM screen. To specify how they will be linked, select one of the following link patterns by clicking the  /  buttons at the left and right of the box located to the right of the STEREO LINK button.

Pattern 1		The channels will move in the same direction for both the front/rear axis and the left/right axis.
Pattern 2		The channels will move in opposite directions for the front/rear axis, and in the same direction for the left/right axis.
Pattern 3		The channels will move in the same direction for the front/rear axis, and in opposite directions for the left/right axis.
Pattern 4		Left↔right movement of the odd-numbered channel will be linked with rear↔front movement of the even-numbered channel. Front↔rear movement of the odd-numbered channel will be linked with left↔right movement of the even-numbered channel.
Pattern 5		Left↔right movement of the odd-numbered channel will be linked with front↔rear movement of the even-numbered channel. Front↔rear movement of the odd-numbered channel will be linked with left↔right movement of the even-numbered channel.
Pattern 6		Front/rear and left/right movement will both be linked in the opposite direction.
Pattern 7		Left↔right movement of the odd-numbered channel will be linked with front↔rear movement of the even-numbered channel. Front↔rear movement of the odd-numbered channel will be linked with right↔left movement of the even-numbered channel.
Pattern 8		Left↔right movement of the odd-numbered channel will be linked with rear↔front movement of the even-numbered channel. Front↔rear movement of the odd-numbered channel will be linked with left↔right movement of the even-numbered channel.

**6 Edit other parameters as desired.**

In the SURR PARAM screen you can also edit the following parameters.

• **Divergence**

These controls specify the proportion at which the signals are sent to each surround bus when the input channel is positioned in the center. The parameters that are displayed will depend on the surround mode that is currently selected. (For details, refer to p.283)

• **LFE**

This adjusts the output level of the signal sent from the input channel to the LFE (Low Frequency Effect) bus for a subwoofer. You can also use the ON/OFF button to switch the signal sent from the input channel to the LFE bus on/off.

**Hint**

- The master level of each surround bus is shown in the upper right of the screen.
- You can use the SURR VIEW screen to see the surround pan settings of all channels at a glance.

# Notes regarding surround pan

---

Here are some notes and limitations that you should be aware of when using surround pan.

## ❑ Scene recall operations

- The surround mode selection and the surround pan settings of each channel are stored as part of the scene.
- If you recall a scene whose surround mode differs from the current scene, the screen and panel display will change accordingly. The surround mode is recalled regardless of Selective Recall or Recall Safe settings.
- If one channel (of a pair of channels) is excluded from recall, and you recall a scene in which the STEREO LINK button is on, the STEREO LINK button will remain on but only the other channel (of the pair) will be recalled.
- SURROUND BUS SETUP settings (MIX bus 1-8/9-16 selection, and assignments to each surround channel) are not included in the scene data.

## ❑ Channel library recall operations

- Surround pan related parameters for inputs are stored in the input channel library.
- If the STEREO LINK button is on, and you recall input channel library settings, the STEREO LINK button will remain on, but only one channel will be recalled. Subsequent operation will be according to STEREO LINK.

## ❑ Channel copy

- When you copy an input channel using panel operations, surround-related parameters will also be copied.
- In order to copy surround-related parameters using the CH COPY screen (INPUT VIEW function), the ALL button must be turned on in the DESTINATION area.

## ❑ Global paste

- In order to paste surround-related parameters, the ALL button must be turned on in the CURRENT SCENE area of the GLOBAL PASTE screen (SCENE function). In addition, the settings of the STEREO LINK area will also be pasted if two adjacent channels are selected.


# 19 Other functions

This chapter explains other functionality of the PM5D not covered elsewhere.

## Using the user defined keys

You can assign the desired functions to the User Defined keys in the USER DEFINED section of the top panel, and press these keys to execute the defined function.

### Items in the USER DEFINED section



- ① USER DEFINED [1]–[24] keys
- ② USER DEFINED [25] key  
These are User Defined keys that execute the assigned function.

### Assigning functions to the User Defined keys


Here's how to assign the functions that will be executed when the USER DEFINED [1]–[25] keys are pressed.

- 1 In the DISPLAY ACCESS section, press the [UTILITY] key repeatedly to access the USER DEFINE screen shown below.



In this screen you can make User Defined key assignments for each of four banks; A–D.

- 2 In the BANK SELECT area at the upper left of the screen, use the A–D buttons to select the bank you want to use.  
To clear the assignments of the current bank, click the CLEAR BANK button located at the bottom of the BANK SELECT area.
- 3 Click the  button located on the line of the User Defined key you want to assign.  
The USER DEFINED KEY ASSIGN window will appear. In this window you can select a function to assign to the User Defined key, and select option parameters.



- 4 Select the desired function in the FUNCTION column, select parameters in the PARAMETER 1/2 columns, and click the OK button.  
For details on the available functions and parameters, refer to the Reference section (➔ p.189).

## 5 Assign functions to other keys and banks in the same way.

### Hint

The User Defined key assignments are not saved in the scene. If desired, you can save the assignments on a memory card as USER DEFINED KEY data.

## Executing functions assigned to the User Defined keys

Here's how to use the USER DEFINED [1]–[25] keys to execute the functions that have been assigned to them.

- 1 In the DISPLAY ACCESS section, repeatedly press the [UTILITY] key to access the USER DEFINE screen.
- 2 In the BANK SELECT area at the upper left of the screen, use the A–D buttons to select the bank (A–D) you want to use.
- 3 Press a USER DEFINED [1]–[25] key. The function assigned to that key will be executed.


## Using the Fader Assign function

“Fader Assign” is a function that lets you assign the desired channels to the DCA faders 1–8 of the DCA strip in the top panel. For each of six layers A–F, you can specify the channel that is assigned to each fader. For example, you might use this to simultaneously control the send level and return level of an internal effect, or to use a fader as the master fader of a MIX bus or MATRIX bus.

For each layer you can specify the channel that is assigned to each fader, and use the FADER MODE section to switch between layers while you operate the faders.

### Items in the FADER MODE section

In the FADER MODE section you can select the combination of channels or DCA groups that will be controlled by DCA faders 1–8.




- 1 **FADER MODE [A]–[F] keys**  
If one of these buttons is on, DCA faders 1–8 will control the level of the channels assigned for that layer (A–F).
- 2 **FADER MODE [DCA] key**  
If this button is on, DCA faders 1–8 will control DCA groups 1–8.


### Assigning channels to DCA faders

Here's how to assign the desired channels to the DCA faders 1–8 of the DCA strip section.

- 1 In the DISPLAY ACCESS section, repeatedly press the [UTILITY] key to access the FADER ASSIGN screen. In this screen you can select the channel assigned to each fader in each layer A–F.



- 2 Use the channel selection boxes for the desired layer (A–F) to select the channel assigned to each fader 1–8.



To select a channel, click the ◀ / ▶ buttons located at the left and right of each box. You can choose from the following channels.

Item	Selected channel
CH 1–CH48	Input channel 1–48
STIN1L/STIN1R–STIN4L/STIN4R	ST IN channel 1–4 L or R
FXRTN1L/FXRTN1R–FXRTN4L/FXRTN4R	FX RTN channel 1–4 L or R
MIX 1–MIX24	MIX channel 1–24
MTRX1–MTRX8	MATRIX channel 1–8
DCA1–8	DCA fader 1–8

#### Hint

- If an input channel or a DCA fader 1–8 is selected, the channel name is displayed immediately below the channel selection box.
- Input channels and output channels can coexist in the same layer.

- 3 Assign channels to other layers in the same way.

#### Hint

Fader Assign settings are not saved in the scene. If desired, you can save these settings on a memory card as DCA FADER MODE data.

## Controlling the channels assigned to DCA faders

- 1 In the FADER MODE section, use the FADER MODE [A]–[F] keys to select the layer you want to use.

The key LED will light, and the corresponding layer will become active. If input channels are assigned to the DCA faders, the channel names will appear in the name indicators of the DCA strip.

#### Hint

You can also switch layers from within the FADER ASSIGN screen. This screen also shows the values of the DCA faders and their approximate positions.

- 2 Operate the faders of the DCA strip.

The level of the corresponding channels will change. If a channel assigned to a DCA fader is paired (or if one side of a stereo channel is assigned), the level of the other paired channel (or the other side of the stereo channel) will follow.

#### Note

When a FADER MODE [A]–[F] key is on, and channels other than DCA channels are assigned to the DCA faders, the [MUTE] keys of the DCA channel strip are inactive. However, the [CUE] keys can be used to cue-monitor the corresponding channel.

# Locking the PM5D (Security functions)

The PM5D lets you prohibit changes to certain parameters (Parameter Lock), or prohibit operation of the console (Console Lock). For example, this lets you prevent an unauthorized person from operating the console while the engineer is taking a break.

You can also apply password protection to the lock function using a “system password” which is remembered even after power-off, or a “console password” which is cleared when the power is turned off. If you specify a system password, both Parameter Lock and Console Lock are available. If you specify a console password, only Console Lock is available.

## Setting the System Password or Console Password

Here’s how to set the password used for Parameter Lock and Console Lock. However, it is possible to apply the lock function even if a password has not been specified.

- 1** In the DISPLAY ACCESS section, repeatedly press the [UTILITY] key to access the SECURITY screen.




In this screen you can use the SYSTEM PASSWORD and CONSOLE PASSWORD fields located at the left to specify the passwords. (If no password has been specified, the corresponding box will indicate “--FREE--”.)

- 2** To set the system password, click the [OK] button for the SYSTEM PASSWORD field. To set the console password, click the [OK] button for the CONSOLE PASSWORD field.

A window will appear, and you will be asked to input the new password. (The upper left of the window indicates “NEW PASSWORD.”)

As an example, the illustration below shows the SYSTEM PASSWORD CHANGE window where you specify the system password.



### Note

- If a password has already been input, you will be requested to input the old password. (The upper left of the window indicates “OLD PASSWORD.”) In this case, input the existing password and click the OK button before you continue to step 3.
- If you want to return the system to a condition in which a password has not been specified, input the existing password, click the OK button, and then leave the new password field blank when you execute steps 3–5.

- 3** Use the character palette to input a password of up to eight characters in the NEW PASSWORD text box.

The characters you input are displayed as “ \* ” (asterisks).

Any character of the character palette except for SPACE can be used in a password. (The password is case-sensitive; i.e., uppercase and lowercase alphabetical characters are distinguished.) When inputting a password, the COPY, PASTE, SPACE, INS, ←, and → keys of the character palette cannot be used.

- 4** Click the OK button.

The indication in the upper left of the window will change to “RE-ENTER PASSWORD”.

- 5** Input the same password once again, and click the OK button.

The password will be applied, and you will return to the SECURITY screen.


### Note

The console password will be cleared when the PM5D is powered-off. In contrast, the system password is remembered even after the power is turned off. This means that if you forget the system password, you will be unable to defeat Parameter Lock or Console Lock except by initializing the entire memory of the PM5D (→ p.147). Please be careful not to lose the system password.


## Using Parameter Lock or Console Lock

Here's how to lock parameters or the console. You can also lock using the password you specified.

- 1 In the DISPLAY ACCESS section, repeatedly press the [UTILITY] key to access the SECURITY screen.



- 2 If you want to lock only specific parameters, use the buttons of the LOCK PARAMETER SELECT area to select the parameters for which you want to prohibit editing.



When you click a button, a check mark will appear for the selected item. You can select the following items (multiple selections are allowed).

Item	Content
SYSTEM CONFIGURATION	Changes to the settings of the MIXER SETUP screen and CASCADE screen
WORD CLOCK SETUP	Changes to the word clock setting
DITHER	Changes to dither-related settings
INPUT PATCH	Changes to the input patch settings (and names)
OUTPUT PATCH	Changes to the output patch settings
INPUT CH ON/OFF	Input channel on/off operations
OUTPUT CH ON/OFF	Output channel on/off operations
MIX TO ST ON/OFF	MIX TO STEREO button on/off operations
DCA MUTE ON	DCA [MUTE] key On operations (Off operations are not included)

### Note

As long as the PARAMETER LOCK button is on, the above settings cannot be edited. You will need to defeat the lock function before editing them.

- 3 Depending on the items you want to lock, click either the PARAMETER LOCK button or one of the two CONSOLE LOCK buttons.


If a password has been specified, a window will ask you to input the password. If you click the CANCEL button without inputting a password in this window, you will return to the previous screen.



- 4 Input the password you assigned beforehand, and click the OK button.

If you clicked the PARAMETER LOCK button in step 3, a message of "Parameter Locked" will appear briefly, and then editing will be disabled for the selected parameters.

If you clicked the CONSOLE LOCK button in step 3, an indication of "CONSOLE LOCKED" will appear on the screen, and all operations other than pressing the UNLOCK button will be disabled.



- 5 To defeat Parameter Lock, click the PARAMETER LOCK button. To defeat Console Lock, click the UNLOCK button.

If a password has been specified, a window will ask you to input the password. Input the password and click the OK button to defeat the lock function. You will return to the screen in which you were prior to applying the security setting.

### Note

The console password will be cleared when the PM5D is powered-off. In contrast, the system password is remembered even after the power is turned off. This means that if you forget the system password, you will be unable to defeat Parameter Lock or Console Lock except by initializing the entire memory of the PM5D (p.147). Please be careful not to lose the system password.


# Using cascade connections

Buses can be shared by cascade-connecting multiple PM5D units (up to four) or the PM5D with an external mixer (such as the Yamaha DM2000/02R96). When multiple PM5D units are cascade-connected, operations such as scene store/recall, cue/solo, and dimmer can also be linked.

## Making cascade connections

Here we will explain cascade connections and operation, using an example in which two PM5D units are cascade-connected.

To cascade-connect two PM5D units, connect the CASCADE IN connectors and CASCADE OUT connectors of the two units to each other. This allows the MIX bus, STEREO bus, and CUE bus output signals to be transmitted and received between the two units.



If you want operations such as scene store/recall and cue/solo to be linked between the two PM5D units, specify one unit as the cascade master and the other as the cascade slave. (This setting is made in the SYS/W.CLOCK function MIXER SETUP screen.) The PM5D assigned as the cascade master will output control signals (operational signals) via its CASCADE IN connector, and the PM5D assigned as the cascade slave will receive these signals via its CASCADE OUT connector.

### Hint

- If you want to daisy-chain two to four PM5D units (i.e., connect the first unit's CASCADE OUT → second unit's CASCADE IN, and the second unit's CASCADE OUT → third unit's CASCADE IN. Up to four units can be connected.), you should assign the PM5D located last in the chain (the PM5D connected only via its CASCADE IN connector) as the cascade master, and the remaining PM5D units as cascade slaves (➡ p.204).
- If you want to cascade-connect a PM5D with a Yamaha DM2000 or 02R96, connect the CASCADE OUT connector of the DM2000/02R96 to the CASCADE IN connector of the PM5D. However in this case, it is not possible to link operations.
- If you want to cascade-connect the PM5D with any other external mixer, use I/O cards installed in slots 1–4 to send and receive the audio signals (➡ p.202).

## Basic settings for cascade connection

Here we will explain the basic settings required for a bi-directional cascade connection between two PM5D units; we will provide separate explanations for the cascade master and the cascade slave.

### ❑ Cascade master

- 1 In the DISPLAY ACCESS section, repeatedly press the [SYS/W.CLOCK] key until the MIXER SETUP screen appears.



CASCADE MODE area

- 2 In the CASCADE MODE area at the lower part of the screen, select "MASTER". In addition, turn on the BI-DIRECTION button located immediately below it.



CASCADE MODE area BI-DIRECTION button



When multiple PM5D units are cascaded, the settings of the CASCADE MODE area specify whether the unit will operate as a cascade master (when "MASTER" is selected) or as a cascade slave (when "SLAVE" is selected).

If you turn the BI-DIRECTION button on, the mixed audio signals of both cascade-connected PM5D units will be output from both units.

- 3 Select "PM5D" in the CASCADE FROM field and in the CASCADE TO field.




In the CASCADE FROM field, select one of the following as the type of the external device that is sending signals to the PM5D via the cascade connection.

Display	Source device	Selectable cascade input port	Parameter linkage
—	Cascade disabled	CASCADE IN, SLOT 4, SLOT 3/4, SLOT 1-4 [CH1-8], SLOT 1-4 [CH9-16]	Not possible
PM5D	another PM5D	CASCADE IN	Possible*1
DM2000 /02R96	YAMAHA DM2000 or 02R96	CASCADE IN	Not possible
MIXER [30BUS]	A mixer other than the above (maximum 30 bus)	SLOT 3/4, SLOT 1-4 [CH1-8], SLOT 1-4 [CH9-16]	
MIXER [16BUS]	A mixer other than the above (maximum 16 bus)	SLOT 4	

\*1. Linked parameters are specified in the CASCADE screen.

In the CASCADE TO field, select either "PM5D" or "--" (transmission disabled) as the external device to which the signal will be sent from the PM5D via the cascade connection.

- 4 Make sure that "CASCADE IN" is selected for the CASCADE IN PORT SELECT field, and "CASCADE OUT" is selected for the CASCADE OUT PORT SOURCE SELECT field.



The CASCADE IN PORT SELECT and CASCADE OUT PORT SOURCE SELECT fields select the ports

through which audio signals will be transmitted to and received from the cascade-connected external device.

If "PM5D" or "DM2000/02R96" are selected as the other cascade-connected device, only "CASCADE IN" can be selected for the CASCADE IN PORT SELECT field. In the CASCADE OUT PORT SOURCE SELECT field, you can choose from the output channels of slots 1-4 as well as "CASCADE OUT" (→ p.203).

**Hint**

If you choose a setting other than "CASCADE OUT" in the CASCADE OUT PORT SOURCE SELECT field, the same signal will be output from both the specified slot/channel and from the CASCADE OUT connector.

**□ Cascade slave**

- 1 In the DISPLAY ACCESS section, repeatedly press the [SYS/W.CLOCK] key to access the MIXER SETUP screen.
- 2 In the CASCADE MODE area at the lower part of the screen, select "SLAVE". In addition, turn on the BI-DIRECTION button located immediately below it.
- 3 Select "PM5D" in the CASCADE FROM field and in the CASCADE TO field.
- 4 Make sure that "CASCADE IN" is selected in the CASCADE IN PORT SELECT field, and "CASCADE OUT" is selected in the CASCADE OUT PORT SOURCE SELECT field.

**Selecting the buses used for cascade connection**

Here we will explain how to select the buses used for the cascade connection, specify the items that will be linked, and enable the cascade connection. Perform the following steps on both the cascade master and cascade slave units.

- 1 In the DISPLAY ACCESS section, repeatedly press the [SYS/W.CLOCK] key until the CASCADE screen shown below appears.



In this combination you can enable/disable buses used for transmission/reception in the cascade connection, and select the operations that will be linked when multiple PM5D units are cascade-connected.

- 2** In the **CASCADE LINK** area at the left of the screen, turn on the buttons for the operations that you want to be linked.



The settings of the **CASCADE LINK** area select the operations that will be linked when multiple **PM5D** units are cascade-connected. You can select the following items.

- **SCENE RECALL**  
Scene recall operations / Recall undo operations
- **SCENE STORE/EDIT**  
Scene store operations, store undo operations, title editing, sorting
- **CUE/SOLO LOGIC**  
Cue/Solo operations
- **DIMMER ON/OFF**  
Dimmer effect (including talkback dimmer)
- **PAGE CHANGE**  
Switching the display screen
- **DCA FADER MODE**  
Switching the mode of the top panel **FADER MODE** section
- **ENCODER MODE**  
Switching the mode of the top panel **ENCODER MODE** section
- **PANEL/LCD BRIGHTNESS**  
**BRIGHTNESS** settings in the **PREFERENCE 2** screen (**UTILITY** function)
- **INPUT METER POINT/OUTPUT METER POINT/PEAK HOLD**  
Input channel / output channel metering point selection, and peak hold on/off
- **DCA LEVEL/MUTE**  
DCA group 1–8 level, name, [CUE] key on/off operations, and [MUTE] key on/off operations
- **MUTE MASTER**  
Mute group 1–8 on/off

**Note**


- Note that linking is enabled only if the **LINK** buttons for the same item are turned on for both the cascade master unit and the cascade slave unit.
- If you have cascade-connected three or more **PM5D** units in a daisy-chain, you can also turn linking off for the cascade master but on between the cascade slaves.

**Hint**

*DCA and MUTE parameter values will be linked as soon as linking is turned on. CUE/SOLO will be initialized as soon as linking is turned on. Other parameters will be linked only when that parameter is first operated after Link is turned on.*

- 3** In the **CASCADE I/O ASSIGN VIEW** area, use the **CASCADE IN** and **CASCADE OUT ON/OFF** buttons to specify whether each bus will transmit or receive audio signals to or from the external cascade-connected device.

CASCADE IN SOURCE area



The **CASCADE IN** and **CASCADE OUT ON/OFF** buttons specify whether signals of each bus will be transmitted to or received from the cascade-connected external device. These settings are made independently for each bus; MIX buses 1–24, STEREO A bus L/R, STEREO B bus L/R, and CUE bus L/R.

Buses whose **CASCADE IN** button is on will receive signals from the external device; buses whose **CASCADE OUT** button is on will send signals to the external device.

The **CASCADE IN SOURCE** fields indicate each of the source buses. If the other cascade-connected device is a **PM5D**, these assignments are fixed and cannot be modified.

**Note**

- When two **PM5D** units are cascade-connected, signal transmission and reception is enabled if the **CASCADE OUT** button of the transmitting unit and the **CASCADE IN** button of the receiving unit are both turned on for the same bus.
- If a device other than the **PM5D** is selected as the other cascade-connected device, the transmission source indication shown in the **CASCADE IN SOURCE** field will change (→ p.205).

- 4** Set the **CASCADE ENABLE/DISABLE** button to **ENABLE**.

The cascade connection will be enabled when the **CASCADE ENABLE/DISABLE** button is set to **ENABLE** on both the cascade master and the cascade slave.

## Connecting the PM5D to a computer via USB

The PM5D Editor application can be installed in a computer and used to control the PM5D's parameters or to backup and restore the contents of the PM5D's memory.

Here we will explain the operations required in order to establish a USB connection between the PM5D and a computer.

### Note

The following procedure assumes that the PM5D Editor program and USB driver have already been correctly installed in the computer. For details on installing the program and driver, refer to the Studio Manager installation guide.

- 1 In the DISPLAY ACCESS section, repeatedly press the [MIDI/REMOTE] key until the MIDI SETUP screen appears.

### MIDI SETUP



PM5D EDITOR area

- 2 In the PM5D EDITOR area at the lower right of the screen, select the port to which the computer is connected, and select the PM5D's ID number.



First use the PORT field to select the port that will be used to communicate with the computer. Click the  /  buttons located at the left and right of the left box to select the type of port, and press the [ENTER] key (or click inside the box) to finalize your selection. If you select USB or SLOT 1–4, use the box at the right to select a port number 1–8.

Next, use the ID field to select an ID number in the range of 1–8 for the PM5D that you want to control. (This number is used to distinguish individual PM5D units when multiple units are being used together.)

### Note

Set the USB port number and PM5D ID number to match the settings in the PM5D Editor. For details, refer to the PM5D Editor owner's manual.

- 3 Start up PM5D Editor on the computer, and use a USB cable to connect the computer to the PM5D.

This enables communication between the computer and the PM5D. For details on operation, refer to the PM5D Editor owner's manual.

### Note

- If you disconnect or reconnect the USB cable, or power-cycle the PM5D, you must close the PM5D Editor and shut down the computer. In some cases, it may not be possible to reconnect with the PM5D until the computer is restarted.
- Use a USB cable no longer than 3 meters. Also, connect the PM5D directly to the USB connector of the computer; do not use a USB hub.

## Caution when using the USB TO HOST connector

You must observe the following points when connecting the PM5D to your computer via the USB TO HOST connector. If you fail to observe these points, your computer or the PM5D may stop operating ("hang up"), causing data to be corrupted or lost. If the computer or the PM5D stops working, turn the power off and then on again, and restart the computer.

- Before connecting the computer via the USB TO HOST connector, disable the power management mode (suspend/sleep/standby/hibernate) on your computer.
- Connect the USB TO HOST connector to the computer before you power-on the PM5D.
- Close all application programs (such as PM5D Editor) before turning the PM5D's power on or off, or connecting or disconnecting the USB cable.
- Leave an interval of at least three seconds between powering the PM5D on and off, or between disconnecting and connecting the USB cable.

# Initializing the PM5D's internal memory


If an error occurs in the PM5D's internal memory, or if you are unable to return to normal operation because you have forgotten the system password, use the following procedure to initialize the internal memory.



All of the content that had been saved in memory will be lost if you initialize the internal memory. You must use extreme caution when performing this operation.

- 1 While holding down the SCENE MEMORY [STORE] key of the panel, turn on the power of the PW800W power supply.

After the opening screen, the following initialization menu screen will appear.



- 2 Click one of the following buttons to select the desired type of initialization.

- **INITIALIZE ALL MEMORIES**  
All memories including scene memories and libraries will return to their factory-set condition.
- **INITIALIZE CURRENT MEMORIES**  
Memories other than scene memories and libraries will return to their factory-set condition.
- **CANCEL**  
The initialization procedure will be aborted, and the PM5D will start up in normal operating mode.

Note

### Note

If the voltage of the backup battery runs low, or if an error occurs in the internal memory, a warning message will appear at the bottom of the screen, and the initialization menu will appear "by force." Please note that if the warning message is displayed, and you click the CANCEL button to start in normal operating mode, we cannot guarantee that the system will operate correctly.

- 3 A message will ask you to confirm that you really want to initialize; click the OK button.


When the internal memory has been initialized, the PM5D will start up in normal operating mode.

# Adjusting the faders and input/output gain (Calibration)

Depending on the conditions of use, discrepancies may occur in the behavior of the motor faders. you can use the Calibration function to correct such discrepancies. If necessary, you can also make fine adjustments to the analog input/output gain.

- 1 While holding down the [ENTER] key of the panel, turn on the power of the PW800W power supply.

After the opening screen, the following calibration menu screen will appear.



- 2 Click one of the following buttons to choose what you want to calibrate.

A window for the calibration item you selected will appear.

<b>CALIBRATE FADER POSITION</b>	The FADER CALIBRATION window will appear, allowing you to calibrate the specified faders.
<b>CALIBRATE AD INPUT GAIN (make fine adjustments to the analog input gain; PM5D-RH model only)</b>	The AD INPUT TRIM window will appear, allowing you to make fine adjustments to the gain of the specified analog input port.
<b>CALIBRATE OUTPUT GAIN (make fine adjustments to the output ports)</b>	The OUTPUT TRIM window will appear, allowing you to make fine adjustments to the gain of the specified output port.


- 3 Make calibration settings as directed by the instructions that appear in the window.

- 4 Click the OK button in the window.

The calibration settings will be applied, and the PM5D will start up in normal mode.

## Calibrating the faders

Here you can execute a semi-automatic procedure for calibrating the faders of the specified channel strip (INPUT, DCA, STEREO A/B, ST IN/FX RTN). This window will also appear if a problem with the fader settings is detected when the PM5D is started up.



- 1 Click a fader select button to add a check mark to the faders you want to calibrate. If problems with certain faders were detected during start-up, those buttons will be on (green), and check marks will already be shown for them.
- 2 Click the START CALIBRATION button; calibration will begin automatically. A progress bar will indicate the state of the process.
- 3 The automatic processing will end when the progress bar reaches 60%. Manually move all faders you specified for calibration to the positions listed below in the following order:
  - ①  $\infty$
  - ② -20 dB
  - ③ 0 dB
  - ④ +10 dB
- 4 After you have set the faders to the correct position, press the [ENTER] key. Processing will proceed to the next fader position.
- 5 Repeat steps 3-4 for each fader position ①-④.
- 6 Verify that calibration has been completed and that all fader select buttons are now off. Then click the OK button.

The calibration settings will be stored in internal memory. If a fader select button remains on (green), calibration has failed. Try executing calibration once again.

### Note


The progress bar will indicate "Writing..." while the settings are being written to internal memory; do not turn off the power while this indication is visible.

## Adjusting the analog input gain (PM5D-RH model only)

If necessary, you can make fine adjustments in steps of 0.1 dB to the gain of the specified analog input port. Since the input levels of all ports are set to match each other when the PM5D is shipped from the factory, you will normally not need to change these settings.

### Note

Since these are set to optimal values at the factory, the default values will differ between input ports. Initializing the internal memory will return these settings to their factory-set values.



To adjust the gain, click the  $\uparrow$  /  $\downarrow$  buttons located at the left and right of each box to specify the gain of each input port in 0.1 dB units. If you want to restore all input ports to their factory settings, click the FACTORY PRESET button. Click the OK button to apply the settings.

## Adjusting the output gain

If necessary, you can make fine adjustments in steps of 0.01 dB to the gain of the specified output port. The factory setting is 0.00 dB.



To adjust the gain, click the  $\uparrow$  /  $\downarrow$  buttons located at the left and right of each box to specify the gain of each output port in 0.01 dB units. If you want to reset all output ports to 0.00 dB, click the FACTORY PRESET button. Click the OK button to apply the settings.

# Reference section

The Reference section explains the functionality and operations for every screen of the PM5D, organized into four main areas; function menu, global functions, output functions, and input functions.


## Information shown in the display

The following illustration is a typical screen on the PM5D.



This screen shows the following information.

### Upper part of the display (always visible)



#### ① Function Name Indication

Displays the name of the function currently selected in the screen. By clicking the BACK/FORWARD buttons you can move through the eight most recent screens that were displayed for at least two seconds (with the exception of function menus). You can also access the Function menu by clicking this function name indication. When the Function menu is displayed, click once again to return to the previously-displayed screen.

#### ② SCENE MEMORY

Indicates the number and title of the last-stored or recalled scene memory. If you select a different scene, the number and title will blink. If you edit the contents of a scene after storing it, the EDIT indicator in the upper right will light. If the scene is write-protected, a lock icon is displayed at the right of the title, and read-only scenes are indicated as "R."

#### Note

- You can move the cursor to the scene number and turn the [DATA] encoder to select a scene.
- If you click here while the number and title are blinking, the most recently stored or recalled scene will be displayed.

#### ③ NEXT SCENE/NEXT EVENT

Indicates the scene/event that will be recalled next by the User Defined keys or the Event List function. The information shown here will differ as follows, depending on the settings in the EVENT LIST screen of the SCENE function.

##### • If the DISABLE button is turned on in the EVENT LIST screen


Indicates the number and name of the next scene (the scene that will be recalled when you press a User Defined key assigned to the "INC RECALL" function). Normally, this will be the scene of the number following the most recently recalled or stored scene.

##### • If the ENABLE [ALL MANUAL] button or the [ENABLE] button is turned on in the EVENT LIST screen

Indicates the number and name of the next event (the scene that will be recalled next by the Event List function). At the right is displayed the time until the next event will be recalled (or the condition upon which the event will be recalled).

#### Note

- The "MANUAL" indication means that the user must execute the Next Event operation in order to recall the next event. (Press a User Defined key assigned to the "NEXT EVENT RECALL" function, or click the NEXT button in the EVENT LIST screen.)
- If a time is displayed, this indicates the remaining time until the next event is recalled automatically.
- The "-----" indication means that there is no event to be recalled next.



#### ④ PRESENT TIME, TIME CODE, CASCADE/Fs

Click this area to cycle through the following three items of information. This is linked with the UPPER PART DISPLAY setting in the PREFERENCE 2 screen (UTILITY function).

- **PRESENT TIME**  
Indicates the present time. The time can be specified in the UTILITY function PREFERENCE 1 screen.
- **TIME CODE**  
Indicates the internal time code being generated by the PM5D, or the time code being received from an external device. This is the same as the time code shown in the SCENE function EVENT LIST screen.
- **CASCADE/Fs**  
Indicates the master/slave status when using a cascade connection, and the sampling frequency at which the PM5D system is currently operating.

#### ⑤ METER SECTION

Indicates the type of channels that are currently shown by the meters in the upper left and right of the panel. You can also click the  /  buttons to switch this directly.

#### ⑥ EVENT indicator

The EVENT indicator is displayed here if the ENABLE [ALL MANUAL] or ENABLE button is turned on in the SCENE function EVENT LIST screen.

#### ⑦ FADING/TRACKING indicator

This area shows the FADING indicator while fade time is being executed, or the TRACKING indicator if Tracking Recall is available. If both are enabled, FADING takes priority.

#### ⑧ LCR/LCR [B] indicator

If there is at least one channel for which LCR is turned on, the LCR indicator is displayed here.

If in the SYS/W.CLOCK function MIXER SETUP screen the BUS SETUP setting STEREO B is set to USE AS CENTER BUS, the LCR [B] indicator is displayed here.

#### ⑨ TB/OSC/DIMM indicator

If talkback, oscillator, or dimmer are on, the respective TB/OSC/DIMM indicator is displayed here. If more than one of these are enabled, the display priority is TB>OSC>DIMM.

#### ⑩ SOLO/INPUT CUE/DCA CUE/OUTPUT CUE/KEY IN CUE/EFFECT CUE/EXTERNAL CUE indicator

If Solo or Cue Monitor is enabled, the corresponding indicator is shown here. If more than one Cue is selected, only the indicator for the currently-valid Cue is shown.


#### ⑪ BUSY/RS422/HA/GPI/MIDI indicator

The BUSY indicator is shown here while internal memory or a PC card in the card slot is being accessed. When RS422/HA/GPI/MIDI signals are received (in the case of RS422, when Status is received to indicate a status change on a connected device), the appropriate indicator will appear briefly. If more than one of these conditions occur simultaneously, the display priority is BUSY>RS422>HA>GPI>MIDI.

#### Note

*In the case of MIDI signals, the indicator will light if signals are received at the MIDI connector, USB connector, or slots 1–4. However, active sensing, MIDI clock, and quarter time code messages will not cause the indicator to light.*

## Main area of the display




#### ① Tabs

Click this area to switch between screens within the selected function.

#### ② Function parameters

This area shows parameters for the currently selected function or screen.

## Lower part of the display (always visible)



#### ① SELECTED CH (Selected channel)

Indicates the type and name of the channel currently selected by the [SEL] key. You can also click the  /  buttons to switch this directly.

#### ② MIX SECTION

Indicates the encoder mode currently selected in the MIX section. In MIX SEND mode this indicates “SEND,” in MIX MASTER mode this indicates “MASTER,” and if a shortcut operation has been used to select TO MATRIX mode this indicates “TO MATRIX.” You can also click the  /  buttons to directly switch between “SEND” and “MASTER.”

#### ③ Encoder/Fader mode

Indicates the parameters that are assigned to the encoders/faders of the input channel strip.

The encoders can be assigned to MIX SEND 1–24, GAIN, ATT, PAN/BAL, LEVEL, or REMOTE. The faders can be assigned to LEVEL, MIX SEND 1–24, or REMOTE. For both the encoders and the faders, you can click  /  to directly select parameters other than REMOTE.

If you select LEVEL for the encoders, the faders will be flipped; the most recently selected of the MIX SEND 1–24 parameters will be assigned to the faders. Similarly, the faders will also be flipped if you select MIX SEND

1–24 for the faders; the LEVEL parameter will be assigned to the encoders.

④ **INPUT CH (Input channel) layer**

This is linked with the [CH 1-24]/[CH 25-48] key in the input channel strip of the panel, and indicates the layer that is selected for the input channel strip. (If the MIDI REMOTE layer is selected, this indicates REMOTE 1-24.) Layers other than MIDI REMOTE can also be switched directly by clicking the / buttons.

⑤ **FADER MODE**

This is linked with the FADER MODE section on the panel, and indicates the function that is assigned to the faders of the DCA strip. You can also click the / buttons to switch this directly.

⑥ **ST IN/FX RTN (ST IN channel / Effect return) layer**

This is linked with the [ST IN] key and [FX RTN 1-4] key in the ST IN channel strip of the panel, and indicates the layer that is selected for the ST IN channel strip. (If the MIDI REMOTE layer is selected, this indicates REMOTE 25-28.) Layers other than MIDI REMOTE can also be switched directly by clicking the / buttons.

⑦ **DIRECT RECALL/MUTE MASTER**

This switches between the following two choices as the function of the [1]–[8] keys in the SCENE MEMORY section of the panel.

- **DIRECT RECALL**

Keys [1]–[8] of the SCENE MEMORY section will directly recall the scene that was assigned in the SCENE screen.

- **MUTE MASTER**

Keys [1]–[8] of the SCENE MEMORY section will switch mute groups 1–8 on/off.

⑧ **USER DEFINED KEY BANK**

Indicates the currently selected bank of User Defined keys. You can also click the / buttons to switch this directly.

# Function menu

Here you can select the function that you want to view in the display. These operate in the same way as the keys of the DISPLAY ACCESS section.



**Hint**

To access this screen from another function, click the Function Name area at the top of the display.

① **Global functions**

These buttons access functions that affect the entire PM5D.

② **Output-related functions**

These buttons access functions related to output channels (MIX channels, MATRIX channels, STEREO A/B channels).

③ **Input-related functions**

These buttons access functions related to input channels (input channels, ST IN channels, FX RTN channels).


# Global functions

## EFFECT functions

### EFFECT PARAM (Effect parameter) screen

Here you can select the type of internal effect, edit its parameters, and perform input/output patching.

#### EFFECT PARAM



#### ① Effect selection

Of the internal effects 1–8, select the effect for which you want to make settings. To switch between effects, place the cursor here and turn the [DATA] encoder, or click the [LEFT] / [RIGHT] buttons at left or right.

#### ② Effect type

Indicates the currently selected effect type, both by name and as a graphic. The number of input/output channels (1 IN/2 OUT or 2 IN/2 OUT) of this effect is also shown at the bottom of this area.

#### Note

You can't switch the effect type in this screen. If you want to switch to a different effect type, recall an effect that uses the desired effect type from the effect library.

#### ③ Input patch

This box lets you select the signal path that will be patched to the L/R input channels of the internal effect. Move the cursor to this box and turn the [DATA] encoder or click the [LEFT] / [RIGHT] buttons at left or right to display the desired signal path, and then press the [ENTER] key to finalize the change.

You can choose the following signal paths.


MIX1–MIX24	MIX channel 1–24 output
INS CH1–INS CH48	Input channel 1–48 insert out
INS STIN1 (L/R)–INS STIN4 (L/R)	ST IN channel 1–4 (L/R) insert out
INS MIX1–INS MIX24	MIX channel 1–24 insert out
INS MTRX1–INS MTRX8	MATRIX channel 1–8 insert out
INS ST A (L/R)	STEREO A channel (L/R) insert out
INS ST B (L/R)	STEREO B channel (L/R) insert out
INS MON (L/R/C)	MONITOR channel (L/R/C) insert out

#### Note

- If you move the cursor away without pressing the [ENTER] key, the setting will revert to its original state.
- If you assign a signal to both input channels for a 1 IN/2 OUT effect type, the two will be mixed to monaural and then input.
- If you assign a signal to only one input channel for a 2 IN/2 OUT effect type, the same signal will be sent to both channels of the effect.
- If STEAL PATCH CONFIRMATION is turned on in the PREFERENCE 1 screen (UTILITY function), and you attempt to make patch settings that would cause an existing patch to be modified, a confirmation message will appear.

#### ④ Input meter

Indicates the level of the signal being input to the effect.



⑤ **MIX BALANCE**

Adjusts the balance of the effect sound relative to the original sound.

0 (%) outputs only the original sound, and 100 (%) outputs only the effect sound.

⑥ **BYPASS**

This button temporarily bypasses the effect.

⑦ **CUE**

This button cue-monitors the output of the effect shown in the screen. Cue is automatically defeated when you switch to a different screen. (However, cue will be held if you switch to the EFFECT ASSIGN screen.)

⑧ **Output meter**

Indicates the level of the signal being output from the effect.

⑨ **Output patch**

This box lets you select the signal path that will be patched to the L/R output channels of the internal effect. The selection method is the same as for Input Patch. You can choose the following signal paths.

CH1-CH48	Input channel 1-48 input
STIN1-STIN4 (L/R)	ST IN channel 1-4 (L/R) input
FXRTN1-FXRTN4 (L/R)	FX RTN channel 1-4 input
INS CH1-INS CH48	Input channel 1-48 insert in
INS ST1 (L/R)-INS ST4 (L/R)	ST IN channel 1-4 (L/R) insert in
INS MIX1-INS MIX24	MIX channel 1-24 insert in
INS MTRX1-INS MTRX8	MATRIX channel 1-8 insert in
INS ST A (L/R)	STEREO A channel (L/R) insert in
INS ST B (L/R)	STEREO B channel (L/R) insert in
INS MON (L/R/C)	MONITOR channel (L/R/C) insert in

**Note**

Even if you've patched multiple channels in the INPUT PATCH/OUTPUT PATCH function INSERT PATCH screen, changing the input/output patch in this screen will turn off patching to other channels.

⑩ **LIBRARY**

This button accesses the EFFECT LIBRARY screen for the currently selected effect.



⑪ **TEMPO parameter**


If a delay-type or modulation-type effect type is selected, the tempo parameter will be displayed here. The TEMPO parameter specifies time-related parameters in units of BPM (Beats Per Minute). For a delay-type effect it sets the DELAY (delay time), and for a modulation-type effect it sets the FREQ. (modulation frequency).

**Note**

For some effect types, a parameter unique to the effect may be shown instead of the TEMPO parameter. For example if FREEZE is selected as the effect type, a button for recording/playing the input signal is shown.

The BPM value can be edited using the on-screen knob, or by repeatedly clicking the TAP TEMPO button. (In this case, the average interval between clicks is detected. If the average value is outside the range of 20-300 BPM, it will be ignored.)

The average of the intervals is input as the parameter value (average of a, b, and c)



If the MIDI CLK button is on, the TEMPO parameter will synchronize to the MIDI timing clock being received from the MIDI port.


⑫ **Effect parameters**

This area shows parameters for the currently selected effect type.

## EFFECT ASSIGN screen

This screen lists the effect types used by internal effects 1–8, and shows their input levels. Here you can also assign signals to input/output channels, and make settings for bypass and cue.

### EFFECT ASSIGN



- ① **Level meter**  
Indicates the input level to the effect.
- ② **Effect type**  
Indicates the selected effect type, both by name and as a graphic. When you click this area, the EFFECT PARAM screen will appear. You can also drag and drop this area onto another effect in this screen to copy the effect settings.
- ③ **BYPASS**  
This button temporarily bypasses the effect.
- ④ **CUE**  
This button cue-monitors the effect output. Cue is automatically defeated when you switch to a different screen. (However, cue will be held if you switch to the EFFECT PARAM screen of the corresponding effect.)
- ⑤ **Input patch**  
This box indicates the signal path that is patched to the L/R input channels of the internal effect. You can also directly assign the signal path in this box.

## ⑥ Output patch



This box indicates the signal path that is patched to the L/R output channels of the internal effect. You can also directly assign the signal path in this box.

### Note


Even if you've patched multiple channels in the INPUT PATCH/OUTPUT PATCH function INSERT PATCH screen, changing the input/output patch in this screen will turn off patching to other channels.

## EFFECT LIBRARY screen

Here you can recall, store, rename, or delete items in the effect library.



- ① **EDIT**  
When you click this button, the EFFECT PARAM screen for the currently selected effect will appear.
- ② **Effect selection**  
Of the internal effects 1–8, select the effect for which you want to make settings.
- ③ **Input meter**  
Indicates the input level of the effect.
- ④ **Current effect type**  
Indicates the effect type of the currently selected effect.
- ⑤ **Output meter**  
Indicates the output level of the effect.



- ⑥ **Library effect type**  
Indicates the effect type of the library item selected in the list.
- ⑦ **RECALL**  
Recalls the library item shown in the list into the currently selected effect.
- ⑧ **STORE**  
Stores the currently selected effect into the selected location of the list. When you click this button a window will appear, allowing you to name and save the effect.
- ⑨ **TITLE EDIT**  
Edits the title of the library item selected in the list. When you click this button a window will appear, allowing you to edit the title.
- ⑩ **CLEAR**  
Deletes the library item selected in the list. When you click this button, a confirmation message will appear.

### Note

Library items with an "R" displayed in the right column of the list are read-only. Read-only items cannot be stored, renamed, or deleted.

- ⑪ **Library list**  
Use the scroll bar to select the library item on which you want to perform an operation. The selected library item will move to the center, and will be highlighted.

### Note

- If the library item selected for operations is different than the last-stored/recalled library item, the last-stored/recalled library item will be shown with a blue background.
- Library items 049 and later that are grayed-out are reserved for Add-On Effects. They will become available if you install a separately sold Add-On Effects package (➔ p.109).

Information shown  
in the display

Function  
menu

Global  
functions

Output  
functions

Input  
functions



Appendices

# GEQ function

## GEQ PARAM (GEQ parameter) screen

Here you can adjust the boost/cut for a 31-band graphic EQ, specify the input/output patching, and assign a GEQ to faders.

### GEQ PARAM



① **Module select**

Of the twelve graphic EQ modules (GEQ1–GEQ12), select the module that you want to operate. To switch between modules, place the cursor here and turn the [DATA] encoder, or click the / buttons at left or right.

② **LINK button**

This button links adjacent odd-numbered → even-numbered graphic EQ modules. When you turn this button on, a window will appear, allowing you to select whether the parameters will be copied from one module to the other, or whether both modules will be initialized.

③ **INSERT (Insert destination)**

Selects the location at which the graphic EQ module will be inserted. Move the cursor to this box and turn the [DATA] encoder or click the / buttons at left or right to display the desired insertion destination, and then press the [ENTER] key to finalize the change.

You can choose the following insertion destinations.

- **INS CH1–INS CH48**  
Input channel 1–48 insert in/out
- **INS STIN1 (L/R)–INS STIN4 (L/R)**  
ST IN channel 1–4 (L/R) insert in/out
- **INS MIX1–INS MIX24**  
MIX channel 1–24 insert in/out
- **INS MTRX1–INS MTRX8**  
MATRIX channel 1–8 insert in/out
- **INS ST A (L/R)**  
STEREO A channel (L/R) insert in/out
- **INS ST B (L/R)**  
STEREO B channel (L/R) insert in/out
- **INS MON (L/R/C)**  
MONITOR channel (L/R/C) insert in/out

**Note**

- When you select the insertion destination here, insert in/out will be patched simultaneously, and insertion will automatically be turned on for the channel into which the graphic EQ module was inserted.
- If you move the cursor away without pressing the [ENTER] key, the setting will revert to its original state.

④ **GEQ ON/OFF button**

Switches the currently selected graphic EQ module on/off.

⑤ **SLOW/FAST**

Switches the fall speed of the spectrum analyzer between slow or fast. This setting does not affect the meters in other screens or the meters on the panel.

⑥ **PEAK HOLD**

Switches the peak hold function on/off for the spectrum analyzer. The peak level for each band is held while this button is on. (To reset the peak level display, turn this button off and then on again). This setting does not affect the meters in other screens or the meters on the panel.

⑦ **Spectrum analyzer**

This is an analyzer that shows a realtime level display for each band of the input signal.

⑧ **EQ graph**

Indicates the current frequency response of the graphic EQ.

⑨ **Faders**

These faders cut/boost the frequency bands of the graphic EQ. The actual values are shown in the numerical boxes below.

⑩ **ASSIGN TO FADERS**

These buttons divide the 31 bands of the graphic EQ into six groups so that you can use the DCA faders to adjust the boost/cut amount of each band. Click one of the six buttons A (20.0–100), B (63.0–315), C (200–1.00k), D (630–3.15k), E (2.00k–10.0k), F (4.00k–20.0k). DCA faders 1–8 will be assigned to the corresponding region of frequency bands, allowing you to control them with the DCA faders. At this time, the divisions of the corresponding faders and the value in the numerical box screen will turn red in the screen. To return to the original state, press the DCA (OFF) button in the screen or the [DCA] button on the panel.

## Note


- If the ASSIGN TO FADERS buttons A–F are off, you can hold down the [SHIFT] button on the panel and press a FADER MODE section button [A]–[F], and then use the DCA faders to control the corresponding region of the graphic EQ in the same way as if you had pressed a button A–F in the screen.
- The currently selected DCA fader mode (DCA, A–F) is disabled while one of the ASSIGN TO FADERS buttons A–F is on. At this time, you can also use the FADER MODE section buttons [A]–[F] to switch between regions of the graphic EQ; the button for the selected region will blink, and the remaining buttons will light.
- The setting in the ASSIGN TO FADERS area is defeated when you switch screens; the currently selected DCA fader mode will again be applied.



- ⑪ **LIBRARY**  
This button accesses the GEQ LIBRARY screen.
- ⑫ **Level meter**  
This meter indicates the peak level before and after the graphic EQ.
- ⑬ **LIMIT**  
The range and direction of adjustment controlled by the faders can be selected from the following:  $\pm 15$  dB,  $\pm 12$  dB,  $\pm 6$  dB (these are valid in both the boost and cut directions), or  $-24$  dB (valid only in the cut direction).
- ⑭ **EQ FLAT**  
Resets all faders to the 0 dB position. When you click this button, a confirmation message will appear.
- ⑮ **AUTO ASSIGN**  
This button automates assignments to the DCA faders. If this button is on, the most recently selected region of GEQ bands will be assigned to the DCA faders when you access the GEQ PARAM screen.

## GEQ ASSIGN screen




This screen lists the approximate values of the graphic EQ settings, and shows the input/output levels. The signal path assignments and on/off status can also be edited in this screen.



- ① **Level meter**  
This meter indicates the peak level before and after the graphic EQ.
- ② **Fader graph**  
This indicates the approximate fader position for each band. When you click this area, the GEQ PARAM screen for the corresponding GEQ module will appear. You can also drag and drop this area onto another GEQ module to copy the GEQ settings.
- ③ **GEQ ON/OFF button**  
Switches the graphic EQ module on/off.
- ④ **Insert destination**  
Indicates the location at which the graphic EQ module is inserted. You can also specify the insert location from within this screen.
- ⑤ **LINK button**  
This button indicates the link status of adjacent odd-numbered  $\rightarrow$  even-numbered graphic EQ modules. When you turn this button on, a window will appear, allowing you to select whether the parameters will be copied from one module to the other, or whether both modules will be initialized.

## GEQ LIBRARY screen

Here you can recall, store, rename, or delete items in the GEQ library.



- ① **EDIT**  
When you click this button, the GEQ PARAM screen for the currently selected GEQ module will appear.
- ② **GEQ module select**  
Of the GEQ modules 1–12, select the module for which you want to make settings.
- ③ **Current EQ graph**  
Indicates the approximate response of the currently selected GEQ module.
- ④ **Level meter**  
This meter indicates the peak level before and after the graphic EQ.

- ⑤ **RECALL**  
Recalls the library item selected in the list into the currently selected GEQ module.
- ⑥ **STORE**  
Stores the settings of the currently selected GEQ module into the selected location in the list. When you click this button a window will appear, allowing you to name and save the GEQ module settings.
- ⑦ **TITLE EDIT**  
Edits the title of the library item selected in the list. When you click this button a window will appear, allowing you to edit the title.
- ⑧ **CLEAR**  
Deletes the library item selected in the list. When you click this button, a confirmation message will appear.

**Note**

*Library items with an "R" displayed in the right column of the list are read-only. Read-only items cannot be stored, renamed, or deleted.*


- ⑨ **Library EQ graph**  
Shows the response curve of the library selected in the list.
- ⑩ **Library list**  
Use the scroll bar to select the library item on which you want to perform an operation. The selected library item will move to the center, and will be highlighted.

# SCENE function

## SCENE screen

Here you can store/recall scenes.

### SCENE



#### ① Scene list

This is a list of the stored scenes. For each scene, the following items are displayed. (To view ⑦ COMMENT and subsequent items, scroll the list to the right.)

#### ② (Scene number)

This is the scene number 0–500. You can click this icon to reverse the order in which the scenes are sorted.

#### ③ TITLE

This is the name assigned to each scene. You can click the TITLE button to sort the scenes in order of their titles. When you click the button at the left, a window will appear, allowing you to edit the title.

#### ④ (Protect)

This button switches Protect on/off for each scene. A lock icon indicates scenes for which Protect is turned on; these scenes cannot be overwritten. Read-only scenes are indicated by a “R” displayed here.

#### ⑤ SEL.RECALL (Selective recall)

For each scene, you can specify whether the Selective Recall function will be used when recalling the scene. If the Selective Recall function is enabled (p.164), scenes for which this button is turned on can recall only specific parameters. (Alternatively, you can exclude only specific parameters from the recall.)


If the scenes are sorted in order of TITLE, a check mark is displayed for scenes for which this is turned on. If the

scenes are sorted in numerical order, a downward or upward arrow is displayed for scenes for which this is turned on; this makes it easy to see which was the original scene prior to selective recall.

#### ⑥ Library link

This area shows the number and title of the INPUT PATCH library, OUTPUT PATCH library, and HA library used by each scene. You can click the button at the left to access a window that lets you change the library number that is linked. The LINK button for each library determines whether library recall operations will be linked to scene recall operations.

If the LINK button is on (this column indicates “LINK”), the library of the corresponding number will also be recalled when you recall that scene. A library whose LINK button is off will not change when you recall that scene.




#### ⑦ COMMENT

In this column you can enter or view a comment for the scene. A text input window will appear when you move the cursor to the COMMENT field and press the [ENTER] key, or when you click the button at the left.

#### ⑧ TIME STAMP

Indicates the time at which the scene was last stored, in the format of month/day/year/hours/minutes/seconds.



#### ⑨ MIDI EVENT

Specifies a MIDI message that will be transmitted from the MIDI OUT connector when the scene is recalled. When you click the button at left a window will appear, allowing you to input a MIDI event in hexadecimal form (p.118).

#### ⑩ TX ON/OFF (MIDI event transmission on/off)

Specifies whether the assigned MIDI event will be transmitted.

Information shown in the display


Function menu

Global functions

Output functions

Input functions

Appendices



**11 GPI OUT CONTROL 1–12**

Specifies the polarity and transmission method (tally/trigger) of the signal that is sent from GPI OUT ports 1–12 when the scene is recalled. When you click a button corresponding to a port 1–12, the setting will change in the following order.


Display	Polarity	Transmission method
None	Disabled	
	High active	Tally
	Low active	Tally
	High active	Trigger
	Low active	Trigger

**Note**

- GPI OUT CONTROL settings are independent of the settings in the MIDI/REMOTE function GPI screen.
- In the case of a Trigger type setting, the time interval between becoming active and returning to the inactive state is 250 msec.

**12 REMOTE TRANSPORT**

Selects the transport command (MMC or RS422 protocol) that will be transmitted when you recall the scene. If you click the button at the left a window will appear, allowing you to select the output destination and the type of command.



**13 SCENE FUNCTION (Recall function)**

Here you can store/recall scenes.

- RECALL**  
Loads the scene currently selected in the scene list into the PM5D.
- STORE**  
Saves the current settings of the PM5D in the scene currently selected in the scene list. (This button is inoperable if the selected scene is read-only or protected.)
- UNDO**  
Cancels the preceding Recall or Store operation. You can click this once again (Redo) to return to the state prior to Undoing.

**PREVIEW**

If this button is on, the PM5D will be in PREVIEW mode; this allows you to view or edit the settings of a scene stored in memory or the settings of a library item without affecting the internal signal processing. This is linked with the [PREVIEW] key in the SCENE MEMORY section of the panel (➔ p.80).

**Note**

- Monitor settings will apply to internal signal processing even during Preview mode. You can perform cue/monitor operations while Previewing.
- EVENT LIST, MIDI, and GPI operations will apply to internal signal processing, but not to Preview.
- Memory card save/load operations cannot be performed during Preview.
- During Preview, user defined operations that affect internal signal processing are disabled; such operations include EVENT LIST, TALKBACK ASSIGN, MONITOR, MIDI DIRECT OUT, MACHINE CONTROL, and GPI OUT CONTROL.

**14 BLANK SKIP**

Specifies how scene numbers can be selected. If the BLANK SKIP button is off, all scene numbers can be selected consecutively regardless of whether they contain scene data. In contrast if the BLANK SKIP button is on, only numbers in which a scene is actually stored can be selected. This setting applies when you switch scenes using the SCENE MEMORY [▲]/[▼] keys in the SCENE MEMORY section of the panel, the [DATA] encoder, or the buttons in the screen.

**15 EDIT**

These buttons let you rearrange the order of the scenes in memory.

- CUT**  
Cuts the scene selected in the list, and holds it in a temporary memory buffer. Subsequent scenes will be moved forward by one.
- COPY**  
Copies the scene selected in the list into the memory buffer. The copy-source and other scenes will not be affected.
- INSERT**  
Inserts the scene from the memory buffer at the number selected in the list. Scenes that follow the number at which you inserted will be moved backward by one.
- PASTE**  
Overwrites the scene from the memory buffer onto the blank number selected in the list. Other scenes will not be affected.
- CLEAR**  
Deletes the scene selected in the list.
- UNDO**  
Cancels the operation that was last performed in the EDIT area.

**Note**

- A confirmation message will appear when you click one of these buttons.
- If a read-only or protected scene is selected in the list, the CUT, INSERT, and CLEAR buttons are grayed-out, and cannot be used.
- If an existing scene is selected in the list, the PASTE button is grayed-out, and cannot be used.
- If the list is sorted by title, the CUT, INSERT, and UNDO buttons are displayed in gray.
- If you modify the contents of a scene by operations in other than the EDIT section, the UNDO button is displayed in gray.

## 16 DIRECT RECALL ASSIGN

This lets you select the scenes that will be directly recalled by the SCENE MEMORY [1]–[8] keys on the panel. This function is available if the DIRECT RECALL button is on.


When you move the cursor to the field on the left and turn the [DATA] encoder, or when you click the / buttons to select a scene number, the scene name will appear in the field on the right.

## 17 DIRECT RECALL/MUTE MASTER

These are linked with the DIRECT RECALL/MUTE MASTER buttons shown at the bottom of the display. (➔ p.151)

## EVENT LIST screen

The Event List function lets you register scenes in the order of use, so that these scenes can be recalled either manually or automatically according to the specified time code or interval.



### 1 EVENT LIST ENABLE/DISABLE

Use the following three buttons to enable/disable the Event List function.

- **DISABLE**  
The Event List function will not recall scenes registered in the event list.
- **ENABLE [ALL MANUAL]**  
Scenes registered in the event list will be recalled only by manual operation. If the list contains events for which a time code has been specified, the candidate event for recall will change as time code progresses, but events will not actually be recalled unless the recall operation is performed manually.
- **ENABLE**  
Scenes registered in the event list will be recalled according to the specified condition (time code, interval, or manual operation).

### 2 Event list

In this list you can register the scenes to be recalled, and the conditions under which the scenes will be recalled. Click a line to select the event of that line for editing; it will be highlighted in the center of the list.

- **No.**  
Indicates the event number.
- **EVENT TRIGGER**  
This column specifies the condition that will recall each event. Click the  button, and in the window that appears, use the following three buttons to select the condition.
  - MANUAL** . . . . The event can be recalled by the DIRECT button in the EVENT RECALL area (③) or by a User Defined key. The EVENT TRIGGER field will indicate “[MANUAL]”.
  - INTERVAL** . . . . The scene will be recalled when a specified time has elapsed after the preceding scene was recalled. If you select this button, specify the wait time in the lower part of the window. The EVENT TRIGGER field in the list shows a “↔” symbol and the wait time.
  - TIME CODE** . . . The scene will be recalled when the time code (LTC, MTC, internal time code) reaches the specified time. If you select this button, specify the time code location (hours/minutes/seconds/frames) in the lower part of the window. The EVENT TRIGGER field in the list shows the time code.

Event that will be recalled when the specified interval elapses after the previous recall operation

Event that will be recalled manually

000	[MANUAL]	001	Openings
001	↔ 240.0sec	000	Initial Data
002	00:15:00.00	002	ACT1
003	00:52:00.00	003	ACT2

Event that will be recalled when time code reaches the specified location


**Hint**

- As long as an event for which MANUAL is specified is selected in the list, the scene will not change until you manually execute a recall.
- However, if an event for which TIME CODE is specified is registered later in the list, events set to MANUAL will be skipped when that time code arrives, and the corresponding scene will be recalled.
- The condition for recalling the scene that will be recalled next is shown in the NEXT SCENE/NEXT EVENT fields in the upper part of the display.

**Note**

- If time code source is OFF, events whose EVENT TRIGGER is set to TIME CODE will not be recalled unless you perform a manual recall.
- In contrast, events whose EVENT TRIGGER is set to INTERVAL will be recalled automatically after the specified interval elapses from the previous recall operation, even if the time code source is OFF.
- In the two-second interval after time code starts, events may not be executed because synchronization is being established. You must start time code at least two seconds earlier than an event you want to execute.

- **SCENE TITLE**  
This is the number and title of the scene to be recalled. Click the  button, and in the window that appears, click the number of a scene to select it.
- ③ **EVENT RECALL**  
Here you can recall events. The following three buttons are provided.
  - **PREV**  
When you click this button, the event of the line preceding the last-recalled event will be recalled and selected.
  - **DIRECT**  
When you click this button, the event currently selected in the event list will be recalled. This is used mainly to recall an event whose EVENT TRIGGER field is set to “[MANUAL]”.
  - **NEXT**  
When you click this button, the event of the line following the last-recalled event will be recalled and selected.



④ **AUTO CAPTURE**

This button lets you automatically register events in realtime while time code runs. If time code is running and this button is on, using the buttons of the panel SCENE MEMORY to recall a scene will cause the corresponding scene number and time code location to be captured, and this will be added as a new event.

**Note**

- If the list contains previously-recorded events, they will be sorted in descending order of their time code.
- If an event already exists at the identical time code location, it will be overwritten by the new event.
- Even if time code source is “OFF,” performing a recall operation while this button is on will register a new event in the list. In this case, the EVENT TRIGGER field will be registered as “[MANUAL]”.
- If an offset value is specified, the sum of the offset value and the displayed time code is captured as the time code.

⑤ **MOVE UP**

This button moves the currently selected event one position earlier in the event list.

## ⑥ MOVE DOWN

This button moves the currently selected event one position later in the event list.

### Note

- The MOVE UP/DOWN buttons are available only for events whose EVENT TRIGGER field is shown as “[MANUAL]” or the “▶” symbol.
- If the EVENT TRIGGER field of the selected event shows a time code, these buttons will be grayed-out and unavailable.

## ⑦ MANUAL INSERT

This button inserts a new event at the location selected in the event list. The EVENT TRIGGER field of the new event will be “[MANUAL],” and its SCENE TITLE field will be “no assignment.” You can change these as desired.

## ⑧ MANUAL OVERWRITE

This button overwrites a new event onto the location currently selected in the event list. (If the line at the current location is blank, this button will be grayed-out and unavailable.) The EVENT TRIGGER field of the new event will be “[MANUAL].”

## ⑨ TIME CODE SETUP

Here you can make settings for the time code received by the PM5D.

### • TC SOURCE (Time code source)

Select one of the following as the time code source that will be used.

- OFF** . . . . . Time code will not be received.
- INTERNAL** . . . . . The time code generated within the PM5D will be used.
- TIME CODE** . . . . . The time code (LTC) received via the rear panel TIME CODE connector will be used.
- MIDI** . . . . . The MIDI time code (MTC) received via the rear panel MIDI IN connector will be used.
- USB** . . . . . The MIDI time code received from the specified port via the rear panel USB connector will be used.
- SLOT 1–4** . . . . . If a card that supports MIDI input is installed in one of the rear panel slots, the MIDI time code received from the specified port will be used.

### Note

- This setting does not affect the MIDI REMOTE function MIDI SETUP screen.
- If you select USB or SLOT 1–4, you will need to specify the port number (1–8) in the field on the right (Depending on the card that is installed, some slots may have only one port.)
- If you switch to INTERNAL, the time code will be set to the Start Time value.

### • FRAME RATE

Select one of the following as the frame rate for the time code (LTC, MTC, internal time code) you are using.

- 30** . . . . . 30 frames/second (non-drop)
- 30D** . . . . . 30 frames/second (drop frame)
- 29.97** . . . . . 29.97 frames/second (non-drop)
- 29.97D** . . . . . 29.97 frames/second (drop frame)
- 25** . . . . . 25 frames/second
- 24** . . . . . 24 frames/second

### • OFFSET TIME/START TIME


If INTERNAL is selected as the time code source, use this field to specify the time at which internal time code will begin (START TIME).

If any other time code source is selected, use this field to specify the offset (OFFSET TIME). The offset is the interval by which the timing at which scenes are recalled is adjusted backward or forward relative to the incoming time code (LTC or MTC).

In either case, you can edit the value by clicking the ▾ button and specifying the value in hours/minutes/seconds/frames units in the window that appears.

## ⑩ Time code display area

This displays the value of the incoming time code (LTC or MTC) or the internal time code. If INTERNAL is selected as the time code source, transport buttons are shown immediately below the time code value; you can use these buttons to rewind, stop, or start the internal time code.



In addition, if INTERNAL is selected you can click the ▾ button to access the TIME CODE window, and specify the time code directly.

### Note

An offset value is not added to the displayed time code.

## ⑪ TIME CODE INSERT

This button registers the time code data in the list in realtime. When the time code source is running, clicking this button will capture the time code value and add it as a new event. The captured time code is input in the EVENT TRIGGER field of the new event, and the SCENE TITLE field will be “no assignment.” At this time, the events within the list are sorted in descending order of time code. (If an event exists at the same time location, it will be overwritten by the new event.)

### Note

If the time code source is OFF, the EVENT TRIGGER column will be “[MANUAL].” If the time code source is TIME CODE, MIDI, USB, or SLOT 1–4, the offset value has been added to the time code value of the newly added event.

## ⑫ TIME CODE OVERWRITE

This button replaces the time code of the event selected in the list in realtime. When the time code source is running, clicking this button will write the current time location as the time code value of the currently selected event. (The SCENE TITLE field will not change.) At this time, the events within the list are sorted in descending order of time code.

If a blank line is selected, this button is grayed-out.

### Note

If the time code source is OFF, the EVENT TRIGGER column will be “[MANUAL].” If the time code source is TIME CODE, MIDI, USB, or SLOT 1–4, the offset value has been added to the rewritten time code value.

13 SCENE INSERT

This button inserts one or more consecutive scenes from scene memory into the event list. Use the FROM/TO fields located at right to specify the starting and ending scene numbers, and click this button; the specified scenes will be inserted as new events for recall immediately before the currently selected event. The EVENT TRIGGER field is set to “[MANUAL]” for all of the new events.

14 SCENE OVERWRITE

This button overwrites the scene assignments of consecutive events in the event list with multiple consecutive scenes from scene memory. Use the FROM/TO fields located at right to specify the starting and ending scene numbers, and click this button; starting at the currently selected line of the event list, the SCENE TITLE field of the corresponding number of subsequent events will be rewritten to the scenes you specified. (The EVENT TRIGGER field will not change.) If a blank line is selected, this button is grayed-out.

15 DELETE

This button deletes the event selected in the event list. If a blank line is selected, this button is grayed-out.

16 UNDO

This button returns the event list to its state prior to the most recent editing operation. If undo cannot be executed, this button is grayed-out.

17 ALL DELETE

This button deletes all events from the event list. When you click this button, a confirmation message will appear.


**Note**

If you edit the list (4-8, 11-17) or change the time code, the NEXT EVENT button in the constantly-displayed area will search from the current time code. However if the time code source is OFF, or if there is no time code setting in the EVENT TRIGGER field (only for [MANUAL] and [INTERVAL]), the NEXT EVENT will be the beginning of the list.

**SELECTIVE RECALL screen**

In this screen you can make settings for the Selective Recall function, which, independently for each scene, lets you exclude specific parameters/channels from recall, or conversely recall only specific parameters/channels.

**SELECTIVE RECALL**



1 SELECTIVE RECALL ENABLE/DISABLE

Enables/disables Selective Recall for the currently selected scene. If this button is set to DISABLE, the Selective Recall function is disabled.


**Note**

- Unlike the RECALL SAFE screen (p.166) which is common to all scenes, the settings in the SELECTIVE RECALL screen are independent for each scene.
- If you edit the settings of the SELECTIVE RECALL screen, you must store that scene in order to make your changes effective.

2 SELECTION MODE

Use the following two buttons to choose how you want to use the SELECTIVE RECALL screen.

- **SAFE PARAMETER button**  
If this button is on, you can specify the channels/parameters that will be excluded from recall operations.
- **RECALL PARAMETER button**  
If this button is on, you can specify the channels/parameters that will be recalled. Immediately after you switch buttons, all channels/parameters will be subject to recall.



③ **SAFE ON/OFF buttons**  
**RECALL ON/OFF buttons**

The function of these buttons will depend on the SELECTION MODE (②) setting.

**If the SAFE PARAMETER button is on**

These buttons function as SAFE ON/OFF buttons that specify the channels excluded from recall operations.

**If the RECALL PARAMETER button is on**

These buttons function as RECALL ON/OFF buttons that specify the channels that will be recalled.

④ **Parameter matrix grid**

Here you can select the parameters that will be recalled (or excluded from recall). SAFE PARAMETER selections are shown in green, and RECALL PARAMETER selections are shown in blue. If the ALL button is on, all parameters other than CH to MIX will be recalled (or excluded from recall).

**Note**

- Matrix grids corresponding to combinations that cannot be selected are grayed-out.
- Settings in the parameter matrix grid are ignored for channels whose SAFE ON/OFF button or RECALL ON/OFF button is switched off.

⑤ **ASSIGN**


This area indicates the number of assigned channels for each parameter.

⑥ **SET ALL**

These buttons turn on the buttons of all channels or all buttons of the corresponding parameter.

⑦ **CLEAR ALL**

These buttons turn off the buttons of all channels or all buttons of the corresponding parameter.



⑧ **OTHER SAFE/RECALL PARAMETERS**

By using these buttons, parameters other than those described above can be excluded from recall operations.

If the SAFE PARAMETER button is turned on in the SELECTION MODE (②) area, these buttons specify the parameters that will be excluded from recall. If the RECALL PARAMETER button is turned on, these buttons specify the parameters that will be recalled.

⑨ **SET ALL**

This button turns on all buttons of the OTHER SAFE PARAMETERS area.

⑩ **CLEAR ALL**

This button turns off all buttons of the OTHER SAFE PARAMETERS area.

In the case of parameters (such as those listed below) for which two adjacent odd-numbered/even-numbered channels or modules share a single parameter, the parameter will be recalled (or excluded from recall) only if selective recall is specified for both channels/modules.



- GATE STEREO LINK
- COMP STEREO LINK
- DELAY GANG
- PAN MODE
- GEQ LINK
- ATT GANG
- MS DECODE
- FIXED/VARI

**Note**

- Recall Safe and Selective Recall can be used together. Channels/parameters excluded from recall operations by either Recall Safe or Selective Recall (or both) will not be recalled.
- Selective Recall applies when a scene is recalled in PREVIEW mode.
- When you recall a scene, there may be cases in which a conflict in pairing settings between Recall Safe and Selective Recall causes the settings of a parameter to differ between L and R channels. In such cases, the parameter will be linked when it is next operated.

## RECALL SAFE screen

Here you can specify parameters/channels that will be excluded from recall operations for all scenes.



### ① HA SAFE ON/OFF (Head Amp safe on/off) buttons

These buttons select the channels whose assigned HA (Head Amp) will be excluded from recall operations.

#### Note

If you scroll the scroll bar downward, you will see that the CH column of the SAFE PARAMETERS area shows not only input channels but also the following input ports.  
 AD1-AD48 . . . INPUT jacks 1-48  
 AD1L-AD4R . . . L/R channels of ST IN jacks 1-4  
 ExHA1-1-ExHA8-8 . . . Channels 1-8 of external head amps 1-8 (AD8HR or AD824)

### ② CH SAFE ON/OFF (Channel safe on/off) buttons

These buttons select the channels that will be excluded from recall operations. These are linked with the [RECALL SAFE] key of the panel.

### ③ Parameter matrix grid

Here you can select the channel parameters that will be excluded from recall operations. If the ALL button is on, all parameters except for CH to MIX will be excluded.

Recall Safe and Selective Recall can be used together. Channels/parameters excluded from recall operations by either Recall Safe or Selective Recall (or both) will not be recalled.

#### Note

Settings in the parameter matrix grid are ignored for channels whose CH SAFE ON/OFF button is OFF.

### ④ ASSIGN


This area indicates the number of assigned channels for each parameter.

### ⑤ SET ALL

These buttons turn on the buttons of all channels or all buttons of the corresponding parameter.

### ⑥ CLEAR ALL

These buttons turn off the buttons of all channels or all buttons of the corresponding parameter.



### ⑦ SELECTIVE RECALL PARAMETERS PASTE

This button copies parameter settings from the SELECTIVE RECALL screen, and pastes them into the RECALL SAFE screen. When you click the button, a confirmation message will appear.

### ⑧ OTHER SAFE PARAMETERS

By using these buttons, parameters other than those described above can be excluded from recall operations.

### ⑨ SET ALL

This button turns on all buttons of the OTHER SAFE PARAMETERS area.

### ⑩ CLEAR ALL

This button turns off all buttons of the OTHER SAFE PARAMETERS area.

In the case of parameters (such as those listed below) for which two adjacent odd-numbered/even-numbered channels or modules share a single parameter, the parameter will be excluded from recall only if recall safe is specified for both channels/modules.



- GATE STEREO LINK
- COMP STEREO LINK
- DELAY GANG
- PAN MODE
- GEQ LINK
- ATT GANG
- MS DECODE
- FIXED/VARI

#### Note

- *Selective Recall applies when a scene is recalled in PRE-VIEW mode.*
- *When you recall a scene, there may be cases in which a conflict in pairing settings between Recall Safe and Selective Recall causes the settings of a parameter to differ between L and R channels. In such cases, the parameter will be linked when it is next operated.*

## FADE TIME screen

Here you can specify how fader and pan will change smoothly to their new values over a specified duration when the scene is recalled.



### ① FADING ENABLE/DISABLE

Enables/disables the Fade function for fader levels.

#### Note

- *The settings in the FADE TIME screen are independent for each scene. If you edit these settings, you must store that scene in order to make your changes effective.*
- *The Fade function will apply when you recall a scene for which the ENABLE button is selected.*

### ② INPUT CH PANNING ENABLE/DISABLE (Input channel panning enable/disable)

If the ENABLE button is selected, the Fade function will also apply to the PAN (BALANCE) parameter of input channels. This button is independent from the FADING ENABLE/DISABLE (①) setting. Use the following two buttons to select the input channels to which this will apply.


- **When the ALL INPUT button is on**  
The Fade function will apply to the PAN (BALANCE) parameter of all input channels.
- **When the SAME AS FADING button is on**  
The Fade function will apply to the PAN (BALANCE) parameter of only the input channels you select in ④.

### ③ FADE TIME/START OFFSET

Use the following two buttons to select the parameters that can be viewed/edited in the FADE TIME screen. The indication at the right shows which button is currently selected.

- **When the FADE TIME button is on**  
Edit the time (fade time) over which the fader or pan parameter of the corresponding channel will reach the new value when you recall a scene for which the Fade function is enabled.

- **When the START OFFSET button is on**  
 Edit the time (start offset time) after which the fader or pan parameter of the corresponding channel will begin changing when you recall a scene for which the Fade function is enabled.



④ **Channel settings**

Here you can turn the Fade function on/off and specify the fade time (or the start offset time) for each input channel / output channel.

Use the channel name buttons to switch the Fade function on/off. The box below each button lets you specify the fade time or start offset time. Move the cursor to a box, and turn the [DATA] encoder or click the [←] / [→] buttons at the left and right to edit the value.

The color of the numerical value shown in the box will change as follows.

- **When the FADE TIME button is on**  
 The value is displayed in white for channels whose start offset time is “----” (unset), and in light blue for channels that are set to 0.1 or above.
- **When the START OFFSET button is on**  
 The value is displayed in red for channels whose start offset time is “----” (unset), and in yellow for channels that are set to 0.1 or above.

If desired, you can copy the fade time / offset time value from one channel to another as follows. Move the cursor to the box that displays the value you want to copy; then hold down the [SHIFT] key and press the [ENTER] key to access the JOB SELECT window.





In this window, select the copy-destination item and click the OK button; the value of the selected channel will be copied.

- ⑤ **SET ALL**  
 This button enables the Fade function for all input channels or output channels.
- ⑥ **CLEAR ALL**  
 This button disables the Fade function for all input channels or output channels.

## TRACKING RECALL screen

Here you can make settings for the Tracking Recall function, which adds a specified offset value to the value of each fader when you recall a scene.




- ① **TRACKING RECALL ENABLE/DISABLE**  
Enables/disables the Tracking Recall function.

### Hint

The settings in the TRACKING RECALL screen apply to all scenes.

- ② **DISPLAY SELECT**  
These buttons select the type of channels that are shown in the TRACKING RECALL screen; either INPUT (input channels) or OUTPUT (output channels).
- ③ **SET ALL**  
This button enables Tracking Recall for all channels (including channels not currently shown in the screen).
- ④ **CLEAR ALL**  
This button disables Tracking Recall for all channels (including channels not currently shown in the screen).
- ⑤ **OFFSET LOCK**  
If this button is on, the sliders of all channels (including channels not currently shown in the screen) will be grayed-out, and you will be unable to edit the offset value.



- ⑥ **ON (Tracking On)**

These buttons enable/disable tracking for each channel. If the TRACKING RECALL ENABLE/DISABLE button is set to ENABLE, tracking is enabled on channels for which this button is ON.

### Note

If OFFSET LOCK (⑤) is off, turning this button on will reset the tracking offset of the corresponding channel to 0 dB. In this state you operate the fader of the corresponding channel, the relative amount of fader movement from the point at which this button was turned on will be memorized as the tracking offset. You can then turn OFFSET LOCK on to lock the offset. This offset value will be added whenever you subsequently recall a scene.

- ⑦ **Tracking offset**

Here you can specify the offset value applied to each channel if tracking is enabled. The range is  $\pm 15$  dB. While OFFSET LOCK (⑤) is off, operating the panel faders will cause these values to change as well; however, adjusting the offset values in the screen will not cause the panel faders to move.

## GLOBAL PASTE screen


This screen lets you copy parameter settings of any desired channel or parameter in the current scene, and paste them into one or more scenes in scene memory.



### ① PASTE MODE

Select the type of copy-source parameter from the following choices. You cannot select more than one type simultaneously.

- INPUT** . . . . . Input channel parameters
- OUTPUT** . . . . Output channel parameters
- DCA, GEQ, EFFECT** . . . . DCA level or mute on/off status, GEQ settings, internal effect settings



### ② CURRENT SCENE

Here you can select the channels and parameters that will be copied from the currently selected scene. The contents shown in this area will depend on the paste mode (①) you choose.

### • If Paste Mode= INPUT

Select input channels in the left area, and select parameters in the right area. You can select the following parameters.

<b>ALL</b>	All parameters except for HA, PATCH, and NAME
<b>ATT</b>	Attenuator
<b>EQ</b>	EQ function settings
<b>GATE</b>	GATE function settings
<b>COMP</b>	COMP function settings
<b>DELAY</b>	DELAY function settings
<b>FADER</b>	Fader level
<b>ON</b>	CH [ON] key on/off status
<b>PAN/BAL</b>	Pan/balance settings
<b>INSERT</b>	Insert on/off status and insert point
<b>SEND<sup>*1</sup></b>	Send level to the desired MIX bus(es)
<b>DCA</b>	Associated DCA group
<b>MUTE</b>	Associated mute group
<b>LCR</b>	LCR screen settings
<b>HA</b>	Settings for the head amp assigned to the corresponding input channel
<b>PATCH</b>	Settings for the input patch assigned to the corresponding input channel
<b>NAME</b>	Name assigned to the corresponding input channel

\*1. If the SEND button is on, use the MIX buttons (1–24) to select the applicable MIX bus. If the MIX bus is paired, SEND PAN is included in PAN/BAL if FOLLOW PAN “VARI” is on, or included in SEND if it is off.

### • If Paste Mode= OUTPUT


Select output channels in the left area, and select parameters in the right area. You can select the following parameters.

<b>EQ</b>	EQ function settings
<b>COMP</b>	COMP function settings
<b>DELAY</b>	DELAY function settings
<b>FADER</b>	Fader level
<b>ON</b>	CH [ON] key on/off status
<b>BAL</b>	Balance settings
<b>INSERT</b>	Insert on/off status and insert point
<b>TO MTRX<sup>*1</sup></b>	Send level to the desired MATRIX bus(es)
<b>DCA</b>	Associated DCA group
<b>MUTE</b>	Associated mute group
<b>LCR</b>	LCR screen settings
<b>WITHOUT MIX SEND/ WITH MIX SEND</b>	Selects whether the send level sent from input channels to the selected MIX bus will be included (WITH...) or will not be included (WITHOUT...) in the pasted data.

\*1. If the TO MTRX button is on, use the MATRIX buttons (1–8) to select the applicable MATRIX bus.

### Note

- If Paste Mode= INPUT, and the parameter being pasted is NAME, the name library linked to the selected scene will be searched automatically and pasted.
- Be aware that if other scenes link to this library, the paste operation will overwrite the library, meaning that other scenes may be affected.



### ③ DESTINATION SCENE (Paste-destination scene)

This list lets you select the scenes to which the data will be pasted. If you want to select multiple consecutive scenes as the paste-destination, select the starting number in the upper list and the ending number in the lower list. (If you're pasting to only one scene, select the same scene in the upper and lower lists.)

You can change the order in which the list is sorted by clicking the buttons shown at the top of the scene number, SCENE TITLE, TIME STAMP, or COMMENT columns.

### ④ PASTE

This button executes the Global Paste operation. When you click this button, a confirmation message will appear.

In the case of parameters such as those listed below, of which only one exists for each two adjacent odd-numbered/even-numbered channels or modules, the parameter will be pasted only if both channels/modules are specified for pasting.

- GATE STEREO LINK
- COMP STEREO LINK
- DELAY GANG
- PAN MODE
- GEQ LINK
- ATT GANG
- MS DECODE
- FIXED/VARI

#### Note


- Paste is valid even in PREVIEW mode.
- When you paste to a scene, there may be cases in which a conflict in pairing settings causes the settings of a parameter to differ between L and R channels. In such cases, the parameter will be recalled with those settings, and will be linked when it is next operated.

## MIDI REMOTE function

### MIDI SETUP screen

Here you can select the types of MIDI message transmitted and received by the PM5D, and select the MIDI port that will be used.

#### MIDI SETUP



#### ① MODE

Here you can select the way in which program changes and control changes will be transmitted/received.

#### • PROGRAM CHANGE MODE

In this area you can select the program change transmission/reception method.

##### SINGLE

If this button is on, program changes will be transmitted/received on a single MIDI channel (Single mode).

##### OMNI ON/OFF

If this button is on, program changes of all MIDI channels will be received in Single mode (this is unavailable in Multi mode).

##### BANK ON/OFF

If this button is on, bank select messages will be transmitted and received in Single mode (this is unavailable in Multi mode).

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

**MULTI**

If this button is on, program changes will be transmitted/received on multiple MIDI channels (Multi mode).

**Hint**

- If program change reception is on, the PM5D's scenes or effects will switch when the appropriate program change is received from an external device. Additionally, if transmission is on, program changes will be transmitted to an external device when scenes or effects are switched on the PM5D.
- The scene/effect assignment for each program change number is made in the MIDI PGM CHANGE screen (► p.173).

- **CONTROL CHANGE MODE**

In this area you can select the control change transmission/reception method.

**NRPN**

If this button is on, PM5D mix parameters will be transmitted/received as NRPN messages.

**TABLE [SINGLE]**

If this button is on, PM5D mix parameters will be transmitted/received as control change messages on a single MIDI channel.

**TABLE [MULTI]**

If this button is on, PM5D mix parameters will be transmitted/received as control change messages on multiple MIDI channels.

**Hint**

- If control change reception is on, the PM5D's parameters will change when the appropriate control change is received from an external device. If transmission is on, a control change will be transmitted to an external device when you edit a parameter on the PM5D.
- If NRPN is selected as the control change mode, the assignment of parameters to NRPN is pre-defined and cannot be changed.
- If TABLE [SINGLE] or TABLE [MULTI] is selected as the control change mode, the parameter assignment for each control number can be edited in the MIDI CTRL CHANGE screen (► p.174).

- ② **Tx (MIDI transmission)**

Here you can make various settings for transmission of MIDI messages.

- **MIDI PORT Tx (MIDI transmission port)**

Select the port at which the PM5D will transmit MIDI messages. You have the following choices.

**MIDI** . . . . . The rear panel MIDI IN connector

**USB** . . . . . The rear panel USB connector

**SLOT 1-4** . . . A card that supports serial transmission and is installed in rear panel slot 1-4

Move the cursor to this box and turn the [DATA] encoder or click the  /  buttons at left or right to change the setting; then press the [ENTER] key to finalize the change.

If you select USB or SLOT 1-4, you will need to specify the port number (1-8) in the field on the right (Depending on the card that is installed, some slots may have only one port.)

- **SINGLE MODE MIDI CH Tx (MIDI transmission channel for Single mode)**

Select the MIDI channel on which the PM5D will transmit program changes, control changes, parameter changes, and bulk data. (This setting is valid only in Single mode.) Move the cursor to this box and turn the

[DATA] encoder or click the  /  buttons at left or right to change the setting; then press the [ENTER] key to finalize the change.

- **PROGRAM CHANGE Tx (Program change transmission)**

- **CONTROL CHANGE Tx (Control change transmission)**

- **PARAMETER CHANGE Tx (Parameter change transmission)**

These buttons turn transmission on/off for program changes, control changes, and parameter changes respectively.

**Hint**

Parameter changes are a method by which PM5D parameters are transmitted in the form of system exclusive messages.

- **MIDI THRU Tx (Thru output)**

Select the port from which messages input to MIDI THRU Rx will be output. The selection method is the same as for MIDI PORT Tx.

- ③ **Rx (MIDI reception)**

Here you can make various settings for reception of MIDI messages.

- **MIDI PORT Rx (MIDI reception port)**

Select the port from which the PM5D will receive MIDI messages.

- **SINGLE MODE MIDI CH Rx (MIDI reception channel for Single mode)**

Select the MIDI channel on which the PM5D will receive program changes, control changes, parameter changes, and bulk data. (This setting is valid only in Single mode.)

- **PROGRAM CHANGE Rx (Program change reception)**

- **CONTROL CHANGE Rx (Control change reception)**

- **PARAMETER CHANGE Rx (Parameter change reception)**


These buttons turn transmission on/off for program changes, control changes, and parameter changes respectively.

- **MIDI THRU Rx (Thru input)**

Here you can select the port that will "thru input" the received MIDI messages.

- ④ **ECHO (MIDI message echo output)**

Here you can select whether received program changes, control changes, parameter changes, and other MIDI messages will be echoed out from the MIDI transmission port.





- ⑤ **MMC OUTPUT PORT**  
This selects the port that will transmit MMC (MIDI Machine Control).
- ⑥ **MIDI REMOTE OUTPUT PORT (MIDI remote output port)**  
Here you can select the port from which MIDI messages will be transmitted by the MIDI Remote function, for each of the four banks. Incoming messages used by the LEARN function of the MIDI REMOTE screen are also received at this port.
- ⑦ **PM5D EDITOR (PM5D EDITOR connection port)**  
Here you can select the port and ID number (1–8) used to communicate with the PM5D EDITOR application, which controls the PM5D from a computer.

## MIDI PGM CHANGE (MIDI program change) screen

In this screen you can select the scene or effect library assigned to each MIDI program number.

### MIDI PGM CHANGE



- ① **MIDI SETUP**  
Select the ports that the PM5D will use to transmit and receive MIDI messages, and the MIDI channels. This item is linked with the settings in the MIDI SETUP screen.
- ② **PROGRAM CHANGE SETUP**  
Here you can specify how program changes will be transmitted and received, and turn transmission and reception on/off. This item is linked with the settings in the MIDI SETUP screen.
- ③ **ECHO ON/OFF**  
This selects whether program changes received from an external device are echoed-out from the MIDI transmission port. This item is linked with the settings in the MIDI SETUP screen.

BANK	PGM No.	LIBRARY NAME
1	1	[SCENE] 001 Openings
1	2	[SCENE] 002 ACT1
1	3	[SCENE] 003 ACT2
1	4	[SCENE] 004 ACT3
1	5	[SCENE] 005 Finale
1	6	[SCENE] 006 [ No Data! ]
1	7	[SCENE] 007 [ No Data! ]
1	8	[SCENE] 008 [ No Data! ]
1	9	[SCENE] 009 [ No Data! ]

④ List

In this list you can view and select the event (scene recall / effect library recall) assigned to each program number.

• CH/BANK (Channel/Bank)

Indicates the MIDI channel on which the program change is transmitted/received. In Single mode when the BANK ON/OFF button is on, this column is displayed as BANK, and the value shown corresponds to the bank number.

• PGM No. (Program number)

Indicates the program number 1–128.

• LIBRARY NAME

Here you can view/select the type and the number of the event (scene or effect) assigned to each channel/program number.

To make an assignment, click the desired line to select it. (That line will be highlighted in the center of the list.) Click the  button shown at the left of the LIBRARY NAME field; the MIDI PGM CHANGE SETUP window will appear. In this window you can select the type of event (a scene, or a library item for effect 1–8) and its number.

When a program change on the corresponding MIDI channel is received, the event assigned to that program number will be recalled. In addition, the corresponding program change will be transmitted when this event is recalled on the PM5D.

⑤ PRESET

Clicking this button will restore all event assignments in the list to their default state.


⑥ CLEAR ALL

Clicking this button will delete all event assignments in the list.

## MIDI CTRL CHANGE (MIDI control change) screen

Here you can select the PM5D parameter (fader operation, [ON] key operation, etc.) assigned to each control number.

### MIDI CTRL CHANGE



① MIDI SETUP

Select the ports that the PM5D will use to transmit and receive MIDI messages, and the MIDI channels. This item is linked with the settings in the MIDI SETUP screen.

② CONTROL CHANGE SETUP

Here you can specify how control changes will be transmitted and received, and turn transmission and reception on/off. This item is linked with the settings in the MIDI SETUP screen. You have the following choices of transmission/reception method.

• NRPN

If this button is on, PM5D mix parameters will be transmitted/received as NRPN messages.

• TABLE [SINGLE]

If this button is on, PM5D mix parameters will be transmitted/received as control change messages on a single MIDI channel according to the assignments in the list (④).

• TABLE [MULTI]

If this button is on, PM5D mix parameters will be transmitted/received as control change messages on

multiple MIDI channels according to the assignments in the list (4).

### ③ ECHO ON/OFF

This selects whether control changes received from an external device are echoed-out from the MIDI transmission port. This item is linked with the settings in the MIDI SETUP screen.

⑤ PRESET      ⑥ CLEAR ALL

CH	No.	CTRL CHANGE EVENT	
1	0	[BANK SELECT]	[MSB]
1	1	FADER H	INPUT CH 1
1	2	FADER H	INPUT CH 2
1	3	FADER H	INPUT CH 3
1	4	FADER H	INPUT CH 4
1	5	FADER H	INPUT CH 5
1	6	FADER H	INPUT CH 6
1	7	FADER H	INPUT CH 7
1	8	FADER H	INPUT CH 8

### ④ List

In this list you can view/select the events assigned to each control number.

- **CH (Channel)**  
Indicates the MIDI channel on which the control change is transmitted/received.
- **CTRL No. (Control number)**  
Indicates the control number 0–119. Control numbers 0, 32, and 96–110 cannot be specified.
- **CTRL CHANGE EVENT (Control change event)**  
Indicates/selects the type of event assigned to the corresponding channel / control number.

To make an assignment, click the desired line (that line will be highlighted in the center of the list); then click the  button at the left of the CTRL CHANGE EVENT field to open the MIDI CTRL CHANGE SETUP window. In this window you can specify the parameter in three levels (mode, parameters 1/2).

When a control change on the corresponding MIDI channel is received, the event assigned to that control number will be edited. In addition, the corresponding control change will be transmitted when this event is edited on the PM5D.

#### Note

*This list is ignored if the control change mode is set to NRPN.*

### ⑤ PRESET



Clicking this button will restore all event assignments in the list to their default state.

### ⑥ CLEAR ALL

Clicking this button will delete all event assignments in the list.

## MIDI REMOTE screen

Here you can assign MIDI messages to panel faders, CH [ON] keys, encoders, and ENCODER [ON] keys, and make settings for the MIDI Remote function used to control external devices.



- ① **TRANSMIT ENABLE/DISABLE (Enable/disable transmission)**  
Enables/disables the MIDI Remote function. You can enable/disable this function for each of the four banks (memories in which MIDI Remote settings are stored).

- ② **ASSIGN TO CH STRIP SECTION (Assign to channel strip)**  
You can choose the following two as the channel strip to which the MIDI Remote function is assigned (both can be selected simultaneously if desired).


INPUT CH . . . . . INPUT channel strip 1–24  
STIN/FXRTN . . . . . ST IN/EX RTN channel strip 1–4

This setting applies to all four banks.

- ③ **Channel selection**  
Select the MIDI Remote channel for which you want to make settings. When you click the  /  buttons at the left and right of the box, the corresponding name is displayed in the box at the right. You can change the name by clicking the  button of the right box.

#### Note

*You cannot change the MIDI Remote channel you're editing while any of the LEARN buttons (7) are on. You will have to turn off the LEARN button first.*



④ **BANK SELECT**

Of the four banks, select the bank for which you want to make settings. When you use the A–D buttons to select a bank, the name of that bank will be displayed in the field immediately above. You can click the button to the left to edit the name of the bank.

⑤ **CLEAR BANK**

This button erases the currently selected bank (all MIDI messages will be deleted).



⑥ **MIDI message**

From the top, these fields assign MIDI messages to the ENCODER [ON] keys, encoders, CH [ON] keys, and faders. Click the to open the MIDI REMOTE SETUP window, and input the message as hexadecimal values. You can input the following values.

Value	Available Assignments	Content
00(H)–FF(H)	All	The MIDI message that is transmitted (hexadecimal).
END	All	Indicates the end of the MIDI message. When you operate the corresponding controller, the MIDI message from the beginning until immediately before END will be transmitted.
SW	All	Indicates the on/off status of the encoder [ON] key or the channel [ON] key. A value of 7F(H) is transmitted when the key turns on, and a value of 00(H) is transmitted when the key turns off. If this is assigned to an ENCODER or FADER, the current value of the key will be transmitted when the encoder or fader is operated.
ENC	ENCODER ON/ ENCODER	Indicates the current position of the encoder. If assigned to an ENCODER, a value of 00–7F(H) is transmitted when the encoder is operated. If assigned to an ENCODER [ON] key, the current value of the encoder is transmitted when the key is switched on.
FAD	CH ON/ FADER	Indicates the current position of the fader. If assigned to a FADER, a value of 00–7F(H) is transmitted when the fader is operated. If assigned to a CH [ON] key, the current value of the fader is transmitted when the key is switched on.

**Hint**

When you click a hexadecimal value, the region interpreted as a MIDI message that includes that value will be displayed in red.

⑦ **LEARN**

Use this button to assign a received MIDI message to a controller. When you turn on one of the four LEARN buttons, the MIDI message received by the PM5D will be assigned to the corresponding controller. The LEARN function uses the MIDI messages received at the input port specified by the MIDI REMOTE OUTPUT PORT in the MIDI SETUP screen.

**Hint**

- MIDI messages assigned using the LEARN button can be a maximum of 16 bytes long (the 17th and subsequent bytes are discarded). If the message is less than 16 bytes long, END will be immediately after the last data value.
- If a control change is received, the third byte will automatically be replaced by FAD (if the assignment destination is FADER), ENC (if the assignment destination is ENCODER), or SW (if the assignment destination is ENCODER ON or CH ON).
- If more than one message is received while a LEARN button is on, the last message will be used. (If the status byte was omitted from the last message, the appropriate status byte will be added.)

⑧ **LATCH**

If a specific byte is set to “SW” in a message assigned to an ENCODER [ON] key or CH [ON] key, use the LATCH button to select one of the following behaviors.



- **If the LATCH button is on**  
The on/off status will change each time you press the key (Latched). If you press the key from the Off state, a MIDI message with 7F(H) as the SW value will be transmitted, and when you press the same key once again a MIDI message with 00(H) as the SW value will be transmitted.
  - **If the LATCH button is off**  
The switch will be on only while you are holding it down, and will turn off when you release it (Unlatched). Immediately after you press the key, a MIDI message with 7F(H) as the SW value will be transmitted; immediately after you release the key, a MIDI message with a SW value of 00(H) will be transmitted.
- If a specific byte is set to “ENC” (or “FAD”) in a message assigned to an ENCODER [ON] key or a CH [ON] key, use the LATCH button to select one of the following behaviors.
- **If the LATCH button is on**  
If you press the key from the Off state, a MIDI message with the current setting of the encoder (or fader) as the ENC (or FAD) value will be transmitted, and when you press the same key once again a MIDI message with a value of 00(H) as the ENC (or FAD) value will be transmitted.
  - **If the LATCH button is off**  
The moment you press the key, a MIDI message with the current setting of the encoder (or fader) as the ENC (or FAD) value will be transmitted; the moment you release the key, a MIDI message with 00(H) as the ENC (or FAD) value will be transmitted.

**Note**

If SW/ENC/FAD is not specified as the last byte of the MIDI message, turning the key on or off will transmit the same MIDI message; i.e., the same message is transmitted when the key goes off.

## GPI screen

Here you can make settings for GPI (General Purpose Interface) input/output, used to transfer control signals between the PM5D and an external device.




- ① **GPI IN port**  
These are the numbers of the GPI IN ports for which you can make settings.
- ② **GPI IN status**  
The yellow bar indicates the input signal voltage state of the corresponding port. If the bar is not shown, the signal is in the grounded state; if the bar is displayed to the right edge, the signal is at the high level state. Use the POLARITY (③) field to select whether the signal is active when low or high.
- ③ **POLARITY**  
This selects how GPI IN on/off will be detected. You can choose Low Active (active when the key is grounded) or High Active (active when key is open, or when a high level signal is input).
- ④ **FUNCTION**
- ⑤ **PARAMETER**  
These fields indicate the function that is executed when the corresponding GPI IN port becomes active (or the function that is controlled by the voltage value being input from the GPI IN port), and option parameters for that function.

To edit the settings, click the  button at the left to open the GPI IN PORT ASSIGN window, and select the function and parameter from the following table.

FUNCTION	PARAMETER	PM5D operation
NO ASSIGN	—	No assignment
MONITOR	DIMMER ON	Switches the Dimmer function on/off
	SOURCE=[monitor source name]	Switches the monitor source
	MONO ON	Switches the monitor section [MONO] key on
TALKBACK ON	LATCH	Switches the Talkback function on/off (latched operation)
	UNLATCH	Switches the Talkback function on/off (unlatched operation)
CH ON-LATCH	[channel name]	Switches the channel on/off (latched operation)
CH ON-UNLATCH	[channel name]	Switches the channel on/off (unlatched operation)
FADER LEVEL	[channel name]	Modifies the fader value (LEVEL parameter) according to the voltage
SUR-ROUND PAN	FRONT-REAR PAN [SEL]	according to the voltage.
	LEFT-RIGHT PAN [SEL]	Modifies the surround panning (left/right) of the selected channel according to the voltage.
	FRONT-REAR PAN [ODD]	Modifies the surround panning (front/rear) of the selected odd-numbered channel according to the voltage.
	LEFT-RIGHT PAN [ODD]	Modifies the surround panning (left/right) of the selected odd-numbered channel according to the voltage.
	FRONT-REAR PAN [EVEN]	Modifies the surround panning (front/rear) of the selected even-numbered channel according to the voltage.
	LEFT-RIGHT PAN [EVEN]	Modifies the surround panning (left/right) of the selected even-numbered channel according to the voltage.
USER DEFINED KEY FUNCTION	[User Defined key bank / key number]	While the external input is active, executes the same operation as when the selected User Defined key is pressed
USER DEFINED KEY LED	[User Defined key bank / key number]	While the external input is active, lights the LED of the selected User Defined key
PEAK HOLD ON		Switches the Peak Hold function on/off
OSCILLATOR ON	—	Switches the Oscillator on/off
SOLO ON		Switches the Solo function on/off

## ❑ GPI IN MONITOR



### ⑥ GPI IN monitor

The voltage from the GPI IN port selected by the X-AXIS field (⑧) and Y-AXIS field (⑨) is respectively indicated by a yellow  in the X-axis (horizontal) and Y-axis (vertical) dimensions of the graph.

The range of voltage variation used to determine the active/inactive status is shown as a red rectangle.

### ⑦ CALIBRATION

This button calibrates the range of voltage variation used by the PM5D to determine active/inactive status, so that the range will be appropriate for the voltages being input from the GPI PORT. (For details on using calibration ➔ p.125)

When you turn this button on, the range of voltage variation will be temporarily cleared; the range will be updated every time the GPI IN voltage changes. When you turn this button off, the range of variation will be memorized, and this range of variation will subsequently be used to determine the active/inactive state.

### ⑧ X-AXIS

### ⑨ Y-AXIS


These fields select the GPI IN port for which calibration will be performed. You can click the  /  buttons at left and right to change the port.

If you are using a two-dimensional controller such as a joystick, specify a port for both the X-axis and Y-axis. If you want to perform calibration for only one direction, set one of the ports to “-----.”

### ⑩ REVERSE

This button inverts the low/high level of the input, changing the displayed direction of the graph. This is equivalent to switching the POLARITY (⑬) of the selected GPI IN port.

## ❑ GPI OUT



### ⑪ GPI OUT port

These are the numbers of the GPI OUT ports for which you can make settings.

### ⑫ GPI OUT status

This indicates the state of the output signal for the corresponding port. The L/H character indicates whether the signal level is Low (the output level is grounded) or High (the output level is high). The background color is yellow when active, and gray when inactive. Use the POLARITY (⑫) field to select whether the signal is active when low or high.

### ⑬ POLARITY

Selects the polarity of the signal that is output when the GPI OUT port becomes active. You can select either Low Active  (grounded when active) or High Active  (high level when active).

### ⑭ TEST

This button tests the operation of each GPI OUT port. While this button is on, the corresponding GPI OUT port will temporarily become active, and a signal will be output according to the POLARITY (⑫) setting.

### ⑮ FADER START

Indicates the channel of the fader assigned as a trigger to each GPI OUT port, and the fader mode (trigger detection method) of that fader.

To edit the settings, click the  button at the left to open the GPI OUT PORT ASSIGN window, and select the fader mode and channel. You can select the following fader modes.

#### • FADER START

A control signal (trigger signal) 250 msec long will be output when the fader of the selected channel moves from  $-60$  dB or below to exceed  $-60$  dB.

#### • FADER STOP

A control signal (trigger signal) 250 msec long will be output when the fader of the selected channel reaches  $-\infty$  dB.

#### • FADER TALLY

A control signal will be output when the fader of the selected channel moves from  $-60$  dB or below to exceed  $-60$  dB. This control signal will be held until the fader reaches  $-\infty$  dB (or until that GPI OUT port receives a different trigger).

The setting of the GPI screen's FADER START field is linked with the GPI-related settings of the FADER START screen (➔ p.179).

## 16 USER DEFINED KEYS

This area indicates the User Defined keys that are assigned as triggers to each GPI OUT port, and their operations.

To edit the setting, click the  button at the left to open the GPI OUT PORT ASSIGN window; from the list, select the User Defined key bank (A–D) and number (1–25), and how the trigger signal will be transmitted. As the transmission method for the trigger signal, you can select either Latch (switch between active/inactive each time the key is pressed) or Unlatch (active only while the key is pressed).

## 17 TALLY



This area indicates the state of other Tally output functions assigned as triggers to each port. When you execute the corresponding operation on the PM5D, a control signal will be output from the corresponding GPI OUT port. This control signal will be held until you defeat the above operation (or until that GPI OUT port receives a different trigger).

To edit the settings, click the  button at the left to open the GPI OUT PORT ASSIGN window, and select one of the following functions.

Function	PM5D operation
NO ASSIGN	No assignment
POWER ON	The PM5D's power is turned on
SOLO ON	[SOLO] key is turned on
GPI IN 1 FUNCTION	The function assigned to GPI IN port 1 becomes active
GPI IN 2 FUNCTION	The function assigned to GPI IN port 2 becomes active
GPI IN 3 FUNCTION	The function assigned to GPI IN port 3 becomes active
GPI IN 4 FUNCTION	The function assigned to GPI IN port 4 becomes active
PREVIEW ON	SCENE MEMORY section [PREVIEW] key is turned on
CUE ON [INPUT ONLY]	Input channel [CUE] key is turned on
CUE ON [DCA ONLY]	DCA [CUE] key is turned on
CUE ON [OUTPUT ONLY]	Output channel [CUE] key is turned on
CUE ON	Any [CUE] key is turned on

## FADER START screen

Here you can make settings for the Fader Start function which lets you use input channel faders to control GPI OUT ports or external devices.



### 1 INPUT CH (Input channel)

This area shows the number and name of the channels (input channels, ST IN channels) for which you can make settings. When you click a line to select it, that line will be highlighted in the center of the list.

### 2 OUTPUT TYPE

### 3 PARAMETER

Indicates the type of signal that will be output when you operate the corresponding fader, and option parameters for it. To edit the setting, click the  button at the left of the OUTPUT TYPE field to open the FADER START ASSIGN window. You can select the following output types and parameters.

- **NO ASSIGN**  
No assignment.

- **GPI**


A trigger will be sent to the specified GPI OUT port according to the fader operation of the corresponding channel, and a control signal will be output. (The polarity of the control signal will be as specified by the settings in the GPI screen.) If this output type is selected, you can choose from the following two option parameters.

**FADER START** ... GPI OUT port from which the trigger is sent when the fader changes from below -60 dB to exceed -60 dB.


**FADER STOP** . . . . . GPI OUT port from which the trigger is sent when the fader reaches  $-\infty$  dB.

Note that the GPI-related settings you make in the FADER START screen are linked with the FADER START field of the GPI screen.

For example, if in the FADER START screen you specify different ports for the FADER START parameter and FADER STOP parameter of a certain channel, the FADER START field of the GPI screen will be assigned to the corresponding channel (Fader Mode= FADER START/FADER STOP) of those ports. (The opposite also applies.)



If the same port is specified for the FADER START parameter and the FADER STOP parameter, the GPI screen FADER START field will be assigned to the channel corresponding to that port (Fader Mode= FADER TALLY). (The opposite is also true.)




- **MMC**  
An MMC command will be sent from the currently-enabled MIDI port according to the fader operation of the corresponding channel. (The MIDI transmit port is selected in the MIDI SETUP screen.)  
An MMC PLAY command is transmitted when the fader changes from below  $-60$  dB to  $-60$  dB or higher, and an MMC STOP command is transmitted when the fader reaches  $-\infty$  dB.  
If this output type is selected, you can use an option parameter to specify the MMC device ID number (1-127 or ALL).
- **RS422**  
An RS422 protocol command will be sent from the RS422 REMOTE connector according to the fader operation of the corresponding channel.  
An RS422 protocol PLAY command is transmitted when the fader changes from below  $-60$  dB to  $-60$  dB or higher, and an RS422 protocol STOP command is transmitted when the fader reaches  $-\infty$  dB.

- ④ **CLEAR ALL**  
Clears the Output Type field assignments of all channels.

## TRANSPORT screen


Here you can use MMC/RS422 protocol commands to remotely control transport/locate operations on a recorder or other external device from the PM5D.



- ① **MMC DEVICE No.**  
Indicates the device ID number of the external device to be controlled via MMC. To change this setting, click the / buttons at left and right to choose from the range 1–127 or ALL (applies to all device ID numbers).



- ② **RS422 DATA FORMAT**  
Select the format (P2 or DENON) of the RS422 commands sent from the RS422 REMOTE connector. When you click this button, a confirmation message will appear.




### Note

The RS422 command format you specify in this screen also applies to the RS422 commands issued by the Fader Start function or the User Defined keys.

### Note

DENON format is a set of commands used in devices such as Denon's professional CD (DN-C680) and MD (DN-M1050R) players. On the CD or MD player, set the settings to 9600 bps and RS422. If you are using DENON format, clicking the button during Play will enter Pause mode; clicking the button during Standby will Stop. While stopped, click the button once again if you want to Standby. Clicking the button will return to the previous track, and clicking the button will advance to the next track. Use a D-sub 9-pin straight cable to connect the REMOTE RS422 connector to the device you wish to control using P2 or DENON format.



### ③ Transport

These buttons operate the transport of an external device. When you click a button, the corresponding MMC/RS422 command (from the left, REWIND, FAST FORWARD, STOP, PLAY, REC) will be transmitted.

There is an indicator above each RS422 transport button; the indicator will light as follows according to the status of the external device being controlled.

#### • P2

Playing	lit
Fast-forwarding	lit
Rewinding	lit
Stopped	lit
Recording	and  lit

#### • DENON

Playing	lit
Paused	blinking
Standby	lit
Stopped	All dark
Recording	and  lit
Recording paused	lit,  blinking

#### ④ LOCATE POINT

These buttons correspond to each locate point. Twenty locate points can be specified for MMC-compatible devices, and another twenty locate points can be separately specified for RS422-compatible devices. When you click buttons 1–20, an MMC command or RS422 command for moving to that locate point will be transmitted.

#### ⑤ Time code

This field indicates the time code that is specified for each locate point. To edit the time code, click the  button located at the left to open the MMC/RS422 LOCATE POINT window, and specify the new time code in hours/minutes/seconds/frames. (In the case of DENON format, use track/minute/second/frame units to specify the value.) You can also use the CAPTURE button located at the right to capture the time code being received by the PM5D.

#### ⑥ CAPTURE

This button captures the time code currently being received by the PM5D, and inputs it in the time code field. In the case of MMC, the time code source, frame rate, and offset time can be specified in the EVENT LIST screen (SCENE function). (➡ p.161) In the case of RS422, the time data at that moment for the external device being controlled will be captured.

### DME CONTROL screen

Here you can remotely control various functions of a Yamaha DME series digital mixing engine.

#### Hint

*As of this writing (August 2004), this function can be used with the DME series models DME64N and DME24N. (This function cannot be used with the DME32.)*



#### ① Component type selection area

Here you can select the type of DME series component that you want to control from the PM5D. When you click the  /  buttons at the left and right to select the type of component, the display in the central area of the screen will change accordingly. The following types of component can be selected.

- **SETUP**  
Select the port connecting the PM5D and the DME series unit, and initiate or terminate communication.
  - **GEQ**  
Control the DME series unit's graphic EQ from the PM5D.
  - **PEQ**  
Control the DME series unit's parametric EQ from the PM5D.
  - **CROSS OVER**  
An internal signal within the DME series unit is divided into six bands, and the output level, filter slope and type, and cutoff frequency etc. can be controlled for each band. This screen also lets you specify the cross-over frequency at which the bands are divided.
  - **LONG DELAY**
  - **SHORT DELAY**  
Control the long delay and short delay functions of the DME series unit from the PM5D.
  - **MATRIX**  
Specify the level of the signals sent from a specific input of the DME series unit to all outputs, or from all inputs to a specific output.
  - **SLOT OUTPUT**  
For each slot of the DME series unit, specify the output level, delay time, and phase setting of each port.
- ② **Component selection area**  
From the type of component you selected in ①, select the component that you want to control.

### ③ SCENE

This area indicates/selects the scene that will be stored/recalled on the DME series unit. When you click the / buttons located at left and right to select a number, the name of that scene is shown in the field at right.

### ④ STORE/RECALL

These buttons save (overwrite) the settings of the DME series unit edited in the PM5D's screen into the scene selected in the SCENE area, or recall the scene selected in the SCENE area into the DME.

#### Note

- When storing a DME scene from the PM5D's screen, you can only store by overwriting an existing scene on the DME; you cannot store the settings as a new scene or edit the scene name.
- If **SETUP** is selected, items ③, ④, and ⑥ are not shown.

### ⑤ Parameter display area

This area displays the parameters of the currently selected component. The displayed contents will depend on the component.

### ⑥ ASSIGN TO FADERS (DCA fader assignments)

You can use DCA faders 1–8 to control the parameters of the component currently shown in the screen.

#### Note

The parameters that can be assigned to DCA faders will depend on the component. This function may not be available for some components.

## □ Connecting the PM5D with a DME series unit


Various methods for connecting the PM5D with a DME series unit to transmit and receive audio signals and control signals are shown below.

#### Note

If characters other than alphabetical characters and symbols (e.g., double-byte characters such as Japanese) are used on the DME series unit in a component name or scene name, such characters may not be displayed correctly.


### ① Bi-directional connection via CobraNet

This connection method uses CobraNet (a format for transmitting multi-channel audio signals and control signals over Ethernet). Install an MY16-C CobraNet format compliant digital I/O card in a slot on both the PM5D and the DME series unit, and use an Ethernet cable to connect the two MY16-C cards. This method allows bi-directional transfer of audio signals over a single cable. For example, signals can be sent via the PM5D's MIX bus to the DME for processing, and then returned to a PM5D input channel.




### ② Bi-directional connection using the CASCADE IN/OUT connectors (DME64N only)

In this connection method, the CASCADE IN connector and CASCADE OUT connector of the PM5D and the DME64N are connected to each other, allowing bi-directional transfer of audio signals. Since the DME24N does not have CASCADE IN/OUT connectors, it cannot use this method.




### ③ Uni-directional connection using the CASCADE IN/OUT connectors — 1 (DME64N only)

This method is a uni-directional connection that sends audio signals from the DME64N to the PM5D via its CASCADE IN connector.



### ④ Uni-directional connection using the CASCADE IN/OUT connectors — 2 (DME64N only)

This method is a uni-directional connection that sends audio signals from the PM5D via its CASCADE OUT connector to the DME64N.



#### Note

When using the CASCADE IN/OUT connectors to make connections, the CASCADE IN/OUT connectors are used as the connectors, but the settings will be the same as when using slot input/output. In the CASCADE CONNECTION area of the MIXER SETUP screen (SYS/W.CLOCK function), you will need to make settings so that the CASCADE IN connector is assigned to the SLOT IN port (if using the CASCADE IN connector) or the SLOT OUT port is assigned to the CASCADE OUT connector (if using the CASCADE OUT connector).


#### Hint

If desired, you can control the DME series unit from the PM5D without transmitting or received audio signals. In this case, simply make one of the connections shown in examples ②–④; control signals will be sent from the PM5D to the DME.

**□ Initiating communication between the PM5D and the DME series unit**

To select the port used for audio signal transmission/reception between the PM5D and the DME series unit, and to initiate communication, proceed as follows.


- 1 **Connect the PM5D and the DME series unit.**
- 2 **In the DISPLAY ACCESS section, press the [MIDI/REMOTE] key several times to access the DME CONTROL screen.**
- 3 **In the component selection area at the upper left of the screen, select SETUP.**  
A screen like the following will appear.



The SETUP screen contains the following items.

- ① **CONNECT**  
This button initiates or terminates the connection between the PM5D and the DME series unit.
- ② **MIDI PGM CHANGE (MIDI program change)**  
If this button is on, a program change message will be transmitted to the DME via the I/O card (MY16-C) or via the CASCADE IN/OUT connectors when a scene is recalled on the PM5D. This allows scenes to be recalled on the DME in tandem with scene recall operations on the PM5D.
- ③ **INPUT PORT**  
Here you can select the PM5D port that will receive audio signals from the DME.
- ④ **MONITOR PORT**  
Here you can select the PM5D port that will receive monitor signals from the DME. Since this monitor signal is sent to the PM5D's CUE bus, the DME's monitor function can be controlled from the PM5D just like the PM5D's own cue function (EXTERNAL CUE function).
- ⑤ **MIXER SETUP (show the MIXER SETUP screen)**  
This button displays the SYS/W.CLOCK function MIXER SETUP screen.
- ⑥ **OUTPUT PORT**  
Here you can select the PM5D port that will output audio signals to the DME.

- 4 **In the INPUT PORT area located at the lower left of the screen, select the PM5D port that will receive audio signals from the DME series unit.**



The types of port that can be selected here will depend on the port that is currently selected for cascade input (MIXER SETUP screen CASCADE IN PORT SELECT field), as follows.


Setting in the CASCADE IN PORT SELECT field (MIXER SETUP screen)	Items available in the INPUT PORT field
CASCADE IN	----, SLOT1–SLOT4
SLOT4	----, CASCADE IN, SLOT1–SLOT3
SLOT3/4	----, CASCADE IN, SLOT1–SLOT2
SLOT1-4 [CH1-8]	----, CASCADE IN
SLOT1-4 [CH9-16]	----, CASCADE IN

**Note**  
You cannot switch the cascade input port setting from the DME CONTROL screen. If necessary, click the MIXER SETUP button to access the MIXER SETUP screen (SYS/W.CLOCK function), and change the port you will use for cascade input.

- 5 **In the MONITOR PORT field, select the PM5D port that will receive monitor signals from the DME series unit.**

The following ports can be selected.  
 ---- .....No assignment  
 SLOT1–1–SLOT4–16 ... The desired port of slot 1–4  
 CASCADE 1–32 .....CASCADE IN ports 1–32

- 6 **In the OUTPUT PORT field located in the lower right of the screen, select the PM5D port that will transmit audio signals to the DME.**



The types of port that can be selected here will depend on the port that is currently selected for cascade output (MIXER SETUP screen CASCADE OUT PORT SELECT field), as follows.

Setting in the CASCADE OUT PORT SELECT field (MIXER SETUP screen)	Items available in the OUTPUT PORT field
CASCADE OUT	----, SLOT1–SLOT4
SLOT3/4	----, SLOT1–SLOT4, CASCADE OUT
SLOT1-4 [CH1-8]	----, SLOT1–SLOT4, CASCADE OUT
SLOT1-4 [CH9-16]	----, SLOT1–SLOT4, CASCADE OUT

**Note**  
You cannot switch the cascade output port setting from the DME CONTROL screen. If necessary, click the MIXER SETUP button to access the MIXER SETUP screen (SYS/W.CLOCK function), and change the port you will use for cascade output.

- If you want scene changes on the PM5D to be linked with scene changes on the DME series unit, turn on the MIDI PGM CHANGE button in the center of the screen.

If the MIDI PGM CHANGE button is on, switching the scene on the PM5D will cause a program change message of a number corresponding to that scene to be sent to the DME.

**Hint**

- The above program change message is always transmitted via the MY16-C card or the CASCADE IN/OUT connector. This is not affected by MIDI PGM CHANGE or by the MIDI program change transmission port or transmission on/off setting selected in the MIDI SETUP screen.
- The program number assignment for each scene can be specified in the MIDI PGM CHANGE screen.

- To initiate communication between the PM5D and the DME series unit, click the CONNECT button to turn it on.

While the CONNECT button is on, parameter operations and scene store/recall operations on the DME can be remotely controlled from the PM5D. To terminate communication, click the CONNECT button once again to turn it off.

**□ Controlling DME parameters**

Here's how the parameters of the DME series unit can be controlled from the PM5D. If desired, the changes you make can be saved in the scene of the DME series unit.

- In the DME CONTROL screen, choose SETUP, and turn on the CONNECT button to initiate communication.
- In the upper left of the screen, use the component type / component selection areas to select the component you want to control. If a component other than SETUP is selected, internal parameters of the DME can be controlled from the PM5D screen. The following illustration is an example of when the SLOT OUTPUT component is selected.



- Use the knobs, sliders, and buttons in the screen to control the parameters of the DME series unit.

Knob, slider, and button operation methods are the same as for the PM5D's internal parameters. For details on the parameters that can be operated for each component, refer to the owner's manual of the DME series unit.

- If you want to use DCA faders 1–8 to control the parameters of the component, click an A–F button in the ASSIGN TO FADERS area.

When you click a button A–F, the corresponding parameters will be assigned to DCA faders 1–8, and can be controlled by the faders. To return to the previous state, click the DCA button.

**Hint**

As an alternative to clicking the A–F buttons, you can obtain the same result by holding down the top panel [SHIFT] key and pressing the [A]–[F] keys of the FADER MODE section.

- If you want to store your changes in a scene of the DME series unit, use the SCENE field in the upper right of the screen to select the store-destination, and click the STORE button.

The edited settings will be stored as a scene in the DME. To recall this scene, use the SCENE field in the upper right of the screen to select the scene, and click the RECALL button.

**Note**

When storing a DME scene from the PM5D's screen, you can only store by overwriting an existing scene on the DME; you cannot store the settings as a new scene or edit the scene name.

# UTILITY function


## PREFERENCE 1/2 screens

Preference settings for the PM5D are divided into two screens.

### PREFERENCE 1



### PREFERENCE 2



#### ① STORE/RECALL

These buttons let you turn on/off options related to scene store/recall operations. You can select the following options.

- **AUTO STORE**  
Turns the Auto Store function on/off. If this button is on, pressing the [STORE] button (SCENE MEMORY section) of the panel twice in succession will store the current scene in the currently selected scene number.
- **LINKED LIBRARY PROTECTION**  
If this button is on, you will be unable to overwrite or delete library items that are linked to a protected scene. This option prevents a protected scene from being modified by having an associated library item edited.
- **USE NUMERIC-KEYPAD**  
If this button is on, the numeric keypad of a PS/2 keyboard connected to the KEYBOARD connector (or a numeric keypad connected to the KEYBOARD connector) can be used to specify the scene number directly.
- **STORE CONFIRMATION**
- **RECALL CONFIRMATION**  
If these buttons are on, a confirmation message will appear when you perform a Store or Recall operation respectively.

#### ② PATCH

These buttons let you turn on/off options related to patch operations. You can select the following options.

- **PATCH CONFIRMATION**  
If this button is on, a confirmation message will appear when you edit an input patch or output patch.
- **STEAL PATCH CONFIRMATION**  
If this button is on, a confirmation message will appear when you edit an input patch or output patch item that is already patched.

#### ③ GATE/COMP (Gate / Compressor)

These buttons let you turn on/off options related to gating and compression.

- **GR METER ON/OFF LINK**  
If this button is on, the GR meter will not show the reduction amount for gates/compressors that are currently off.

#### ④ METER SECTION

Here you can set the following meter-related options.

- **FOLLOW INPUT LAYER**  
This option lets you specify how the [CH 1-24]/[CH 25-48] keys (INPUT channel strip) and [STIN 1-4]/[FXRTN 1-4] keys will select the layer that is shown by the meters in the center of the panel and the meters in the upper right of the panel. Click the / buttons at left and right to make your choice.

**OFF** . . . . . Operating the [CH 1-24]/[CH 25-48] keys will not affect the content shown by the meters in the center of the panel. Pressing the [STIN 1-4]/[FXRTN 1-4] keys will not affect the content shown by the meters in the upper right of the panel.

**SAME** . . . . . When you press the [CH 1-24] or [CH 25-48] key, the corresponding layer will be shown by the meters in the center of the panel (if an input channel is selected in the meter section). When you press the [STIN 1-4] or [FXRTN 1-4] key, the corresponding layer will be shown by the meters in the upper right of the panel.


**ALTERNATIVE . . .** When you press the [CH 1-24] or [CH 25-48] key, the opposite layer will be shown by the meters in the center of the panel (if an input channel is selected in the meter section). When you press the [STIN 1-4] or [FXRTN 1-4] key, the opposite layer will be shown by the meters in the upper right of the panel.

**Note**

- If this is set to SAME or ALTERNATIVE, the meters in the center of the panel and the meters in the upper right can be switched independently.
- If the selected layer is switched from the panel, the layer shown by the meters will also change. However if you switch the METER SECTION field in the constantly-displayed area in the upper part of the screen, the layer selected on the panel will not change.

• **FOLLOW MIX MASTER MODE**

If this button is on, pressing the MIX section [MIX MASTER] key will cause the meters in the center of the panel and the meters in the upper right of the panel to show the MIX/MATRIX channel levels. Press the MIX section [MIX SEND] key to return to the original input channel level display.



⑤ **PANEL OPERATION**

Here you can set the following options for panel operation.

- **AUTO CHANNEL SELECT**  
This specifies whether the corresponding channel will be selected when you operate a channel's [ON] key, fader, or encoder. INPUT CH (input channels) and OUTPUT CH (output channels) can be turned on/off separately.
- **AUTO DISPLAY**  
For each of the following items, you can individually specify whether the related screen will automatically appear when you use the SELECTED CHANNEL section to operate a specific parameter. The following table shows the parameters corresponding to each button and the screen that will appear.

Button name	Corresponding parameters	Screen that appears
HA	Input channel head amp gain	INPUT HA/INSERT function screens
PHASE/ATT	Input channel phase/attenuator	INPUT EQ function $\phi$ /ATT screen
EQUALIZER	EQ-related parameters	INPUT EQ/OUTPUT EQ function EQ PARAM screen
DYNAMICS	Gate/compressor-related parameters	INPUT GATE/COMP function or OUTPUT COMP function GATE PARAM or COMP PARAM screen
DELAY	Delay-related parameters	INPUT DELAY/OUTPUT DELAY function screens
DCA/MUTE/SAFE	DCA group / Mute group / Recall safe-related parameters	INPUT DCA/GROUP function or OUTPUT DCA/GROUP function DCA GROUP ASSIGN, MUTE GROUP ASSIGN or RECALL SAFE screen
TO MIX/STEREO	TO MIX/TO STEREO-related parameters	PAN/ROUTING function CH to MIX screen or SURR PARAM screen, or MATRIX/ST function MATRIX/ST ROUTING screen
TO MATRIX	Send level to MATRIX bus	MATRIX/ST function MATRIX/ST ROUTING screen
OUTPUT MASTER	MIX/MATRIX channel output level	OUTPUT VIEW function FADER VIEW screen

• **MAKE PAIR ON PANEL**

If this button is on, you can use the [SEL] keys to set/defeat pairing. In Horizontal Pair mode, you can set/defeat pairing by simultaneously pressing the [SEL] keys of two pairable channels. In Vertical Pair mode, you can set/defeat pairing by holding down the [SHIFT] key and pressing the [SEL] key of one of the channels. (For more about pair modes ➔ p.45)

• **DCA/MUTE FLASH INDICATE**

If this button is on, the DCA [MUTE] key LED and the DCA assign LED for channels belonging to that DCA group will blink when you turn on a DCA [MUTE] key (DCA section).

• **MIX MINUS CONFIRMATION**

If this button is on, a confirmation message will appear when you execute the Mix Minus setting (hold down the [SEL] key of an input channel and press the [SEL] key of a MIX channel) from the panel.

• **SCENE UP/DOWN KEY**

This specifies what the SCENE MEMORY [▲]/[▼] keys will do when pressed in the SCENE screen. You can choose one of the following two operations.

**SCENE +1/-1 . . . .** Pressing the SCENE MEMORY [▲] key will select the next highest-numbered scene, and pressing the SCENE MEMORY [▼] key will select the next lowest-numbered scene. (Key presses will increment/decrement the scene number.)

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

**LIST UP/DOWN** . . . Pressing the SCENE MEMORY [▲] key will scroll the list upward, and pressing the SCENE MEMORY [▼] key will scroll the list downward. (Key presses will scroll the list upward/downward.)

• **LIST ORDER**

This specifies the order in which scene memories and library items will appear in the screen.

**NORMAL** . . . . . Show the list in ascending numerical order.

**REVERSE** . . . . . Show the list in descending numerical order.


⑥ **INTERNAL CLOCK**

This indicates the date (DATE) and time (TIME) of the internal clock. To edit the setting, click the SET button.

⑦ **BATTERY**

This indicates the voltage of the internal battery.

☐ **PREFERENCE screen 2**



⑧ **BRIGHTNESS**

Here you can make settings for the brightness of the panel LED and LCD displays.

• **PANEL UNITY POINT**

If this button is on, LEDs corresponding to a specific reference value (e.g., 0 dB or CENTER) will light more brightly than usual. However, this is valid only if PANEL BRIGHTNESS is set to 5 or less.

• **PANEL ASSISTANCE**

If this button is on, even LEDs that should be off will stay dimly lit so that you can tell their location even in a dark environment. However, this is valid only if PANEL BRIGHTNESS is set to 5 or less.

• **PANEL BRIGHTNESS**

This adjusts the brightness of all panel LEDs in a range of 1–8.

• **LCD BRIGHTNESS**

You can adjust the brightness of the LCD display in a three-step range: HIGH, MID, or LOW.

• **LCD BACK LIGHT**

You can adjust the brightness of the LCD display back-light in a two-step range: HIGH or LOW.

⑨ **TRACK PAD/MOUSE**

Here you can make settings for the built-in track pad or a PS/2 mouse connected to the MOUSE connector.

• **TRACK PAD TAPPING**

This enables/disables the Tapping function (a function that lets you perform the track pad left-click operation by tapping quickly on the track pad).


• **MOVING SPEED**

This selects the speed at which the cursor in the screen will move when you operate the built-in track pad or a PS/2 mouse connected to the MOUSE connector. Choose one of three speeds; FAST, MID, or SLOW.

⑩ **SCREEN TIPS**

• **SHOW SCREEN TIPS**

If this button is on, moving the cursor onto an item in the screen and waiting for a short time will (in some cases) display a “screen tip” reminding you of the operation. The screen tip is displayed when you open the JOB SELECT window by holding down the [SHIFT] key and pressing the [ENTER] key, or when you need to press the [ENTER] key to finalize an edited value.



⑪ **UPPER PART DISPLAY**

These buttons select the item that is shown in the center right (to the right of the scene memory indication) of the upper part of the display (the constantly displayed area).

• **PRESENT TIME**

Indicates the present time.

• **TIME CODE**

Indicates the internal time code being generated by the PM5D, or the time code being received from an external device. This is the same as the time code shown in the SCENE function EVENT LIST screen.

• **CASCADE/Fs**

Indicates the master/slave status when using a cascade connection, and the sampling frequency at which the PM5D system is currently operating.

**Hint**

You can also cycle through these choices by clicking in this display section.



⑫ **NAME DISPLAY ([NAME] indicator display)**

Choose one of the following as the content that will be shown by the [NAME] indicators of the INPUT channel strip and DCA strip.

- **NAME**  
The indicators will show the names assigned to the input channels / DCA groups in the NAME screen (INPUT PATCH function). (➔ p.257)
  - **PORT**  
For input channels, the indicators will show the name of the currently assigned port. For DCA groups, the indicators will show the ID number.
  - **ID**  
For both input channels and DCA groups, the indicators will show the fixed ID number.
- ⑬ **WARNING DISPLAY**  
Here you can select whether a warning will be displayed when the following problems occur.
- **TIME CODE DROP**  
When time code (LTC, MTC) being received from an external device is dropped.
  - **DIGITAL I/O ERROR**  
When a DIO error is detected.
  - **MIDI I/O ERROR**  
When a MIDI error is detected.

## USER DEFINE screen

Here you can assign functions to the User Defined keys (USER DEFINED [1]–[25] keys).



- ① **BANK**  
Select a bank A–D (groups of functions assigned to the User Defined keys).
- ② **CLEAR BANK**  
Clears the currently selected bank.
- ③ **List**  
This area lists the functions and option parameters assigned to the User Defined keys in the currently selected bank.  
To edit the settings, click the button at the left to open the USER DEFINED KEY ASSIGN window, and select the function and parameter from the following table.

FUNCTION	PARAMETER 1	PARAMETER 2	Explanation
NO ASSIGN	—	—	No assignment
SCENE	INC RECALL	—	Recall the scene of the next existing number.
	DEC RECALL	—	Recall the scene of the previous existing number.
	DIRECT RECALL	SCENE #000–#500	Directly recall the scene of the specified number
EVENT LIST	TIME CODE [RTN TO START]	—	The same functions as the RETURN TO START TIME, STOP, and PLAY buttons displayed when INTERNAL is selected as the time code source in the EVENT LIST screen
	TIME CODE [STOP]		
	TIME CODE [PLAY]		
	TIME CODE [INSERT]		
	AUTO CAPTURE ON	—	The same function as the TIME CODE INSERT button in the EVENT LIST screen
	DIRECT EVENT RECALL	EVENT #000–#999	Recall the specified event registered in the EVENT LIST screen
	NEXT EVENT RECALL	—	Recall the next-numbered event
	PREV EVENT RECALL		Recall the previous-numbered event
	ENABLE/DISABLE		Switch the ENABLE button and DISABLE button in the EVENT LIST screen
ENABLE [ALL MANUAL]/DIS-ABLE	—	Switch the ENABLE [ALL MANUAL] button and DISABLE button in the EVENT LIST screen	
EFFECT LIBRARY	DIRECT RECALL → EFFECT 1–8	INC RECALL	Recall the next-numbered library item into effect 1–8
		DEC RECALL	Recall the previous-numbered library item into effect 1–8
		LIBRARY #001–#199	Recall the library item of the specified number into effect 1–8
EFFECT BYPASS	EFFECT 1–EFFECT 8	BYPASS ON	Bypass the specified effect
INPUT CH LIBRARY	DIRECT RECALL	LIBRARY #000–#199	Recall the library item of the specified number into the selected channel/GEQ module
OUTPUT CH LIBRARY			
GATE LIBRARY			
COMP LIBRARY		LIBRARY #001–#199	
INPUT EQ LIBRARY			
OUTPUT EQ LIBRARY			
INPUT PATCH LIBRARY		LIBRARY #00–#99	
OUTPUT PATCH LIBRARY			
HA LIBRARY		LIBRARY #000–#199	
GEQ LIBRARY	DIRECT RECALL → GEQ 1–12	LIBRARY #000–#199	
TRACKING RECALL	ENABLE/DISABLE	—	The same function as the ENABLE/DISABLE button in the TRACKING RECALL screen
	OFFSET LOCK		The same function as the OFFSET LOCK button in the TRACKING RECALL screen
	SELECTED CH ON		Switch the Tracking Recall function on/off for the currently selected channel
TALKBACK ASSIGN	SELECTED CH ASSIGN	—	When an output channel is selected, turn talkback transmission on/off for that channel
	DIRECT ASSIGN	MIX 1–24, MATRIX 1–8, STEREO A L/R, STEREO B L/R	Send the talkback signal to the specified output channel
MONITOR	DIRECT ASSIGN	MIX 1–24, MATRIX 1–8	Monitor the desired MIX/MATRIX channel <sup>*1</sup>
	DIMMER ON	—	Switch on the monitor dimmer function
TAP TEMPO	CURRENT PAGE	—	Control the Tap Tempo function in the displayed screen
	EFFECT 1–EFFECT 8		Control the Tap Tempo function of the specified effect
SURROUND PAN	GRAB	SELECTED CH, ODD CH, EVEN CH	Use a joystick assigned to GPI to begin controlling the surround pan of the corresponding channel
NAME DISPLAY	NAME → PORT → ID	—	Each time you press the key, the [NAME] indicator for each fader will cycle through the channel name → port name → ID (channel number)
	ID	UNLATCH	The [NAME] indicator for each fader will show the ID (channel number) only while you hold down the key
	PORT		The [NAME] indicator for each fader will show the port name only while you hold down the key
	NAME		The [NAME] indicator for each fader will show the channel name only while you hold down the key

FUNCTION	PARAMETER 1	PARAMETER 2	Explanation
PAGE CHANGE	PAGE BACK	—	Display the screen that you used immediately prior to the current screen
	PAGE FORWARD		Display the screen that you used immediately after the current screen
	PAGE BOOKMARK		Memorize the currently selected screen (hold down the key for two seconds or longer), or display the last-memorized screen (press and release the key within two seconds) <sup>*2</sup>
	GEQ PARAM PAGE	GEQ 1–12	Display the GEQ PARAM screen
	EFFECT PARAM PAGE	EFFECT 1–8	Display the EFFECT PARAM screen
LAYER SNAPSHOT	—	—	Memorize the state of the layer assigned to the panel (hold down the key for two seconds or longer), or display the last-memorized layer (press and release the key within two seconds) <sup>*3</sup>
DIRECT RECALL/ MUTE MASTER	MODE CHANGE	LATCH	Switch the function of the SCENE MEMORY [1]–[8] keys (DIRECT RECALL / MUTE MASTER) each time you press the User Defined key
		UNLATCH	The SCENE MEMORY [1]–[8] keys will function as DIRECT RECALL while you hold down the User Defined key
USER DEFINED KEY BANK	NEXT BANK	—	Switch to the next bank of User Defined key assignments
	PREVIOUS BANK		Switch to the previous bank of User Defined key assignments
	DIRECT SELECT	BANK A–D	Switch to the desired bank of User Defined key assignments
MIDI DIRECT OUT	MIDI NOTE	C-2–G 8	When you press the key, transmit a note-on message with the specified note number and a velocity of 127 When you release the key, transmit a note-off message of the same note number with a velocity of 0 (= note-off) <sup>*4</sup>
	MIDI PGM CHANGE	1–128	When you press the key, transmit a program change message with the specified number <sup>*4</sup>
	MIDI CTRL CHANGE	0–119	When you press the key, transmit a control change message with the specified control number and a value of 127 When you release the key, transmit a control change message of the same control number with a value of 0 <sup>*4</sup>
MACHINE CONTROL	SET LOCATION, RS-422 REC, RS-422 PLAY, RS-422 STOP, RS-422 FF, RS-422 REW, RS-422 LOCATE 1–20	—	Transmit the specified RS422/MMC command from the RS422 REMOTE connector or the currently-valid MIDI port (the SET LOCATION command is common to RS422 and MMC)
	MMC REC, MMC PLAY, MMC STOP, MMC FF, MMC REW, MMC LOCATE 1–20	MMC ID= 1–127, ALL	
GPI OUT CONTROL	PORT 1–12	LATCH	Switch the specified GPI OUT port between active/inactive each time you press the key
		UNLATCH	Switch the specified GPI OUT port to inactive while you hold down the key
PM5D EDITOR CONTROL	*5	*5	Switch windows in PM5D Editor on a PC

\*1. The corresponding channel will be selected in the DEFINE field of the MONITOR screen, and the monitor source will switch to DEFINE.

\*2. The LED will light for User Defined keys for which a screen has been memorized. The column in the right of the list in the USER DEFINE screen shows the name of the memorized screen.

\*3. Layers that can be memorized include the following items.

- The layer selected in the INPUT channel strip (CH 1-24, CH 25-48, MIDI REMOTE)
- The layer selected in the ST IN/FX RTN channel strip (ST IN 1-4, FX RTN 1-4, MIDI REMOTE)
- The layer shown by the DCA channel strip (DCA, A–F, GEQ)
- If the DCA channel strip is controlling GEQ, the GEQ module number and band
- The encoder mode selected by ENCODER MODE (SEND, PAN, HA, ATT, ALT)
- The FADER FLIP status
- The currently selected MIX send
- The mode selected in the MIX section (MIX SEND, MIX MASTER)
- The source selected in the METER section (CH 1-24 ST IN, CH 25-48 ST IN, MIX/MATRIX)

\*4. The output port and MIDI channel can be specified in the MIDI SETUP screen.

\*5. This parameter specifies the PM5D Editor window that you want to control. If the specified window is closed or inactive, the window will be opened and made active. If the specified window is already open and active, the window will be closed. This function can be selected if the system software supports PM5D Editor. For details on the most recent system software version, refer to the website. <http://www.yamahaproaudio.com>

## Note

During PREVIEW mode, the following USER DEFINE functions that affect internal signal processing are disabled; EVENT LIST, TALKBACK ASSIGN, MONITOR, MIDI DIRECT OUT, MACHINE CONTROL, and GPI OUT CONTROL.

## SAVE screen

Here you can save PM5D scenes and library data on a memory card inserted in the MEMORY CARD slot. This cannot be used while in PREVIEW mode.




### ① MODE

Choose one of the following as the mode in which files will be saved: BASIC, ADVANCED, CSV EXPORT. The left side of the screen will change according to the mode you select.

### □ BASIC mode

In BASIC mode you can save all scene memory and library data (or just a selected portion of data) to a card. If BASIC is selected, the left side of the screen will show the items listed in the following table.




### ② Select the items to save

Choose one of the following to specify the data that will be saved.

Button	Content
ALL DATA	All items of each type, and the contents of the current scene
SCENE MEMORY	Contents of scene memory
LINKED LIBRARY	Libraries linked to the scene (available only if the SCENE MEMORY button is on)
HA	Contents of the HA library
INPUT PATCH	Contents of the input patch library
OUTPUT PATCH	Contents of the output patch library
INPUT CH	Contents of the input channel library
OUTPUT CH	Contents of the output channel library
INPUT EQ	Contents of the input EQ library
OUTPUT EQ	Contents of the output EQ library
GATE	Contents of the gate library
COMP	Contents of the compressor library
EFFECT	Contents of the effect library
GEQ	Contents of the GEQ library
SETUP	Various settings not saved in a scene
USER DEFINED KEY	User Defined key settings
DCA FADER MODE	Fader mode settings
MIDI REMOTE	MIDI remote settings
MIDI PGM TABLE	Contents of the list in the MIDI PGM CHANGE screen
MIDI CTRL TABLE	Contents of the list in the MIDI CTRL CHANGE screen
EVENT LIST	Contents of the list in the EVENT LIST screen

If the SCENE MEMORY, HA, INPUT PATCH, or OUTPUT PATCH button is on, you can use the box at the right to specify the starting number and ending number of the scenes or library items that will be saved.



### Hint

If the specified range of numbers includes empty scenes or library items, the correspondingly-numbered scenes or library items will be empty when that data is loaded.

### ③ TOTAL SIZE

Indicates the file size of the currently selected item(s) (common to all modes).

## ADVANCED mode

In this mode you can select either scene memory or a library, specify a starting number and ending number, and save the specified range of data on a card. If desired, you can also specify that the starting number be shifted forward or backward when the data is saved. If ADVANCED is selected, the left side of the screen will show the following items.



### 4 CATEGORY



Indicates the category of data that is selected for saving; scene memories or library data. Click the  $\leftarrow$  /  $\rightarrow$  buttons at left and right to change the category.

### 5 SOURCE (save-source numbers)

This area shows the starting and ending number (and the corresponding scene names or library titles) of the scene memories or library items that will be saved on the card. Click the  $\leftarrow$  /  $\rightarrow$  buttons at the left and right of each box to change the number.


### 6 DESTINATION (save-destination number)

This area shows the starting and ending number (and the corresponding scene names or library titles) with which the data will be saved on the card. If you want to save the data to the card with a different range of numbers, click the  $\leftarrow$  /  $\rightarrow$  buttons at the left and right of the starting number box. (The value in the ending number box will change automatically as the starting number is edited.)



## CSV EXPORT mode

In this mode you can select items such as scene memory or library titles, or channel names, and write them to a card as a separate CSV format file for each item. If CSV EXPORT is selected, the left side of the screen will show the items listed in the following table.



### 7 LIBRARY TITLE

### 8 CHANNEL NAME

From the following table, select the parameters that will be written (e.g., library title, channel name).

	Button	Content
LIBRARY TITLE	SCENE MEMORY	Scene memory names
	HA	HA library titles
	INPUT PATCH	Input patch library titles
	OUTPUT PATCH	Output patch library titles
	INPUT CH	Input channel library titles
	OUTPUT CH	Output channel library titles
	INPUT EQ	Input EQ library titles
	OUTPUT EQ	Output EQ library titles
	GATE	Gate library titles
	COMP	Compressor library titles
	EFFECT	Effect library titles
CHANNEL NAME	GEQ	GEQ library titles
	INPUT 1-48	Input channel names
	ST IN	ST IN channel names
	FX RTN	FX RTN channel names
PATCH	DCA	DCA names
	INPUT PATCH	Input patch connection status
	OUTPUT PATCH	Output patch connection status

### Hint

Files saved in CSV format can be edited using a word processor or spreadsheet software on a computer, and loaded back into the PM5D. However be aware that it will not be possible to reload the file back into the PM5D if you change the syntax, file format, or file name.


If you use Microsoft Excel to edit these files, use the Data menu to import the CSV file, and use the Text File Wizard to delete the character string quotation ("). (If you fail to do so, symbols such as "-" and "+" will not be displayed correctly.)

⑨ SET ALL

Selects all LIBRARY TITLE / CHANNEL NAME items.

⑩ CLEAR ALL

De-selects all items.



⑪ FILE PATH

Indicates the directory (folder) that is currently selected on the memory card inserted in the MEMORY CARD slot, and the location of the file. (The directory name is delineated by “\” characters.)

⑫ SCAN

This scans the directory that is currently selected on the memory card, and displays the contents in the file list (⑬).

⑬ File list

This area shows the files/directories contained in the current directory. The currently selected file/directory is always shown in the middle line. (The TYPE and DATE SIZE fields will be highlighted.)

The list is divided into four columns; FILE NAME, TYPE, DATE/SIZE, and COMMENT. (To see the COMMENT field, use the scroll bar to scroll the list toward the right.)

The headings at the top of each column of the list also function as buttons to sort the list. When you click these buttons, the list will be sorted in ascending or descending order for that item. The text of the currently selected button will change to red, and an arrow indicating ascending (↑) or descending (↓) order will appear.

These columns display the following content.

• FILE NAME

These are the names of the files/directories saved in the currently selected directory. If a lower directory is selected, you can move to that directory by clicking the directory name shown in this column.

BAND#1	SCENE+LIB	02/27/2004 03:18:40	111KB	
BAND#2	SCENE+LIB	02/27/2004 03:18:56	111KB	
BAND#3	SCENE+LIB	02/27/2004 03:19:10	111KB	
PATCH	[DIR]	02/27/2004 03:20:14		
REHEARSE	SCENE MEM	02/27/2004 03:19:40	108KB	



..	[DIR]	02/27/2004 03:20:14		
PATCH#1	IN PATCH	02/27/2004 03:24:40	3KB	
PATCH#2	IN PATCH	02/27/2004 03:25:12	3KB	
PATCH#3	IN PATCH	02/27/2004 03:25:26	3KB	

If a higher directory is selected, this column will show a “..” symbol. You can click this symbol to return to that directory.

..	[DIR]	02/27/2004 03:20:14		
PATCH#1	IN PATCH	02/27/2004 03:24:40	3KB	
PATCH#2	IN PATCH	02/27/2004 03:25:12	3KB	
PATCH#3	IN PATCH	02/27/2004 03:25:26	3KB	



BAND#1	SCENE+LIB	02/27/2004 03:18:40	111KB	
BAND#2	SCENE+LIB	02/27/2004 03:18:56	111KB	
BAND#3	SCENE+LIB	02/27/2004 03:19:10	111KB	
PATCH	[DIR]	02/27/2004 03:20:14		
REHEARSE	SCENE MEM	02/27/2004 03:19:40	108KB	

• TYPE

This indicates the type of data that is saved. In the case of a directory, this column will indicate [DIR]. Data that cannot be used by the PM5D is indicated as UNKNOWN.

• DATE / SIZE

This shows the date on which the file was last saved, and its size. In the case of a directory, only the date of creation is displayed.

• COMMENT

This displays comments (up to 32 characters) stored for the files on the memory card. To create or edit a comment, click the COMMENT field of the file selected in the list to open the FILE COMMENT EDIT window.

⑭ **Number of files / Free area**

This displays the number of files and directories in the current directory, and the free area on the memory card.

**Note**

A maximum of 99 files and directories can be displayed in the file list. If there are more than 99, a blinking message of "Too Many Files" will be displayed. In this case, please delete unneeded files or move files to another directory.

⑮ **SAVE**

This saves the data selected in the left side of the screen to the currently selected directory. When you click this button, the FILE NAME EDIT window will appear, allowing you to assign a filename of up to eight characters and save the file.

**Note**

- If an identically-named file exists in that directory, a message will warn you that you will be overwriting the file. If you don't want to overwrite the existing file, you can either change the filename or select a different directory in which to save the file.
- When you execute the Save operation in CSV EXPORT mode, a new directory will be created within the current directory of the memory card, and a CSV file for each selected item will be created in the new directory.
- The name of the CSV file is fixed for each type of data, and cannot be changed. The newly created directory will have the name you specified when saving.

⑯ **RENAME**

This button lets you rename the currently selected file or directory. When you click this button, the FILE NAME EDIT window will appear, allowing you to edit the name.

⑰ **MAKE DIR (Make directory)**

This button creates a new sub-directory within the currently selected directory. When you click this button, the DIR NAME EDIT popup window will appear, allowing you to specify a name for the new directory.

⑱ **DELETE**

This button deletes the currently selected file or directory. When you click this button, the FILE DELETE window will appear, asking you to confirm the deletion.

**Note**



- A deleted file cannot be recovered.
- If you attempt to delete a directory that contains files, a warning message will appear, and the operation cannot be executed. Before deleting a directory, you must first delete any files it contains.

**Note**

- As memory cards, the PM5D can use either PCMCIA Type II flash ATA cards or CompactFlash media inserted in a PC card adaptor (power supply voltage of 3.3V/5V in either case). Operation is not guaranteed for any other type of media.
- Normally, the above cards are sold in an already-formatted state, so formatting will not be necessary. If you need to format a card, use a computer or other external device to format the card in FAT16 format.

**LOAD screen**

In this screen, scene or library data from a memory card inserted in the MEMORY CARD can be loaded into the PM5D. This cannot be used while in PREVIEW mode.



① **FILE PATH**

Indicates the location of the directory (folder) or file that is currently selected on the memory card. (The directory name is delineated by “\” characters.)

② **SCAN**

This scans the directory that is currently selected on the memory card, and displays the contents in the file list (③).

③ **File list**

This area shows the files/directories contained in the current directory. The currently selected file/directory is always shown in the middle line. (The TYPE and DATE SIZE fields will be highlighted.)

The list is divided into four columns; FILE NAME, TYPE, DATE/SIZE, and COMMENT. (To see the COMMENT field, use the scroll bar to scroll the list toward the right.) The contents of each column are the same as in the SAVE screen (➡ p.194).

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices



④ Mode


Here you can select the mode in which files will be loaded. If a file other than CSV is selected in the file list, you will be able to select BASIC mode or ADVANCED mode. (The CSV button will be grayed-out and unavailable.)

If a CSV file or directory is selected in the file list, CSV IMPORT mode will be selected automatically. (The BASIC and ADVANCED buttons will be grayed-out and unavailable.)

The right side of the screen will change as follows according to the currently selected mode.

□ BASIC mode

In BASIC mode you can load all scene memory and library data (or just a selected portion of data) from a card. If BASIC is selected, the right side of the screen will show the following items.



⑤ Select the data to be loaded

Here you can select the data that will be loaded. The contents of each item are the same as in BASIC mode of the SAVE screen (p.192). However, the items that can be selected will depend on the currently selected file. Buttons for items that cannot be loaded will be grayed-out and unavailable.

If the SCENE MEMORY, HA, INPUT PATCH, or OUTPUT PATCH button is on, you restrict the scenes or library items that will be loaded by using the box at the right to specify the starting number and ending number.

**Hint**

*If the data saved on the card includes empty scenes or library items, the corresponding scenes or library items will be empty when the data is loaded.*


⑥ LOAD

This button loads the data selected in the left side of the screen into the parameters you specify. When you click

this button, a message will ask you to confirm the Load operation. (This is common to all modes.)

□ ADVANCED mode

In this mode you can select either scene memory or a library, specify a starting number and ending number, and load the specified range of data from the card.



⑦ CATEGORY



This indicates the type of data (scene memory or library) saved in the currently selected file.

⑧ SOURCE (load-source)

This area shows the starting and ending number (and the corresponding scene names or library titles) of the scene memories or library items that will be loaded from the card. Click the [ ] / [ ] buttons at the left and right of each box to change the number.

⑨ DESTINATION (load-destination)

If you've changed the starting number of the load-destination, this area shows the starting and ending number (and the corresponding scene names or library titles) of the PM5D's internal scene memories or library items into which the data selected in the SOURCE area will be loaded. To edit the setting, click the [ ] / [ ] buttons located at the left and right of the starting number box. (The ending number value will change automatically as you edit the starting number.)




**Hint**

- Even if you've selected data that was saved in BASIC mode, you can switch to ADVANCED mode and load only specific numbers.
- However, an exception is that if the selected data was saved as ALL DATA or SCENE MEMORY+LINKED LIBRARY in BASIC mode, the ADVANCED button will be grayed-out, and you will not be able to switch to ADVANCED mode.

## CSV IMPORT mode

If a CSV file or directory is selected, CSV IMPORT mode will be selected automatically. The selected CSV file (or CSV files in the selected directory) will be searched, and the following items will appear in the right of the screen.



### ⑩ LIBRARY TITLE

### ⑪ CHANNEL NAME

Use these buttons to select the data you want to load (e.g., library titles or channel names). (The contents of each item are the same as in the SAVE screen.)

However, you will only be able to select items that match the CSV file (or the CSV files in the directory) selected in the list for loading. The buttons for other items will be grayed-out and unavailable.

### ⑫ SET ALL

This button selects all available items for loading.

### ⑬ CLEAR ALL


De-selects all items.

#### Note

*Note that the screen will automatically switch to CSV IMPORT mode even if the directory selected in the list does not contain an appropriate CSV file. (In this case, all buttons will be grayed-out.)*


## FADER ASSIGN screen

Here you can assign the desired input channels / output channels to the eight faders in the DCA section of the panel.




### ① FADER MODE

Indicates the currently selected fader mode (DCA, layer A–F). You can also click the buttons to switch the fader mode directly.



### ② Faders 1–8

The parameter assigned to each fader of the DCA fader section is shown here. This will depend on the FADER MODE (①) and channel selection (③). You can also operate the fader directly by dragging it upward or downward.



### ③ Channel selection

This indicates the channel that is assigned to each fader in layers A–F, and its name (only for input channels). Click the / buttons at left and right to change the assignment. You can choose from CH 1–48, ST IN 1L–ST IN 4R, FXRTN 1L–FXRTN 4R, MATRIX 1–8, MIX 1–24, and DCA 1–8.

## SECURITY screen

In this screen you can prohibit console operation (Console Lock) or prohibit editing for specific parameters (Parameter Lock). Two passwords of differing levels can be specified to allow locking and unlocking.



### ① SYSTEM PASSWORD

This is a permanent password (maximum of eight characters) for the entire system. The password you specify here is valid for the PARAMETER LOCK button (②) and for the CONSOLE LOCK button (③). However, you can perform the Lock operation even without specifying a password.

If no password has been specified, this box will indicate "--FREE--". If a password has been specified, asterisks (\*) will be displayed to represent the characters of the password.

To set or change the password, click the button to open the SYSTEM PASSWORD CHANGE window.

When setting the password for the first time, you will input the same password twice for confirmation. To change the password, you will input both the old password and the new password. By specifying a blank entry as the new password, you can restore the state to a condition in which no password has been set.

#### Note

*The system password is remembered even when the power is turned off. This means that if you forget the password, you will be unable to defeat Parameter Lock or Console Lock except by initializing the entire memory of the PM5D (➔ p.147). Please be careful not to lose the system password.*


### ② PARAMETER LOCK

This button sets/defeats Parameter Lock for the parameters selected in the LOCK PARAMETER SELECT area (④). If not even one parameter is selected, these buttons will be grayed-out and cannot be turned on. If the system password has been set, clicking this button will

open the SYSTEM PASSWORD CHECK window, where you will need to input the system password.

### ③ CONSOLE LOCK

This button locks the console operations. If the system password has been set, clicking this button will open the SYSTEM PASSWORD CHECK window, where you will need to input the system password.



### ④ LOCK PARAMETER SELECT

If the PARAMETER LOCK button (②) is on, parameters for which editing will be disabled can be selected from the following table. As long as the PARAMETER LOCK button (②) is on, these parameters cannot be edited.

<b>SYSTEM CONFIGURATION</b>	Changes to the settings of the MIXER SETUP screen and the CASCADE screen
<b>WORD CLOCK SETUP</b>	Changes in the word clock setting
<b>DITHER</b>	Changes in dither-related settings
<b>INPUT PATCH</b>	Changes to the input patch (and NAME) settings
<b>OUTPUT PATCH</b>	Changes to the output patch settings
<b>INPUT CH ON/OFF</b>	Input channel on/off operations
<b>OUTPUT CH ON/OFF</b>	Output channel on/off operations
<b>MIX TO ST ON/OFF</b>	MIX channel [TO STEREO] key operations
<b>DCA MUTE ON</b>	DCA [MUTE] key On operations (Off operations are not included)



### ⑤ CONSOLE PASSWORD

This is a temporary password (maximum of eight characters) that is separate from the system password. The password you specify here is valid for the CONSOLE LOCK button (⑥). The method for setting or changing the password is the same as for the system password.

#### Hint

*The Console Password is cleared when the PM5D's power is turned off, and will return to the unset state (the box will indicate "--FREE--").*

### ⑥ CONSOLE LOCK


This button locks the console operations. If the console password has been set, clicking this button will open the CONSOLE PASSWORD CHECK window, where you will need to input the console password.

# SYS/W.CLOCK function

## WORD CLOCK screen

Here you can select the word clock on which the PM5D will operate. You can also view and edit settings for cards installed in slots 1–4.

### WORD CLOCK



#### ① MASTER CLOCK SELECT

As the master clock to use, you can select the internal clock or an external clock input from a connector or slot. This setting determines the sampling frequency at which the PM5D will operate. You can select the following items.

Display	Content
INT 96k	The PM5D's internal clock (sampling rate= 96 kHz)
INT 88.2k	The PM5D's internal clock (sampling rate= 88.2 kHz)
INT 48 k	The PM5D's internal clock (sampling rate= 48 kHz)
INT 44.1 k	The PM5D's internal clock (sampling rate= 44.1 kHz)
W.CLOCK IN	The word clock supplied from the rear panel WORD CLOCK IN connector
CASCADE IN	The word clock supplied via the CASCADE IN connector from another cascade-connected PM5D
2TR IN D1	The clock data of the digital audio signal supplied from 2TR IN DIGITAL connector 1
2TR IN D2	The clock data of the digital audio signal supplied from 2TR IN DIGITAL connector 2
2TR IN D3	The clock data of the digital audio signal supplied from 2TR IN DIGITAL connector 3
SLOT 1–4	The clock data of the digital audio signal supplied via a digital I/O card in slot 1–4 (selectable in two-channel units)

The operational status of each clock is shown by the color of the symbol at the left of each button. Each color has the following significance.


- **LOCK (blue)**  
This indicates that a clock synchronized with the source selected in (②) is being input. If an external device is connected to the corresponding connector or slot, input/output is occurring normally between that device and the PM5D. If the sampling frequency is close, this status may be displayed even if not synchronized.
- **UNLOCK (red)**  
A valid clock is not being input. If an external device is connected to the corresponding connector, input/output cannot occur correctly between that device and the PM5D.
- **LOCK, BUT NOT SYNC'ED (orange)**  
A valid clock is being input, but is not synchronized with the clock source selected in (②). If an external device is connected to the corresponding connector, input/output cannot occur correctly between that device and the PM5D.
- **UNKNOWN (yellow)**  
This indicates that the clock status cannot be detected because no external device is connected or because there is no valid clock input. You will be able to select this connector/slot, but successful synchronization cannot occur until a valid connection is established.
- **SRC ON (green)**  
This is a special status only for SLOT 1–4 and 2TR IN 2TR IN D1–3, indicating that the corresponding channel's SRC (Sampling Rate Converter) is enabled. This means that even if the signal is not synchronized, normal input/output with the PM5D is occurring.

#### Note

- Noise may occur at the output jacks when the word clock setting is changed. In order to protect your speaker system, be sure to turn down the power amp output before changing the word clock setting.
- If you attempt to select a channel whose SRC is on as the word clock master, a message will appear, warning you that the sampling rate converter will be disabled.

#### ② Fs (Sampling frequency)


This indicates the sampling frequency at which the PM5D is operating. This will indicate “UNLOCKED” while synchronization is lost (such as immediately after switching the master clock).



- ③ **Slot number / Card type**  
This area shows the type of digital I/O card installed in slots 1–4.
- ④ **INPUT FORMAT (Input signal format)**
- ⑤ **OUTPUT FORMAT (Output signal format)**  
Select one of the following as the method by which signals will be exchanged with a digital I/O card installed in the slot when the PM5D is operating at a high sampling rate (88.2/96 kHz).
  - **SINGLE**  
This setting allows transmission/reception of the normal number of channels when existing equipment that operates at 44.1/48 kHz is connected. The sampling rate will be converted for each channel of the digital I/O card, and transmitted/received at half the sampling frequency (44.1/48 kHz) of the PM5D. (This setting can be selected only for slots in which a digital I/O card that does not support 96 kHz is installed.)
  - **DOUBLE SPEED**  
This setting allows high sampling rate audio signals to be transmitted/received without change when equipment that operates at a high sampling rate (88.2/96 kHz) is connected. (This setting can be connected only for slots in which a digital I/O card that supports 96 kHz is installed.)
  - **DOUBLE CHANNEL**  
This setting allows high sampling rate (88.2/96 kHz) audio signals to be handled when existing equipment that operates at 44.1/48 kHz is connected. Two channels of signals at half the PM5D’s sampling frequency (44.1/48 kHz) are transmitted/received together as a high sampling rate monaural signal. (The number of usable channels will be half.)
- ⑥ **FREQUENCY (Sampling frequency)**  
This indicates the sampling frequency of the signal being input to each channel of the digital I/O card, in sets of two channels.
- ⑦ **SRC (Sampling Rate Converter)**  
This button switches the Sampling Rate Converter on/off, in sets of two channels. This is available only for slots in which a digital I/O card with a built-in sampling rate converter is installed.
- ⑧ **EMPHASIS STATUS**  
This indicates whether emphasis is applied to the input signal, in sets of two channels. This is available only for slots in which a digital I/O card is installed.

## MIXER SETUP screen

Here you can make settings that apply to the entire PM5D system.



- ① **PAIR MODE**  
Select one of the following two methods by which input channels will be paired.
  - **HORIZONTAL PAIR**  
If this button is on, input channels of adjacent numbers (1/2, 3/4 ...) will be paired.
  - **VERTICAL PAIR**  
If this button is on, input channels of different layers that share the same fader (1/25, 2/26 ...) will be paired. This setting lets you use the faders of the INPUT channel strip to control up to 24 pairs (48 channels).

### Hint

The graphic below the buttons will change according to the pair mode you select.

When you switch from horizontal pair mode to vertical pair mode, new numbers will be assigned to the input channels as follows.

- Channel 1 → no change
- Channel 2 → Channel 25
- Channel 3 → Channel 2
- Channel 4 → Channel 26
- :
- Channel 47 → Channel 24
- Channel 48 → no change

(If you again switch back to horizontal pair mode, the channels will return to their previous number.) However, please note that this simply means the input channel that was previously called “channel 2” is now called “channel 25”; the name and parameter settings of that channel have not changed.

In the various screens of the display (except for the TRACKING RECALL screen and the FADER VIEW screen), switching the pair mode will only change the displayed numbers; the arrangement of the input channels will not change.

## ② PAN NOMINAL POSITION

Here you can specify whether a signal will be at nominal level when panned to center, or at nominal level when panned far left or far right. Choose one of the following two settings; you can choose independently for monaural channels and paired channels.

### • CENTER

The signal will be at nominal level (+0 dB) when panned to the center, and will rise +3 dB when panned to far left or far right.

### • L ↔ R

The signal will be at nominal level (+0 dB) when panned to far left or far right, and will decrease -3 dB when panned to the center.

### Hint

The current setting is also shown by the graph below the buttons.



## ③ BUS SETUP

This area indicates the MIX bus mode (VARI/FIXED) for every two adjacent odd-numbered/even-numbered MIX buses. You can edit the setting by clicking the / buttons at the left and right.

## ④ STEREO B

Select one of the following two choices to specify how the STEREO B bus will function.

### • USE AS STEREO BUS

If this button is on, the STEREO B bus will function as a conventional stereo bus; the same signal as the STEREO A bus will be sent to it.

### • USE AS CENTER BUS

If this button is on, the STEREO B bus will function as the CENTER bus of LCR mode. When you turn this on, the CENTER bus output signal will be added to the L/R channels of the STEREO A bus, allowing LCR playback (three-channel playback). (The monitor sig-

nal will also be played back from the three MONITOR OUT connectors L/C/R.

### Note

If the USE AS STEREO BUS button is on, LCR mode is disabled.

## ⑤ SURROUND BUS ALLOCATION

Choose which of the following two ranges of MIX bus will be used as surround buses.

**MIX 1-8** . . . . MIX bus 1-8

**MIX 9-16** . . . . MIX bus 9-16

## ⑥ SURROUND MODE


Choose one of the following as the surround mode when using the Surround Pan function (➔ p.132).

### • STEREO

This is conventional stereo mode.


### • 3-1ch

This mode uses four channels: L (front left), C (front center), R (front right), and S (surround).




### • 5.1ch

This mode uses six channels: L (front left), C (front center), R (front right), Ls (rear left), Rs (rear right), and LFE (subwoofer).




• 6.1ch

This mode uses seven channels: 5.1ch with the addition of Bs (rear center).



**Hint**

The graphic below the buttons will change according to the mode you select.



⑦ **CASCADE FROM (Source when cascade-connected)**

Select one of the following as the external device that is sending audio signals to the PM5D via a cascade connection.

Display	Source device	Available cascade input port	Parameter linkage
—	Cascade disabled	CASCADE IN, SLOT 3/4, SLOT 1-4 [CH1-8], SLOT 1-4 [CH9-16]	Not possible
PM5D	another PM5D	CASCADE IN	Possible*1
DM2000 /02R96	YAMAHA DM2000 or 02R96	CASCADE IN	Not possible
MIXER [30BUS]	A mixer other than the above (maximum 30 bus)	SLOT 3/4, SLOT 1-4 [CH1-8], SLOT 1-4 [CH9-16]	
MIXER [16BUS]	A mixer other than the above (maximum 16 bus)	SLOT 4	

\*1. Linked parameters are specified in the CASCADE screen.

⑧ **CASCADE IN PORT SELECT**

Select one of the following as the port that will receive the audio signals from the cascade-connected device.

**Hint**


- If you select a choice other than CASCADE IN, the signal from the slot will be assigned to the cascade input, and the signal from the CASCADE IN connector will be assigned to the corresponding slot input.
- The signal assigned from the CASCADE IN connector to the slot input can be used as a patch source in the IN PATCH screen.

• **CASCADE IN**

Up to 30 channels of audio signals can be received from another PM5D via the rear panel CASCADE IN connector. If PM5D is selected as the cascade source (⑦), control signals for parameter linkage will also be transmitted and received.


• **SLOT 4**

Up to 16 channels of audio signals can be received via input channels 1–16 of an I/O card installed in slot 4 of the rear panel. If you choose this setting, the signals from the CASCADE IN connector (channels 1–16) will be assigned to channels 1–16 of the SLOT IN 4 port instead.




• **SLOT 3/4**

Up to 30 channels of audio signals can be received via input channels 1–16 of I/O cards installed in slots 3 and 4. (Since channels 15/16 of SLOT 4 are not used, only 30 channels are actually available.) If you choose this setting, the signals from the CASCADE IN connector (channels 1–32) will be assigned to channels 1–16 of the SLOT IN 3/4 ports instead.




- **SLOT 1-4 [CH1-8]**

Up to 30 channels of audio signals can be received via input channels 1–8 of I/O cards installed in slots 1–4. (Since channels 7/8 of SLOT 4 are not used, only 30 channels are actually available.) If you choose this setting, the signals from the CASCADE IN connector (channels 1–32) will be assigned to channels 1–8 of the SLOT IN 1–4 ports instead.



- **SLOT 1-4 [CH9-16]**

Up to 30 channels of audio signals can be received via input channels 9–16 of I/O cards installed in slots 1–4. (Since channels 15/16 of SLOT 4 are not used, only 30 channels are actually available.) If you choose this setting, the signals from the CASCADE IN connector (channels 1–32) will be assigned to channels 9–16 of the SLOT IN 1–4 ports instead.



- ⑨ **CASCADE TO (Transmission destination when cascade-connected)**

As the external device to which audio signals will be transmitted and control signals exchanged over the cascade connection, you can select either PM5D (i.e., a different PM5D unit) or “----” (transmission disabled).

- ⑩ **CASCADE OUT PORT SOURCE SELECT**

Select one of the following as the signal source that will be output from the CASCADE OUT connector.

**Hint**

*If you select a setting other than CASCADE OUT, the same signals will be output both to the corresponding slots and to the CASCADE OUT connector.*

- **CASCADE OUT**

The audio signals sent by the cascade function will be output from the CASCADE OUT connector. If PM5D is selected as the transmission destination (⑨), control signals for parameter linkage will also be transmitted and received. The type of signals that are output can be selected in the CASCADE screen.

- **SLOT 3/4**

The same audio signals (up to 32 channels) as are output from output channels 1–16 of slots 3/4 will be output in parallel from the CASCADE OUT connector.

- **SLOT 1-4 [CH1-8]**

The same audio signals (up to 32 channels) that are output from output channels 1–8 of slots 1–4 will also be output in parallel from the CASCADE OUT connector.

- **SLOT 1-4 [CH9-16]**

The same audio signals (up to 32 channels) that are output from output channels 9–16 of slots 1–4 will also be output in parallel from the CASCADE OUT connector.

- ⑪ **CASCADE MODE**

Choose one of the following two modes of operation when multiple PM5D units are cascade-connected.

- **MASTER**

If the Cascade function is enabled, control signals will be sent to an external PM5D.


- **SLAVE**

If the Cascade function is enabled, control signals will be received from an external PM5D.

- ⑫ **BI-DIRECTION (Bi-directional communication)**


When multiple PM5D units are connected, this button selects whether they will mix each other’s audio signals. Set the Cascade mode and the BI-DIRECTION button according to the type of cascade connection, as discussed below.

If you cascade-connect two PM5D units in a “ring” topology (i.e., connect the CASCADE IN connector of each unit to the OUT connector of the other unit), set the cascade mode to MASTER on one unit and SLAVE on the other unit. Turn the BI-DIRECTION button On for both units.



In this state, the SLAVE unit will follow when you operate the MASTER unit. The same mix will be output from both PM5D units.

If you daisy-chain two to four PM5D units (i.e., connect the first unit's CASCADE OUT → second unit's CASCADE IN, and the second unit's CASCADE OUT → third unit's CASCADE IN. Up to four units can be connected.), set the PM5D located last in the chain to MASTER, and the remaining PM5D units to SLAVE. Turn the BI-DIRECTION button Off for all units.



In this state, the SLAVE units will follow when you operate the MASTER unit. The final mix of all signals will be output from the PM5D that is connected last in the chain.

- ⑬ **CASCADE ENABLE/DISABLE**  
Turns the Cascade function on/off.



**Note**

If you edit the settings of the CASCADE CONNECTION parameters (⑦-⑫), the cascade function will temporarily be reset to Off.

- ⑭ **DME CONTROL**  
This button accesses the DME CONTROL screen (➔ p.182).

**CASCADE screen**

Here you can make various settings related to cascade connection.



- ① **CASCADE ENABLE/DISABLE**  
Enables/disables cascade connection.
- ② **CASCADE LINK**  
Here you can select the operations and parameters that will be linked when multiple PM5D units are cascade-connected. You can select the following items.
  - **SCENE RECALL**  
Scene recall operations / Recall undo operations
  - **SCENE STORE/EDIT**  
Scene store operations, store undo operations, title editing, sorting
  - **CUE/SOLO LOGIC**  
Cue/Solo operations (however, all Cue settings are cleared when linking occurs)
  - **DIMMER ON/OFF**  
Dimmer effect (including talkback dimmer)
  - **PAGE CHANGE**  
Switching the display screen

- **DCA FADER MODE**  
Switching the mode of the top panel FADER MODE section
- **ENCODER MODE**  
Switching the mode of the top panel ENCODER MODE section
- **PANEL/LCD BRIGHTNESS**  
BRIGHTNESS settings in the PREFERENCE 2 screen (UTILITY function)
- **INPUT METER POINT/OUTPUT METER POINT/PEAK HOLD**  
Input channel / output channel metering point selection, and peak hold on/off
- **DCA LEVEL/MUTE**  
DCA group 1–8 level, name, [CUE] key on/off operations, and [MUTE] key on/off operations


**Hint**

DCA and MUTE parameter values will be linked the instant Link is turned on. Other parameters will be linked for the first time only when that parameter is operated after Link is turned on.

- **MUTE MASTER**  
Mute group 1–8 on/off

**Hint**

- For details on the actual procedure of cascade-connecting multiple PM5D units, refer to p.143.
- To enable cascade link, you must turn on linking for the corresponding parameters on the other cascade-connected PM5D units as well.
- You can also turn linking off for the master PM5D. For example if you've cascade-connected multiple PM5D units, you can (for example) make settings so that DCA 1 is linked only between the master and the second unit, DCA 2 is linked for all PM5D units, and DCA 3 is linked only between the second unit and third unit.



③ **CASCADE IN SOURCE (Cascade IN source I/O assignment view)**

Here you can view and select the signals that are sent to the PM5D's internal buses from the cascade-connected external device. The type of signals received will depend on the selection in the CASCADE FROM field of the MIXER SETUP screen (SYS/W.CLOCK function)

External device selected in the CASCADE FROM field				Destination bus
PM5D*1	DM2000/02R96*11	MIXER [30BUS]	MIXER [16BUS]*2	
MIX 1	BUS 1	*3	SLOT4- 1	MIX 1
MIX 2	BUS 2		SLOT4-2	MIX 2
MIX 3	BUS 3		SLOT4-3	MIX 3
MIX 4	BUS 4		SLOT4-4	MIX 4
MIX 5	BUS 5		SLOT4-5	MIX 5
MIX 6	BUS 6		SLOT4-6	MIX 6
MIX 7	BUS 7		SLOT4-7	MIX 7
MIX 8	BUS 8		SLOT4-8	MIX 8
MIX 9	AUX 1		SLOT4-9	MIX 9
MIX10	AUX 2		SLOT4-10	MIX10
MIX11	AUX 3		SLOT4-11	MIX11
MIX12	AUX 4		SLOT4-12	MIX12
MIX13	AUX 5		SLOT4- 1	MIX13
MIX14	AUX 6		SLOT4- 2	MIX14
MIX15	AUX 7		SLOT4- 3	MIX15
MIX16	AUX 8		SLOT4- 4	MIX16
MIX17	AUX 9		SLOT4- 5	MIX17
MIX18	AUX10		SLOT4- 6	MIX18
MIX19	AUX11		SLOT4- 7	MIX19
MIX20	AUX12		SLOT4- 8	MIX20
MIX21	—		SLOT4- 9	MIX21
MIX22	—		SLOT4-10	MIX22
MIX23	—		SLOT4-11	MIX23
MIX24	—		SLOT4-12	MIX24
ST AL	ST L	SLOT4-13	ST AL	
ST AR	ST R	SLOT4-14	ST AR	
ST BL	—	SLOT4- 9	ST BL	
ST BR	—	SLOT4-10	ST BR	
CUE L	CUE L	SLOT4-15	CUE L	
CUE R	CUE R	SLOT4-16	CUE R	

- \*1. The signal assigned to each bus is fixed; it cannot be changed.
- \*2. You can enable/disable the assignment for each bus. However, you cannot send the signal of the same slot or same input channel to multiple buses. If a signal already assigned to a bus is selected for a different bus, the previous assignment will be cancelled.
- \*3. Assigned from the top in ascending numerical order of slot number / channel number, according to the settings of the CASCADE IN PORT SELECT area of the MIXER SETUP screen (SYS/W.CLOCK function). (this cannot be changed.)

④ **CASCADE IN ON/OFF**

For each of the PM5D's internal buses, you can specify whether signals from the cascade master will be input.

⑤ **CASCADE OUT ON/OFF**

For each of the PM5D's internal buses, you can specify whether signals will be output to the cascade slave.

## HA (Head Amp) screen

In this screen you can make settings such as phantom power (+48V), gain, and HPF for each of the internal head amps (PM5D-RH model only), or for each channel of an external head amp device that supports remote control via the dedicated protocol (e.g., Yamaha AD8HR or AD824).



### ① DISPLAY MODE

Select one of the following as the type of head amp displayed in the screen.

- **INTERNAL HA (PM5D-RH model only)**  
The internal head amp channels (AD IN 1–48, AD STIN 1–4) will be displayed.
- **EXTERNAL HA 1-4**
- **EXTERNAL HA 5-8**  
The channels of an external head amp device (ID number= 1–4, or ID number= 5–8) connected via the [HA REMOTE] connector will be displayed.

### Hint

Up to eight external devices can be daisy-chained to the PM5D's [HA REMOTE] connector. In this case, an ID number (1–8) is automatically assigned to each device, starting from the device that is connected directly to the PM5D's [HA REMOTE] connector.

### ② Model name

For each ID number, this indicates the model name of the external head amp device that is connected. If no device is connected this will indicate “----”. However even in this case, you will be able to make the same settings as when a Yamaha AD8HR is connected.

### ③ Slot/Channel

Here you can view/select the slot and channels to which the audio output of the external head amp device is connected.

### Note

If an external head amp device is connected to a PM5D slot, you must specify the appropriate slot/channels manually. Please note that if you specify an incorrect setting, the input channel HA indication in screens such as the IN HA screen may differ from the actual state.

### ④ +48V MASTER

If an AD8HR is connected via the [HA REMOTE] connector, this indicates the master phantom power on/off status. (Otherwise, this indicates “----”).

### ⑤ +48V

Switches phantom power (+48V) on/off for each channel.

### ⑥ HPF (High Pass Filter)

Turns the HPF on/off for each channel.

### ⑦ Cutoff frequency

Specifies the HPF cutoff frequency for each channel of the AD8HR. Move the cursor to the box, and turn the [DATA] encoder to adjust the cutoff frequency in a range of 20–600 Hz.

### ⑧ GAIN

Adjusts the gain for each channel. Move the cursor to the knob, and turn the [DATA] encoder to adjust the gain in a range of –62 dB to +10 dB. The current value is shown in the box below.

### ⑨ GANG

If this button is on, the gain settings of two adjacent odd-numbered/even-numbered channels will change in tandem, maintaining the current offset value.



### ⑩ LIBRARY


This button displays the HA LIBRARY screen (➔ p.208).

### Note

When an external head amp device is connected for the first time, the settings on the external head amp device are used. If you subsequently recall a HA library item, the HA library settings are used.

## OUTPUT PORT ATT (Output port attenuation) screen

In this screen you can specify the amount of attenuation for each output channel and for each output channel of an I/O card.



### ① DISPLAY MODE

Select the channels that will appear in the display, from the following choices.

#### • OUTPUT

The screen will show the amount of attenuation for output channels (MIX channels 1–24, MATRIX channels 1–8, STEREO A L/R channels, STEREO B L/R channels), CUE L/R channels, MONITOR L/R/C channels, and 2TR OUT DIGITAL 1–3 L/R channels.

#### • SLOT 1-4


The screen will show the amount of attenuation for each output channel of the I/O cards installed in slots 1–4.

### ② ATT (Attenuation)

Adjusts the amount of attenuation for each channel. Move the cursor to the knob, and turn the [DATA] encoder to adjust the attenuation in a range of –9 dB to 0 dB. The current value is shown in the box below each knob.



## DITHER screen

In this screen you can turn dithering on/off and specify the bit depth for dithering. These settings are made individually for each digital output jack and each output channel of the digital I/O cards.



### ① Digital output jack dither settings

Specify the number of bits (16, 20, 24 bits) used when dithering the output signals from 2TR DIGITAL OUT jacks 1–3. If you select OFF, dithering will not be performed.



### ② Slots 1–4



This area shows the type of digital I/O card installed in each slot.

### ③ Digital I/O card dither settings


For each output channel of the digital I/O cards installed in the slots, specify the number of bits used when dithering.

## HA LIBRARY screen

In this screen you can recall, store, rename, or delete items in the HA library.



- ① **EDIT**  
When you click this button, the HA screen will appear.
- ② **DATA FORMAT**  
Indicates the model name (PM5D-RH or PM5D).
- ③ **EXTERNAL HA TYPE INFORMATION**  
This area shows the model names (AD8HR/AD824) of the external head amp devices (ID numbers= 1–8) connected to the PM5D's [HA REMOTE] connector.



- ④ **RECALL**  
Recalls the HA library item selected in the list into memory.
- ⑤ **STORE**  
Stores the current settings of the HA screen into the location selected in the list. When you click this button a window will appear, allowing you to name and save the settings.
- ⑥ **TITLE EDIT**  
Edits the title of the library item selected in the list. When you click this button a window will appear, allowing you to edit the title.
- ⑦ **CLEAR**  
Deletes the library item selected in the list. When you click this button, a confirmation message will appear.

**Note**

Library items with an "R" displayed in the right column of the list are read-only. Read-only items cannot be stored, renamed, or deleted.

- ⑧ **DATA FORMAT**  
Indicates the data format (PM5D-RH or PM5D) of the library item selected in the list.
- ⑨ **EXTERNAL HA TYPE INFORMATION**  
This area indicates the model name (AD8HR/AD824) of the external head amps (ID numbers= 1–8) for which data is stored in the library.
- ⑩ **Library list**  
Use the scroll bar to select the library item on which you want to perform an operation. The selected library item will move to the center, and will be highlighted.

**Note**



- If PM5D format data is recalled to the PM5D-RH, the internal head amp settings will not change. If PM5D-RH format data is recalled to the PM5D, the internal head amp settings will be ignored.
- If the recall-source and recall-destination head amp devices have the same ID number but are assigned to different slots/channels, the data will not be recalled to head amps of those ID numbers.
- AD8HR data can be recalled into an AD824, and AD824 data can be recalled into an AD8HR. However when AD8HR data is recalled to an AD824, the gain settings of each channel will be converted into 6 dB units in order to match the specifications of the AD824.

# METER function

## INPUT METER screen

This screen contains meters that show the input level of the input channels (input channels 1–48, ST IN channels 1–4, EXTRN channels 1–4).

### INPUT METER



- ④ **Meters**  
These peak level meters indicate the input level of each channel. The current fader value is shown in the box below.  
If clipping occurs at any point PRE ATT, POST EQ, POST GATE, POST COMP, INSERT IN, or POST FADER, the Σ segment will light.
- ⑤ **Pair icon**  
This indicates the pairing status of two adjacent odd-numbered/even-numbered channels.



- ① **METERING POINT**  
Select one of the following as the point at which the input level will be detected. This setting also applies to the meters on the panel.
  - PRE ATT . . . . . Immediately before the attenuator
  - PRE GATE . . . . . Immediately before the internal gate
  - PRE FADER . . . . . Immediately before the fader
  - POST FADER . . . . . Immediately after the fader
  - POST ON . . . . . Immediately after the [ON] key
- ② **CH METER ALWAYS PRE ATT**  
If this button is on, the input channel meters of the panel will always show the pre-attenuator levels.
- ③ **PEAK HOLD**  
If this button is on, the peak level of each meter will be held. When you turn this button off, the peak level indication that had been held will be cleared. Peak hold will be cleared when you change the metering point (①). This button is linked with the [PEAK HOLD] key in the METER section of the top panel.

Information shown in the display

Function menu

Global functions



Output functions

Input functions

Appendices

## OUTPUT METER screen

This screen contains meters that show the output level of output channels (MIX channels 1–24, MATRIX channels 1–8, STEREO A/B channels), MONITOR (L/R/C), and CUE (L/R).



④ **Meters**

These peak level meters indicate the output level of each channel. The current master level value is shown in the box below.

If clipping occurs at any point POST EQ, POST COMP, POST ON, POST FADER, or INSERT IN, the Σ segment will light.

⑤ **Pair icon**

This indicates the pairing status of two adjacent odd-numbered/even-numbered channels.



① **METERING POINT**

Select one of the following as the point at which the output level will be detected.

- PRE EQ . . . . . Immediately before the EQ
- PRE FADER . . . . . Immediately before the fader
- POST FADER . . . . . Immediately after the fader
- POST ON . . . . . Immediately after the [ON] key
- POST DELAY . . . . . Immediately after the internal delay (of an output channel)

② **CUE METERING POINT**

Select one of the following as the point at which the output level of the cue signal will be detected.


- PRE DELAY . . . . . Immediately before the internal delay (of a monitor/cue channel)
- POST DELAY . . . . . Immediately after the internal delay (of a monitor/cue channel)

③ **PEAK HOLD**


If this button is on, the peak level of each meter will be held. When you turn this button off, the peak level indication that had been held will be cleared. Peak hold will be cleared when you change the metering point (①). This button is linked with the [PEAK HOLD] key in the METER section of the top panel.

## INPUT GR (Input Gain Reduction) screen

This screen contains meters that show the amount of gain reduction produced by the gate/compressor for each input channel (input channels 1–48, ST IN channels 1–4).





- ① **GATE/COMP (Gate / Compressor)**  
These buttons select either Gate or Compressor as the processor whose gain reduction amount is shown by the meters. The display at the left will change according to your selection.



- ② **Meters**  
These peak level meters indicate the amount of gain reduction for each channel. The current fader value is shown in the box below.
- ③ **Pair icon**  
This indicates the pairing status of two adjacent odd-numbered/even-numbered channels.

## OUTPUT GR (Output Gain Reduction) screen

This screen contains meters that show the amount of gain reduction produced by the compressor for each output channel (MIX channels 1–24, MATRIX channels 1–8, STEREO A/B channels).



- ① **Meters**  
These peak level meters indicate the amount of gain reduction for each channel. The current master level value is shown in the box below.
- ② **Pair icon**  
This indicates the pairing status of two adjacent odd-numbered/even-numbered channels.

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

# MON/CUE function


## TALKBACK screen

In this screen you can switch talkback on/off, and select the talkback destination.

### TALKBACK



- ③ **Talkback input selection**  
If you want to use an input jack other than the TALKBACK jack for purposes of talkback, you can choose it here from analog inputs AD IN 1–48. The talkback input selection is not included in the input patch library.
- ④ **HA (PM5D-RH model only)**  
Here you can switch phantom power on/off and adjust the gain for the analog input selected in ③. The LEVEL volume in the TALKBACK section of the panel does not affect the talkback input from the analog input channel. The HA setting is included in the HA library.
- ⑤ **Level meter (Analog input level meter)**  
This level meter indicates the peak level of the signal being input from the analog input selected in ③.
- ⑥ **ON/OFF (Analog input on/off)**  
This button switches the talkback input selected in ③ on/off.




- ① **Level meter (TALKBACK jack level meter)**  
This level meter indicates the peak level of the signal being input from the TALKBACK jack of the top panel.
- ② **+48V (TALKBACK jack phantom power)**  
This button switches phantom power on/off for the TALKBACK jack.

**Note**

The WITH ANALOG VOLUME icon below the button indicates that the LEVEL volume in the TALKBACK section of the panel will affect only the signal being input from the TALKBACK jack.



- ⑦ **ON/OFF (Talkback on/off)**  
This button switches Talkback on/off. This is linked with the TALKBACK [ON] key in the TALKBACK section of the panel.
- ⑧ **NEVER LATCH**  
This button selects one of the following as the mode in which the TALKBACK ON/OFF button and the panel TALKBACK [ON] key will behave.
  - **If the NEVER LATCH button is off**  
Talkback will be switched on/off (Latched operation) each time you click the ON/OFF button or press the TALKBACK [ON] key. However if you press and hold down the TALKBACK [ON] key, talkback will stay on only while you continue holding down the key; talkback will turn off when you release the key (Unlatched operation).
  - **If the NEVER LATCH button is on**  
Talkback will be on only while you click and hold down the ON/OFF button or press and hold down the TALKBACK [ON] button; talkback will turn off when you release the button or key (Unlatched operation).



⑨ **BUS ASSIGN**

Here you can select the bus(es) or output jack(s) from which the talkback signal will be sent. (Multiple selections are allowed.)



- MIX 1–24 . . . . . MIX bus 1–24
- MATRIX 1–8 . . . . . MATRIX bus 1–8
- ST A L/R . . . . . STEREO A bus L/R channels
- ST B L/R . . . . . STEREO B bus L/R channels

⑩ **TALKBACK OUT (Talkback direct output)**

This indicates the channel of the output jack / slot that is selected as the output destination for direct output of the talkback signal. If more than one output destination is patched, “...” will be displayed following the name of the output destination that was found first. If you want to change the output destination, click the PATCH button to access the OUTPUT PATCH screen.

**OSCILLATOR screen**

Here you can make settings and perform operations related to the internal oscillator.



- ① **OSC ON/OFF (Oscillator on/off)**  
Turns the Oscillator on/off. This is linked with the OSCILLATOR [ON] switch of the top panel.
- ② **OSC MODE (Oscillator mode)**  
These buttons select the waveform or type of noise produced by the oscillator.
  - SINE WAVE 1CH . . . . . Sine wave x 1 channel
  - SINE WAVE 2CH . . . . . Sine wave x 2 channels
  - PINK NOISE . . . . . Pink noise
  - BURST NOISE . . . . . Burst noise (repeated output of pink noise)
- ③ **PARAMETERS**  
Here you can set various items according to the selection in (2).

Information shown in the display

Function menu


Global functions

Output functions


Input functions

Appendices


- If SINE WAVE 1CH is selected




- If SINE WAVE 2CH is selected



- If PINK NOISE is selected



- If BURST NOISE is selected



**④ LEVEL**

This knob adjusts the output level of the oscillator. The range is -96 dB to 0 dB. The level meter beside the knob indicates the output level.

**⑤ FREQ (Frequency)**

This knob specifies the frequency of the sine wave produced by the oscillator. The range is 20 Hz–20 kHz (the current setting is shown in the numerical box below). You can use the 10 kHz / 1 kHz / 100 Hz buttons to select a preset frequency.

**Hint**

*If SINE WAVE 2CH is selected, you can specify the level and frequency of each channel independently.*

**⑥ HPF (High Pass Filter)**

**⑦ LPF (Low Pass Filter)**


Here you can make settings for the HPF/LPF through which the pink noise or burst noise is sent. The knob above sets the cutoff frequency (20 Hz–20 kHz), and the button below switches the filter on/off.

**⑧ WIDTH**

**⑨ INTERVAL**

If burst noise is selected, these knobs select the duration of the noise itself (WIDTH) and the duration of silence between noise bursts (INTERVAL).

The range is 0.1–10 sec for WIDTH, and 1–30 sec for INTERVAL. (The current setting is shown in the box below each knob.)




The BURST NOISE button is on



**⑩ OSC OUT (Oscillator direct output)**

This indicates the channel of the output jack / slot that directly outputs the oscillator signal. If you want to change the output destination, click the PATCH button to access the OUTPUT PATCH screen.

If SINE WAVE 2CH is selected, the L channel of the oscillator is sent to the oscillator direct output.



**⑪ BUS ASSIGN**

Here you can select the bus(es) or output jack(s) from which the sine wave or noise will be sent. (Multiple selections are allowed.)

**MIX 1–24** . . . . . MIX bus 1–24

**MATRIX 1–8** . . . . . MATRIX bus 1–8


**AL/AR** . . . . . STEREO A bus L/R channels

**BL/BR** . . . . . STEREO B bus L/R channels


If SINE WAVE 2CH is selected, the L channel of the oscillator is output to the odd-numbered bus or the L jack, and the R channel of the oscillator is output to the even-numbered bus or the R jack.

## 2TR I/O screen

This screen contains various settings and indications for 2TR IN / 2TR OUT.



- ① **Input level meters**  
These indicate the input level of 2TR IN DIGITAL jacks 1–3 and 2TR IN ANALOG jacks 1–2.
- ② **FREQUENCY (Sampling frequency)**  
Indicates the sampling frequency of the input signal from 2TR IN DIGITAL jacks 1–3.
- ③ **SRC (Sampling Rate Converter)**  
These are on/off switches for the sampling rate converters built into 2TR IN DIGITAL jacks 1–3. (If turned off, this indicates “THROUGH.”)
- ④ **EMPHASIS STATUS**  
Indicates whether emphasis processing is being applied to the input signal from 2TR IN DIGITAL jacks 1–3.



- ⑤ **Output level meter**  
Indicates the output level of 2TR OUT DIGITAL jacks 1–3.
- ⑥ **SRC (Sampling Rate Converter)**  
These are on/off and output frequency select switches for the sampling rate converters built into 2TR OUT DIGITAL jacks 1–3. As the output frequency you can select either 44.1 kHz or 48 kHz. The on/off button selects either ON or THROUGH (off).
- ⑦ **Fs (Sampling frequency)**  
This indicates the sampling frequency at which the PM5D is operating.

Information shown in the display

Function menu

Global functions


Output functions

Input functions

Appendices

## MONITOR screen

Here you can make settings and perform operations related to monitoring.



### ① MONITOR SOURCE

Selects the source that will be monitored from the L/R/C MONITOR OUT jacks. You can select one from 2TR IN A1/A2, 2TR IN D1–D3, or DEFINE, and also simultaneously select one from STEREO A/B or LCR. These buttons are linked with the various keys of the MONITOR section in the top panel.

2TR IN A1	2TR IN ANALOG jack 1 input signal
2TR IN A2	2TR IN ANALOG jack 2 input signal
2TR IN D1	2TR IN DIGITAL jack 1 input signal
2TR IN D2	2TR IN DIGITAL jack 2 input signal
2TR IN D3	2TR IN DIGITAL jack 3 input signal
STEREO A	STEREO A channel output signal (*)
STEREO B	STEREO B channel output signal (*)
LCR	LCR channel output signal (*)
DEFINE	The signal selected in the DEFINE section (②) of this screen

If a monitor source indicated by (\*) is selected, the signal that is output will change depending on whether the USE AS STEREO BUS button or the USE AS CENTER BUS button is turned on in the STEREO B section of the MIXER SETUP screen (➡ p.201).

❑ If the USE AS STEREO BUS button is on

Monitor source	L	R	C
ST A	STEREO A L	STEREO A R	—
ST B	STEREO B L	STEREO B R	
LCR	—	—	

❑ If the USE AS CENTER BUS button is on


Monitor source	L	R	C
ST A	STEREO A L	STEREO A R	—
ST B	—	—	
LCR	STEREO A L	STEREO A R	STEREO B L

### ② DEFINE

If “DEFINE” is selected in the MONITOR SOURCE section, you can choose the signal that will be monitored from the following.

MIX 1–24 . . . . . MIX bus 1–24 output signal

MATRIX 1–8. . . . . MATRIX bus 1–8 output signal



### ③ MONITOR / CUE DELAY

Here you can make settings for the delay function provided on the MONITOR/CUE bus output. Use the knob to specify the delay time (0–1000 msec), and use the ON/OFF button to switch the delay on/off. If the ON/OFF button is on, the monitor signal and cue signal will be delayed by the specified time. The delay time units can be changed in the DELAY SCALE field found in each screen of the INPUT DELAY/OUTPUT DELAY function.

### ④ DIMMER

When you turn this button on, the level of the signal being monitored will be temporarily attenuated. The knob adjusts the amount of attenuation that will occur when the button is on. The range of adjustment is –96 dB to 0 dB. While this button is on, the DIMM indicator will appear in the upper right of the display.

#### Hint

You can also use an external switch connected to the GPI IN connector to switch the dimmer on/off. To do so, assign the MONITOR DIMMER ON function to the GPI IN port to which the switch is connected. (➡ p.177).

### ⑤ TALKBACK DIMMER

This adjusts the amount by which the monitor signal will be attenuated when talkback is on. The range of adjustment is –96 dB to 0 dB. The talkback on/off status is shown in the box below.



⑥ **Level meter**

These peak level meters indicate the level of the output signal from the MONITOR OUT jacks. You can select the level detection point to be immediately before the delay that is provided on the MONITOR/CUE bus output (when the PRE DELAY button is on) or immediately after the delay (when the POST DELAY button is on).

⑦ **CUE INTERRUPTION**

If this button is on, the cue/solo signal will also be output from the MONITOR OUT jacks while the Cue/Solo function is active. During this time, the monitor source selected in the MONITOR SOURCE section will be disabled.

If this button is off, the cue/solo signal will never be output from the MONITOR OUT jacks.

⑧ **MONITOR MODE**

Here you can select one of the following two ways in which the signal will be output from the MONITOR OUT jacks.


**STEREO** . . . . The L/R channels will be output in stereo.

**MONO** . . . . . The L/R channels will be mixed, and output in monaural.

The status of these two buttons is linked with on/off operations of the [MONO] key in the MONITOR section of the panel.

⑨ **OUTPUT ON/OFF**

This is an on/off switch for the signal that is output from the MONITOR OUT jacks.



⑩ **MONITOR INSERT**

This area shows the input jacks (and input channels of the digital I/O card) that are inserted into the MONITOR OUT L/C/R channels. The input level of the inserted signal is shown by the level meter at the right. If GEQ or EFFECT is inserted, the corresponding information is shown here.

⑪ **INSERT ON/OFF**

This button enables/disables insertion.

⑫ **PATCH**

Displays the INSERT PATCH screen.

**CUE/SOLO screen**

Here you can make settings and perform operations related to the Cue/Solo function.



① **SOLO ON/OFF**


This button selects either CUE mode or SOLO mode as the type of monitoring performed by the [CUE] key. When you turn this button on, a confirmation message will appear. Each mode operates as follows.

• **CUE mode (SOLO ON/OFF button is off)**

The signal of the channel whose [CUE] key is pressed will be sent to the dedicated CUE bus, and monitored via the CUE OUT jacks, MONITOR OUT jacks (if CUE INTERRUPTION is on), and PHONE jack. This mode lets you monitor the signal of a specific channel without affecting other buses.

• **SOLO mode (SOLO ON/OFF button is on)**

When using Input Solo, the familiar “solo” function is enabled; only the signal of the channel whose [CUE] key is pressed will be sent to the MIX, MATRIX, and STEREO A/B buses, and other channels will be muted. When using Output Solo, only that channel will be on. The signal of a channel whose [CUE] key is pressed can also be monitored from the CUE OUT jacks, MONITOR OUT jacks, and PHONES jack.



Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

## ② CUE MODE

This button selects one of the following two possibilities for when the [CUE] key of more than one channel is pressed.

### • MIX CUE mode

All channels / DCA groups whose [CUE] key is on will be mixed for monitoring.

### Note

*As an exception to MIX CUE, turning on a CUE button in the EFFECT PARAM screen or GATE PARAM screen or turning on a CUE button in the DME CONTROL screen (EXTERNAL CUE) will give priority to monitoring only the corresponding signal. (Any [CUE] keys that had been on until then will be forcibly defeated.)*

### • LAST CUE mode

Only the channel / DCA group whose [CUE] key was pressed last will be monitored.

## ③ CUE FUNCTION

These buttons let you turn on/off various functions related to Cue. You can select the following functions.

### • MIX CUE LINK

Specifies whether cue operations will be linked to MIX channel selection. If this button is on, pressing the mix key selected in the ENCODER MODE section of the panel once again will simultaneously switch on the [CUE] key of that channel.

### • CUE/SEL LINK

Specifies whether channel selection will be linked with cue operations. If this button is on, pressing the [CUE] key of a channel will simultaneously select that channel and light its [SEL] key.

### • FADER/CUE RELEASE

This specifies whether cue operations will be restricted according to the fader position. If this button is on, cue will be defeated if you raise the fader from the  $-\infty$  dB position for a channel whose [CUE] key is lit. For a channel whose fader is above the  $-\infty$  dB position, cue operation will not be possible. (Pressing the [CUE] key will do nothing.) This means that cue can be turned on only when the fader is at the  $-\infty$  dB position.

## ④ CUE OUT

Turns the cue output on/off.



## ⑤ INPUT

Here you can select the position from which an input channel will be cued.

### PFL (Pre-Fader Listen)

..... Immediately before the fader

### AFL (After-Fader Listen)

..... Immediately after the fader

### POST PAN

..... Immediately after pan

If you select PFL, you can also use the knob located at the left to adjust the output level in a range of  $-20$  dB to  $+10$  dB.

## ⑥ DCA

Here you can make cue output settings for DCA groups.

### • DCA TRIM

Adjusts the level of cue output from a DCA group in a range of  $-20$  dB to  $+10$  dB.

### • DCA UNITY

If this button is on, pressing a DCA [CUE] key will always monitor the corresponding DCA group at unity gain (the same level at when the DCA fader is at 0 dB).

### Hint

- If you leave the DCA UNITY button on, you will be able to monitor the desired DCA group even if that DCA group is muted or its fader is lowered.
- Even when the DCA UNITY button is on, the value specified by the DCA TRIM knob is still valid. (In this case, the DCA TRIM knob specifies an offset value relative to unity gain.)

### • PRE PAN/POST PAN

This selects whether the pre-pan signal (PRE PAN button on) or the post-pan signal (POST PAN button is on) will be monitored when the DCA [CUE] button is turned on.

## ⑦ OUTPUT

Here you can select the position from which an output channel will be cued.


### PFL (Pre-Fader Listen)

..... Immediately before the fader

### POST ON

... Immediately after the [ON] key


If you select PFL, you can also use the knob located at the left to adjust the output level in a range of  $-20$  dB to  $+10$  dB.



### ⑧ INPUT SOLO SAFE

Here you can specify input channels that will be excluded from Solo operations. (You can specify more than one.) The buttons correspond to the following input channels.

<b>INPUT 1-48</b>	Input channels 1-48
<b>ST IN 1-4</b>	ST IN channels 1-4
<b>FX RTN 1-4</b>	FX RTN channels 1-4
<b>SET ALL</b>	Sets all input channels to the Solo Safe condition
<b>CLEAR ALL</b>	Defeats the Solo Safe setting for all input channels



### ⑨ OUTPUT SOLO SAFE

Here you can specify output channels that will be excluded from Solo operations. (You can specify more than one.) The buttons correspond to the following output channels.

<b>MIX 1-24</b>	MIX channels 1-24
<b>MATRIX 1-8</b>	MATRIX channels 1-8
<b>STEREO A/B</b>	STEREO A/B channels
<b>SET ALL</b>	Sets all output channels to the Solo Safe condition
<b>CLEAR ALL</b>	Defeats the Solo Safe setting for all output channels

#### Hint

*Solo Safe settings and Cue on/off operations are linked for paired channels. Solo Safe operations can be performed independently of the scene memory.*



### ⑩ Level meter

This is a peak level meter that indicates the level of the signals output from the CUE OUT jacks. You can select the level detection point to be immediately before the delay that is provided on the MONITOR/CUE bus output (when the PRE DELAY button is on), or immediately after the delay (when the POST DELAY button is on).

### ⑪ MONITOR / CUE DELAY

Here you can make settings for the delay function provided on the MONITOR/CUE bus output. Use the knob to specify the delay time (0-1000 msec), and use the DELAY button to switch the delay on/off. In general, this is linked with the MONITOR/CUE DELAY setting in the MONITOR screen. However, the difference is that in this screen, turning the AUTO BYPASS button on lets you automatically bypass the delay when you perform the Cue any input channels.



# Output functions

## OUTPUT PATCH function

### OUTPUT PATCH screen

Here you can make patch settings to send output channel signals to the outputs of I/O cards installed in the slots, to the input of internal effects, and to the 2TR OUT DIGITAL jacks.

#### OUTPUT PATCH



- ① **SELECTED PATCH**  
This indicates the output channel number and output port of the grid at which the cursor is located.
- ② **CH (Output channel)**  
This is the number of the output channel (MIX channel, MATRIX channel, STEREO A/B channel, MONITOR L/C/R channel, TALKBACK OUT channel, OSC OUT channel) whose output destination will be patched. The channel number at which the cursor is located will be highlighted.
- ③ **ASSIGN**  
For each output channel, this indicates the number of output ports that are currently assigned.
- ④ **Grid**  
This grid lets you patch output ports (horizontal rows) to output channels (vertical columns). Currently-patched grids are indicated by a ● symbol. By clicking a grid location you can set/cancel patching.

The red lines at the left and top indicate the grid location to which you move the cursor.

#### Hint

- If **PATCH CONFIRMATION** is turned on in the **PREFERENCE 1** screen (UTILITY function), a confirmation message will appear each time you attempt to change a patch setting. If **STEAL PATCH CONFIRMATION** is turned on, a confirmation message will also appear when you attempt to make patch settings that would cause an existing patch to be modified.
- To move the cursor location rapidly in or out of the grid, hold down the [SHIFT] key and press the CURSOR [◀]/[▶]/[▲]/[▼] keys.
- To move rapidly to left or right inside the grid, turn the [DATA] encoder. To move up or down, hold down the [SHIFT] key and turn the [DATA] encoder.


#### Note

You can patch an output channel to more than one output port, but you cannot patch multiple output channels to a single output port.

### ⑤ Output port

From the top, this area indicates the type of output port, the ID number, the output channel number, and the number of output channels assigned. The following types of output port can be selected.

<b>SLOT OUT</b>	Output channels of an I/O card installed in slots 1–4
<b>FX IN</b>	L/R inputs of internal effects 1–8 (MIX channels are the only output channels that can be selected)
<b>2TR OUT</b>	L/R channels of 2TR OUT DIGITAL jacks 1–3



### ⑥ LIBRARY button

This button accesses the OUTPUT PATCH LIBRARY screen (➔ p.223), where you can store/recall patch library settings for output channels.

#### Hint

- The signal from immediately after the delay and immediately before the output port attenuation will be sent to output ports you patch in this screen. Subsequently, in the case of **SLOT OUT** and **2TR OUT**, the specified output port attenuation will be applied respectively.
- The rear panel **MIX OUT** jacks 1–24, **MATRIX OUT** jacks 1–8, and **STEREO OUT** jacks A/B always output the signal of the corresponding output channel. They are not affected by the settings in this screen.

## INSERT PATCH screen

In this screen you can patch the input/output ports into which external devices will be inserted. Select the output port in the left side of the screen, and the input port in the right side of the screen.




### ① SELECTED PATCH

This indicates the number of the output channel at which the cursor is located in the grid.

### ② Insert in/out

This indicates the input/output ports that are patched as insert in/out for the output channel at which the cursor is located. If multiple ports are assigned for insert-out, only the first port is displayed.



### ③ CH (Output channel)

This area shows the numbers of the output channels (MIX channels, MATRIX channels, STEREO A/B channels, MONITOR L/R/C channels). The channel number at which the cursor is located will be highlighted.

### ④ ASSIGN

For each output channel, this indicates the number of output ports that are currently assigned as insert-out.

### ⑤ Grid

For each output channel (vertical column), this grid lets you can patch one or more output ports (horizontal row) to be used as insert-outs. Currently-patched grids are indicated by a symbol.

By clicking a grid location you can set/cancel patching. The red lines at the left and top indicate the grid location to which you move the cursor.

#### Hint

Operations in the grid are the same for all of the patching screens. For details, refer to the Hint on p.220.


### ⑥ Output port

From the top, this area indicates the type of output port, the ID number, the output channel number, and the number of output channels assigned. The following types of output port can be patched as insert-out.

<b>SLOT OUT</b>	Output channels of an I/O card installed in slots 1-4
<b>FX IN</b>	L/R inputs of internal effects 1-8
<b>GEQ IN</b>	Inputs of internal GEQ modules 1-12
<b>2TR OUT</b>	L/R channels of 2TR OUT DIGITAL jacks 1-3

#### Hint

If you select **FX IN** as an insert-out, the output of the same internal effect will automatically be selected as the insert-in. If you select **GEQ IN**, the output of the same GEQ module will automatically be selected as the insert-in.



### ⑦ ASSIGN

For each input channel, this indicates the number of input ports that are currently assigned as insert-in.

### ⑧ Input port

From the top, this area indicates the type of input port, the ID number, the input channel number, and the number of input channels assigned. The following types of input port can be selected.

<b>AD IN</b>	INPUT jacks 1-48
<b>AD ST IN</b>	ST IN jacks 1-4 L/R
<b>SLOT IN</b>	Input channels of an I/O card installed in slots 1-4
<b>FX OUT</b>	L/R outputs of internal effects 1-8
<b>GEQ OUT</b>	Outputs of GEQ modules 1-12
<b>2TR IN</b>	L/R channels of 2TR IN DIGITAL jacks 1-3 and 2TR IN ANALOG jacks 1/2




⑨ LIBRARY button

This button accesses the OUTPUT PATCH LIBRARY screen (➔ p.223), where you can store/recall patch library settings for output channels.

▢ Using the [SHIFT] key + CURSOR [◀]/[▶] to move the cursor

When operating from the panel, you can move the cursor from the right side of the screen to the left side (or vice versa) by holding down the [SHIFT] key and using the CURSOR [◀]/[▶] keys.

To quickly move the cursor in or out of the grid, hold down the [SHIFT] key and press the CURSOR [◀]/[▶]/[▲]/[▼] keys.



**Note**

To enable an insert-in assigned to an output channel in this screen, you must turn on the ON/OFF button for the corresponding output channel in the INSERT POINT screen (OUTPUT PATCH function). (➔ p.222) However, the insert-out is always on, regardless of the state of the ON/OFF button. An exception to the above is that if you insert GEQ, its insert-in will automatically be on.

**INSERT POINT screen**


In this screen you can select the position at which the insert-in/out of each output channel will be patched. Here you can also switch insert-in on/off.

INSERT POINT



① Insert view

When you move the cursor to the insert I/O point (④), the insert point for that output channel will be shown graphically.



② OUTPUT CH (Output channel)

This is the number of the output channel you are editing. Two paired channels are indicated by a heart symbol shown at the left; settings ③–④ will be linked for these channels. You can click this symbol to enable/disable pairing.

③ ON/OFF (Insert on/off)

This button switches insert on/off for each channel. This is linked for paired channels.

**Note**

Be aware that if you turn on this button when either insert-in or insert-out are unpatched, the signal will no longer be output from the corresponding output channel.



④ INSERT I/O (Insert I/O point)

Here you can select one of the following as the insert-in/out location for each output channel.

PRE EQ	Immediately before the EQ
POST EQ	Immediately after the EQ
PRE FADER	Immediately before the fader
POST ON	Immediately after the [ON] key

## OUTPUT PATCH LIBRARY screen

Here you can recall, store, rename, or delete items in the output patch library.




### 1 EDIT

When you click this button, the OUTPUT PATCH screen will appear.

### 2 Patch information for the current scene

This area shows the output patch settings for the current scene.



### 3 RECALL

Recalls the output patch library item selected in the list into memory.

### 4 STORE

Stores the current settings of the OUTPUT PATCH screen into the location selected in the list. When you click this button a window will appear, allowing you to name and save the settings.

### 5 TITLE EDIT

Edits the title of the library item selected in the list. When you click this button a window will appear, allowing you to edit the title.

### 6 CLEAR

Deletes the library item selected in the list. When you click this button, a confirmation message will appear.

### Note

*Library items with an "R" displayed in the right column of the list are read-only. Read-only items cannot be stored, renamed, or deleted.*

### 7 Patch settings of the library item

Displays the settings of the library item selected in the list.

### 8 Library list

Use the scroll bar to select the library item on which you want to perform an operation. The selected library item will move to the center, and will be highlighted.

Information shown  
in the display

Function  
menu

Global  
functions

Output  
functions

Input  
functions

Appendices

# OUTPUT INSERT function

## INSERT IN MIX 1-24 screen

## INSERT IN MATRIX/STEREO/MONITOR screen

Here you can make settings for the internal HA (PM5D-RH model only) or external HA assigned to the insert-in of an output channel or MONITOR L/C/R channel.

### INSERT IN MIX1-24



### INSERT IN MATRIX/STEREO/MONITOR



- ① **+48V**  
Switches phantom power (+48V) on/off for each channel.
- ② **HPF (High Pass Filter)**  
Turns the HPF on/off for each channel.
- ③ **Cutoff frequency**  
Specifies the HPF cutoff frequency for each channel. Move the cursor to the box, and turn the [DATA] encoder to adjust the cutoff frequency in a range of 20–600 Hz.
- ④ **GAIN**  
Adjusts the gain for each channel. Move the cursor to the knob, and turn the [DATA] encoder to adjust the attenuation in a range of +10 dB to –62 dB. The current value is shown in the box below each knob.

#### Note

Since settings ①–④ are for the patched input port, they are linked for channels that are patched to the same port.

- ⑤ **Input port**  
This indicates the type and number of the input port assigned to the insert-in of that channel.

#### Note

- Items ①–④ are not shown for channels to whose insert-in nothing is patched, or for channels patched to an input port that does not have a HA. Items ② and ③ are not shown for channels patched to a port that has no high pass filter.
- Use the INSERT PATCH screen (OUTPUT PATCH function) to patch an input port to an insert-in.

- ⑥ **Channel**  
This is the number of the channel you are editing. Two paired channels are indicated by a heart symbol displayed between them.

#### Note


HA settings are not linked even if two channels are paired. However, the GAIN knob setting is linked for HAs whose GANG button is turned on in the HA screen (SYS/W.CLOCK function).

#### Hint

The HA settings you edit in this screen are also reflected in the HA screen (SYS/W.CLOCK function).

## HA LIBRARY screen

This screen is shared with HA LIBRARY in the SYS/W.CLOCK function (➔ p.208).



## OUTPUT EQ function

### EQ PARAM (EQ Parameter) screen

Here you can edit the EQ parameters of the selected output channel.

#### EQ PARAM



(If a MIX channel or STEREO A/B channel is selected)

#### EQ PARAM



(If a MATRIX channel is selected)

Information shown  
in the display


Function  
menu

Global  
functions

Output  
functions

Input  
functions

Appendices



**1 Channel selection**

Select the output channel that you want to edit. You can use eight-band EQ (four UPPER bands + four LOWER bands) for MIX channels and STEREO A/B channels, and four-band EQ for MATRIX channels. If a channel is paired (or if a STEREO A/B channel is selected), a heart symbol is displayed at the right. For MIX channels or MATRIX channels, you can click this symbol to enable/disable pairing.

**2 EQ ON/OFF (EQ on/off)**

Turns the EQ on/off for that channel.

**3 EQ LINK GROUP**

Selects the EQ link group (A–H) to which the EQ of that channel belongs. EQ parameters are linked for output channels belonging to the same group.

**Note**

*The EQ of MIX channels and STEREO A/B channels can be assigned only to groups A–F, and the EQ of MATRIX channels can be assigned only to groups G/H.*

**4 LIBRARY**

This button accesses the OUTPUT EQ LIBRARY screen (➔ p.228), where you can store/recall EQ library settings for output channels.

**5 EQ TYPE**

Selects the type of EQ. Turning the TYPE I button on selects the algorithm used in the 02R series. Turning the TYPE II button on selects a newly developed algorithm. TYPE II reduces the interference between bands.

**6 EQ graph**

This graph shows the approximate response of the EQ parameters. The colored vertical lines indicate the FREQ (center frequency) of the band for the parameter at which the cursor is located. (The color of each line matches the knob markings for each band.) The response curve will change when you edit the Q or GAIN of each band.

**7 Level meter**

These meters indicate the peak levels before EQ and after EQ. If the signal clips before EQ, the OVER segment will light.

**8 EQ FLAT**

This button resets the GAIN parameters of all bands to the default value (±0.0 dB). When you click this button, a confirmation message will appear.

**9 LOWER/UPPER (only for MIX channels and STEREO A/B channels)**

This indicator shows which four bands (LOWER or UPPER) are selected in the SELECTED CHANNEL section of the panel. The text label of the selected group is displayed in yellow.

**10 Knobs**

These knobs adjust the Q, FREQ (center frequency), and GAIN (amount of boost/cut) for each band.

**11 BYPASS**

These buttons bypass each band of the EQ.

**12 > (LOW shelving)**

If this button is on, the LOW EQ will function as a shelving-type EQ. The Q knob will disappear.

**13 HPF (High Pass Filter)**

If this button is on, the LOW EQ will function as a high-pass filter. The Q knob will disappear, and the GAIN knob is used to switch the HPF on/off.

**14 < (HIGH shelving)**

If this button is on, the HIGH EQ will function as a shelving-type EQ. The Q knob will disappear.



**15 LPF (Low Pass Filter)**

If this button is on, the HIGH EQ will function as a low-pass filter. The Q knob will disappear, and the GAIN knob is used to switch the LPF on/off.

## MIX 1-24 screen

## MATRIX/STEREO screen

These screens list the EQ settings for all output channels. Here you can also copy EQ settings between output channels.



### ① EQ graph

This mini-graph shows the approximate EQ response for each output channel.

When you click the graph at which the cursor is currently located, the EQ PARAM screen for that channel will appear.

In this screen you can drag and drop the mini-graph from the desired channel to copy its EQ settings. (When you drag and drop the mini-graph, a message will ask you to confirm the copy operation.)



You can also copy EQ settings between the MIX 1-24 screen and the MATRIX/STEREO screen. First drag the mini-graph over the MIX 1-24 tab or MATRIX/STEREO tab in the screen (the screen will switch). Then drag and drop the mini-graph onto the desired channel, and a message will ask you to confirm the copy operation.



You can also copy settings between the eight-band EQ of a MIX channel or STEREO A/B channel and the four-band EQ of a MATRIX channel. In this case, only the LOWER four bands will be copied for MIX channels or STEREO A/B channels.

### ② EQ ON/OFF (EQ on/off)

Turns the EQ on/off for that channel. This is linked for paired channels.

### ③ Channel

This is the number of the channel you are editing. Two paired channels are indicated by a heart symbol displayed between them.

### ④ Level meter

This meter indicates the peak level after EQ. If the signal clips, the OVER segment will light.

Information shown in the display

Function menu

Global functions




Output functions

Input functions

Appendices

## OUTPUT EQ LIBRARY screen

Here you can recall, store, rename, or delete items in the output EQ library.



- ① **EDIT**  
When you click this button, the EQ PARAM screen for the currently selected output channel will appear.
- ② **Channel selection**  
Select the channel that you want to edit.
- ③ **EQ graph for the selected channel**  
This graph shows the approximate response of the EQ for the currently selected channel.
- ④ **Level meter**  
These meters indicate the peak levels before EQ and after EQ. If the signal clips before EQ, the OVER segment will light.

- ⑤ **RECALL**  
Recalls the EQ library item selected in the list into memory.
- ⑥ **STORE**  
Stores the EQ settings of the currently selected channel into the location selected in the list. When you click this button a window will appear, allowing you to name and save the settings.
- ⑦ **TITLE EDIT**  
Edits the title of the library item selected in the list. When you click this button a window will appear, allowing you to edit the title.
- ⑧ **CLEAR**  
Deletes the library item selected in the list. When you click this button, a confirmation message will appear.

**Note**

*Library items with an "R" displayed in the right column of the list are read-only. Read-only items cannot be stored, renamed, or deleted.*

- ⑨ **Library EQ graph**  
This graph indicates the approximate response of the EQ library item selected in the list. The LIBRARY TYPE indication shows whether the item contains eight-band EQ settings (MIX, STEREO A/B) or four-band EQ settings (MATRIX).
- ⑩ **Library list**  
Use the scroll bar to select the library item on which you want to perform an operation. The selected library item will move to the center, and will be highlighted.

# OUTPUT COMP function

## COMP PARAM (Compressor parameter) screen

Here you can edit the compressor parameters of the selected output channel.

### COMP PARAM



### 1 Channel selection

Select the channel that you want to edit. If the corresponding MIX channel or MATRIX channel is paired (or if a STEREO A/B channel is selected), a heart symbol is displayed at the right. For MIX channels or MATRIX channels, you can click this symbol to enable/disable pairing.

### 2 COMP ON/OFF (Compressor on/off)


Turns the compressor on/off for that channel.

### 3 COMP LINK GROUP (Compressor link group)

Selects the compressor link group (A–H) to which that channel belongs. Compressor parameters are linked for output channels belonging to the same group.

### 4 LIBRARY

This button accesses the COMP LIBRARY screen (p.232), where you can store/recall compressor library settings for output channels.




### 5 Level meters

These meters indicate the amount of gain reduction (GR), the peak level before (PRE) and after (POST) the compressor, and the peak level of the key-in signal (KEY IN) that causes the compressor to operate. If the signal clips, the OVER segment will light.

If stereo link is turned on for the corresponding MIX channel or MATRIX channel (or if a STEREO A/B channel is selected), level meters for two channels are displayed.

### Hint

If GR METER ON/OFF LINK is turned on in the PREFERENCE 1 screen (UTILITY function), the gain reduction meter will not be displayed when the compressor is off.



### 6 Type

Indicates the type of the currently selected compressor.

### Hint

To change the compressor type, use the OUTPUT COMP LIBRARY screen to recall a library item that has a different type. You cannot change the compressor type in this screen.

### 7 STEREO LINK

This specifies whether parameter settings and compressor operation by a key-in signal will be linked (STEREO LINK button on) for adjacent odd-numbered/even-numbered MIX/MATRIX channels or the L/R channels of the STEREO A/B channels, or not (STEREO LINK button off).

Information shown in the display

Function menu


Global functions

Output functions


Input functions

Appendices

❑ Key-in signal flow when Link= On



❑ Key-in signal flow when Link= Off



**Note**

*Stereo Link is fixed at On for paired channels and for STEREO A/B channels.*

⑧ **Compressor graph**

This graph displays the approximate response of the compressor.

⑨ **KEY IN SOURCE**

Select the desired key-in signal from the following choices.

<b>SELF PRE EQ</b>	The pre-EQ signal of the currently selected output channel
<b>SELF POST EQ</b>	The post-EQ signal of the currently selected output channel
<b>MIX1-24 POST EQ</b>	The post-EQ signal of the corresponding output channel (however, you can only select from the group to which that channel belongs, from the three groups MIX 1-12, MIX 13-24, and MATRIX/ST)
<b>MATRIX1-8 POST EQ</b>	
<b>ST AL/AR POST EQ</b>	
<b>ST BL/BR POST EQ</b>	
<b>MIX21-24 OUT</b>	The output signal of the corresponding MIX channel immediately before the output port attenuation



⑩ **THRESHOLD (Threshold level)**

Specifies the threshold level at which the compressor will operate. The input signal will start being compressed when the key-in signal exceeds this level; compression will be removed when the signal falls below this level.

⑪ **RATIO**

Specifies the ratio at which the input signal will be compressed when the key-in signal exceeds the threshold level.

⑫ **ATTACK (Attack time)**

Specifies the time from when the key-in signal exceeds the threshold level until compression begins.

⑬ **RELEASE (Release time)**

Specifies the time from when the key-in signal falls below the threshold level until compression is removed.

⑭ **GAIN**

Specifies the output level gain.


⑮ **KNEE**

Select the sharpness at which the output level changes; the range is HARD or 1-5. HARD produces the sharpest change, and 5 produces the most gradual change.

## MIX 1-24 screen

## MATRIX/STEREO screen

These screens show the compressor settings for all output channels. Here you can also copy compressor settings between output channels.



## MATRIX/STEREO




### ① Compressor graph

This mini-graph shows the approximate compressor response for each output channel.

When you click the graph at which the cursor is currently located, the COMP PARAM screen for that channel will appear.

In this screen you can drag and drop the mini-graph from the desired channel to copy its compressor settings. (When you drag and drop the mini-graph, a popup window will ask you to confirm the copy operation.)



You can also copy compressor settings between the MIX 1-24 screen and the MATRIX/STEREO screen. First drag the mini-graph over the MIX 1-24 tab or MATRIX/STEREO tab in the screen (the screen will switch). Then drag and drop the mini-graph onto the desired channel, and a message will ask you to confirm the copy operation.



### ② Level meters

These meters show the amount of gain reduction produced by the compressor (at left), and the peak level of the signal after passing through the compressor (at right). If the signal clips, the OVER segment will light.

### ③ COMP ON/OFF (Compressor on/off)




Turns the compressor on/off for that channel.

### ④ Channel

This is the number of the channel you are editing. Two paired channels are indicated by a heart symbol displayed between them.

## COMP LIBRARY (Compressor library) screen

Here you can recall, store, rename, or delete items in the compressor library. The contents of this screen are in common with the COMP LIBRARY screen of the INPUT GATE/COMP function.



- ① **EDIT**  
When you click this button, the COMP PARAM screen for the currently selected channel will appear.
- ② **Channel selection**  
Select the channel that you want to edit.
- ③ **Compressor graph of the selected channel**  
This graph shows the approximate response of the compressor for the currently selected channel.
- ④ **Level meters**  
These meters show the amount of gain reduction (GR), and the peak levels before the compressor (PRE) and after the compressor (POST). If the signal clips, the OVER segment will light.

- ⑤ **RECALL**  
Recalls the compressor library item selected in the list into memory.
- ⑥ **STORE**  
Stores the compressor settings of the currently selected channel into the location selected in the list. When you click this button a window will appear, allowing you to name and save the settings.
- ⑦ **TITLE EDIT**  
Edits the title of the library item selected in the list. When you click this button a window will appear, allowing you to edit the title.
- ⑧ **CLEAR**  
Deletes the library item selected in the list. When you click this button, a confirmation message will appear.

**Note**

*Library items with an "R" displayed in the right column of the list are read-only. Read-only items cannot be stored, renamed, or deleted.*

- ⑨ **Compressor graph of the library item**  
This graph indicates the approximate response of the compressor library item selected in the list.
- ⑩ **Library list**  
Use the scroll bar to select the library item on which you want to perform an operation. The selected library item will move to the center, and will be highlighted.

# OUTPUT DELAY function

## MIX 1-24 screen


## MATRIX/STEREO screen

Here you can edit the delay parameters of the selected output channel.

MIX1-24



MATRIX/STEREO



### 1 DELAY SCALE

The unit you select here is used to indicate the delay time in the box below the delay time knob (3) and in other screens. You can choose one of the following units.

- **METER**  
The distance in meters, calculated as the speed of sound at an air temperature of 20°C (343.59 m/s) x the delay time (seconds).
- **FEET**  
The distance in feet, calculated as the speed of sound at an air temperature of 20°C (68°F) (1127.26 feet/s) x the delay time (seconds).

- **SAMPLE**  
The delay time is shown as a number of samples. If you change the sampling frequency at which the PM5D operates, the number of samples will change accordingly.
- **msec (milliseconds)**  
The delay time is shown in units of milliseconds. If this button is on, the boxes above and below the delay time knob (3) will show the same values.
- **BEAT**  
The delay time is shown in units relative to the note length (considered as 1.0) specified by the tempo (BPM) and note value (NOTE).  
To specify the tempo, you can either use the  $\uparrow$  /  $\downarrow$  buttons located immediately below the BEAT button, or repeatedly tap (click) the TAP button, or repeatedly click a User Defined key that is assigned to [TAP TEMPO]-[CURRENT PAGE].
- **FRAME**  
The delay time is shown in units of frames.  
Use the six buttons located below the FRAME button to select the number of frames per second.

### Hint

- If you change the DELAY SCALE setting of the OUTPUT DELAY function screen, the DELAY SCALE setting of the INPUT DELAY function screen will change in tandem.
- The TAP button of the OUTPUT DELAY function is independent from the TAP TEMPO button of the internal effect.
- The number of frames per second is linked with the TIME CODE SETUP field in the EVENT LIST screen (SCENE function).



### 2 GANG

This button specifies whether the delay parameters will be linked for adjacent odd-numbered/even-numbered channels. This can be specified independently of pairing. If the GANG button is turned on for channels of differing delay times, turning the delay time knob (3) will change the delay times of both channels while maintaining the difference in their delay time.

### 3 Delay time knob

This knob sets the delay time of each channel. The box below the knob shows the delay time in the units you selected in (1). The box above the knob always shows the delay time in millisecond units.

### 4 DELAY ON/OFF

This button switches delay on/off. This is linked for paired channels.

### 5 Channel


This is the number of the channel you are editing. Two paired channels are indicated by a heart symbol displayed between them. You can click this symbol to enable/disable pairing.

# OUTPUT DCA/GROUP function

## DCA GROUP ASSIGN screen

Here you can specify the output channels that will be assigned to DCA groups 7/8. You can use DCA faders 7/8 to uniformly adjust the levels of output channels belonging to the same DCA group.


### DCA GROUP ASSIGN



- ① **DCA group**  
This is the number of the DCA group. The number corresponding to the grid where the cursor is located is highlighted.
- ② **Name**  
This is the name of the DCA group. You can also click this area to edit the name.
- ③ **Grid**  
This grid lets you assign output channels (horizontal rows) to DCA groups (vertical columns). Currently-patched grids are indicated by a symbol. Move the cursor to the desired grid and press the [ENTER] key (or click) to set/disable the assignment.

### Hint

- You can also assign an output channel to both DCA groups for multiple DCA control.
- DCA groups 1–6 are for input channels only, but DCA groups 7/8 can be used with both input channels and output channels. DCA groups 7/8 allow you to use both types of channel in the identically-numbered group.



- ④ **SET BY CUE (Assign by [CUE] key)**  
This specifies whether the [CUE] key will be used to make/cancel DCA group assignments. While the DCA group SET BY CUE button is on, pressing the [CUE] key of a channel that can be assigned to the corresponding group will assign the channel to the group. (Press the [CUE] key once again to cancel the assignment.)

### Hint

- The SET BY CUE button can be turned on for only one DCA group. This is automatically turned off when you change screens or turn off the power.
- To turn on SET BY CUE from the panel, press the ASSIGN MODE [DCA] key and then turn on the DCA group 7/8 [CUE] key.



- ⑤ **CLEAR**  
This button clears all output channels assigned to that DCA group.



- ⑥ **MUTE**  
These buttons switch muting on/off for DCA groups 7/8. They are linked with DCA [MUTE] keys 7/8 in the DCA strip of the panel.
- ⑦ **DCA faders**  
These faders adjust the levels of DCA groups 7/8. They are linked with DCA faders 7/8 in the DCA strip.
- ⑧ **CUE**  
These buttons cue-monitor DCA groups 7/8. They are linked with DCA [CUE] keys 7/8 in the DCA strip of the panel.
- ⑨ **DCA LEVEL SET**  
Use the following two buttons to operate DCA groups 7/8 together.
  - **ALL NOMINAL**  
Clicking this button will move DCA faders 7/8 to nominal level (0 dB).
  - **ALL MINIMUM**  
Clicking this button will move DCA faders 7/8 to the  $-\infty$  dB position.

## MUTE GROUP ASSIGN screen

Here you can specify the output channels that will be assigned to mute groups 1–8. Muting can be switched on/off together for channels assigned to the same mute group.



### ① Mute group

This area shows the mute group number. The number corresponding to the grid where the cursor is located is highlighted.

### ② MUTE (Mute master)

These buttons switch muting on/off for each mute group. These buttons are linked with the SCENE MEMORY [1]–[8] keys of the panel (if the MUTE MASTER button is On in the constantly-shown area at the bottom of the display).

#### Hint

When you turn muting on, channels belonging to that mute group will behave just as though their panel [ON] key had been turned off; no signal will be output. During this time, the panel [ON] key LED will blink.

### ③ Grid

This grid lets you assign output channels (horizontal rows) to mute groups (vertical columns). Currently-patched grids are indicated by a ● symbol. Move the cursor to the desired grid and press the [ENTER] key (or click) to set/cancel the assignment.

### ④ MUTE SAFE


These buttons temporarily defeat the muted state of a channel. When a button is displayed as “–”, clicking it will change its display to “ON,” and the corresponding output channel will be excluded from mute groups. Clicking the button once again restores the original state.

#### Note

Normally, Mute Safe operations can be performed independently of the scene memory.

#### Hint

Mute groups 1–8 can be used with both input channels and output channels. Both types of channel can exist in the identically-numbered mute group.



### ⑤ SET BY CUE (Assign by [CUE] key)

This specifies whether the [CUE] key will be used to make/cancel mute group assignments. While the mute group SET BY CUE button is on, pressing the [CUE] key of a channel that can be assigned to the corresponding group will assign the channel to the group. (Press the [CUE] key once again to cancel the assignment.)

#### Hint

The SET BY CUE button can be turned on for only one mute group. This is automatically turned off when you change screens or turn off the power.

### ⑥ CLEAR


This button clears all output channels assigned to that mute group.

### ⑦ DIRECT RECALL/MUTE MASTER

This is the same function as the DIRECT RECALL/MUTE MASTER buttons located at the bottom of the display (➔ p.151).

## EQ LINK ASSIGN screen

Here you can specify the output channels that will be assigned to EQ link groups A–H. EQ parameters are linked for channels belonging to the same group.



### ③ SET BY CUE (Assign by [CUE] key)


This specifies whether the [CUE] key will be used to make/cancel EQ link group assignments. While the EQ link group SET BY CUE button is on, pressing the [CUE] key of a channel that can be assigned to the corresponding group will assign the channel to the group. (Press the [CUE] key once again to cancel the assignment.)

#### Hint

The SET BY CUE button can be turned on for only one EQ link group. This is automatically turned off when you change screens or turn off the power.

### ④ CLEAR

This button clears all output channels assigned to that EQ link group.



### ① EQ link group

These are the EQ link group numbers. The number corresponding to the grid where the cursor is located is highlighted.

### ② Grid



This grid lets you assign output channels (horizontal rows) to EQ link groups (vertical columns). Currently-patched grids are indicated by a ● symbol. Move the cursor to the desired grid and press the [ENTER] key (or click) to set/cancel the assignment.

#### Hint

- The MIX channels and STEREO A/B channels can be assigned only to EQ link groups A–F, and MATRIX channels can be assigned only to EQ link groups G/H.
- Grey areas in the grid indicate combinations that cannot be assigned.
- Input channels and output channels use separate EQ link groups. Output channels use groups A–H, and input channels use groups 1–8.

## COMP LINK ASSIGN (Compressor link assign) screen

Here you can specify the output channels that will be assigned to compressor link groups A–H. Compressor parameters are linked for channels belonging to the same group.



### ① Compressor link group


This area shows the compressor link group number. The number corresponding to the grid where the cursor is located is highlighted.

### ② Grid

This grid lets you assign output channels (horizontal rows) to compressor link groups (vertical columns). Currently-patched grids are indicated by a ● symbol. Move the cursor to the desired grid and press the [ENTER] key (or click) to set/cancel the assignment.

#### Hint

Input channels and output channels use separate compressor link groups. Output channels use groups A–H, and input channels use groups 1–8.



### ③ SET BY CUE (Assign by [CUE] key)

This specifies whether the [CUE] key will be used to make/cancel compressor link group assignments. While the compressor link group SET BY CUE button is on, pressing the [CUE] key of a channel that can be assigned to the corresponding group will assign the channel to the group. (Press the [CUE] key once again to cancel the assignment.)

#### Hint

The SET BY CUE button can be turned on for only one compressor link group. This is automatically turned off when you change screens or turn off the power.

### ④ CLEAR

This button clears all output channels assigned to that compressor link group.

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

# MATRIX/ST function

## MATRIX/ST ROUTING screen

Here you can send the signal from MIX channels and STEREO A/B channels to the STEREO bus or the desired MATRIX bus.

### MATRIX/ST ROUTING





MIX channel  
STEREO A/B channel

□ If the MATRIX channels are used individually

### LEVEL knobs

Adjust the send level of the signals sent from the MIX channels and STEREO A/B channels to each MATRIX bus.



① **MATRIX bus**

This is the number of the MATRIX bus to which the signal is sent. Paired MATRIX channels are indicated by a heart symbol displayed between them. You can click this symbol to enable/disable pairing.

② **Send level**

These knobs specify the send level of each signal that is sent from the MIX channel or STEREO A/B channel (vertical column) to the MATRIX buses (horizontal row).

The knobs shown in this area will depend on how the MATRIX channels are paired.



❑ If the MATRIX channels are paired

**PAN knobs**

Adjust the panning of the signals sent from the MIX channels and STEREO A/B channels to each pair of adjacent odd-numbered/ even-numbered MATRIX buses.

**LEVEL knobs**

Adjust the send level of the signals sent from the MIX channels and STEREO A/B channels to each MATRIX bus.



③ **MIX TO MATRIX ON/OFF**

This button is an on/off switch for the signal sent from each MIX channel or STEREO A/B channel to the MATRIX buses. If this button is off, no signal will be sent from that channel to the MATRIX buses.

④ **PRE FADER/POST FADER/POST ON**

These buttons select the position from which the signal is sent from the MIX channel or STEREO A/B channel to the MATRIX buses, from the following choices.

<b>PRE FADER</b>	Immediately before the fader
<b>POST FADER</b>	Immediately after the fader
<b>POST ON</b>	Immediately after the MIX [ON] key / STEREO [ON] key

This parameter applies to the signal sent from the corresponding channel to all MATRIX buses.

⑤ **MIX TO STEREO ON/OFF**

This button is an on/off switch for the signal sent from each MIX channel to the STEREO bus. If this button is off, no signal will be sent from that channel to the STEREO bus.

⑥ **PRE/POST (Pre-on/Post-on)**

This button selects the position from which the signal is sent from the MIX channel to the STEREO bus, from the following choices.

<b>PRE</b>	Immediately before the MIX [ON] key (immediately after the fader)
<b>POST</b>	Immediately after the MIX [ON] key

⑦ **PAN (MIX → STEREO pan)**

This knob specifies the panning of the signal sent from the MIX channel to the STEREO bus. If a MIX channel is selected in the SELECTED CHANNEL section, the STEREO [PAN] encoder is linked with this knob.

**Hint**

If the source is a STEREO A/B channel, parameters ⑤–⑦ are not displayed.

⑧ **MIX channel, STEREO A/B channel**

This area indicates the MIX channel or STEREO A/B channel from which the signal is being sent. Paired MIX channels are indicated by a heart symbol displayed between them. You can click this symbol to enable/disable pairing.

## MIX to MATRIX VIEW screen

This screen lists the signals sent from the MIX channels to the MATRIX buses. You can also edit the settings from within this screen.



① **MIX to MTRX/MTRX from MIX**  
Select one of the following two types of screen display.

❑ **When the MIX to MTRX button is on**  
You can view the status of the signals sent from a specific MIX channel or STEREO A/B channel to all MATRIX buses.




❑ **When the MTRX from MIX button is on**  
You can view the status of the signals sent from all MIX channels or STEREO A/B channels to a specific MATRIX bus.



② **SEND LEVEL/SEND POINT**  
Select one of the following two parameters to view in the grid.

❑ **When the SEND LEVEL button is on**  
The send levels sent from the MIX channels or STEREO A/B channels to the MATRIX buses will be shown as a bar graph in each grid. Channels for which the signal sent to the MATRIX bus is turned off are shown by gray bars, and channels for which the signal is turned on are shown by blue bars.



Channels for which the signal sent to the MATRIX bus is turned off (gray bar graph)

Channels for which the signal sent to the MATRIX bus is turned on (blue bar graph)

Pan value (orange line)

To edit the send level, move the cursor to the grid where the MIX or STEREO A/B channel (vertical column) intersects the MATRIX bus (horizontal row), and turn the [DATA] encoder.

To switch the signal sent from a specific MIX or STEREO A/B channel to the MATRIX buses on/off, move the cursor to the vertical column for that channel, and press the [ENTER] key.

### Hint

- If the send level is set above nominal (0 dB), a red line indicating nominal level is displayed.
- If the send-destination MATRIX channel is paired, the grid for the odd-numbered MATRIX bus will show an orange line indicating the pan value instead of a bar graph. (In MTRX from MIX mode, upward indicates R, and downward indicates L.)

If the SEND LEVEL button is on, you can select a desired grid and copy its send level (pan) value to other channels (horizontal direction) or to other MATRIX buses (vertical direction), or switch all grids on/off simultaneously.

To do so, move the cursor to the desired grid; then hold down the [SHIFT] key and press the [ENTER] key. (Alternatively, hold down the [SHIFT] key and click the desired grid.) When the JOB SELECT win-

down appears, select one of the following choices to copy, and click the OK button.



**LEVEL COPY [ALL MATRIX ↑↓]**

Copy the send level (pan) value of the selected grid to all send level (pan) settings of the corresponding MIX (or STEREO A/B) channel in the vertical direction of the grid.

**Note**

*If the selected grid is a send level, only the send levels will be copied. If the selected grid is a pan value, only the pan values will be copied.*

**LEVEL COPY [ALL MIX ↔]**

Copy the send level (pan) value of the selected grid to all send level (pan) settings of the corresponding MATRIX bus in the horizontal direction of the grid.

**LEVEL COPY [ALL MIX x ALL MATRIX]**

Copy the send level (pan) value of the selected grid to the send level (pan) settings of all MIX (and STEREO A/B) channels and MATRIX buses.

**ALL ON [ALL MIX ↔]**

Turn on the signals sent from all channels (MIX, STEREO A/B) to the corresponding MATRIX bus.

**ALL OFF [ALL MIX ↔]**

Turn off the signals sent from all channels (MIX, STEREO A/B) to the corresponding MATRIX bus.

**When the SEND POINT button is on**

The grid will show the position from which the signal is sent from the MIX channels or STEREO A/B channels to the MATRIX buses.

	MIX 1	MIX 2	MIX 3
MTRX 1	PRE	POST	POST
MTRX 2	PRE	POST	POST
MTRX 3	PRE	POST	POST
MTRX 4	PRE	POST	POST

PRE FADER      POST FADER      POST ON

Each indication has the following significance.

- PRE** (yellow) . . . PRE FADER (immediately before the fader)
- POST** (gray) . . . . POST FADER (immediately after the fader)
- POST** (red) . . . . POST ON (immediately after the [ON] key)

To change the position from which the signal is sent, move the cursor to the vertical column for the desired channel, and press the [ENTER] key, click, or turn the [DATA] encoder. (The position of all signals sent from that channel to all MATRIX buses will change simultaneously.)

If the SEND POINT button is on, the send position for all grid locations can be changed simultaneously. To do so, hold down the [SHIFT] key and click the desired grid. (Alternatively, move the cursor to the desired grid; then hold down the [SHIFT] key and press the [ENTER] key.) When the JOB SELECT window appears, select one of the following choices, and click the OK button.



**ALL PRE FADER [ALL MIX ↔]**

All grids will be set to PRE FADER.

**ALL POST FADER [ALL MIX ↔]**

All grids will be set to POST FADER.

**ALL POST ON [ALL MIX ↔]**


All grids will be set to POST ON.

③

	MIX 1	MIX 2	MIX 3	MIX 4	MIX 5	MIX 6	MIX 7	MIX 8
MTRX 1	POST	PRE	POST	POST	PRE	PRE	POST	POST
MTRX 2	POST	PRE	POST	POST	PRE	PRE	POST	POST
MTRX 3	POST	PRE	POST	POST	PRE	PRE	POST	POST
MTRX 4	POST	PRE	POST	POST	PRE	PRE	POST	POST
MTRX 5	POST	PRE	POST	POST	PRE	PRE	POST	POST
MTRX 6	POST	PRE	POST	POST	PRE	PRE	POST	POST
MTRX 7	POST	PRE	POST	POST	PRE	PRE	POST	POST
MTRX 8	POST	PRE	POST	POST	PRE	PRE	POST	POST

**③ Grid**

The grid shows various settings for the signals sent from the MIX or STEREO A/B channels (vertical columns) to the MATRIX buses (horizontal rows). The red lines shown in the upward, downward, left, and right directions indicate the channel (MIX or STEREO A/B) and MATRIX bus corresponding to the grid where the cursor is located.



④ **SELECTED PARAMETER (currently selected parameter)**

This area indicates the channel (MIX or STEREO A/B) and MATRIX bus corresponding to the grid where the cursor is currently located. The four boxes at right indicate the values for the grid where the cursor is currently located.

**LCR screen**

Here you can make settings for LCR mode, which allows three-channel playback by adding a CENTER channel to the L/R channels of the STEREO bus. This function can be used only with MIX channels.




① **Response graph**

These graphs indicate the approximate LCR response for each MIX channel. The graph will change as the CSR knob (②) is edited.

② **CSR (Center Side Ratio)**


This knob adjusts the proportional level of the CENTER channel relative to the L/R channels. The range is 0–100%.

If the CSR knob is set to 0%, turning the PAN knob in the MIX TO STEREO area of the MATRIX/ST ROUTING screen (or the [PAN] encoder in the SELECTED CHANNEL section) will change the signal levels of the L/R channels as shown below.



In this case, MIX TO STEREO PAN will operate as a conventional PAN control, and no signal will be sent to the CENTER channel.

If CSR is set to 100%, turning the PAN knob ([PAN] encoder) will change the signal levels of the L/R channels as shown below.



When the PAN knob ([PAN] encoder) is in the center position, the signal level of the CENTER channel will be at maximum, and no signal will be sent to the L/R channels.


### ③ LCR (LCR mode on/off)

For each MIX channel, this turns LCR mode on/off.


For channels where LCR mode is turned on, the PAN knob in the MIX TO STEREO area of the MATRIX/ST ROUTING screen can be used to simultaneously control the levels of the L/R channels and the CENTER channel.

If you have selected a MIX channel for which LCR is on, you can also use the [PAN] encoder in the SELECTED CHANNEL section of the top panel. In this case, the peripheral LEDs will change as follows when you operate the [PAN] encoder.

- When LCR = off



- When LCR = on



#### Note

In order to use the LCR function, the USE AS CENTER BUS button must be turned On in the MIXER SETUP screen (SYS/W.CLOCK function) (► p.201). Be aware that when this button is on, the CENTER channel signal is not sent to the STEREO B bus, and will not play back appropriately. (In this case, the STEREO B bus is sent the same signal as the STEREO A bus.)

### ④ MIX channel

This is the number of the MIX channel you are editing. Paired MIX channels are indicated by a heart symbol displayed at the right. You can click this symbol to enable/disable pairing. The values of parameters ②-③ are linked for paired channels.

#### Hint

- The master level of the CENTER channel is controlled by the STEREO B channel fader. You can also use the STEREO B channel EQ and compressor to process the signal.
- Use either one of the output jacks patched to the STEREO B channel as the output jack for the CENTER channel. (When the USE AS CENTER BUS button is On in the MIXER SETUP screen, the L/R channels of the STEREO B bus output the same signal.)
- By selecting LCR as the monitor source, you can monitor the LCR signal from the MONITOR OUT jacks L/C/R.

## SURR SETUP screen

Here you can make various settings related to surround functionality, such as selecting the surround mode, and assigning MIX buses to surround channels.





① **SURROUND MODE**  
Choose one of the following as the surround mode when using the Surround Pan function (p.132). This is the same as the SURROUND MODE in the MIXER SETUP screen (SYS/W.CLOCK function). The graphic below the buttons will change according to the mode you select.

- **STEREO**  
This is conventional stereo mode.
- **3-1ch**  
This mode uses four channels: L (front left), C (front center), R (front right), and S (surround).
- **5.1ch**  
This mode uses six channels: L (front left), C (front center), R (front right), Ls (rear left), Rs (rear right), and LFE (subwoofer).
- **6.1ch**  
This mode uses seven channels: 5.1ch with the addition of Bs (rear center).

**Hint**

*If 3-1ch, 5.1ch, or 6.1ch is selected as the surround mode, MIX buses 1-8 or 9-16 are used as surround buses, starting with the earlier-numbered buses. (Buses not used as surround buses can be used as conventional buses.) These MIX buses cannot be used as conventional bus outputs until you return to stereo mode.*



② **Bus assignments**

This area indicates the surround channels assigned to the MIX buses that are being used as surround buses. You can edit these settings by clicking the [L] / [R] buttons at the left and right.

When you change the surround channel assignment, the MIX bus whose channel assignment you changed will be exchanged with the MIX bus that had been previously assigned to that channel.

**Note**


*The MIX buses used are fixed for each surround mode. For surround mode 3-1, MIX buses 1-4 or 9-13 can be used. For surround mode 5.1, MIX buses 1-6 or 9-14 can be used. For surround mode 6.1, MIX buses 1-7 or 9-15 can be used. Other MIX buses can be used as conventional MIX buses. However in the case of 6.1, MIX bus 8 or MIX bus 16 are always handled as FIXED buses.*

③ **INIT (Initialize)**

For each surround mode, this restores the surround channel assignments to the MIX buses to their initial state.

④ **SURROUND BUS ALLOCATION**

Select either MIX buses 1-8 or 9-16 as the range of MIX buses used as surround buses.




- ⑤ **DELAY**  
This specifies the delay time for each surround channel in a range of 0–1000 msec. The current value is shown by the two boxes below the knob. (The upper box shows the delay time in millisecond units, and the lower box shows the delay time in the units selected in the MIX 1-24 screen of the OUT DELAY function.)
- ⑥ **DELAY ON/OFF**  
Turns the delay on/off for each surround channel.
- ⑦ **FADER (Fader level)**  
Adjusts the level of the signal sent from the surround channel to the corresponding MIX bus in a range of  $-\infty$  to +10 dB. The current value is shown in the box below.
- ⑧ **CUE**  
This button lets you cue-monitor the surround channel. This is linked with the [CUE] key of the corresponding MIX channel.
- ⑨ **ON/OFF (Channel on/off)**  
Turns the surround channel on/off. This is linked with the MIX [ON] key of the corresponding MIX channel.
- ⑩ **Level meter**  
Indicates the output level of the surround channel.
- ⑪ **Surround channel**  
This is the name of the surround channel.

## OUTPUT VIEW function

### CH VIEW (Channel view) screen

This screen displays the mix parameters of the currently selected MIX channel, MATRIX channel, or STEREO A/B channel. In this screen you can also edit the principal parameters and access other screens.

#### CH VIEW



- ① **Channel**  
This is the number of the channel you are editing. If the corresponding MIX/MATRIX channel is paired (or if a STEREO A/B channel is selected), a heart symbol is displayed at the right. You can click this symbol to enable/disable pairing for the MIX/MATRIX channel.  
**Note**  
*The screen shown above is for when a paired channel is selected. If the selected channel is not paired, the parameters for only one channel are displayed, and pairing-related settings are not displayed.*
- ② **EQ**  
This area shows the post-EQ level, the approximate EQ response, and the EQ on/off status. You can click the EQ ON/OFF button to switch EQ on/off in this screen.


If you click the mini-graph, the EQ PARAM screen for that channel will appear.

③ **Compressor**

This area shows the amount of gain reduction and the output level of the compressor, a mini-graph showing the approximate response of the compressor, and the compressor on/off status. You can click the COMP ON/OFF button to switch the compressor on/off in this screen. If you click the mini-graph, the COMP PARAM screen for that channel will appear.

④ **Insert in**

This area indicates the insert point, the insert on/off status, and the type and input level of the port that is patched to insert-in. You can click the INSERT ON/OFF button to switch insertion on/off in this screen. If an internal effect is patched, the effect type and BYPASS button are displayed. If a GEQ module is patched, the GEQ ON/OFF button and a mini-graph showing the GEQ response are displayed.



⑤ **DELAY**

In this area you can view and edit the delay time of the internal delay and its on/off status.


⑥ **TO MATRIX (only for MIX channels and STEREO A/B channels)**

This area shows the send level, send position, and on/off status of the signals sent from the corresponding MIX channel or STEREO A/B channel to MATRIX buses 1–8. You can also edit the send level, send position, and on/off status in this screen. Here’s how to do this.

- **To edit the send level of signals sent to the MATRIX bus**  
Move the cursor to the desired bar graph in the list, and turn the [DATA] encoder.
- **To edit the send position of signals sent to the MATRIX bus**  
Click either the PRE FADER, the POST FADER, or the POST ON button located below.  
Alternatively, you can edit the setting by moving the cursor to the PRE or POST indication in the list and pressing the [ENTER] key or turning the [DATA] encoder.

- **To switch the signal sent to the MATRIX bus on/off**  
Click the ON/OFF button located below.

You can also switch this on/off by moving the cursor to a bar graph in the list and pressing the [ENTER] key. The bar graph is colored blue when on, and gray when off.



⑦ **DCA group / Mute group**

Here you can assign or cancel DCA group and MUTE group assignments.

⑧ **RECALL SAFE / MUTE SAFE**

Here you can enable or disable Recall Safe and Mute Safe settings.

⑨ **TO STEREO (MIX channels only)**

Here you can switch the signal sent from a MIX channel to the STEREO bus on/off, and edit its panning and send position (pre-on / post-on) (➔ p.239).

⑩ **BALANCE (only for paired MIX/MATRIX channels and STEREO A/B channels)**

This adjusts the left/right volume balance of the signals output from paired MIX channels or STEREO A/B channels.

⑪ **LCR (MIX channels only)**

Here you can switch LCR mode on/off, and adjust CSR (the level of the CENTER channel relative to the L/R channels) (➔ p.242).

⑫ **LIBRARY**

This button accesses the OUTPUT CH LIBRARY screen (➔ p.251), where you can store/recall library settings for output channels.

⑬ **Level meter**

This level meter indicates the output level of the channel.


⑭ **Signal detection point**

This is the point at which the signal level shown in the level meter (⑬) is detected (PRE EQ, PRE FADER, POST FADER, POST DELAY, or POST ON). You can edit this setting by clicking the [ ] / [ ] buttons at the left and right.

- ⑮ **Fader**  
This controls the output level of the channel.
- ⑯ **CUE**  
This button cue-monitors the signal of the channel. This is linked with the [CUE] key of the corresponding channel.
- ⑰ **ON/OFF (Channel on/off)**  
This is an on/off switch for the signal that is output from the channel. This is linked with the [ON] key of that channel.

## SIGNAL FLOW screen

This screen shows the signal flow for adjacent odd-numbered/even-numbered MIX/MATRIX channels or for STEREO A/B channels. In this screen you can also edit some of the parameters, and access other screens. You can also determine the location within the signal flow at which clipping occurred.



- ① **Channels**  
These are the numbers of the channels you are editing. By clicking the [ ] / [ ] buttons at left and right, you can switch the display in units of two channels. If the corresponding MIX/MATRIX channels are paired (or if a STEREO A/B channel is selected), a heart symbol is displayed at the right. You can click this symbol to enable/disable pairing for the MIX/MATRIX channels.
- ② **Insert**  
This area displays insert-related information for the two selected channels (insert point, the ports patched to insert in/out, and insert on/off status). Here you can also select the insert point (use the [ ] / [ ] buttons at left and right), or switch insertion on/off (use the ON/OFF button).

Information shown in the display


Function menu

Global functions

Output functions

Input functions

Appendices



③ Level meters

These meters indicate the levels within the signal flow. Levels are detected at the following locations.

- EQ (immediately before and after the EQ)
- COMP (immediately before and after the compressor)
- FADER (immediately before and after the fader)
- DELAY (immediately before and after the delay)
- INSERT IN (immediately after the insert point)



④ Signal flow

This area indicates the signal flow of the selected channel. The following parameters are displayed.

- **EQ (Equalizer)**  
This indicates the EQ on/off status and the approximate response curve. You can click the EQ button to switch EQ on/off, or click the mini-graph to access the EQ PARAM screen for the corresponding channel.
- **COMP (Compressor)**  
This indicates the compressor on/off status and the approximate response curve. You can click the COMP button to switch the compressor on/off, or click the mini-graph to access the COMP PARAM screen for the corresponding channel.
- **FADER**  
This indicates the output level of the channel. This is linked with the encoder or fader of the corresponding channel.
- **ON/OFF (On/off)**  
Turns the channel on/off. This is linked with the [ON] key of the corresponding channel.
- **DELAY**  
Here you can switch the internal delay on/off and edit the delay time.

**Hint**

- If insert is enabled, the currently selected insert point is shown in this signal flow.
- If the signal clips, the signal flow (horizontal line) after clipping is displayed in red. If an output is turned off so that the signal does not flow any further, the subsequent flow is displayed in gray. If PEAK HOLD is on, the flow indication will stay red if clipping occurs even once, making it easier to see that clipping has occurred.



⑤ TO MATRIX (only for MIX channels and STEREO A/B channels)


This area shows the on/off status of the signal sent from the MIX channel or STEREO A/B channel to the MATRIX buses, and the point from which the signal is sent.

⑥ TO STEREO (MIX channels only)

This area shows the pan, the send position, and the on/off status of the signal sent from the MIX channel to the STEREO bus.

## FADER VIEW screen

This screen shows the on/off status, level, and cue monitor status of the output channels and DCA groups.



### ① ON/OFF (On/off)

Here you can switch output channels on/off, and switch DCA group muting on/off. These settings are linked with the [ON] keys of the corresponding channels and the [MUTE] keys of the DCA groups.

### ② Level


Here you can adjust the level of the output channels and DCA groups. The current value is shown in the box immediately below. These are linked with the encoder or fader of the corresponding channel or DCA group.

### ③ Cue

Here you can switch cue monitoring on/off for output channels and DCA groups. These are linked with the [CUE] key of the corresponding channel or DCA group.

## CH COPY (Channel copy) screen

In this screen you can copy the desired parameter(s) from the selected output channel into a memory buffer, and paste them to the same type of channel (you may select more than one paste-destination).



### ① COPY

When you click this button, the settings of the currently selected channel will be copied to a temporary memory buffer.


If the corresponding MIX/MATRIX channel is paired (or if a STEREO A/B channel is selected), a heart symbol is displayed at the right.

### ② BUFFERED CH (Channel in the buffer)

This shows the channel that is currently copied into buffer memory.

#### Note

- The same buffer memory is used to copy channel settings for both input channels and output channels.
- If input channel settings have been copied to the buffer memory, a message of "TYPE CONFLICT!" is displayed below, and you cannot paste to an output channel.
- The contents of the buffer memory are erased when the PM5D is powered-off.



③ **PASTE**

When you click this button, the specified parameters will be copied from buffer memory to the specified paste-destination channel.

If an input channel is copied to buffer memory, or if no paste-destination has been specified, this is grayed-out and the Paste operation is unavailable.

④ **PARAMETER SELECT**

Here you can select the parameter(s) that will be pasted. You can select the following parameters.

<b>ALL</b>	All parameters
<b>EQ</b>	EQ function settings
<b>COMP</b>	COMP function settings
<b>DELAY</b>	DELAY function settings
<b>FADER</b>	Fader level
<b>ON</b>	CH [ON] key on/off status
<b>BAL</b>	Balance settings
<b>INSERT</b>	Insert on/off status and insert point
<b>TO MTRX</b>	Send level to the desired MATRIX bus(es)
<b>DCA</b>	Associated DCA group
<b>MUTE</b>	Associated mute group
<b>LCR</b>	LCR screen settings
<b>WITHOUT MIX SEND/ WITH MIX SEND</b>	Selects whether the send level sent from input channels to the selected MIX bus will be included (WITH...) or will not be included (WITHOUT...) in the pasted data.

If the TO MTRX button is on, you can use the MATRIX buttons (1–8) to select the applicable MATRIX buses.

⑤ **CH SELECT (Channel selection)**

Here you can select the paste-destination channel(s). You can only select channels of the same type as the copy-source.

**Hint**

*If the copy-source MIX/MATRIX channel is paired, the odd-numbered channel is copied to the odd-numbered channel(s), and the even-numbered channel is copied to the even-numbered channel(s).*

⑥ **SET ALL**


Specifies the paste-destination as all channels of the same type as the copy-source.

⑦ **CLEAR ALL**

De-selects all channels.

## OUTPUT CH LIBRARY screen

Here you can recall, store, rename, or delete items in the output channel library.



### ① EDIT

When you click this button, the CH VIEW screen (OUTPUT CH VIEW screen) for the currently selected output channel will appear.

### ② Channel


This is the number of the channel you will store or recall.

#### Note

- Channel library store/recall operations are performed in units of one channel.
- If the channel selected by the [SEL] key is paired (or if a STEREO A/B channel is selected), the operation will apply to only one of the currently selected channels (in the case of STEREO A/B, only the L or the R channel).
- When you recall a channel library item into one of a pair of MIX/MATRIX channels (or into L or R of the STEREO A/B channel), any linked parameters will be copied to the other channel.

### ③ LIBRARY TYPE (Channel type)

Indicates the type of the currently selected channel. If a MIX or STEREO A/B channel is selected, the pairing configuration of MATRIX buses 1–8 is shown immediately below.



### ④ RECALL

Recalls the channel library item selected in the list into memory.

If the channel selected in (①) is of a different type than the channel selected in the list, this button is grayed-out and the Recall operation is unavailable. (However, Initial Data can be recalled to any output channel.)

### ⑤ STORE

Stores the settings of the currently selected output channel into the location selected in the list. When you click this button a window will appear, allowing you to name and save the settings.

### ⑥ TITLE EDIT

Edits the title of the library item selected in the list. When you click this button a window will appear, allowing you to edit the title.

### ⑦ CLEAR

Deletes the library item selected in the list. When you click this button, a confirmation message will appear.

#### Note

Library items with an "R" displayed in the right column of the list are read-only. Read-only items cannot be stored, renamed, or deleted.

### ⑧ LIBRARY TYPE

Displays the type of channel for the library item selected in the list. If the channel selected in (①) is of a different type than the channel selected in the list, a message of "CONFLICT!" is displayed at the right and the Recall operation is unavailable.

If a MIX or STEREO A/B channel is selected, the pairing configuration of MATRIX buses 1–8 is shown immediately below.

### ⑨ Library list

Use the scroll bar to select the library item on which you want to perform an operation. The selected library item will move to the center, and will be highlighted.

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices



# Input functions

## INPUT PATCH function

### INPUT PATCH screen

Here you can assign input ports (INPUT jacks, ST IN jacks, 2TR IN DIGITAL/ANALOG jacks, input channels of slots, outputs of internal effects) to input channels.

#### INPUT PATCH



- ① **SELECTED PATCH**  
This indicates the name and number of the input channel at which the cursor is located, and the input port.
- ② **CH (Input channel)**  
This is the number and name of the input channel (input channel, ST IN channel, FX RTN channel) assigned to the input port. The channel number at which the cursor is located will be highlighted. If you click the name, a window will open allowing you to assign a name to the channel.
- ③ **ASSIGN**  
For each channel, this indicates the number (1 or 0) of input ports currently assigned.

- ④ **Grid**  
This grid lets you patch input ports (horizontal rows) to input channels (vertical columns). Currently-patched grids are indicated by a ● symbol. By clicking a grid location you can set/cancel patching. The red lines at the left and top indicate the grid location to which you move the cursor.


- Hint**
- If PATCH CONFIRMATION is turned on in the PREFERENCE 1 screen (UTILITY function), a confirmation message will appear each time you attempt to change a patch setting. If STEAL PATCH CONFIRMATION is turned on, a confirmation message will also appear when you attempt to make patch settings that would cause an existing patch to be modified.
  - To move the cursor location rapidly in or out of the grid, hold down the [SHIFT] key and press the CURSOR [◀]/[▶]/[▲]/[▼] keys.
  - To move rapidly to left or right inside the grid, turn the [DATA] encoder. To move up or down, hold down the [SHIFT] key and turn the [DATA] encoder.

**Note**  
You can patch multiple input channels to a single input port, but you cannot patch multiple input ports to a single input channel.

- ⑤ **Input port**  
From the top, this area indicates the type of input port, the ID number, the input channel number, and the number of input channels assigned. The following types of input port can be selected.

<b>AD IN</b>	INPUT jacks 1–48
<b>AD STIN</b>	L/R channels of ST IN jacks 1–4
<b>SLOT IN</b>	Input channels of an I/O card installed in slots 1–4
<b>FX OUT</b>	L/R outputs of internal effects 1–8
<b>2TR IN</b>	L/R channels of 2TR IN DIGITAL jacks 1–3 and 2TR IN ANALOG jacks 1/2

- Hint**
- The port number is grayed-out for ports that are currently unavailable.
  - If the CASCADE connector is being used as a SLOT IN port, the port number of the CASCADE connector is displayed in yellow instead of the SLOT IN port number.



### ⑥ PRESET

This button resets the input port → input channel assignments to the following default settings.

Channel	Input port
Input channels 1–48	AD IN 1–48
ST IN channels 1–4 L/R	AD STIN L/R
FX RTN channels 1–4 L/R	FX OUT 1–4 L/R

### ⑦ CLEAR ALL

This button clears all assignments of input ports to input channels.



### ⑧ LIBRARY

This button accesses the INPUT PATCH LIBRARY screen (→ p.257), where you can store/recall input channel patch library settings.

## DIRECT OUT PATCH screen

Here you can patch an input channel to an output port so that the input signal will be output directly from that port.

### DIRECT OUT PATCH



### ① SELECTED PATCH

This indicates the name and number of the input channel at which the cursor is located, and the output port.

### ② CH (Input channel)

This is the number and name of the input channel (input channel, ST IN channel) for assignment to an output port. The channel number at which the cursor is located will be highlighted. If you click the name, a window will open allowing you to assign a name to the channel.

### ③ ASSIGN

For each channel, this indicates the number of output ports that are currently assigned.

### ④ Grid

This grid lets you patch input channels (vertical columns) to output ports (horizontal rows). Currently-patched grids are indicated by a ● symbol. By clicking a grid location you can set/cancel patching.

The red lines at the left and top indicate the grid location to which you move the cursor.

### Hint

Operations in the grid are the same for all of the patching screens. For details, refer to the Hint on p.252.

⑤ Output port

From the top, this area indicates the type of output port, the ID number, the output channel number, and the number of input channels assigned. The following types of output port can be selected.

<b>SLOT OUT</b>	Output channels of an I/O card installed in slots 1-4
<b>2TR OUT</b>	L/R channels of 2TR OUT DIGITAL jacks 1-3

**Hint**

- The port number is grayed-out for ports that are currently unavailable.
- For **SLOT OUT** ports that are also being output to the **CASCADE** connector, the port number of the **CASCADE** connector is displayed in yellow instead of the **SLOT OUT** port number.



⑥ LIBRARY button



This button accesses the INPUT PATCH LIBRARY screen (➔ p.257), where you can store/recall input channel patch library settings.

**Note**

To enable direct output from the selected port, you will need to make settings in the INSERT/DIRECT OUT POINT screen (INPUT PATCH function) to turn on direct output for the corresponding input channel (➔ p.256).

**INSERT PATCH screen**

In this screen you can patch the input/output ports by which external devices will be inserted into each input channel. Select the output port in the left side of the screen, and the input port in the right side of the screen.




① SELECTED PATCH

This indicates the number and name of the input channel at which the cursor is located in the grid.

② Insert in/out

This indicates the input/output ports that are patched as insert in/out for the input channel at which the cursor is located.



③ CH (Input channel)

This area shows the number and name of each input channel (input channel, ST IN channel L/R). The channel number at which the cursor is located will be highlighted. If you click the name, a window will open allowing you to assign a name to the channel.

④ ASSIGN

For each input channel, this indicates the number of output ports that are currently assigned as insert-out.

⑤ **Grid**

For each input channel (vertical column), this grid lets you can patch one or more output ports (horizontal row) to be used as insert-outs. Currently-patched grids are indicated by a  symbol.

By clicking a grid location you can set/cancel patching. The red lines at the left and top indicate the grid location to which you move the cursor.

**Hint**

*Operations in the grid are the same for all of the patching screens. For details, refer to the Hint on p.252.*


⑥ **Output port**

From the top, this area indicates the type of output port, the ID number, the output channel number, and the number of input channels assigned. The following types of output port can be patched as insert-out.

<b>SLOT OUT</b>	Output channels of an I/O card installed in slots 1–4
<b>FX IN</b>	L/R inputs of internal effects 1–8
<b>GEQ IN</b>	Inputs of GEQ modules 1–12
<b>2TR OUT</b>	L/R channels of 2TR OUT DIGITAL jacks 1–3

**Hint**


- The port number is grayed-out for ports that are currently unavailable.
- For **SLOT OUT** ports that are also being output to the **CASCADE** connector, the port number of the **CASCADE** connector is displayed in yellow instead of the **SLOT OUT** port number.
- If you select **GEQ IN** as an insert-out, the output of the same **GEQ** module will automatically be selected as the insert-in.



⑦ **Input port**

From the top, this area indicates the type of input port, the ID number, L/R, the input channel number, and the total number of input channels (including insert-in) that are patched to each input port. You can select the following input ports.

<b>AD IN</b>	INPUT jacks 1–48
<b>AD ST IN</b>	ST IN jacks 1–4 L/R
<b>SLOT IN</b>	Input channels of an I/O card installed in slots 1–4
<b>FX OUT</b>	L/R outputs of internal effects 1–8
<b>GEQ OUT</b>	Outputs of GEQ modules 1–12
<b>2TR IN</b>	L/R channels of 2TR IN DIGITAL jacks 1–3 or 2TR IN ANALOG jacks 1/2



⑧ **LIBRARY button**

This button accesses the INPUT PATCH LIBRARY screen (➔ p.257), where you can store/recall input channel patch library settings.

**Note**

*To enable the insert ins/outs that you assigned to input channels in this screen, you need to turn Insert on for the corresponding input channel in the INSERT/DIRECT OUT POINT screen (INPUT PATCH function) (➔ p.256). However, insertion is automatically enabled if you assigned insert in/out to a GEQ.*


**Hint**

*When operating from the panel, you can move the cursor from the right side of the screen to the left side (or vice versa) by holding down the [SHIFT] key and using the CURSOR [◀]/[▶] keys.*

## INSERT/DIRECT OUT POINT screen


For each input channel, you can specify the point at which insert in/out will be patched, and the point from which direct output will be taken. Here you can also switch Insert or Direct Output on/off.

### INSERT/DIRECT OUT POINT



#### 1 Insert view

When you move the cursor to an insert I/O point (4), the insert and direct output locations for that input channel will be shown graphically.



#### 2 INPUT CH (Input channel)

This is the number of the input channel you are editing. Two paired channels are indicated by a heart symbol shown at the left; settings 3–6 will be linked for these channels. You can click this symbol to enable/disable pairing.

#### 3 INSERT ON/OFF

This button switches insert on/off for each channel. This is linked for two paired channels.


#### Note

*Be aware that if you turn on this button when either insert-in or insert-out are unpatched, the signal will no longer be output from the corresponding input channel.*

#### 4 INSERT I/O (Insert I/O point)

Here you can select one of the following as the insert-in/out location for each channel.

PRE EQ	Immediately before the EQ
POST EQ	Immediately after the EQ
PRE DELAY	Immediately before the delay
POST FADER	Immediately after the fader



#### 5 DIRECT OUT ON/OFF

These buttons switch direct output on/off for each channel.


#### 6 DIRECT OUT

Here you can select one of the following as the direct output location for each channel.

PRE HPF	Immediately before the high-pass filter
PRE EQ	Immediately before the EQ (immediately after the PRE EQ of the INSERT I/O)
PRE FADER	Immediately before the fader
POST ON	Immediately after the CH [ON] key



## NAME screen

Here you can assign a name to each input channel and DCA group.



## INPUT PATCH LIBRARY screen

Here you can recall, store, rename, or delete items in the input patch library.



- ① **Channel**  
This area indicates the input channel (input channel, ST IN channel) and DCA group numbers.
- ② **Name**  
This area indicates the names currently assigned to each input channel and DCA group. If you click the name, a window will open allowing you to assign a name to the channel.
- ③ **LIBRARY**  
This button accesses the INPUT PATCH LIBRARY screen (➔ p.257), where you can store/recall input channel patch (and name) library settings.

Except for the fact that these are patch settings for input channels, display and operations are the same as in the OUTPUT PATCH function OUTPUT PATCH LIBRARY screen. Refer to p.223.

# INPUT HA/INSERT function

## CH 1-24 (Input channel 1-24) screen


### STIN/FXRTN (ST IN/FXRTN channel) screen

Here you can make settings for internal HAs (PM5D-RH model only) or external HAs assigned to input channels.

#### CH 1-24



#### STIN/FXRTN



- ① +48V
- ② HPF (High Pass Filter)
- ③ Cutoff frequency
- ④ GAIN
- ⑤ Input port  
These items are the same as in the OUTPUT INSERT function INSERT IN MIX1-24 screen and INSERT IN MATRIX/STEREO/MONITOR screen (➔ p.224).
- ⑥ Channel  
This area shows the number and name of the channel you are editing. Two paired channels are indicated by a heart symbol displayed between them.

#### Note

- Items ①–④ are not shown for channels to which nothing is patched, or for channels patched to an input port that does not have a HA. Items ② and ③ are not shown for channels patched to a port that has no high pass filter.
- To assign input ports to input channels, use the INPUT PATCH screen (INPUT PATCH function).
- HA settings are not linked even if two channels are paired. However, the GAIN knob setting is linked for HAs whose GANG button is turned on in the HA screen (SYS/W.CLOCK function).



- ⑦ LIBRARY button  
This button displays the HA LIBRARY screen (➔ p.208), where you can store/recall internal HA or external HA settings as library items.

#### Hint

The HA settings you edit in this screen are also reflected in the HA screen (SYS/W.CLOCK function).

## INSERT 1-24 screen

## INSERT 25-48 screen


## INSERT STIN screen

Here you can make settings for internal HAs (PM5D-RH model only) or external HAs assigned to the insert-in of input channels.

INSERT 1-24



STIN/FXRTN IN



- ① +48V
- ② HPF (High Pass Filter)
- ③ Cutoff frequency
- ④ GAIN
- ⑤ Input port
- ⑥ Channel

These items are the same as in the OUTPUT INSERT function INSERT IN MIX1-24 screen and INSERT IN MATRIX/STEREO/MONITOR screen (→ p.224).

This area shows the number and name of the channel you are editing. Two paired channels are indicated by a heart symbol displayed between them.

### Note

- Items ①–④ are not shown for channels to whose insert-in nothing is patched, or for channels patched to an input port whose insert-in does not have a HA. Items ② and ③ are not shown for channels patched to a port that has no high pass filter.
- To assign an input port to an insert-in, use the INPUT PATCH screen (INPUT PATCH function).
- HA settings are not linked even if two channels are paired. However, the GAIN knob setting is linked for HAs whose GANG button is turned on in the HA screen (SYS/W.CLOCK function).




- ⑦ LIBRARY button
- This button displays the HA LIBRARY screen (→ p.208), where you can store/recall internal HA or external HA settings as library items.

### Hint

The HA settings you edit in this screen are also reflected in the HA screen (SYS/W.CLOCK function).

## HA LIBRARY screen

This screen is the same as HA LIBRARY in the SYS/W.CLOCK function (➔ p.208).



## INPUT $\phi$ /EQ function


### EQ PARAM (EQ parameter) screen

Here you can edit the EQ parameters of the selected input channel.

#### EQ PARAM



- ① **Channel selection**  
Selects the input channel (input channel 1–48, STIN channel 1–4 L/R, FXRTN channel 1–4 L/R).
- ② **Name**  
This is the name of the currently selected input channel. If the input channel is paired (or if a ST IN channel or FX RTN channel is selected), a heart symbol is displayed at the right. For an input channel, you can click this symbol to enable/disable pairing.
- ③ **EQ ON/OFF**  
Turns the EQ on/off for that channel.
- ④ **EQ LINK GROUP**  
Selects the EQ link group (1–8) to which the EQ of that channel belongs. EQ parameters are linked for input channels belonging to the same group.  
**Note**  
*The input channel EQ link groups are independent from the output channel EQ link groups.*
- ⑤ **LIBRARY**  
This button accesses the INPUT EQ LIBRARY screen (➔ p.263), where you can store/recall input channel EQ library settings.



- ⑥ **ATT (Attenuation)**  
This knob adjusts the amount of attenuation/gain immediately following AD conversion in a range of -96 dB to +24 dB. This is linked with the ATT knob in the  $\emptyset$ /ATT 1-48 screen and  $\emptyset$ /ATT STIN/FXRTN screen. The current value is displayed in the box located below the knob.
- ⑦ **EQ TYPE**  
Selects the type of EQ. Turning the TYPE I button on selects the algorithm used in the 02R series. Turning the TYPE II button on selects a newly developed algorithm. TYPE II reduces the interference between bands.
- ⑧ **EQ graph**  
This graph shows the approximate response of the EQ parameters. The colored vertical lines indicate the **FREQ** (center frequency) of the band for the parameter at which the cursor is located. (The color of each line matches the knob markings for each band.) The response curve will change when you edit the **Q** or **GAIN** of each band.
- ⑨ **Level meters**  
These meters indicate the peak levels before EQ and after EQ. If the signal clips before or after EQ, the **OVER** segment will light.
- ⑩ **EQ FLAT**  
This button resets the **GAIN** parameters of all bands to the default value ( $\pm 0.0$  dB). When you click this button, a confirmation message will appear.



- ⑪ **HPF (High Pass Filter)**  
The high pass filter located after attenuation and before EQ can be switched on/off, and you can adjust its cut-off frequency. The cutoff frequency can be adjusted in a range of 20–600 Hz.
- ⑫ **Knobs**  
These knobs adjust the **Q**, **FREQ** (center frequency), and **GAIN** (amount of boost/cut) for each band.
- ⑬ **[>] (LOW shelving)**  
If this button is on, the **LOW** EQ will function as a shelving-type EQ. The **Q** knob will disappear.
- ⑭ **[<] (HIGH shelving)**  
If this button is on, the **HIGH** EQ will function as a shelving-type EQ. The **Q** knob will disappear.
- ⑮ **LPF (Low Pass Filter)**  
If this button is on, the **HIGH** EQ will function as a low-pass filter. The **Q** knob will disappear, and the **GAIN** knob is used to switch the LPF on/off.

## EQ 1-24 screen

## EQ 25-48 switch

## EQ STIN/FXRTN screen

These screens list the EQ settings for the input channels. Here you can also copy EQ settings between input channels.

### Note

*In some screens that include channel numbers as part of the screen name, changing the Pair Mode to Vertical Pairing in the MIXER SETUP screen will change the name of the screen.*

*Example: EQ 1-24 screen → EQ 1,25- screen*

### EQ 1-24



### EQ STIN/FXRTN



Information shown in the display


Function menu

Global functions

Output functions

Input functions

Appendices



① EQ graph


This mini-graph shows the approximate EQ response for each input channel.

When you click the graph at which the cursor is currently located, the EQ PARAM screen for that channel will appear.

In this screen you can drag and drop the mini-graph from the desired channel to copy its EQ settings. (When you drag and drop the mini-graph, a window will appear, asking you to confirm the copy operation.)



You can also copy EQ settings between the three screens EQ 1-24, EQ 25-48, and EQ STIN/FXRTN. First drag the mini-graph over the EQ 1-24, EQ 25-48, or EQ STIN/FXRTN tabs in the screen (the screen will switch). Then drag and drop the mini-graph onto the desired channel, and a window will appear, asking you to confirm the copy operation.



② EQ ON/OFF

Turns the EQ on/off for that channel. This is linked for two paired channels.

③ Channel

This is the number of the channel you are editing. Two paired channels are indicated by a heart symbol displayed between them.

④ Level meter

This meter indicates the peak level after EQ. If the signal clips, the OVER segment will light.

$\phi$ /ATT 1-48 (Phase/Attenuation 1-48) screen

$\phi$ /ATT STIN/FXRTN (Phase/Attenuation STIN/FXRTN) screen

Here you can adjust the amount of attenuation/gain immediately following AD conversion, and reverse the phase.

$\phi$  /ATT 1-48



$\phi$  /ATT STIN/FXRTN





① **GANG**

When you turn this button on, attenuation/gain settings will be linked for adjacent odd-numbered/even-numbered channels (or the L/R sides of an STIN/FXRTN channel).

If the settings are different when you turned the button on, they will maintain their relative difference while linked.

② **∅ (Phase)**

This button inverts the phase of each channel's signal following AD conversion.

③ **Attenuation/gain**


For each channel, you can adjust the amount of attenuation/gain immediately following AD conversion over a range of -96 dB to +24 dB. This is linked with the ATT knob of the EQ PARAM screen. The current value is displayed in the box located below the knob.

④ **Channel**

This is the number and name of the channel. If two adjacent odd-numbered/even-numbered channels are paired (or if a STIN channel or FXRTN channel is displayed), a heart symbol is displayed between the two channels.

## INPUT EQ LIBRARY screen

Here you can recall, store, rename, or delete items in the input EQ library.



Except for the fact that these are EQ settings for the input channels, display and operations are the same as in the OUTPUT EQ function OUTPUT EQ LIBRARY screen. Refer to p.228.

Information shown in the display

Function menu

Global functions

Output functions

Input functions


Appendices

# INPUT GATE/COMP function

## GATE PARAM (Gate parameter) screen


Here you can edit the gate parameters of the selected input channel.

### GATE PARAM




- ① **Channel selection**  
Select the input channel (input channel, ST IN channel) that you want to edit.
- ② **Name**  
This is the name of the currently selected input channel. If the input channel is paired (or if a ST IN channel is selected), a heart symbol is displayed at the right. For an input channel, you can click this symbol to enable/disable pairing.
- ③ **GATE ON/OFF**  
Turns the gate for that channel on/off.
- ④ **LIBRARY**  
This button accesses the GATE LIBRARY screen (→ p.268), where you can store/recall gate library settings for input channels.

- ⑤ **Level meters**  
These meters indicate the amount of gain reduction (GR), the peak level before (PRE) and after (POST) the gate, and the peak level of the key-in signal (KEY IN) that causes the gate to operate. If the signal clips, the OVER segment will light.  
If stereo link is turned on for the input channel (or if a ST IN channel is selected), level meters for two channels are displayed.




**Hint**  
If GR METER ON/OFF LINK is turned on in the PREFERENCE 1 screen (UTILITY function), the gain reduction meter will not be displayed when the gate is off.




- ⑥ **Type**  
Indicates the type of the currently selected gate.  
**Hint**  
To change the gate type, use the INPUT GATE LIBRARY screen to recall a library item that has a different type. You cannot change only the gate type in this screen.
- ⑦ **STEREO LINK**  
This specifies whether parameter settings and gate operation by a key-in signal will be linked (STEREO LINK button on) for adjacent odd-numbered/even-numbered input channels and the L/R channels of ST IN channels, or not (STEREO LINK button off).

### □ Key-in signal flow when Link= On



## ❑ Key-in signal flow when Link= Off



### Note

Stereo Link is fixed at On for paired channels.

## ⑧ Gate graph

This graph displays the approximate response of the gate.



## ⑨ KEY IN SOURCE

Here you can select one of the following as the key-in signal that will be used. (If an input channel is selected, its name will be displayed at the right.)

<b>SELF PRE EQ</b>	The pre-EQ signal of the currently selected input channel
<b>SELF POST EQ</b>	The post-EQ signal of the currently selected input channel
<b>CH 1–48 POST EQ</b>	The post-EQ signal of the corresponding input channel (however, you can only choose channels belonging to the same group, within the seven groups CH1–8, CH9–16, CH17–24, CH25–32, CH33–40, CH41–48, and ST IN 1L/1R–4L/4R)
<b>ST IN 1L/1R–4L/4R POST EQ</b>	
<b>MIX 21–24 OUT</b>	The output signal of the corresponding MIX channel immediately before the output attenuation

## ⑩ FILTER

Select the type of filter to be applied to the selected key-in signal, from the following types.

- **HPF (High Pass Filter)**  
Passes the portion of the signal above the specified frequency (the cutoff frequency), and cuts the portion below. If you select this filter, use the knob at the right to adjust the cutoff frequency (20 Hz–20 kHz).
- **BPF (Band Pass Filter)**  
Passes only the specified frequency region (the band pass frequency), and cuts the rest of the signal. If you select this filter, use the knobs at the right to adjust the band pass frequency (20 Hz–20 kHz) and Q (10.0–0.10).
- **LPF (Low Pass Filter)**  
Passes the portion of the signal below the specified frequency (the cutoff frequency), and cuts the portion above. If you select this filter, use the knob at the right to adjust the cutoff frequency (20 Hz–20 kHz).

## ⑪ FILTER ON/OFF


This is an on/off switch for the filter applied to the key-in signal.

## ⑫ CUE

This button cue-monitors the currently selected key-in signal.

### Note

Even if the cue mode is set to MIX CUE (which lets you monitor the mix of all channels whose [CUE] key is on), only the corresponding signal will take priority for monitoring when you turn on the CUE button in the GATE PARAM screen. (Any [CUE] keys that had been on at that time will be forcibly turned off.)



## ⑬ THRESHOLD (Threshold level)

Specifies the level at which the gate will open and close. The gate will open when the key-in signal exceeds this level, and will close when the signal falls below this level.

## ⑭ ATTACK (Attack time)

Specifies the time from when the key-in signal exceeds the threshold level until the gate opens.

## ⑮ HOLD (Hold time)

Specifies the time that the gate will remain open after the key-in signal falls below the threshold.

## ⑯ DECAY (Decay time)


Specifies the time over which the gate will close after the hold time has elapsed.

## ⑰ RANGE

Specifies the amount of attenuation while the gate is closed.

## COMP PARAM (Compressor parameter) screen

Here you can edit the compressor parameters of the selected input channel.



### ① Channel selection

Select the input channel (input channel, ST IN channel) that you want to edit.

### ② Name

This is the name of the currently selected input channel. If the input channel is paired (or if a ST IN channel is selected), a heart symbol is displayed at the right. For an input channel, you can click this symbol to enable/disable pairing.

### ③ COMP ON/OFF (Compressor on/off)

Turns the compressor on/off for that channel.

### ④ COMP LINK GROUP (Compressor link group)

Selects the compressor link group (1–8) to which that channel belongs. Compressor parameters are linked for input channels belonging to the same group.

#### Note



*Input channel compressor link groups are independent from output channel compressor link groups.*

### ⑤ LIBRARY

This button accesses the COMP LIBRARY screen (➔ p.232), where you can store/recall compressor library settings for input channels.

### ⑥ Level meters

These meters indicate the amount of gain reduction (GR), the peak level before (PRE) and after (POST) the compressor, and the peak level of the key-in signal (KEY IN) that causes the compressor to operate. If the signal clips, the OVER segment will light.



### ⑦ Type

Indicates the type of the currently selected compressor.

### ⑧ STEREO LINK

This specifies whether compressor parameter settings and key-in signal operation will be linked for adjacent odd-numbered/even-numbered input channels (STEREO LINK button on), or will be independent (STEREO LINK button off). (For details on compressor stereo link ➔ p.229)

### ⑨ Compressor graph


This graph displays the approximate response of the compressor.



### 10 KEY IN SOURCE

Select the desired key-in signal from the following choices.

<b>SELF PRE EQ</b>	The pre-EQ signal of the currently selected input channel
<b>SELF POST EQ</b>	The post-EQ signal of the currently selected input channel
<b>CH 1–48 POST EQ</b>	The post-EQ signal of the corresponding input channel (however, you can only choose channels belonging to the same group, within the seven groups CH1–8, CH9–16, CH17–24, CH25–32, CH33–40, CH41–48, and ST IN 1L/1R–4L/4R)
<b>ST IN 1L/1R–4L/4R POST EQ</b>	
<b>MIX 21–24 OUT</b>	The output signal of the corresponding MIX channel immediately before the output attenuation



- 11 THRESHOLD (Threshold level)
- 12 RATIO
- 13 ATTACK (Attack time)
- 14 RELEASE (Release time)
- 15 GAIN
- 16 KNEE

These parameters are the same as in the OUTPUT COMP function COMP PARAM screen (➔ p.230).

### CH 1-12 (Input channel 1–12) screen



### CH 13-24 (Input channel 13–24) screen

### CH 25-36 (Input channel 25–36) screen

### CH 37-48 (Input channel 37–48) screen

### ST IN (ST IN channel) screen

These screens list the gate/compressor settings for the input channels. Here you can also copy gate/compressor settings between input channels.



Information shown in the display


Function menu

Global functions

Output functions

Input functions



Appendices




- ① **Gate graph**  
This mini-graph shows the approximate gate response for each input channel. If you click the mini-graph, the GATE PARAM screen for that channel will appear.
- ② **Level meters**  
These meters show the amount of gain reduction produced by the gate (at left), and the peak level of the signal after passing through the gate (at right). If the signal clips, the OVER segment will light.
- ③ **GATE ON/OFF**  
Turns the gate for that channel on/off.
- ④ **Compressor graph**  
This mini-graph shows the approximate compressor response for each input channel. If you click the mini-graph, the COMP PARAM screen for that channel will appear.
- ⑤ **Level meters**  
These meters show the amount of gain reduction produced by the compressor (at left), and the peak level of the signal after passing through the compressor (at right). If the signal clips, the OVER segment will light.
- ⑥ **COMP ON/OFF (Compressor on/off)**  
Turns the compressor on/off for that channel.
- ⑦ **Channel**  
This area shows the number and name of the channel you are editing. Two paired channels are indicated by a heart symbol displayed between them.  
In this screen, you can copy gate/compressor settings by dragging and dropping the mini-graph of a desired channel onto another channel. You can also copy gate/compressor settings between different screens (for the procedure ➔ p.231).

## GATE LIBRARY screen

Here you can recall, store, rename, or delete items in the gate library.



- ① **EDIT**  
When you click this button, the GATE PARAM screen for the currently selected input channel will appear.
- ② **Channel selection**  
Select the input channel that you want to edit. The name of the channel is displayed at the right.
- ③ **Gate graph of the selected channel**  
This graph shows the approximate response of the gate for the currently selected channel.
- ④ **Level meters**  
These meters show the amount of gain reduction (GR), and the peak levels before the gate (PRE) and after the gate (POST). If the signal clips, the OVER segment will light.



- ⑤ **RECALL**  
Recalls the gate library item selected in the list into memory.
- ⑥ **STORE**  
Stores the gate settings of the currently selected channel into the location selected in the list. When you click this button a window will appear, allowing you to name and save the settings.
- ⑦ **TITLE EDIT**  
Edits the title of the library item selected in the list. When you click this button a window will appear, allowing you to edit the title.
- ⑧ **CLEAR**  
Deletes the library item selected in the list. When you click this button, a confirmation message will appear.


**Note**

*Library items with an "R" displayed in the right column of the list are read-only. Read-only items cannot be stored, renamed, or deleted.*

- ⑨ **Library gate graph**  
This graph indicates the approximate response of the gate library item selected in the list.
- ⑩ **Library list**  
Use the scroll bar to select the library item on which you want to perform an operation. The selected library item will move to the center, and will be highlighted.

## COMP LIBRARY (Compressor library) screen

Here you can recall, store, rename, or delete items in the compressor library.



Except for the fact that these settings are for input channels, this is the same as the OUTPUT COMP function COMP LIBRARY screen. Refer to p.232.

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

# INPUT DELAY function

## CH 1-24 (Input channel 1-24) screen

## CH 25-48 (Input channel 25-48) screen

## ST IN (ST IN channel) screen

Here you can edit the delay parameters of the selected input channel.

CH 1-24



ST IN



1



### 1 DELAY SCALE

Here you can select the units in which the delay time is displayed. The units that can be selected are the same as in OUTPUT DELAY function DELAY SCALE (p.233). When you change the delay scale in the INPUT DELAY function, the delay scale of the OUTPUT DELAY function will also change accordingly.



### 2 GANG

### 3 Delay time knob

### 4 DELAY ON/OFF

These are the same as in the OUTPUT DELAY function (p.233).

### 5 Channel


This area shows the number and name of the input channel you are editing. Two paired channels (or a ST IN channel) are indicated by a heart symbol displayed between them. You can click this symbol to enable/disable pairing.

# INPUT DCA/GROUP function

## DCA GROUP ASSIGN screen

Here you can specify the input channels that will be assigned to DCA groups 1–8. The level of input channels belonging to the same DCA group can be adjusted as a whole using DCA faders 1–8.

### DCA GROUP ASSIGN




- ① **DCA group**  
This is the number of the DCA group. The number corresponding to the grid where the cursor is located is highlighted.
- ② **Name**  
This is the name of the DCA group. You can also click this area to edit the name.
- ③ **Grid**  
This grid lets you assign input channels (horizontal rows) to DCA groups (vertical columns). Currently-patched grids are indicated by a yellow symbol. Move the cursor to the desired grid and press the [ENTER] key (or click) to set/disable the assignment.

#### Hint

You can also assign a single input channel to multiple DCA groups for multiple DCA control.

#### Hint

DCA groups 1–6 are for input channels only, but DCA groups 7/8 can be used with both input channels and output channels. Both types of channel can exist in an identically-numbered group.



- ④ **SET BY CUE (Assign by [CUE] key)**  
This specifies whether the [CUE] key will be used to make/cancel DCA group assignments. While the DCA group SET BY CUE button is on, pressing the [CUE] key of an input channel that can be assigned to the corresponding group will assign the channel to the group. (Press the [CUE] key once again to cancel the assignment.)

#### Hint

The SET BY CUE button can be turned on for only one DCA group. This is automatically turned off when you change screens or turn off the power.

- ⑤ **CLEAR**  
This button clears all input channels assigned to that DCA group.




- ⑥ **MUTE**  
These buttons switch muting on/off for DCA groups 1–8. They are linked with DCA [MUTE] keys 1–8 in the DCA strip of the panel.
- ⑦ **DCA faders**  
These faders adjust the levels of DCA groups 1–8. They are linked with DCA faders 1–8 in the DCA strip.
- ⑧ **CUE**  
These buttons cue-monitor DCA groups 1–8. They are linked with DCA [CUE] keys 1–8 in the DCA strip of the panel.
- ⑨ **DCA LEVEL SET**  
Use the following two buttons to operate DCA groups 1–8 together.
  - **ALL NOMINAL**  
Clicking this button will move DCA faders 1–8 to nominal level (0 dB).
  - **ALL MINIMUM**  
Clicking this button will move DCA faders 1–8 to the  $-\infty$  dB position.

### MUTE GROUP ASSIGN screen

Here you can specify the input channels that will be assigned to mute groups 1–8. Muting can be switched on/off together for channels assigned to the same mute group.

MUTE GROUP ASSIGN



Except for the fact that these settings apply to input channels, the display and operations are the same as in the OUTPUT DCA/GROUP function MUTE GROUP ASSIGN screen. Refer to p.235.


**Hint**

Mute groups 1–8 can be used with both input channels and output channels. Both types of channel can exist in the identically-numbered mute group.

### EQ LINK ASSIGN screen

Here you can specify the input channels that will be assigned to EQ link groups 1–8. EQ parameters are linked for channels belonging to the same group.


EQ LINK ASSIGN



- ① **EQ link group**  
These are the EQ link group numbers. The number corresponding to the grid where the cursor is located is highlighted.
- ② **Grid**  
This grid lets you assign input channels (horizontal rows) to EQ link groups (vertical columns). Currently-patched grids are indicated by a ● symbol. Move the cursor to the desired grid and press the [ENTER] key (or click) to set/disable the assignment.

**Hint**

Input channels and output channels use separate EQ link groups. Input channels use groups A–H, and output channels use groups 1–8.



### ③ SET BY CUE (Assign by [CUE] key)

This specifies whether the [CUE] key will be used to make/cancel EQ link group assignments. While the EQ link group SET BY CUE button is on, pressing the [CUE] key of a channel that can be assigned to the corresponding group will assign the channel to the group. (Press the [CUE] key once again to cancel the assignment.)

#### Hint


The SET BY CUE button can be turned on for only one EQ link group. This is automatically turned off when you change screens or turn off the power.

### ④ CLEAR

This button clears all input channels assigned to that EQ link group.

## COMP LINK ASSIGN (Compressor link assign) screen

Here you can specify the input channels that will be assigned to compressor link groups 1–8. Compressor parameters are linked for channels belonging to the same group.



Except for the fact that these settings apply to input channels, the display and operations are the same as in the OUTPUT DCA/GROUP function COMP LINK ASSIGN screen. Refer to p.237.

#### Hint


Input channels and output channels use separate compressor link groups. Input channels use groups A–H, and output channels use groups 1–8.

# PAN/ROUTING function

## CH to MIX (Channel to mix) screen

Here you can send signals from input channels to the desired MIX bus. In this screen you can also switch the type (VARI or FIXED) of each MIX bus, and specify the location from which the signal will be sent.

### CH to MIX



### ① Type selection

Here you can select the mix bus type for every two adjacent odd-numbered/even-numbered MIX buses. You can choose one of the following types.

#### • FIXED

The send level of the MIX bus is fixed at nominal level (0.0 dB). Choose this if you want to use the MIX bus as a group output or as a bus output for recording on a multitrack recorder.

#### • VARI (Variable)

The send level of the MIX bus is adjustable. Choose this if you want to use the MIX bus as an external effect send or as a foldback output.

#### Hint

If surround mode is enabled, the type indication will change to "SURROUND" for MIX buses used as surround buses. You cannot change the mix bus type during this time.

### ② MIX bus

This is the number of the MIX bus to which the signal is sent. Paired MIX buses are indicated by a heart symbol displayed between them. You can click this symbol to enable/disable pairing.


### ③ POST ON/POST TO ST (Post on / Post to stereo)

This button lets you specify in greater detail the location from which post-fader signals will be sent from input channels to this MIX bus. You can choose one of the following two send locations.

#### □ POST ON

The signal will be sent from immediately after the [ON] key.


POST ON/POST TO ST= **POST ON**



#### □ POST TO ST

The signal will be sent from immediately after the [TO STEREO] key.

POST ON/POST TO ST= **POST TO ST**



#### Hint


This setting applies to the signals sent from all input channels to the corresponding MIX bus.

### ④ CH to MIX (Channel to mix)

In this area, the signals sent from input channels / ST IN channels (vertical columns) to MIX buses (horizontal rows) can be switched on/off and their level adjusted.

The buttons and knobs displayed here will differ depending on the type (FIXED or VARI) of the send-destination MIX bus, and on whether the MIX buses are paired.


❑ Type = FIXED, Pairing = disabled





**SEND ON/OFF button**  
On/off switch for the signal sent from input channels to each MIX bus.



❑ Type = FIXED, Pairing = enabled



**SEND ON/OFF button**  
On/off switch for the signal sent from input channels to the two MIX buses.



Information shown in the display

Function menu


Global functions

Output functions


Input functions

Appendices


☐ Type = VARI, Pairing = disabled




☐ Type = VARI, Pairing = enabled




• PRE/POST button= PRE




• PRE/POST button= PRE




• PRE/POST button= POST



• PRE/POST button= POST





### ⑤ PRE EQ/PRE FADER

These buttons let you specify in greater detail the location from which the pre-fader signal will be sent from an input channel to the MIX buses. You can choose one of the following two send locations.

<b>PRE FADER</b>	Immediately before the fader
<b>PRE EQ</b>	Immediately before the EQ

#### Hint

*This setting applies to the signal sent from the corresponding input channel to all MIX buses.*

### ⑥ FOLLOW PAN

These buttons specify how the TO ST PAN knob (⑧) will affect the signal sent from the input channel to MIX buses.

#### • VARI

If this button is on, the PAN knob displayed in the CH to MIX area (④) will be linked with the TO ST PAN knob (⑧) if VARI-type MIX buses are paired.

#### • FIXED

If this button is on, the signal from after the TO ST PAN (⑧) knob will be sent to FIXED-type MIX buses.

### ⑦ TO ST (To stereo)

This button specifies whether the input channel / ST IN channel will send its signal to the STEREO bus. This is linked with the [TO STEREO] switch in the SELECTED CHANNEL section.

### ⑧ TO ST PAN (To stereo pan)

Here you can adjust the panning of the signal sent from the input channel / ST IN channel to the STEREO bus. (The current value is shown in the boxes immediately below.) This is linked with the encoder if PAN is selected as the encoder mode, and with the [PAN] encoder of the SELECTED CHANNEL section.

### ⑨ PAN MODE

Here you can select one of the following ways in which pan settings will be linked between adjacent odd-numbered/even-numbered input channels (or the left/right channels of a ST IN channel).

#### • INDIVIDUAL

The two pan settings will be independent.

#### • GANG PAN

The two pan settings will be linked in the same direction. If the two pan values are different when you turn on this button, pan will be linked while preserving the existing difference in values.

#### • INV. GANG (Inverted gang)

The two pan settings will operate in opposite directions.

### • BALANCE

The two PAN knobs will function as BALANCE knobs that adjust the balance of the signal sent from the odd-numbered/even-numbered channels (or the L/R channels of the ST IN channel) to the STEREO bus L/R. If you choose this setting, the two knobs will be reset to the center position, and will be linked in the same direction. Also, the knob markings will change from red to white.

#### Note

- Pan mode is always valid, even if the send-source input channels are not paired.
- You will be unable to operate the TO ST PAN knobs if you select GANG PAN mode when the two pan knobs are set to far left and right, or if you select INV.GANG when both pan knobs are turned all the way in the same direction.

### ⑩ MIX MINUS

This function sends the same mix as the STEREO bus — but with a specific input channel removed — to the desired MIX bus. If you need to send a monitor mix to a performer or announcer, this is a quick way to give them the same mix as the STEREO bus but without their own voice.

Access the desired source input channel in the screen, and click the MIX MINUS button for that channel; a window will appear, allowing you to select the MIX bus for which to make Mix Minus settings.



#### Hint

*As a shortcut to access the above window, you can simultaneously press the [SEL] key of the INPUT/ST IN channel strip and the [SEL] key of the MIX section. However, be aware that holding down either one of these keys by itself will access a different shortcut.*

In the above window, select the send-destination MIX bus and click the OK button; the following parameters will change in the CH to MIX screen.

- In the CH to MIX area of the send-destination MIX bus, all ON/OFF buttons will turn on.
- In the CH to MIX area of the send-destination MIX bus, all PRE/POST buttons will be set to POST.
- The send level of signals sent from the source input channel to the destination MIX bus will be lowered to  $-\infty$  dB.
- The send level of signals sent from all input channels other than the above to the destination MIX bus will be set to nominal level (0.0 dB).

- The POST ON/POST TO ST button will be set to POST TO ST for the destination MIX bus.

**Note**

- *Mix Minus does not switch a “mode”; rather, it is a quick way to make certain settings. This means that even after executing Mix Minus, you can freely edit the parameters of the CH to MIX screen.*
- *When you execute the Mix Minus operation, only the input channel you selected as the source will be removed from the mix. If you want to remove more than one input channel from the signal sent to a specific MIX bus, execute the Mix Minus operation and then manually change the settings of other channels.*
- *If the input channel is paired (or if a ST IN channel is selected), the send level of the signal sent from both channels to the target MIX bus will be set to  $-\infty$ .*
- *The Mix Minus operation is valid even if the destination MIX bus is paired. In this case, the PAN setting of the input channel will be reflected by the PAN settings of the paired MIX buses.*

⑪ **Input channel**

This is the source input channel (or channels). Paired input channels (or a ST IN channel) are indicated by a heart symbol displayed between them. For an input channel, you can click this symbol to enable/disable pairing.

You can move the cursor to a parameter in the CH to COPY area, and then hold down the [SHIFT] key and click (or press the [SHIFT] key + [ENTER] key) to copy the value of that parameter to another channel (in the horizontal direction) or to another MIX bus (in the vertical direction), or to switch all parameters on/off. You can use this method to set the following parameters.

• **Mix send on/off**

Move the cursor to the SEND ON/OFF button of the CH to COPY area; then hold down the [SHIFT] key and click (or press the [SHIFT] key + [ENTER] key) to access the following window.



To set multiple parameters at once, use the [DATA] encoder to select one of the following items, and click the OK button.

- ALL OFF [ALL MIX ↑↓]**
- ALL ON [ALL MIX ↑↓]**

Switch the signals sent from the selected input channel to all MIX buses on or off together.

- ALL OFF [ALL CH ↔]**
- ALL ON [ALL CH ↔]**

Switch the signals sent from all input channels to the selected MIX bus on or off together.

- ALL OFF [ALL CH x ALL MIX]**
- ALL ON [ALL CH x ALL MIX]**

Switch the signals sent from all input channels to all MIX buses on or off together.

• **Mix send position**

Move the cursor to a PRE/POST button in the CH to COPY area; then hold down the [SHIFT] key and click (or press the [SHIFT] key + [ENTER] key) to access the following window.



To set multiple parameters at once, use the [DATA] encoder to select one of the following items, and click the OK button.

- ALL POST [ALL MIX ↑↓]**
- ALL PRE [ALL MIX ↑↓]**

Switch the send position of the signal sent from the selected input channel to all MIX buses to either post-fader or pre-fader.

- ALL POST [ALL CH ↔]**
- ALL PRE [ALL CH ↔]**

Switch the send position of the signal sent from all input channels to the selected MIX bus to either post-fader or pre-fader.

- ALL POST [ALL CH x ALL MIX]**
- ALL PRE [ALL CH x ALL MIX]**

Switch the send position of the signal sent from all input channels to all MIX buses to either post-fader or pre-fader.

**Note**

*These “all-at-once” operations are ignored by FIXED-type MIX buses.*

• **Mix send level**

Move the cursor to a SEND LEVEL knob in the CH to COPY area; then hold down the [SHIFT] key and click (or press the [SHIFT] key + [ENTER] key) to access the following window.



To set multiple parameters at once, use the [DATA] encoder to select one of the following items, and click the OK button.

**LEVEL COPY [ALL MIX ↑↓]**

The value of the selected SEND LEVEL knob will be copied to the send level of the signals sent from that input channel to all MIX buses.

**LEVEL COPY [ALL MIX ↔]**

The value of the selected SEND LEVEL knob will be copied to the send level of the signals sent from all input channels to that MIX bus.

**LEVEL COPY [ALL CH x ALL MIX]**

The value of the selected SEND LEVEL knob will be copied to the send level of the signals sent from all input channels to all MIX buses.

**Note**

*These "all-at-once" operations are ignored by FIXED-type MIX buses.*

• **Mix pan/balance**

When the destination MIX bus is paired, move the cursor to a MIX PAN/BALANCE knob displayed in the CH to COPY area; then hold down the [SHIFT] key and click (or press the [SHIFT] key + [ENTER] key) to access the following window.



To set multiple parameters at once, use the [DATA] encoder to select one of the following items, and click the OK button.

**PAN (BAL) COPY [ALL MIX ↑↓]**

The value of the selected MIX PAN/BALANCE knob will be copied to the pan (balance) of signals sent from that channel to all paired MIX buses.

**PAN (BAL) COPY [ALL MIX ↔]**

The value of the selected MIX PAN/BALANCE knob will be copied to the pan (balance) of signals sent from all channels to that MIX bus.

**PAN (BAL) COPY [ALL CH x ALL MIX]**

The value of the selected parameter will be copied to the pan (balance) of signals sent from all channels to all paired MIX buses.



**Note**

- This operation is ignored by unpaired MIX buses and FIXED-type MIX buses.
- You cannot copy PAN parameters to BALANCE parameters (or vice versa).
- Copying is invalid for channels whose VARI button (in the FOLLOW PAN area) is on.

### MIX SEND VIEW screen

This screen lists the signals sent from the input channels to the MIX buses. You can also edit the settings from within this screen.

#### MIX SEND VIEW



#### ① CH to MIX/MIX from CH

Select one of the following two types of screen display.


##### □ When the CH to MIX button is on

The screen shows the status of the signals sent from a specific input channel (input channel / ST IN channel) to all MIX buses. (Use the scroll bar to see input channels that are not currently shown.)



##### □ When the MIX from CH button is on

The screen shows the status of the signals sent from all input channels to a specific MIX bus.



#### ② SEND LEVEL, PRE/POST (Send level / Send point)

Select one of the following two parameters to view in the grid.


##### □ When the SEND LEVEL button is on

The send levels of the signals sent from input channels to MIX buses are shown in the grid as bar graphs. Except for the fact that the send-sources are input channels and the send-destinations are MIX buses, the bar graph display is the same as in the MIX to MATRIX VIEW screen (MATRIX/ST function) (→ p.240).

To edit the send level of a signal, move the cursor to the grid where the desired channel and MIX bus intersect, and turn the [DATA] encoder. To switch a MIX send on/off, click the grid where the desired channel and MIX bus intersect.

If the SEND LEVEL button is on, you can select a desired grid and copy its send level (pan) value to other channels (horizontal direction) or to other MIX buses (vertical direction), or switch all grids on/off simultaneously.

To do so, move the cursor to the desired grid; then hold down the [SHIFT] key and press the [ENTER] key. (Alternatively, hold down the [SHIFT] key and click the desired grid.) When the following window appears, select one of the following choices to copy, and click the OK button.



##### LEVEL COPY [ALL MIX ↑↓]

Copy the send level (pan) value of the selected grid to all MIX buses.

##### LEVEL COPY [ALL CH ↔]

Copy the send level (pan) value of the selected grid to all input channels.

##### LEVEL COPY [ALL CH x ALL MIX]

Copy the send level (pan) value of the selected grid to all input channels / all MIX buses.

##### ALL OFF [ALL MIX ↑↓]

Turn off the signals sent from the specified input channel to all MIX buses.

##### ALL ON [ALL MIX ↑↓]

Turn on the signals sent from the specified input channel to all MIX buses.

##### ALL OFF [ALL CH ↔]

Turn off the signals sent from all input channels to the specified MIX bus.

### ALL ON [ALL CH ↔]

Turn on the signals sent from all input channels to the specified MIX bus.

### ALL OFF [ALL CH x ALL MIX]

Turn off the signals sent from all input channels to all MIX buses.

### ALL ON [ALL CH x ALL MIX]

Turn on the signals sent from all input channels to all MIX buses.

#### ❑ When the PRE/POST button is on

This screen shows the send positions of the signals sent from the input channels to the MIX buses.


MODE	CH to MIX		MIX from CH		SEND LEVEL		PRE/POST		
	CH 1	CH 2	CH 3	CH 4	CH 5	CH 6	CH 7	CH 8	CH
MIX 1	PRE	PRE	POST	POST	POST	POST	PRE	POST	PD
MIX 2	PRE	PRE	POST	POST	POST	POST	PRE	POST	PD
MIX 3	POST	POST	POST	POST	POST	POST	POST	POST	PD
MIX 4	POST	POST	POST	POST	POST	POST	POST	POST	PD
MIX 5	POST	POST	POST	POST	POST	POST	POST	POST	PD
MIX 6	POST	POST	POST	POST	POST	POST	POST	POST	PD
MIX 7	POST	POST	POST	POST	POST	POST	PRE	POST	PD
MIX 8	POST	POST	POST	POST	POST	POST	PRE	POST	PD

Each indication has the following significance.

- PRE** (green) . . . PRE EQ (immediately before the EQ)
- PRE** (yellow) . . . PRE FADER (immediately before the fader)
- POST** (gray) . . . . . POST ON (immediately after the [ON] key)
- POST** (red) . . . . . POST TO ST (immediately after the [TO ST] key)

To change the send position of a signal, move the cursor to the grid where the desired channel and MIX bus intersect, and press the [ENTER] key, or click, or turn the [DATA] encoder.

If the PRE/POST button is on, the send position for all grid locations can be changed simultaneously. To do so, hold down the [SHIFT] key and click the desired grid. (Alternatively, move the cursor to the desired grid; then hold down the [SHIFT] key and press the [ENTER] key.) When the following window appears, select one of the following choices and click the OK button.



### ALL PRE [ALL MIX ↑↓]

Specify pre-fader as the send position for signals sent from the specified input channel to all MIX buses.

### ALL POST [ALL MIX ↑↓]

Specify post-fader as the send position for signals sent from the specified input channel to all MIX buses.

### ALL PRE [ALL CH ↔]

Specify pre-fader as the send position for signals sent from all input channels to the specified MIX bus.

### ALL POST [ALL CH ↔]

Specify post-fader as the send position for signals sent from all input channels to the specified MIX bus.

### ALL PRE [ALL CH x ALL MIX]


Specify pre-fader as the send position for signals sent from all input channels to all MIX buses.

### ALL POST [ALL CH x ALL MIX]

Specify post-fader as the send position for signals sent from all input channels to all MIX buses.

#### ③ Grid

This area shows various settings for the signals sent from the input channels (horizontal rows) to the MIX buses (vertical columns). The red lines extending toward the left and upward indicate the corresponding input channel and MIX bus for the grid at which the cursor is now located.





#### ④ SELECTED PARAMETER (currently selected parameter)

This indicates the input channel and MIX bus for the grid where the cursor is currently located. The four boxes at right indicate the values for the grid where the cursor is currently located.

### FIX ASSIGN VIEW screen

This screen lists the signals sent from the input channels to the buses and direct outputs. You can also set or cancel these assignments from within this screen.



① **Input channel**

This area indicates the number and name of the input channel you are editing.

② **PAN**

If this button is on, the input channel's TO STEREO PAN knob setting will also apply to the signal sent to FIXED-type MIX buses. This is linked with the FOLLOW PAN FIXED button of the CH to MIX screen (PAN/ROUTING function).

③ **Bus assignments**

These buttons assign the corresponding input channel to FIXED-type MIX buses. These are linked with the SEND ON/OFF buttons of the CH to MIX screen (PAN/ROUTING function). For VARI-type MIX buses, the buttons are grayed-out and inoperable.

**Note**

*If a surround mode other than STEREO is selected, the buttons for MIX buses used as surround buses will be named by their surround channel (e.g., L, C, R) rather than by number.*

④ **TO ST (To stereo)**


If this button is on, the corresponding input channel is assigned to the STEREO bus. This is linked with the TO ST button of the CH to MIX screen (PAN/ROUTING function).

⑤ **DIRECT**

If this button is on, the signal of the corresponding input channel will be sent to the output port selected as the direct output. This is linked with the DIRECT OUT ON/OFF button in the INSERT/DIRECT OUT POINT screen (IN PATCH function).

⑥ **Output port**

This area indicates the output port that is patched in the DIRECT OUT PATCH screen (INPUT PATCH function) to the direct output of this input channel



⑦ **ALL STEREO**

Clicking this button enables the assignment of all input channels to the STEREO bus.

⑧ **ALL BUS**

Clicking this button enables the assignment of all input channels to FIXED-type MIX buses.

⑨ **ALL CLEAR**

Clicking this button cancels all assignments in the FIX ASSIGN VIEW screen.

⑩ **SURROUND MODE**

This indicates the currently selected surround mode.

## LCR screen


Here you can make settings for LCR mode, which allows three-channel playback by adding a CENTER channel to the L/R channels of the STEREO bus.



Except for the fact that the send-sources are input channels, the display and operations are the same as in the MATRIX/ST function LCR screen. Refer to p.242.

## SURR PARAM (Surround parameter) screen

Here you can perform realtime control of surround panning for the two currently selected input channels.



### ① Channel selection

Select the two adjacent odd-numbered/even-numbered input channels (or ST IN channel L/R) that you want to control. The names of these channels are displayed at the right.

### ② DIVERGENCE

These controls specify the proportion at which the signals are sent to each surround bus when the input channel is positioned in the center. Depending on the currently selected surround mode, the displayed parameters will differ as follows.

#### □ If Surround Mode = 3-1ch/5.1ch

A knob for controlling the front divergence is displayed. Use this knob to specify the proportion (0–100) at which a signal positioned in the center will be sent to the center bus (C) and the left/right buses (L, R). With a setting of 0 the signal will be sent only to the left/right buses, and with a setting of 100 it will be sent only to the center bus. With a setting of 50, the signal will be sent at the same level to the left/right and center buses.



Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

**▣ If Surround Mode = 6.1ch**

An F knob for controlling the front divergence and an R knob for controlling the rear divergence are displayed. Use these two knobs to specify the proportion (0–100) at which a signal positioned in the center will be sent to the center buses (C, S, Bs) and the left/right buses (L, R, Ls, Rs).

In 6.1ch mode, a LINK button that links the front and rear divergence is displayed between the F knob and R knob. When you turn the LINK button on, the F knob value will be copied to the R knob, and the F knob and R knob values will be linked.



**③ LFE (Low Frequency Effect)**

This adjusts the output level of the signal sent from the input channel to the LFE (Low Frequency Effect) bus for a subwoofer. You can use the ON/OFF button to switch the signal sent from the input channel to the LFE bus on/off.

The LFE knob and ON/OFF button are displayed only when the surround mode is 5.1ch or 6.1ch.



**⑧ STEREO LINK**


This specifies whether sound image movement will be linked between the two channels shown in the screen. To link the movement of the two channels, use the / buttons at left and right to select one of the eight link patterns. (For details on how each pattern will operate, refer to p.136)

**⑨ SURROUND MODE**

This indicates the currently selected surround mode.

**⑩ Level meters**

These meters show the master levels of the surround buses.



**④ Surround pan grid**

This grid lets you control the surround panning, with the listening point at the center. The current setting is indicated by a O symbol.

**⑤ Position buttons**

These buttons correspond to each surround bus. When you click a button, the surround panning will move to that position.

**⑥ SURROUND BUS ON/OFF buttons**



These buttons are on/off switches for the signal sent from the input channel to the corresponding surround bus.

**⑦ Surround pan position**

This indicates the coordinate locations of the O symbol in the left/right direction and the front/rear direction.

## SURR VIEW (Surround view) screen



This screen shows the surround settings for each input channel. From this screen you can also jump to the SURR PARAM screen for the desired channel.



- ① **Surround pan grid**  
For each input channel, the approximate surround pan position is shown by the O symbol. If you click this area, the SURR PARAM screen for that channel will appear.
- ② **Surround pan position**  
This indicates the surround pan coordinate positions in the left/right direction (L/R) and the front/rear direction (F/R).
- ③ **Channel**  
This is the number and name of the input channel.

## M/S screen

For two adjacent odd-numbered/even-numbered input channels (or ST IN channel L/R), these settings convert the two-channel signal from an MS mic into L/R signals.



- ① **S-GAIN knob**  
This knob sets the proportionate level of the S mic relative to the level of the M mic. The current value is shown in the numerical box at the right.  
At the MONO position, the S mic level will be at  $-\infty$ , at the STEREO position the M mic and S mic will be at the same level, and at the EXP.ST position the S mic level will be +10 dB.
- ② **M/S DECODE ON/OFF**  
This button switches M/S decoding on/off for two adjacent odd-numbered/even-numbered input channels (or ST IN channel L/R). M/S decoding can be switched on even for channels that are not assigned as a stereo pair.
- ③ **Channel**  
This is the number and name of the input channel.

### Hint


M/S is a stereo recording technique in which two microphones are used; a uni-directional M (Middle) mic and a bi-directional S (Side) mic. The M mic captures the main signal and the S mic captures the directional signal, and the sum (M+S) and difference (M-S) of the two signals (this procedure is known as "decoding") is recorded on the L and R channels respectively.

# INPUT VIEW function

## CH VIEW (Channel view) screen


This screen lists the mix parameters of the currently selected input channel. In this screen you can also edit the principal parameters and access other screens.

### CH VIEW




- ① **Channel**  
This is the number of the input channel you are editing. If the input channel is paired (or if a ST IN channel is selected), a heart symbol is displayed at the right. You can click this symbol to enable/disable pairing for the input channel.
- ② **HA (Head Amp)**  
This area indicates the input port that is patched to the input channel, the setting of the internal head amp (PM5D-RH model only) or external head amp, and the input level. In this screen you can also adjust the head amp gain and switch phantom power (+48V) on/off.
- ③ **ATT (Attenuation)**  
This area shows the attenuation and  $\phi$  (phase) settings. You can also adjust the attenuation and switch the phase from this screen.

- ④ **EQ**  
Refer to the explanation of the OUTPUT VIEW function CH VIEW screen (➔ p.245).
- ⑤ **GATE**  
This area shows the amount of gain reduction and the output level of the gate, a mini-graph showing the approximate response of the gate, and the gate on/off status. You can also switch the gate on/off from this screen. If you click the mini-graph, the GATE PARAM screen for that channel will appear.
- ⑥ **COMP (Compressor)**  
Refer to the explanation of the OUTPUT VIEW function CH VIEW screen (➔ p.246).




- ⑦ **DELAY**  
In this area you can view and edit the delay time of the internal delay and its on/off status.
- ⑧ **TO MIX**  
In this area you can specify the send level, output position, and on/off status of the signals sent from the corresponding input channel to MIX buses 1–24. (Operation is the same as in the TO MATRIX area of the OUTPUT VIEW function CH VIEW screen.) Refer to p.246.
- ⑨ **TO STEREO**  
Here you can specify the on/off status, pan, and FOLLOW PAN settings of the signal sent from the corresponding input channel to the STEREO bus.




- ⑩ **DCA group / Mute group**
- ⑪ **Recall safe / Mute safe**  
Refer to the explanation of the OUTPUT VIEW function CH VIEW screen (➔ p.246).
- ⑫ **DIRECT**  
Turns direct output on/off for the corresponding input channel.
- ⑬ **INSERT**  
Turns insert on/off for the corresponding input channel.
- ⑭ **SURROUND (Surround pan)**  
If surround mode is enabled, the surround pan position of the corresponding input channel is indicated by the O symbol in the surround pan grid and also as a front/rear/left/right coordinate position. If you click the surround pan grid, the SURR PARAM screen for that channel will appear.
- ⑮ **LCR**  
Here you can switch LCR mode on/off, and adjust CSR (the level of the CENTER channel relative to the L/R channels) (➔ p.242).
- ⑯ **LIBRARY**  
This button accesses the INPUT CH LIBRARY screen (➔ p.289), where you can store/recall input channel library settings.
- ⑰ **Level meter**  
This level meter indicates the input level of the channel.
- ⑱ **Signal detection point**  
This is the point at which the signal level shown in the level meter (⑰) is detected (PRE ATT, PRE GATE, PRE FADER, POST FADER, or POST ON). You can edit this setting by clicking the [ ] / [ ] buttons at the left and right.
- ⑲ **Fader**  
This controls the input level of the channel.
- ⑳ **CUE**
- ㉑ **ON/OFF (Channel on/off)**  
Refer to the explanation of the OUTPUT VIEW function CH VIEW screen (➔ p.247).

## SIGNAL FLOW screen

This screen shows the signal flow for two adjacent odd-numbered/even-numbered input channels or ST IN channels. In this screen you can also edit some of the parameters, and access other screens. You can also determine the location within the signal flow at which clipping occurred.



- ① **Channel**
- ② **Insert**  
Except for the fact that this screen depicts input channels, the contents are the same as the OUTPUT VIEW function SIGNAL FLOW screen. Refer to p.247.
- ③ **Direct out**  
This area displays information about the direct output of the two selected channels (the signal output position, the port patched to direct out, and the direct output on/off status).  
Here you can also select the signal output position (use the [ ] / [ ] buttons at left and right), and switch direct output on/off (use the ON/OFF button).



- ④ **Level meters**  
These meters indicate the levels at various points in the signal flow. Levels are detected at the following locations.
  - PRE ATT (immediately before the attenuator)
  - EQ (immediately before and after the EQ)
  - GATE (immediately before and after the gate)
  - COMP (immediately before and after the compressor)
  - FADER (immediately before and after the fader)

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

- POST ON (immediately after the CH [ON] key)
- INSERT IN (immediately after the insert point)



⑤ **Signal flow**

This area indicates the signal flow of the selected channel. The following parameters are displayed.

- **ATT (Attenuation)**  
Specifies the amount of attenuation immediately after AD conversion for the corresponding channel.
- **HPF (High Pass Filter)**  
Specifies the high pass filter on/off and cutoff frequency for the corresponding channel.
- **EQ (Equalizer)**
- **GATE**
- **COMP (Compressor)**  
These areas show the approximate response of the equalizer, gate, and compressor for the corresponding channel. You can also switch these on/off in this screen, or click a mini-graph to access the individual parameter screen.
- **DELAY**  
Here you can switch the internal delay on/off and edit the delay time.
- **FADER**  
This indicates the input level of the channel. This is linked with the encoder or fader of the corresponding channel.
- **ON/OFF (On/off)**  
Turns the channel on/off. This is linked with the [ON] key of the corresponding channel.
- **TO STEREO**  
Here you can specify the on/off status and pan settings of the signal sent from the corresponding channel to the STEREO bus. These are linked with the [TO STEREO] key and STEREO [PAN] encoder of the corresponding channel.


**Hint**

- If insert or direct out is turned on, the current insert point or direct out point within the signal flow is shown.
- If the signal clips, the signal flow (horizontal line) after clipping is displayed in red. If an output is turned off so that the signal does not flow any further, the subsequent flow is displayed in gray. If PEAK HOLD is on, the flow indication will stay red if clipping occurs even once, making it easier to see that clipping has occurred.

**FADER VIEW screen**

This screen shows the on/off status, level, and cue monitor status of the input channels and DCA groups.


**FADER VIEW**



Except for the fact that this screen is for input channels, DCA groups, and STEREO A/B channels, this is the same as the OUTPUT VIEW function FADER VIEW screen. Refer to p.249.

## CH COPY screen

In this screen you can copy the desired parameter(s) from the selected input channel into a memory buffer, and paste them to the same type of channel (you may select more than one paste-destination).



Except for the fact that these settings are for input channels, this is the same as the OUTPUT VIEW function CH COPY screen. Refer to p.249.

### Note

- The same buffer memory is used to copy channel settings for both input channels and output channels.
- If output channel settings have been copied to the buffer memory, a message of "TYPE CONFLICT!" is displayed in the box at the left, and you cannot paste to an input channel.
- The contents of the buffer memory are erased when the PM5D is powered-off.

## INPUT CH LIBRARY (Input channel library) screen

Here you can recall, store, rename, or delete items in the input channel library.

### INPUT CH LIBRARY



Except for the fact that these settings are for input channels, this is the same as the OUTPUT VIEW function CH LIBRARY screen. Refer to p.251.

Information shown  
in the display

Function  
menu

Global  
functions

Output  
functions

Input  
functions

Appendices

# Appendices

## EQ Library List

#	Title	Parameter				
		LOW	L-MID	H-MID	HIGH	
01	Bass Drum 1		PEAKING	PEAKING	PEAKING	H.SHELF
		G	+3.5 dB	-3.5 dB	0.0 dB	+4.0 dB
		F	100 Hz	265 Hz	1.06 kHz	5.30 kHz
		Q	1.2	10	0.9	—
02	Bass Drum 2		PEAKING	PEAKING	PEAKING	LPF
		G	+8.0 dB	-7.0 dB	+6.0 dB	ON
		F	80 Hz	400 Hz	2.50 kHz	12.5 kHz
		Q	1.4	4.5	2.2	—
03	Snare Drum 1		PEAKING	PEAKING	PEAKING	H.SHELF
		G	-0.5 dB	0.0 dB	+3.0 dB	+4.5 dB
		F	132 Hz	1.00 kHz	3.15 kHz	5.00 kHz
		Q	1.2	4.5	0.11	—
04	Snare Drum 2		L.SHELF	PEAKING	PEAKING	PEAKING
		G	+1.5 dB	-8.5 dB	+2.5 dB	+4.0 dB
		F	180 Hz	335 Hz	2.36 kHz	4.00 kHz
		Q	—	10	0.7	0.1
05	Tom-tom 1		PEAKING	PEAKING	PEAKING	PEAKING
		G	+2.0 dB	-7.5 dB	+2.0 dB	+1.0 dB
		F	212 Hz	670 Hz	4.50 kHz	6.30 kHz
		Q	1.4	10	1.2	0.28
06	Cymbal		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	-2.0 dB	0.0 dB	0.0 dB	+3.0 dB
		F	106 Hz	425 Hz	1.06 kHz	13.2 kHz
		Q	—	8	0.9	—
07	High Hat		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	-4.0 dB	-2.5 dB	+1.0 dB	+0.5 dB
		F	95 Hz	425 Hz	2.80 kHz	7.50 kHz
		Q	—	0.5	1	—
08	Percussion		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	-4.5 dB	0.0 dB	+2.0 dB	0.0 dB
		F	100 Hz	400 Hz	2.80 kHz	17.0 kHz
		Q	—	4.5	0.56	—
09	E. Bass 1		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	-7.5 dB	+4.5 dB	+2.5 dB	0.0 dB
		F	35.5 Hz	112 Hz	2.00 kHz	4.00 kHz
		Q	—	5	4.5	—
10	E. Bass 2		PEAKING	PEAKING	PEAKING	H.SHELF
		G	+3.0 dB	0.0 dB	+2.5 dB	+0.5 dB
		F	112 Hz	112 Hz	2.24 kHz	4.00 kHz
		Q	0.1	5	6.3	—
11	Syn. Bass 1		PEAKING	PEAKING	PEAKING	H.SHELF
		G	+3.5 dB	+8.5 dB	0.0 dB	0.0 dB
		F	85 Hz	950 Hz	4.00 kHz	12.5 kHz
		Q	0.1	8	4.5	—
12	Syn. Bass 2		PEAKING	PEAKING	PEAKING	H.SHELF
		G	+2.5 dB	0.0 dB	+1.5 dB	0.0 dB
		F	125 Hz	180 Hz	1.12 kHz	12.5 kHz
		Q	1.6	8	2.2	—
13	Piano 1		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	-6.0 dB	0.0 dB	+2.0 dB	+4.0 dB
		F	95 Hz	950 Hz	3.15 kHz	7.50 kHz
		Q	—	8	0.9	—

#	Title	Parameter				
		LOW	L-MID	H-MID	HIGH	
14	Piano 2		PEAKING	PEAKING	PEAKING	H.SHELF
		G	+3.5 dB	-8.5 dB	+1.5 dB	+3.0 dB
		F	224 Hz	600 Hz	3.15 kHz	5.30 kHz
		Q	5.6	10	0.7	—
15	E. G. Clean		PEAKING	PEAKING	PEAKING	H.SHELF
		G	+2.0 dB	-5.5 dB	+0.5 dB	+2.5 dB
		F	265 Hz	400 Hz	1.32 kHz	4.50 kHz
		Q	0.18	10	6.3	—
16	E. G. Crunch 1		PEAKING	PEAKING	PEAKING	PEAKING
		G	+4.5 dB	0.0 dB	+4.0 dB	+2.0 dB
		F	140 Hz	1.00 kHz	1.90 kHz	5.60 kHz
		Q	8	4.5	0.63	9
17	E. G. Crunch 2		PEAKING	PEAKING	PEAKING	H.SHELF
		G	+2.5 dB	+1.5 dB	+2.5 dB	0.0 dB
		F	125 Hz	450 Hz	3.35 kHz	19.0 kHz
		Q	8	0.4	0.16	—
18	E. G. Dist. 1		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	+5.0 dB	0.0 dB	+3.5 dB	0.0 dB
		F	355 Hz	950 Hz	3.35 kHz	12.5 kHz
		Q	—	9	10	—
19	E. G. Dist. 2		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	+6.0 dB	-8.5 dB	+4.5 dB	+4.0 dB
		F	315 Hz	1.06 kHz	4.25 kHz	12.5 kHz
		Q	—	10	4	—
20	A. G. Stroke 1		PEAKING	PEAKING	PEAKING	H.SHELF
		G	-2.0 dB	0.0 dB	+1.0 dB	+4.0 dB
		F	106 Hz	1.00 kHz	1.90 kHz	5.30 kHz
		Q	0.9	4.5	3.5	—
21	A. G. Stroke 2		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	-3.5 dB	-2.0 dB	0.0 dB	+2.0 dB
		F	300 Hz	750 Hz	2.00 kHz	3.55 kHz
		Q	—	9	4.5	—
22	A. G. Arpeg. 1		L.SHELF	PEAKING	PEAKING	PEAKING
		G	-0.5 dB	0.0 dB	0.0 dB	+2.0 dB
		F	224 Hz	1.00 kHz	4.00 kHz	6.70 kHz
		Q	—	4.5	4.5	0.12
23	A. G. Arpeg. 2		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	0.0 dB	-5.5 dB	0.0 dB	+4.0 dB
		F	180 Hz	355 Hz	4.00 kHz	4.25 kHz
		Q	—	7	4.5	—
24	Brass Sec.		PEAKING	PEAKING	PEAKING	PEAKING
		G	-2.0 dB	-1.0 dB	+1.5 dB	+3.0 dB
		F	90 Hz	850 Hz	2.12 kHz	4.50 kHz
		Q	2.8	2	0.7	7
25	Male Vocal 1		PEAKING	PEAKING	PEAKING	PEAKING
		G	-0.5 dB	0.0 dB	+2.0 dB	+3.5 dB
		F	190 Hz	1.00 kHz	2.00 kHz	6.70 kHz
		Q	0.11	4.5	0.56	0.11
26	Male Vocal 2		PEAKING	PEAKING	PEAKING	H.SHELF
		G	+2.0 dB	-5.0 dB	-2.5 dB	+4.0 dB
		F	170 Hz	236 Hz	2.65 kHz	6.70 kHz
		Q	0.11	10	5.6	—

#	Title	Parameter				
		LOW	L-MID	H-MID	HIGH	
27	Female Vo. 1		PEAKING	PEAKING	PEAKING	PEAKING
		G	-1.0 dB	+1.0 dB	+1.5 dB	+2.0 dB
		F	118 Hz	400 Hz	2.65 kHz	6.00 kHz
		Q	0.18	0.45	0.56	0.14
28	Female Vo. 2		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	-7.0 dB	+1.5 dB	+1.5 dB	+2.5 dB
		F	112 Hz	335 Hz	2.00 kHz	6.70 kHz
		Q	—	0.16	0.2	—
29	Chorus & Harmo		PEAKING	PEAKING	PEAKING	PEAKING
		G	-2.0 dB	-1.0 dB	+1.5 dB	+3.0 dB
		F	90 Hz	850 Hz	2.12 kHz	4.50 kHz
		Q	2.8	2	0.7	7
30	Total EQ 1		PEAKING	PEAKING	PEAKING	H.SHELF
		G	-0.5 dB	0.0 dB	+3.0 dB	+6.5 dB
		F	95 Hz	950 Hz	2.12 kHz	16.0 kHz
		Q	7	2.2	5.6	—
31	Total EQ 2		PEAKING	PEAKING	PEAKING	H.SHELF
		G	+4.0 dB	+1.5 dB	+2.0 dB	+6.0 dB
		F	95 Hz	750 Hz	1.80 kHz	18.0 kHz
		Q	7	2.8	5.6	—
32	Total EQ 3		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	+1.5 dB	+0.5 dB	+2.0 dB	+4.0 dB
		F	67 Hz	850 Hz	1.90 kHz	15.0 kHz
		Q	—	0.28	0.7	—
33	Bass Drum 3		PEAKING	PEAKING	PEAKING	PEAKING
		G	+3.5 dB	-10.0 dB	+3.5 dB	0.0 dB
		F	118 Hz	315 Hz	4.25 kHz	20.0 kHz
		Q	2	10	0.4	0.4
34	Snare Drum 3		L.SHELF	PEAKING	PEAKING	PEAKING
		G	0.0 dB	+2.0 dB	+3.5 dB	0.0 dB
		F	224 Hz	560 Hz	4.25 kHz	4.00 kHz
		Q	—	4.5	2.8	0.1
35	Tom-tom 2		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	-9.0 dB	+1.5 dB	+2.0 dB	0.0 dB
		F	90 Hz	212 Hz	5.30 kHz	17.0 kHz
		Q	—	4.5	1.2	—
36	Piano 3		PEAKING	PEAKING	PEAKING	H.SHELF
		G	+4.5 dB	-13.0 dB	+4.5 dB	+2.5 dB
		F	100 Hz	475 Hz	2.36 kHz	10.0 kHz
		Q	8	10	9	—
37	Piano Low		PEAKING	PEAKING	PEAKING	H.SHELF
		G	-5.5 dB	+1.5 dB	+6.0 dB	0.0 dB
		F	190 Hz	400 Hz	6.70 kHz	12.5 kHz
		Q	10	6.3	2.2	—
38	Piano High		PEAKING	PEAKING	PEAKING	PEAKING
		G	-5.5 dB	+1.5 dB	+5.0 dB	+3.0 dB
		F	190 Hz	400 Hz	6.70 kHz	5.60 kHz
		Q	10	6.3	2.2	0.1
39	Fine-EQ Cass		L.SHELF	PEAKING	PEAKING	H.SHELF
		G	-1.5 dB	0.0 dB	+1.0 dB	+3.0 dB
		F	75 Hz	1.00 kHz	4.00 kHz	12.5 kHz
		Q	—	4.5	1.8	—
40	Narrator		PEAKING	PEAKING	PEAKING	H.SHELF
		G	-4.0 dB	-1.0 dB	+2.0 dB	0.0 dB
		F	106 Hz	710 Hz	2.50 kHz	10.0 kHz
		Q	4	7	0.63	—

## GATE Library List

#	Title	Type	Parameter	Value
1	Gate	GATE	Threshold (dB)	-26
			Range (dB)	-56
			Attack (ms)	0
			Hold (ms)	2.56
			Decay (ms)	331
2	Ducking	DUCKING	Threshold (dB)	-19
			Range (dB)	-22
			Attack (ms)	93
			Decay (ms)	6.32 S
3	A. Dr. BD	GATE	Threshold (dB)	-11
			Range (dB)	-53
			Attack (ms)	0
			Hold (ms)	1.93
			Decay (ms)	400
4	A. Dr. SN	GATE	Threshold (dB)	-8
			Range (dB)	-23
			Attack (ms)	1
			Hold (ms)	0.63
			Decay (ms)	238

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

# Compressor Library List

#	Title	Type	Parameter	Value
1	Comp	COMP	Threshold (dB)	-8
			Ratio ( :1)	2.5
			Attack (ms)	60
			Out gain (dB)	0.0
			Knee	2
			Release (ms)	250
2	Expand	EXPAND	Threshold (dB)	-23
			Ratio ( :1)	1.7
			Attack (ms)	1
			Out gain (dB)	3.5
			Knee	2
			Release (ms)	70
3	Compander (H)	COMPAND-H	Threshold (dB)	-10
			Ratio ( :1)	3.5
			Attack (ms)	1
			Out gain (dB)	0.0
			Width (dB)	6
			Release (ms)	250
4	Compander (S)	COMPAND-S	Threshold (dB)	-8
			Ratio ( :1)	4
			Attack (ms)	25
			Out gain (dB)	0.0
			Width (dB)	24
			Release (ms)	180
5	A. Dr. BD	COMP	Threshold (dB)	-24
			Ratio ( :1)	3
			Attack (ms)	9
			Out gain (dB)	5.5
			Knee	2
			Release (ms)	58
6	A. Dr. BD	COMPAND-H	Threshold (dB)	-11
			Ratio ( :1)	3.5
			Attack (ms)	1
			Out gain (dB)	-1.5
			Width (dB)	7
			Release (ms)	192
7	A. Dr. SN	COMP	Threshold (dB)	-17
			Ratio ( :1)	2.5
			Attack (ms)	8
			Out gain (dB)	3.5
			Knee	2
			Release (ms)	12
8	A. Dr. SN	EXPAND	Threshold (dB)	-23
			Ratio ( :1)	2
			Attack (ms)	0
			Out gain (dB)	0.5
			Knee	2
			Release (ms)	151
9	A. Dr. SN	COMPAND-S	Threshold (dB)	-8
			Ratio ( :1)	1.7
			Attack (ms)	11
			Out gain (dB)	0.0
			Width (dB)	10
			Release (ms)	128
10	A. Dr. Tom	EXPAND	Threshold (dB)	-20
			Ratio ( :1)	2
			Attack (ms)	2
			Out gain (dB)	5.0
			Knee	2
			Release (ms)	749

#	Title	Type	Parameter	Value
11	A. Dr. OverTop	COMPAND-S	Threshold (dB)	-24
			Ratio ( :1)	2
			Attack (ms)	38
			Out gain (dB)	-3.5
			Width (dB)	54
			Release (ms)	842
12	E. B. Finger	COMP	Threshold (dB)	-12
			Ratio ( :1)	2
			Attack (ms)	15
			Out gain (dB)	4.5
			Knee	2
			Release (ms)	470
13	E. B. Slap	COMP	Threshold (dB)	-12
			Ratio ( :1)	1.7
			Attack (ms)	6
			Out gain (dB)	4.0
			Knee	hard
			Release (ms)	133
14	Syn. Bass	COMP	Threshold (dB)	-10
			Ratio ( :1)	3.5
			Attack (ms)	9
			Out gain (dB)	3.0
			Knee	hard
			Release (ms)	250
15	Piano1	COMP	Threshold (dB)	-9
			Ratio ( :1)	2.5
			Attack (ms)	17
			Out gain (dB)	1.0
			Knee	hard
			Release (ms)	238
16	Piano2	COMP	Threshold (dB)	-18
			Ratio ( :1)	3.5
			Attack (ms)	7
			Out gain (dB)	6.0
			Knee	2
			Release (ms)	174
17	E. Guitar	COMP	Threshold (dB)	-8
			Ratio ( :1)	3.5
			Attack (ms)	7
			Out gain (dB)	2.5
			Knee	4
			Release (ms)	261
18	A. Guitar	COMP	Threshold (dB)	-10
			Ratio ( :1)	2.5
			Attack (ms)	5
			Out gain (dB)	1.5
			Knee	2
			Release (ms)	238
19	Strings1	COMP	Threshold (dB)	-11
			Ratio ( :1)	2
			Attack (ms)	33
			Out gain (dB)	1.5
			Knee	2
			Release (ms)	749
20	Strings2	COMP	Threshold (dB)	-12
			Ratio ( :1)	1.5
			Attack (ms)	93
			Out gain (dB)	1.5
			Knee	4
			Release (ms)	1.35 S

#	Title	Type	Parameter	Value
21	Strings3	COMP	Threshold (dB)	-17
			Ratio ( :1)	1.5
			Attack (ms)	76
			Out gain (dB)	2.5
			Knee	2
			Release (ms)	186
22	BrassSection	COMP	Threshold (dB)	-18
			Ratio ( :1)	1.7
			Attack (ms)	18
			Out gain (dB)	4.0
			Knee	1
			Release (ms)	226
23	Syn. Pad	COMP	Threshold (dB)	-13
			Ratio ( :1)	2
			Attack (ms)	58
			Out gain (dB)	2.0
			Knee	1
			Release (ms)	238
24	SamplingPerc	COMPAND-S	Threshold (dB)	-18
			Ratio ( :1)	1.7
			Attack (ms)	8
			Out gain (dB)	-2.5
			Width (dB)	18
			Release (ms)	238
25	Sampling BD	COMP	Threshold (dB)	-14
			Ratio ( :1)	2
			Attack (ms)	2
			Out gain (dB)	3.5
			Knee	4
			Release (ms)	35
26	Sampling SN	COMP	Threshold (dB)	-18
			Ratio ( :1)	4
			Attack (ms)	8
			Out gain (dB)	8.0
			Knee	hard
			Release (ms)	354
27	Hip Comp	COMPAND-S	Threshold (dB)	-23
			Ratio ( :1)	20
			Attack (ms)	15
			Out gain (dB)	0.0
			Width (dB)	15
			Release (ms)	163
28	Solo Vocal1	COMP	Threshold (dB)	-20
			Ratio ( :1)	2.5
			Attack (ms)	31
			Out gain (dB)	2.0
			Knee	1
			Release (ms)	342
29	Solo Vocal2	COMP	Threshold (dB)	-8
			Ratio ( :1)	2.5
			Attack (ms)	26
			Out gain (dB)	1.5
			Knee	3
			Release (ms)	331
30	Chorus	COMP	Threshold (dB)	-9
			Ratio ( :1)	1.7
			Attack (ms)	39
			Out gain (dB)	2.5
			Knee	2
			Release (ms)	226

#	Title	Type	Parameter	Value
31	Click Erase	EXPAND	Threshold (dB)	-33
			Ratio ( :1)	2
			Attack (ms)	1
			Out gain (dB)	2.0
			Knee	2
			Release (ms)	284
32	Announcer	COMPAND-H	Threshold (dB)	-14
			Ratio ( :1)	2.5
			Attack (ms)	1
			Out gain (dB)	-2.5
			Width (dB)	18
			Release (ms)	180
33	Limiter1	COMPAND-S	Threshold (dB)	-9
			Ratio ( :1)	3
			Attack (ms)	20
			Out gain (dB)	-3.0
			Width (dB)	90
			Release (ms)	3.90 s
34	Limiter2	COMP	Threshold (dB)	0
			Ratio ( :1)	∞
			Attack (ms)	0
			Out gain (dB)	0.0
			Knee	hard
			Release (ms)	319
35	Total Comp1	COMP	Threshold (dB)	-18
			Ratio ( :1)	3.5
			Attack (ms)	94
			Out gain (dB)	2.5
			Knee	hard
			Release (ms)	447
36	Total Comp2	COMP	Threshold (dB)	-16
			Ratio ( :1)	6
			Attack (ms)	11
			Out gain (dB)	6.0
			Knee	1
			Release (ms)	180

Information shown  
in the display

Function  
menu

Global  
functions

Output  
functions

Input  
functions

Appendices

# Dynamics Parameters

Each channel has a GATE section (input channels and ST IN channels only) and a COMP section. The Gate section includes Gate and Ducking types. The Comp section includes Compressor, Expander, Compressor Hard (COMP. (H)), and Compressor Soft (COMP. (S)) types.


## GATE section

### GATE


A gate attenuates signals below a set THRESHOLD level by a specified amount (RANGE).

Parameter	Range	Description
THRESHOLD (dB)	-54.0 to 0.0 (541 points)	This determines the level at which the gate effect is applied.
RANGE (dB)	-70 to 0 (71 points)	This determines the amount of attenuation when the gate closes.
ATTACK (ms)	0-120 (121 points)	This determines how fast the gate opens when the signal exceeds the threshold level.
HOLD (ms)	44.1kHz: 0.02 ms - 2.13 sec 48kHz: 0.02 ms - 1.96 sec 88.2kHz: 0.01 ms - 1.06 sec 96kHz: 0.01 ms - 981 ms (160 points)	This determines how long the gate stays open once the trigger signal has fallen below the threshold.
DECAY (ms)	44.1kHz: 6 ms - 46.0 sec 48kHz: 5 ms - 42.3 sec 88.2kHz: 3 ms - 23.0 sec 96kHz: 3 ms - 21.1 sec (160 points)	This determines how fast the gate closes once the hold time has expired. The value is expressed as the duration required for the level to change by 6 dB.

• I/O Characteristics



• Time Series Analysis




### DUCKING


Ducking is commonly used for voice-over applications in which the background music level is reduced automatically when an announcer speaks. When the KEY IN source signal level exceeds the specified THRESHOLD, the output level is attenuated by a specified amount (RANGE).

Parameter	Range	Description
THRESHOLD (dB)	-54.0 to 0.0 (541 points)	This determines the level of trigger signal (KEY IN) required to activate ducking.
RANGE (dB)	-70 to 0 (71 points)	This determines the amount of attenuation when ducking is activated.
ATTACK (ms)	0-120 (121 points)	This determines how soon the signal is ducked once the ducker has been triggered.
HOLD (ms)	44.1kHz: 0.02 ms - 2.13 sec 48kHz: 0.02 ms - 1.96 sec 88.2kHz: 0.01 ms - 1.06 sec 96kHz: 0.01 ms - 981 ms (160 points)	This determines how long ducking remains active once the trigger signal has fallen below the THRESHOLD level.
DECAY (ms)	44.1kHz: 6 ms - 46.0 sec 48kHz: 5 ms - 42.3 sec 88.2kHz: 3 ms - 23.0 sec 96kHz: 3 ms - 21.1 sec (160 points)	This determines how soon the ducker returns to its normal gain once the trigger signal level drops below the threshold. The value is expressed as the duration required for the level to change by 6 dB.

• I/O Characteristics



• Time Series Analysis




## COMP section

### Compressor (COMP)


The COMP processor attenuates signals above a specified THRESHOLD by a specified RATIO. The COMP processor can also be used as a limiter, which, with a RATIO of  $\infty:1$ , reduces the level to the threshold. This means that the limiter's output level never actually exceeds the threshold.

Parameter	Range	Description
THRESHOLD (dB)	-54.0 to 0.0 (541 points)	This determines the level of input signal required to trigger the compressor.
RATIO	1.0:1, 1.1:1, 1.3:1, 1.5:1, 1.7:1, 2.0:1, 2.5:1, 3.0:1, 3.5:1, 4.0:1, 5.0:1, 6.0:1, 8.0:1, 10:1, 20:1, $\infty:1$ (16 points)	This determines the amount of compression, that is, the change in output signal level relative to change in input signal level.
ATTACK (ms)	0-120 (121 points)	This determines how soon the signal will be compressed once the compressor has been triggered.
RELEASE (ms)	44.1kHz: 6 ms - 46.0 sec 48kHz: 5 ms - 42.3 sec 88.2kHz: 3 ms - 23.0 sec 96kHz: 3 ms - 21.1 sec (160 points)	This determines how soon the compressor returns to its normal gain once the trigger signal level drops below the threshold. The value is expressed as the duration required for the level to change by 6 dB.
OUT GAIN (dB)	0.0 to +18.0 (180 points)	This sets the compressor's output signal level.
KNEE	Hard, 1-5 (6 points)	This determines how compression is applied at the threshold. For higher knee settings, compression is applied gradually as the signal exceeds the specified threshold, creating a more natural sound.

- I/O Characteristics (KNEE= hard, OUT GAIN=0.0dB)



- Time Series Analysis (RATIO=  $\infty:1$ )




### Expander (EXPAND)


An expander attenuates signals below a specified THRESHOLD by a specified RATIO.

Parameter	Range	Description
THRESHOLD (dB)	-54.0 to 0.0 (541 points)	This determines the level of input signal required to trigger the expander.
RATIO	1.0:1, 1.1:1, 1.3:1, 1.5:1, 1.7:1, 2.0:1, 2.5:1, 3.0:1, 3.5:1, 4.0:1, 5.0:1, 6.0:1, 8.0:1, 10:1, 20:1, $\infty:1$ (16 points)	This determines the amount of expansion.
ATTACK (ms)	0-120 (121 points)	This determines how soon the expander returns to its normal gain once the trigger signal level exceeds the threshold.
RELEASE (ms)	44.1kHz: 6 ms - 46.0 sec 48kHz: 5 ms - 42.3 sec 88.2kHz: 3 ms - 23.0 sec 96kHz: 3 ms - 21.1 sec (160 points)	This determines how soon the signal is expanded once the signal level drops below the threshold. The value is expressed as the duration required for the level to change by 6 dB.
OUT GAIN (dB)	0.0 to +18.0 (180 points)	This sets the expander's output signal level.
KNEE	Hard, 1-5 (6 points)	This determines how expansion is applied at the threshold. For higher knee settings, expansion is applied gradually as the signal falls below the specified threshold, creating a more natural sound.

- I/O Characteristics (KNEE= hard, OUT GAIN= 0.0dB)




- Time Series Analysis (RATIO=  $\infty:1$ )



❑ **COMPANDER HARD (COMP.(H))**

❑ **COMPANDER SOFT (COMP.(S))**

The hard and soft companders combine the effects of the compressor, expander and limiter.



The companders function differently at the following levels:

- ① **0 dB and higher** ..... Functions as a limiter.
- ② **Exceeding the threshold** ..... Functions as a compressor.
- ③ **Below the threshold and width** ... Functions as an expander.

The hard compander has an expansion ratio of 5:1, while the soft compander has an expansion ratio of 1.5:1. The expander is essentially turned off when the width is set to maximum. The compressor has a fixed knee setting of 2.

\* The gain is automatically adjusted according to the ratio and threshold values, and can be increased by up to 18 dB.

\* The OUT GAIN parameter enables you to compensate for the overall level change caused by the compression and expansion processes.

Parameter	Range	Description
<b>THRESHOLD (dB)</b>	-54.0 to 0.0 (541 points)	This determines the level at which compression is applied.
<b>RATIO</b>	1.0:1, 1.1:1, 1.3:1, 1.5:1, 1.7:1, 2.0:1, 2.5:1, 3.0:1, 3.5:1, 4.0:1, 5.0:1, 6.0:1, 8.0:1, 10:1, 20:1, (15 points)	This determines the amount of compression.
<b>ATTACK (ms)</b>	0-120 (121 points)	This determines how soon the signal is compressed or expanded once the compander has been triggered.
<b>RELEASE (ms)</b>	44.1kHz: 6 ms – 46.0 sec 48kHz: 5 ms – 42.3 sec 88.2kHz: 3 ms – 23.0 sec 96kHz: 3 ms – 21.1 sec (160 points)	This determines how soon the compressor or expander returns to the normal gain once the trigger signal level drops below or exceeds the threshold respectively. The value is expressed as the duration required for the level to change by 6 dB.
<b>OUT GAIN (dB)</b>	-18.0 to 0.0 (180 points)	This sets the compander's output signal level.
<b>WIDTH (dB)</b>	0-90 (91 points)	This determines how far below the threshold expansion will be applied. The expander is activated when the level drops below the threshold and width.

# Effect Library List

This is a list of the built-in effects. By installing a separately sold Add-On Effects package you can add new effect types to number 49 and following.

No.	Title	Type	Description
001	Reverb Hall	REVERB HALL	Concert hall reverberation simulation with gate
002	Reverb Room	REVERB ROOM	Room reverberation simulation with gate
003	Reverb Stage	REVERB STAGE	Reverb designed for vocals, with gate
004	Reverb Plate	REVERB PLATE	Plate reverb simulation with gate
005	Early Ref.	EARLY REF.	Early reflections without the subsequent reverb
006	Gate Reverb	GATE REVERB	Gated early reflections
007	Reverse Gate	REVERSE GATE	Gated reverse early reflections
008	Mono Delay	MONO DELAY	Simple mono delay
009	Stereo Delay	STEREO DELAY	Simple stereo delay
010	Mod.Delay	MOD.DELAY	Simple repeat delay with modulation
011	Delay LCR	DELAY LCR	3-tap (left, center, right) delay
012	Echo	ECHO	Stereo delay with crossed left/right feedback
013	Chorus	CHORUS	Chorus
014	Flange	FLANGE	Flanger
015	Symphonic	SYMPHONIC	Proprietary Yamaha effect that produces a richer and more complex modulation than normal chorus
016	Phaser	PHASER	16-stage stereo phase shifter
017	Auto Pan	AUTO PAN	Auto-panner
018	Tremolo	TREMOLO	Tremolo
019	HQ. Pitch	HQ.PITCH	Mono pitch shifter, producing stable results
020	Dual Pitch	DUAL PITCH	Stereo pitch shifter
021	Rotary	ROTARY	Rotary speaker simulation
022	Ring Mod.	RING MOD.	Ring modulator
023	Mod.Filter	MOD.FILTER	Modulated filter
024	Distortion	DISTORTION	Distortion
025	Amp Simulate	AMP SIMULATE	Guitar amp simulation
026	Dyna.Filter	DYNA.FILTER	Dynamically controlled filter
027	Dyna.Flange	DYNA.FLANGE	Dynamically controlled flanger
028	Dyna.Phaser	DYNA.PHASER	Dynamically controlled phase shifter
029	Rev+Chorus	REV+CHORUS	Reverb and chorus in parallel
030	Rev→Chorus	REV→CHORUS	Reverb and chorus in series
031	Rev+Flange	REV+FLANGE	Reverb and flanger in parallel
032	Rev→Flange	REV→FLANGE	Reverb and flanger in series
033	Rev+Sympho.	REV+SYMPHO.	Reverb and symphonic in parallel
034	Rev→Sympho.	REV→SYMPHO.	Reverb and symphonic in series
035	Rev→Pan	REV→PAN	Reverb and auto-pan in series
036	Delay+Er.	DELAY+ER.	Delay and early reflections in parallel
037	Delay+Er.	DELAY→ER.	Delay and early reflections in series
038	Delay+Rev	DELAY+REV	Delay and reverb in parallel
039	Delay→Rev	DELAY→REV	Delay and reverb in series
040	Dist→Delay	DIST→DELAY	Distortion and delay in series

No.	Title	Type	Description
041	Multi.Filter	MULTI.FILTER	3-band parallel filter (24 dB/octave)
042	Freeze	FREEZE	Simple sampler
043	Stereo Reverb	ST REVERB	Stereo reverb
044	M.Band Dyna.	M.BAND DYNA.	Multi-band dynamics processor
045	M.Band Comp	M.BAND COMP	Multi-band compressor
046	REV-X Hall	REV-X HALL	New reverb algorithm that delivers dense and rich reverberation, smooth decay, and provides a spaciousness and depth that enhances the original sound. Choose from three types depending on your location and needs; REV-X HALL, REV-X ROOM, and REV-X PLATE.
047	REV-X Room	REV-X ROOM	
048	REV-X Plate	REV-X PLATE	
049	Comp276 *	COMP276 *	—
050	Comp276S *	COMP276S *	—
051	Comp260*	COMP260*	—
052	Comp260S *	COMP260S *	—
053	Equalizer601 *	EQUALIZER601*	—
054	OpenDeck *	OPENDECK *	—

\* These library numbers are reserved for the installation of Add-On Effects. Effects that are not installed are grayed-out and unavailable.

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

## Effects Parameters

### REVERB HALL, REVERB ROOM, REVERB STAGE, REVERB PLATE

One input, two output hall, room, stage, and plate reverb simulations, all with gates.

Parameter	Range	Description
REV TIME	0.3–99.0 s	Reverb time
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
HI. RATIO	0.1–1.0	High-frequency reverb time ratio
LO. RATIO	0.1–2.4	Low-frequency reverb time ratio
DIFF.	0–10	Reverb diffusion (left–right reverb spread)
DENSITY	0–100%	Reverb density
E/R DLY	0.0–100.0 ms	Delay between early reflections and reverb
E/R BAL.	0–100%	Balance of early reflections and reverb (0% = all reverb, 100% = all early reflections)
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
GATE LVL	OFF, –60 to 0 dB	Level at which gate kicks in
ATTACK	0–120 ms	Gate opening speed
HOLD	*1	Gate open time
DECAY	*2	Gate closing speed

\*1. 0.02 ms–2.13 s (fs=44.1 kHz), 0.02 ms–1.96 s (fs=48 kHz), 0.01 ms–1.06 s (fs=88.2 kHz), 0.01 ms–981 ms (fs=96 kHz)

\*2. 6.0 ms–46.0 s (fs=44.1 kHz), 5.0 ms–42.3 s (fs=48 kHz), 3 ms–23.0 s (fs=88.2 kHz), 3 ms–21.1 s (fs=96 kHz)

### EARLY REF.

One input, two output early reflections.

Parameter	Range	Description
TYPE	S-Hall, L-Hall, Random, Revers, Plate, Spring	Type of early reflection simulation
ROOMSIZE	0.1–20.0	Reflection spacing
LIVENESS	0–10	Early reflections decay characteristics (0 = dead, 10 = live)
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
DIFF.	0–10	Reflection diffusion (left–right reflection spread)
DENSITY	0–100%	Reflection density
ER NUM.	1–19	Number of early reflections
FB GAIN	–99 to +99%	Feedback gain
HI. RATIO	0.1–1.0	High-frequency feedback ratio
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency

### GATE REVERB, REVERSE GATE

One input, two output early reflections with gate, and early reflections with reverse gate.

Parameter	Range	Description
TYPE	Type-A, Type-B	Type of early reflection simulation
ROOMSIZE	0.1–20.0	Reflection spacing
LIVENESS	0–10	Early reflections decay characteristics (0 = dead, 10 = live)
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
DIFF.	0–10	Reflection diffusion (left–right reflection spread)
DENSITY	0–100%	Reflection density
HI. RATIO	0.1–1.0	High-frequency feedback ratio
ER NUM.	1–19	Number of early reflections
FB GAIN	–99 to +99%	Feedback gain
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency

### MONO DELAY

One input, one output basic repeat delay.

Parameter	Range	Description
DELAY	0.0–2730.0 ms	Delay time
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
HI. RATIO	0.1–1.0	High-frequency feedback ratio
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine DELAY

\*1.  Max. value depends on tempo setting)

### STEREO DELAY

Two input, two output basic stereo delay.


Parameter	Range	Description
DELAY L	0.0–1350.0 ms	Left channel delay time
DELAY R	0.0–1350.0 ms	Right channel delay time
FB. G L	–99 to +99%	Left channel feedback (plus values for normal-phase feedback, minus values for reverse-phase feedback)
FB. G R	–99 to +99%	Right channel feedback (plus values for normal-phase feedback, minus values for reverse-phase feedback)
HI. RATIO	0.1–1.0	High-frequency feedback ratio
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE L	*1	Used in conjunction with TEMPO to determine left channel DELAY
NOTE R	1	Used in conjunction with TEMPO to determine right channel DELAY


\*1.  (Maximum value depends on the tempo setting)

## MOD. DELAY

One input, two output basic repeat delay with modulation.

Parameter	Range	Description
DELAY	0.0–2725.0 ms	Delay time
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
HI. RATIO	0.1–1.0	High-frequency feedback ratio
FREQ.	0.05–40.00 Hz	Modulation speed
DEPTH	0–100%	Modulation depth
WAVE	Sine/Tri	Modulation waveform
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
SYNC	OFF/ON	Tempo parameter sync on/off
DLY.NOTE	*1	Used in conjunction with TEMPO to determine DELAY
MOD.NOTE	*2	Used in conjunction with TEMPO to determine FREQ


\*1.  (Maximum value depends on the tempo setting)

\*2. 

## DELAY LCR

One input, two output 3-tap delay (left, center, right).


Parameter	Range	Description
DELAY L	0.0–2730.0 ms	Left channel delay time
DELAY C	0.0–2730.0 ms	Center channel delay time
DELAY R	0.0–2730.0 ms	Right channel delay time
FB. DLY	0.0–2730.0 ms	Feedback delay time
LEVEL L	–100 to +100%	Left channel delay level
LEVEL C	–100 to +100%	Center channel delay level
LEVEL R	–100 to +100%	Right channel delay level
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
HI. RATIO	0.1–1.0	High-frequency feedback ratio
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE L	*1	Used in conjunction with TEMPO to determine DELAY L
NOTE C	1	Used in conjunction with TEMPO to determine DELAY C
NOTE R	1	Used in conjunction with TEMPO to determine DELAY R
NOTE FB	1	Used in conjunction with TEMPO to determine FB. DLY

\*1.  (Maximum value depends on the tempo setting)

## ECHO

Two input, two output stereo delay with crossed feedback loop.


Parameter	Range	Description
DELAY L	0.0–1350.0 ms	Left channel delay time
DELAY R	0.0–1350.0 ms	Right channel delay time
FB.DLY L	0.0–1350.0 ms	Left channel feedback delay time
FB.DLY R	0.0–1350.0 ms	Right channel feedback delay time
FB. G L	–99 to +99%	Left channel feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
FB. G R	–99 to +99%	Right channel feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
L→R FBG	–99 to +99%	Left to right channel feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
R→L FBG	–99 to +99%	Right to left channel feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
HI. RATIO	0.1–1.0	High-frequency feedback ratio
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE L	*1	Used in conjunction with TEMPO to determine DELAY L
NOTE R	1	Used in conjunction with TEMPO to determine DELAY R
NOTE FBL	1	Used in conjunction with TEMPO to determine FB. D L
NOTE FBR	1	Used in conjunction with TEMPO to determine FB. D R

\*1.  (Maximum value depends on the tempo setting)

## CHORUS

Two input, two output chorus effect.

Parameter	Range	Description
FREQ.	0.05–40.00 Hz	Modulation speed
AM DEPTH	0–100%	Amplitude modulation depth
PM DEPTH	0–100%	Pitch modulation depth
MOD. DLY	0.0–500.0 ms	Modulation delay time
WAVE	Sine, Tri	Modulation waveform
LSH F	21.2 Hz–8.00 kHz	Low shelving filter frequency
LSH G	–12 to +12 dB	Low shelving filter gain
EQ F	100 Hz–8.00 kHz	EQ (peaking type) frequency
EQ G	–12 to +12 dB	EQ (peaking type) gain
EQ Q	10.0–0.10	EQ (peaking type) bandwidth
HSF F	50.0 Hz–16.0 kHz	High shelving filter frequency
HSF G	–12 to +12 dB	High shelving filter gain
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine FREQ.

\*1. 

### FLANGE

Two input, two output flange effect.

Parameter	Range	Description
FREQ.	0.05–40.00 Hz	Modulation speed
DEPTH	0–100%	Modulation depth
MOD. DLY	0.0–500.0 ms	Modulation delay time
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
WAVE	Sine, Tri	Modulation waveform
LSH F	21.2 Hz–8.00 kHz	Low shelving filter frequency
LSH G	–12 to +12 dB	Low shelving filter gain
EQ F	100 Hz–8.00 kHz	EQ (peaking type) frequency
EQ G	–12 to +12 dB	EQ (peaking type) gain
EQ Q	10.0–0.10	EQ (peaking type) bandwidth
HSH F	50.0 Hz–16.0 kHz	High shelving filter frequency
HSH G	–12 to +12 dB	High shelving filter gain
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine FREQ.

\*1. 

### SYMPHONIC

Two input, two output symphonic effect.

Parameter	Range	Description
FREQ.	0.05–40.00 Hz	Modulation speed
DEPTH	0–100%	Modulation depth
MOD. DLY	0.0–500.0 ms	Modulation delay time
WAVE	Sine, Tri	Modulation waveform
LSH F	21.2 Hz–8.00 kHz	Low shelving filter frequency
LSH G	–12 to +12 dB	Low shelving filter gain
EQ F	100 Hz–8.00 kHz	EQ (peaking type) frequency
EQ G	–12 to +12 dB	EQ (peaking type) gain
EQ Q	10.0–0.10	EQ (peaking type) bandwidth
HSH F	50.0 Hz–16.0 kHz	High shelving filter frequency
HSH G	–12 to +12 dB	High shelving filter gain
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine FREQ.

\*1. 

### PHASER

Two input, two output 16-stage phaser.

Parameter	Range	Description
FREQ.	0.05–40.00 Hz	Modulation speed
DEPTH	0–100%	Modulation depth
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
OFFSET	0–100	Lowest phase-shifted frequency offset
PHASE	0.00–354.38 degrees	Left and right modulation phase balance
STAGE	2, 4, 6, 8, 10, 12, 14, 16	Number of phase shift stages
LSH F	21.2 Hz–8.00 kHz	Low shelving filter frequency
LSH G	–12 to +12 dB	Low shelving filter gain
HSH F	50.0 Hz–16.0 kHz	High shelving filter frequency
HSH G	–12 to +12 dB	High shelving filter gain
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine FREQ.


\*1. 

### AUTOPAN

Two input, two output autopanner.

Parameter	Range	Description
FREQ.	0.05–40.00 Hz	Modulation speed
DEPTH	0–100%	Modulation depth
DIR.	*1	Panning direction
WAVE	Sine, Tri, Square	Modulation waveform
LSH F	21.2 Hz–8.00 kHz	Low shelving filter frequency
LSH G	–12 to +12 dB	Low shelving filter gain
EQ F	100 Hz–8.00 kHz	EQ (peaking type) frequency
EQ G	–12 to +12 dB	EQ (peaking type) gain
EQ Q	10.0–0.10	EQ (peaking type) bandwidth
HSH F	50.0 Hz–16.0 kHz	High shelving filter frequency
HSH G	–12 to +12 dB	High shelving filter gain
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*2	Used in conjunction with TEMPO to determine FREQ.


\*1. L↔R, L→R, L←R, Turn L, Turn R

\*2. 

### TREMOLO

Two input, two output tremolo effect.


Parameter	Range	Description
FREQ.	0.05–40.00 Hz	Modulation speed
DEPTH	0–100%	Modulation depth
WAVE	Sine, Tri, Square	Modulation waveform
LSH F	21.2 Hz–8.00 kHz	Low shelving filter frequency
LSH G	–12 to +12 dB	Low shelving filter gain
EQ F	100 Hz–8.00 kHz	EQ (peaking type) frequency
EQ G	–12 to +12 dB	EQ (peaking type) gain
EQ Q	10.0–0.10	EQ (peaking type) bandwidth
HSH F	50.0 Hz–16.0 kHz	High shelving filter frequency
HSH G	–12 to +12 dB	High shelving filter gain
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine FREQ.

\*1. 

### HQ. PITCH

One input, two output high-quality pitch shifter.

Parameter	Range	Description
PITCH	–12 to +12 semitones	Pitch shift
FINE	–50 to +50 cents	Pitch shift fine
DELAY	0.0–1000.0 ms	Delay time
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
MODE	1–10	Pitch shift precision
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine DELAY

\*1.  (Maximum value depends on the tempo setting)

## DUAL PITCH

Two input, two output pitch shifter.

Parameter	Range	Description
PITCH 1	-24 to +24 semitones	Channel #1 pitch shift
FINE 1	-50 to +50 cents	Channel #1 pitch shift fine
LEVEL 1	-100 to +100%	Channel #1 level (plus values for normal phase, minus values for reverse phase)
PAN 1	L63 to R63	Channel #1 pan
DELAY 1	0.0-1000.0 ms	Channel #1 delay time
FB. G 1	-99 to +99%	Channel #1 feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
PITCH 2	-24 to +24 semitones	Channel #2 pitch shift
FINE 2	-50 to +50 cents	Channel #2 pitch shift fine
LEVEL 2	-100 to +100%	Channel #2 level (plus values for normal phase, minus values for reverse phase)
PAN 2	L63 to R63	Channel #2 pan
DELAY 2	0.0-1000.0 ms	Channel #2 delay time
FB. G 2	-99 to +99%	Channel #2 feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
MODE	1-10	Pitch shift precision
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE 1	*1	Used in conjunction with TEMPO to determine Channel #1 delay
NOTE 2	1	Used in conjunction with TEMPO to determine Channel #2 delay

\*1.  (Maximum value depends on the tempo setting)

## ROTARY


One input, two output rotary speaker simulator.

Parameter	Range	Description
ROTATE	STOP, START	Rotation stop, start
SPEED	SLOW, FAST	Rotation speed (see SLOW and FAST parameters)
SLOW	0.05-10.00 Hz	SLOW rotation speed
FAST	0.05-10.00 Hz	FAST rotation speed
DRIVE	0-100	Overdrive level
ACCEL	0-10	Acceleration at speed changes
LOW	0-100	Low-frequency filter
HIGH	0-100	High-frequency filter

## RING MOD.

Two input, two output ring modulator.


Parameter	Range	Description
SOURCE	OSC, SELF	Modulation source: oscillator or input signal
OSC FREQ	0.0-5000.0 Hz	Oscillator frequency
FM FREQ.	0.05-40.00 Hz	Oscillator frequency modulation speed
FM DEPTH	0-100%	Oscillator frequency modulation depth
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE FM	*1	Used in conjunction with TEMPO to determine FM FREQ

\*1. 

## MOD. FILTER

Two input, two output modulation filter.

Parameter	Range	Description
FREQ.	0.05-40.00 Hz	Modulation speed
DEPTH	0-100%	Modulation depth
PHASE	0.00-354.38 degrees	Left-channel modulation and right-channel modulation phase difference
TYPE	LPF, HPF, BPF	Filter type: low pass, high pass, band pass
OFFSET	0-100	Filter frequency offset
RESO.	0-20	Filter resonance
LEVEL	0-100	Output level
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine FREQ

\*1. 

## DISTORTION

One input, two output distortion effect.

Parameter	Range	Description
DST TYPE	DST1, DST2, OVD1, OVD2, CRUNCH	Distortion type (DST = distortion, OVD = overdrive)
DRIVE	0-100	Distortion drive
MASTER	0-100	Master volume
tone	-10 to +10	Tone
N. GATE	0-20	Noise reduction

## AMP SIMULATE

One input, two output guitar amp simulator.

Parameter	Range	Description
AMP TYPE	*1	Guitar amp simulation type
DST TYPE	DST1, DST2, OVD1, OVD2, CRUNCH	Distortion type (DST = distortion, OVD = overdrive)
DRIVE	0-100	Distortion drive
MASTER	0-100	Master volume
BASS	0-100	Bass tone control
MIDDLE	0-100	Middle tone control
TREBLE	0-100	High tone control
CAB DEP	0-100%	Speaker cabinet simulation depth
EQ F	100 Hz-8.0 kHz	EQ (peaking type) frequency
EQ G	-12 to +12 dB	EQ (peaking type) gain
EQ Q	10.0-0.10	EQ (peaking type) bandwidth
N. GATE	0-20	Noise reduction

\*1. STK-M1, STK-M2, THRASH, MIDBST, CMB-PG, CMB-VR, CMB-DX, CMB-TW, MINI, FLAT

## DYNA. FILTER

Two input, two output dynamically controlled filter.

Parameter	Range	Description
SOURCE	INPUT, MIDI	Control source: input signal or MIDI Note On velocity
SENSE	0-100	Sensitivity
DIR.	UP, DOWN	Upward or downward frequency change
DECAY	*1	Filter frequency change decay speed
TYPE	LPF, HPF, BPF	Filter type
OFFSET	0-100	Filter frequency offset
RESO.	0-20	Filter resonance
LEVEL	0-100	Output Level

\*1. 6.0 ms-46.0 s (fs=44.1 kHz), 5.0 ms-42.3 s (fs=48 kHz), 3 ms-23.0 s (fs=88.2 kHz), 3 ms-21.1 s (fs=96 kHz)

### □ DYNA. FLANGE

Two input, two output dynamically controlled flanger.

Parameter	Range	Description
SOURCE	INPUT, MIDI	Control source: input signal or MIDI Note On velocity
SENSE	0–100	Sensitivity
DIR.	UP, DOWN	Upward or downward frequency change
DECAY	*1	Decay speed
OFFSET	0–100	Delay time offset
FB.GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
LSH F	21.2 Hz–8.00 kHz	Low shelving filter frequency
LSH G	–12 to +12 dB	Low shelving filter gain
EQ F	100 Hz–8.00 kHz	EQ (peaking type) frequency
EQ G	–12 to +12 dB	EQ (peaking type) gain
EQ Q	10.0–0.10	EQ (peaking type) bandwidth
HSH F	50.0 Hz–16.0 kHz	High shelving filter frequency
HSH G	–12 to +12 dB	High shelving filter gain

\*1. 6.0 ms–46.0 s (fs=44.1 kHz), 5.0 ms–42.3 s (fs=48 kHz),  
3 ms–23.0 s (fs=88.2 kHz), 3 ms–21.1 s (fs=96 kHz)

### □ DYNA. PHASER

Two input, two output dynamically controlled phaser.


Parameter	Range	Description
SOURCE	INPUT, MIDI	Control source: input signal or MIDI Note On velocity
SENSE	0–100	Sensitivity
DIR.	UP, DOWN	Upward or downward frequency change
DECAY	*1	Decay speed
OFFSET	0–100	Lowest phase-shifted frequency offset
FB.GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
STAGE	2, 4, 6, 8, 10, 12, 14, 16	Number of phase shift stages
LSH F	21.2 Hz–8.00 kHz	Low shelving filter frequency
LSH G	–12 to +12 dB	Low shelving filter gain
HSH F	50.0 Hz–16.0 kHz	High shelving filter frequency
HSH G	–12 to +12 dB	High shelving filter gain

\*1. 6.0 ms–46.0 s (fs=44.1 kHz), 5.0 ms–42.3 s (fs=48 kHz),  
3 ms–23.0 s (fs=88.2 kHz), 3 ms–21.1 s (fs=96 kHz)

### □ REV+CHORUS

One input, two output reverb and chorus effects in parallel.


Parameter	Range	Description
REV TIME	0.3–99.0 s	Reverb time
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
HI. RATIO	0.1–1.0	High-frequency reverb time ratio
DIFF.	0–10	Spread
DENSITY	0–100%	Reverb density
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
REV/CHO	0–100%	Reverb and chorus balance (0% = all reverb, 100% = all chorus)
FREQ.	0.05–40.00 Hz	Modulation speed
AM DEPTH	0–100%	Amplitude modulation depth
PM DEPTH	0–100%	Pitch modulation depth
MOD. DLY	0.0–500.0 ms	Modulation delay time
WAVE	Sine, Tri	Modulation waveform
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine FREQ.

\*1. 

### □ REV→CHORUS

One input, two output reverb and chorus effects in series.


Parameter	Range	Description
REV TIME	0.3–99.0 s	Reverb time
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
HI. RATIO	0.1–1.0	High-frequency reverb time ratio
DIFF.	0–10	Spread
DENSITY	0–100%	Reverb density
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
REV.BAL	0–100%	Reverb and chorused reverb balance (0% = all chorused reverb, 100% = all reverb)
FREQ.	0.05–40.00 Hz	Modulation speed
AM DEPTH	0–100%	Amplitude modulation depth
PM DEPTH	0–100%	Pitch modulation depth
MOD. DLY	0.0–500.0 ms	Modulation delay time
WAVE	Sine, Tri	Modulation waveform
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine FREQ.

\*1. 

## REV+FLANGE

One input, two output reverb and flanger effects in parallel.


Parameter	Range	Description
REV TIME	0.3–99.0 s	Reverb time
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
HI. RATIO	0.1–1.0	High-frequency reverb time ratio
DIFF.	0–10	Spread
DENSITY	0–100%	Reverb density
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
REV/FLG	0–100%	Reverb and flange balance (0% = all reverb, 100% = all flange)
FREQ.	0.05–40.00 Hz	Modulation speed
DEPTH	0–100%	Modulation depth
MOD. DLY	0.0–500.0 ms	Modulation delay time
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
WAVE	Sine, Tri	Modulation waveform
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine FREQ.

\*1. 

## REV→FLANGE

One input, two output reverb and flanger effects in series.


Parameter	Range	Description
REV TIME	0.3–99.0 s	Reverb time
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
HI. RATIO	0.1–1.0	High-frequency reverb time ratio
DIFF.	0–10	Spread
DENSITY	0–100%	Reverb density
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
REV.BAL	0–100%	Reverb and flanged reverb balance (0% = all flanged reverb, 100% = all reverb)
FREQ.	0.05–40.00 Hz	Modulation speed
DEPTH	0–100%	Modulation depth
MOD. DLY	0.0–500.0 ms	Modulation delay time
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
WAVE	Sine, Tri	Modulation waveform
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine FREQ.

\*1. 

## REV+SYMPHO.

One input, two output reverb and symphonic effects in parallel.


Parameter	Range	Description
REV TIME	0.3–99.0 s	Reverb time
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
HI. RATIO	0.1–1.0	High-frequency reverb time ratio
DIFF.	0–10	Spread
DENSITY	0–100%	Reverb density
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
REV/SYM	0–100%	Reverb and symphonic balance (0% = all reverb, 100% = all symphonic)
FREQ.	0.05–40.00 Hz	Modulation speed
DEPTH	0–100%	Modulation depth
MOD. DLY	0.0–500.0 ms	Modulation delay time
WAVE	Sine, Tri	Modulation waveform
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine FREQ.

\*1. 

## REV→SYMPHO.

One input, two output reverb and symphonic effects in series.

Parameter	Range	Description
REV TIME	0.3–99.0 s	Reverb time
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
HI. RATIO	0.1–1.0	High-frequency reverb time ratio
DIFF.	0–10	Spread
DENSITY	0–100%	Reverb density
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
REV.BAL	0–100%	Reverb and symphonic reverb balance (0% = all symphonic reverb, 100% = all reverb)
FREQ.	0.05–40.00 Hz	Modulation speed
DEPTH	0–100%	Modulation depth
MOD. DLY	0.0–500.0 ms	Modulation delay time
WAVE	Sine, Tri	Modulation waveform
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*1	Used in conjunction with TEMPO to determine FREQ.

\*1. 

**REV→PAN**

One input, two output reverb and autopan effects in parallel.

Parameter	Range	Description
REV TIME	0.3–99.0 s	Reverb time
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
HI. RATIO	0.1–1.0	High-frequency reverb time ratio
DIFF.	0–10	Spread
DENSITY	0–100%	Reverb density
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
REV.BAL	0–100%	Reverb and panned reverb balance (0% = all panned reverb, 100% = all reverb)
FREQ.	0.05–40.00 Hz	Modulation speed
DEPTH	0–100%	Modulation depth
DIR.	*1	Panning direction
WAVE	Sine, Tri, Square	Modulation waveform
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE	*2	Used in conjunction with TEMPO to determine FREQ.

\*1. L↔R, L→R, L←R, Turn L, Turn R

\*2.

**DELAY+ER.**

One input, two output delay and early reflections effects in parallel.

Parameter	Range	Description
DELAY L	0.0–1000.0 ms	Left channel delay time
DELAY R	0.0–1000.0 ms	Right channel delay time
FB. DLY	0.0–1000.0 ms	Feedback delay time
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
HI. RATIO	0.1–1.0	High-frequency feedback ratio
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
DLY/ER	0–100%	Delay and early reflections balance (0% = all delay, 100% = all early reflections)
TYPE	S-Hall, L-Hall, Random, Revers, Plate, Spring	Type of early reflection simulation
ROOMSIZE	0.1–20.0	Reflection spacing
LIVENESS	0–10	Early reflections decay characteristics (0 = dead, 10 = live)
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
DIFF.	0–10	Spread
DENSITY	0–100%	Reverb density
ER NUM.	1–19	Number of early reflections
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE L	*1	Used in conjunction with TEMPO to determine left channel DELAY L
NOTE R	1	Used in conjunction with TEMPO to determine right channel DELAY R
NOTE FB	1	Used in conjunction with TEMPO to determine FB. DLY

\*1.

**DELAY→ER.**

One input, two output delay and early reflections effects in series.

Parameter	Range	Description
DELAY L	0.0–1000.0 ms	Left channel delay time
DELAY R	0.0–1000.0 ms	Right channel delay time
FB. DLY	0.0–1000.0 ms	Feedback delay time
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
HI. RATIO	0.1–1.0	High-frequency feedback ratio
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
DLY.BAL	0–100%	Delay and early reflected delay balance (0% = all early reflected delay, 100% = all delay)
TYPE	S-Hall, L-Hall, Random, Revers, Plate, Spring	Type of early reflection simulation
ROOMSIZE	0.1–20.0	Reflection spacing
LIVENESS	0–10	Early reflections decay characteristics (0 = dead, 10 = live)
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
DIFF.	0–10	Spread
DENSITY	0–100%	Reverb density
ER NUM.	1–19	Number of early reflections
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE L	*1	Used in conjunction with TEMPO to determine left channel DELAY L
NOTE R	1	Used in conjunction with TEMPO to determine right channel DELAY R
NOTE FB	1	Used in conjunction with TEMPO to determine FB. DLY

\*1.

**DELAY+REV**

One input, two output delay and reverb effects in parallel.

Parameter	Range	Description
DELAY L	0.0–1000.0 ms	Left channel delay time
DELAY R	0.0–1000.0 ms	Right channel delay time
FB. DLY	0.0–1000.0 ms	Feedback delay time
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
DELAY HI	0.1–1.0	Delay high-frequency feedback ratio
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
DLY/REV	0–100%	Delay and reverb balance (0% = all delay, 100% = all reverb)
REV TIME	0.3–99.0 s	Reverb time
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
REV HI	0.1–1.0	High-frequency reverb time ratio
DIFF.	0–10	Spread
DENSITY	0–100%	Reverb density
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE L	*1	Used in conjunction with TEMPO to determine left channel DELAY L
NOTE R	1	Used in conjunction with TEMPO to determine right channel DELAY R
NOTE FB	1	Used in conjunction with TEMPO to determine FB. DLY

\*1.

## □ DELAY→REV

One input, two output delay and reverb effects in series.

Parameter	Range	Description
DELAY L	0.0–1000.0 ms	Left channel delay time
DELAY R	0.0–1000.0 ms	Right channel delay time
FB. DLY	0.0–1000.0 ms	Feedback delay time
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
DELAY HI	0.1–1.0	Delay high-frequency feedback ratio
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency
DLY.BAL	0–100%	Delay and delayed reverb balance (0% = all delayed reverb, 100% = all delay)
REV TIME	0.3–99.0 s	Reverb time
INI. DLY	0.0–500.0 ms	Initial delay before reverb begins
REV HI	0.1–1.0	High-frequency reverb time ratio
DIFF.	0–10	Spread
DENSITY	0–100%	Reverb density
SYNC	OFF/ON	Tempo parameter sync on/off
NOTE L	*1	Used in conjunction with TEMPO to determine left channel DELAY L
NOTE R	*1	Used in conjunction with TEMPO to determine right channel DELAY R
NOTE FB	*1	Used in conjunction with TEMPO to determine FB. DLY

\*1.  (Maximum value depends on the tempo setting)

## □ DIST→DELAY

One input, two output distortion and delay effects in series.

Parameter	Range	Description
DST TYPE	DST1, DST2, OVD1, OVD2, CRUNCH	Distortion type (DST = distortion, OVD = overdrive)
DRIVE	0–100	Distortion drive
MASTER	0–100	Master volume
TONE	–10 to +10	Tone control
N. GATE	0–20	Noise reduction
DELAY	0.0–2725.0 ms	Delay time
FB. GAIN	–99 to +99%	Feedback gain (plus values for normal-phase feedback, minus values for reverse-phase feedback)
HI. RATIO	0.1–1.0	High-frequency feedback ratio
FREQ.	0.05–40.00 Hz	Modulation speed
DEPTH	0–100%	Modulation depth
DLY.BAL	0–100%	Distortion and delay balance (0% = all distortion, 100% = all delayed distortion)
SYNC	OFF/ON	Tempo parameter sync on/off
DLY.NOTE	*1	Used in conjunction with TEMPO to determine DELAY
MOD.NOTE	*2	Used in conjunction with TEMPO to determine FREQ.

\*1.  (Maximum value depends on the tempo setting)

\*2. 

## □ MULTI FILTER

Two input, two output 3-band multi-filter (24 dB/octave).

Parameter	Range	Description
TYPE 1	HPF, LPF, BPF	Filter 1 type: high pass, low pass, band pass
TYPE 2	HPF, LPF, BPF	Filter 2 type: high pass, low pass, band pass
TYPE 3	HPF, LPF, BPF	Filter 3 type: high pass, low pass, band pass
FREQ. 1	28.0 Hz–16.0 kHz	Filter 1 frequency
FREQ. 2	28.0 Hz–16.0 kHz	Filter 2 frequency
FREQ. 3	28.0 Hz–16.0 kHz	Filter 3 frequency
LEVEL 1	0–100	Filter 1 level
LEVEL 2	0–100	Filter 2 level
LEVEL 3	0–100	Filter 3 level
RESO. 1	0–20	Filter 1 resonance
RESO. 2	0–20	Filter 2 resonance
RESO. 3	0–20	Filter 3 resonance

## □ FREEZE

One input, one output basic sampler.

Parameter	Range	Description
REC MODE	MANUAL, INPUT	In MANUAL mode, recording is started by pressing the REC and PLAY buttons. In INPUT mode, Record-Ready mode is engaged by pressing the REC button, and actual recording is triggered by the input signal.
REC DLY	–1000 to +1000 ms	Recording delay. For plus values, recording starts after the trigger is received. For minus values, recording starts before the trigger is received.
TRG LVL	–60 to 0 dB	Input trigger level (i.e., the signal level required to trigger recording or playback)
TRG MASK	0–1000 ms	Once playback has been triggered, subsequent triggers are ignored for the duration of the TRG MASK time.
PLY MODE	MOMENT, CONTI., INPUT	In MOMENT mode, the sample plays only while the that the PLAY button is pressed. In CONT mode, playback continues once the PLAY button has been pressed. The number of times the sample plays is set using the LOOP NUM parameter. In INPUT mode, playback is triggered by the input signal.
START	*1	Playback start point in milliseconds
END	1	Playback end point in milliseconds
LOOP	1	Loop start point in milliseconds
LOOP NUM	0–100	Number of times the sample plays
START [SAMPLE]	0–262000	Playback start point in samples
END [SAMPLE]	0–262000	Playback end point in samples
LOOP [SAMPLE]	0–262000	Loop start point in samples
PITCH	–12 to +12 semi-tones	Playback pitch shift
FINE	–50 to +50 cents	Playback pitch shift fine
MIDI TRG	OFF, C1–C6, ALL	PLAY button can be triggered by using MIDI Note on/off messages.

\*1. 0.0–5941.0 ms (fs=44.1 kHz), 0.0 ms–5458.3 ms (fs=48 kHz), 0.0–2970.5 ms (fs=88.2 kHz), 0.0 ms–2729.2 ms (fs=96 kHz)

## □ ST REVERB

Two input, two output stereo reverb.

Parameter	Range	Description
REV TIME	0.3–99.0 s	Reverb time
REV TYPE	Hall, Room, Stage, Plate	Reverb type
INI. DLY	0.0–100.0 ms	Initial delay before reverb begins
HI. RATIO	0.1–1.0	High-frequency reverb time ratio
LO. RATIO	0.1–2.4	Low-frequency reverb time ratio
DIFF.	0–10	Reverb diffusion (left–right reverb spread)
DENSITY	0–100%	Reverb density
E/R BAL.	0–100%	Balance of early reflections and reverb (0% = all reverb, 100% = all early reflections)
HPF	THRU, 21.2 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	50.0 Hz–16.0 kHz, THRU	Low-pass filter cutoff frequency

## □ M. BAND DYNA.

Two input, two output 3-band dynamics processor, with individual solo and gain reduction metering for each band.

Parameter	Range	Description
LOW GAIN	–96.0 to +12.0 dB	Low band level
MID GAIN	–96.0 to +12.0 dB	Mid band level
HI. GAIN	–96.0 to +12.0 dB	High band level
PRESENCE	–10 to +10	For positive values, the threshold of the high band is lowered and the threshold of the low band is increased. For negative values, the opposite will occur. When set to 0, all three bands are affected the same.
CMP. THRE	–24.0 dB to 0.0 dB	Compressor threshold
CMP. RAT	1:1 to 20:1	Compressor ratio
CMP. ATK	0–120 ms	Compressor attack
CMP. REL	1	Compressor release time
CMP. KNEE	0–5	Compressor knee
LOOKUP	0.0–100.0 ms	Lookup delay
CMP. BYP	ON/OFF	Compressor bypass
L–M XOVR	21.2 Hz–8.00 kHz	Low/mid crossover frequency
M–H XOVR	21.2 Hz–8.00 kHz	Mid/high crossover frequency
SLOPE	–6 dB, –12 dB	Filter slope
CEILING	–6.0 dB to 0.0 dB, OFF	Specifies the maximum output level
EXP. THRE	–54.0 dB to –24.0 dB	Expander threshold
EXP. RAT	1:1 to ∞:1	Expander ratio
EXP. REL	*1	Expander release time
EXP. BYP	ON/OFF	Expander bypass
LIM. THRE	–12.0 dB to 0.0 dB	Limiter threshold
LIM. ATK	0–120 ms	Limiter attack
LIM. REL	1	Limiter release time
LIM. BYP	ON/OFF	Limiter bypass
LIM. KNEE	0–5	Limiter knee

\*1. 6.0 ms–46.0 s (fs=44.1 kHz), 5.0 ms–42.3 s (fs=48 kHz), 3 ms–23.0 s (fs=88.2 kHz), 3 ms–21.1 s (fs=96 kHz)

## □ M.BAND COMP

Two input, two output 3-band compressor, with individual solo and gain reduction metering for each band.

Parameter	Range	Description
LOW GAIN	–96.0 to +12.0 dB	Low band level
MID GAIN	–96.0 to +12.0 dB	Mid band level
HI. GAIN	–96.0 to +12.0 dB	High band level
L–M XOVR	21.2 Hz–8.00 kHz	Low/mid crossover frequency
M–H XOVR	21.2 Hz–8.00 kHz	Mid/high crossover frequency
SLOPE	–6 dB, –12 dB	Filter slope
CEILING	–6.0 dB to 0.0 dB, OFF	Specifies the maximum output level
LOOKUP	0.0–100.0 ms	Lookup delay
LOW THRE	–54.0 dB to 0.0 dB	Low band threshold level
MID THRE	–54.0 dB to 0.0 dB	Mid band threshold level
HI. THRE	–54.0 dB to 0.0 dB	High band threshold level
RATIO	1:1 to 20:1	Compression ratio
ATTACK	0–120 ms	Compressor attack time
CMP. REL	*1	Compressor release time
KNEE	0–5	Compressor knee
BYPASS	ON/OFF	Bypasses the compressor

\*1. 6.0 ms–46.0 s (fs=44.1 kHz), 5.0 ms–42.3 s (fs=48 kHz), 3 ms–23.0 s (fs=88.2 kHz), 3 ms–21.1 s (fs=96 kHz)

## □ REV-X HALL, REV-X ROOM, REV-X PLATE

Newly-developed two input, two output reverb algorithm. Delivers dense and rich reverberation, smooth decay, and provides a spaciousness and depth that enhances the original sound. Choose from three types depending on your location and needs; REV-X HALL, REV-X ROOM, and REV-X PLATE.

Parameter	Range	Description
REV TIME	0.47–46.92 s <sup>*1</sup>	Reverb time
INI. DLY	0.0–120.0 ms	Initial delay before reverb begins
HI. RATIO	0.1–1.0	High-frequency reverb time ratio
LO. RATIO	0.1–2.4	Low-frequency reverb time ratio
LO.FREQ	22.0 Hz–18.0 kHz	Frequency point for LO.RATIO setting
DIFF.	0–10	Reverb diffusion (left–right reverb spread)
ROOM SIZE	0–28	Size of room
DECAY	0–53	Gate closing speed
HPF	THRU, 22.0 Hz–8.00 kHz	High-pass filter cutoff frequency
LPF	1.00 kHz–18.0 kHz, THRU	Low-pass filter cutoff frequency

\*1. These values are for when the effect type is REV-X HALL and the ROOM SIZE=28. The range will differ depending on the effect type and ROOM SIZE setting.

Other preset effects (COMP276, COMP276S, COMP260, COMP260S, EQUALIZER601, OPENDECK) are separately sold Add-On Effects. For details on these effects, refer to the owner's manual included with the Add-On Effects package.

## Effects and tempo synchronization

Some of the PM5D's effects allow you to synchronize the effect with the tempo. There are two such types of effect; delay-type effects and modulation-type effects. For delay-type effects, the delay time will change according to the tempo. For modulation-type effects, the frequency of the modulation signal will change according to the tempo.

### Parameters related to tempo synchronization

The following five parameters are related to tempo synchronization.

1) SYNC 2) NOTE 3) TEMPO 4) DELAY 5) FREQ.

SYNC: ..... This is the on/off switch for tempo synchronization.

NOTE and TEMPO:..... These are the basic parameters for tempo synchronization.

DELAY and FREQ.: ..... DELAY is the delay time, and FREQ. is the frequency of the modulation signal. These directly affect the way in which the effect sound will change. DELAY is relevant only for delay-type effects, and FREQ. is relevant only for modulation-type effects.

### How the parameters are related

Tempo synchronization uses TEMPO and NOTE to calculate a value that will be the basis for the tempo, and continues making adjustments so that this tempo basis stays essentially the same as the DELAY (or FREQ.). This means that when TEMPO, NOTE, and DELAY (or FREQ.) are synchronized, and you change any of these values, the other parameters will be re-set in order to maintain the correct relationship. The parameters that are re-set and the calculation method(\*a) used are as follows.

**If you turn SYNC on → NOTE will be set**

**If you edit DELAY (or FREQ.) → NOTE will be set**

In this case, the NOTE value is calculated as follows.

$$\text{NOTE} = \text{DELAY (or FREQ.)} / (4 \times (60/\text{TEMPO}))$$

**If you edit NOTE → DELAY (or FREQ.) will be set**

In this case, the DELAY (or FREQ.) value is calculated as follows.

$$\text{DELAY (or FREQ.)} = \text{NOTE} \times 4 \times (60/\text{TEMPO})$$

**If you edit TEMPO → DELAY (or FREQ.) will be set**

In this case, the DELAY (or FREQ.) value is calculated as follows.

$$\text{DELAY (or FREQ.)} = \text{original DELAY (or FREQ.)} \times (\text{previous TEMPO/new TEMPO})$$

Example 1: When SYNC=ON, DELAY=250 ms, TEMPO=120, you change NOTE from 8th note to quarter note

$$\text{DELAY} = \text{new NOTE} \times 4 \times (60/\text{TEMPO})$$

$$= (1/4) \times 4 \times (60/120)$$

$$= 0.5 \text{ (sec)}$$

$$= 500 \text{ ms}$$

Thus, the DELAY will change from 250 ms to 500 ms.

Example 2: When SYNC=ON, DELAY=250 ms, NOTE=8th note, you change TEMPO from 120 to 121

$$\text{DELAY} = \text{original DELAY} \times (\text{previous TEMPO/new TEMPO})$$

$$= 250 \times (120/121)$$

$$= 247.9 \text{ (ms)}$$

Thus, the TEMPO will change from 250 ms to 247.9 ms.

\*a Rounded values are used for the calculation results.

### Ranges of the NOTE and TEMPO values

The ranges of the NOTE and TEMPO values are limited by the ranges of the DELAY or FREQ. values. You cannot set NOTE or TEMPO values that would cause DELAY or FREQ. to exceed their maximum possible values when synchronized to tempo. This limitation also applies even when SYNC is OFF.

### Special characteristics of the TEMPO parameter

The TEMPO parameter has the following characteristics that are unlike other parameters.

- It is a common value shared by all effects
- You cannot store it to or recall it from the Effects Library. (You can store it to and recall it from a Scene.)

This means that the TEMPO value may not necessarily be the same when an effect is recalled as when that effect was stored. Here is an example.

Store the effect: TEMPO=120 → Change TEMPO to 60 → Recall the effect: TEMPO=60

Normally when you change the TEMPO, the DELAY (or FREQ.) will be re-set accordingly. However if the DELAY (or FREQ.) were changed, the effect would sound differently when recalled than when it was stored. To prevent the effect from changing in this way between store and recall, the PM5D does not update the DELAY (or FREQ.) value when an effect is recalled, even if the TEMPO is no longer the same as when that effect was stored.

\* The NOTE parameter is calculated based on the following values.

$$\text{♩} = 1/48$$

$$\text{♩} = 1/24$$

$$\text{♪} = 1/16$$

$$\text{♩} = 1/12$$

$$\text{♩} = 3/32$$

$$\text{♪} = 1/8$$

$$\text{♩} = 1/6$$

$$\text{♩} = 3/16$$

$$\text{♪} = 1/4$$

$$\text{♩} = 3/8$$

$$\text{♩} = 1/2$$

$$\text{♩} = 3/4$$

$$\text{♩} = 1/1$$

$$\text{♩} = 2/1$$

# Scene Memory/Effect Library to Program Change Table

## □ Preset Bank/Ch# 1

Program Change#	Scene/Effect	Preset#	Program Change#	Scene/Effect	Preset#
001		001	065		065
002		002	066		066
003		003	067		067
004		004	068		068
005		005	069		069
006		006	070		070
007		007	071		071
008		008	072		072
009		009	073		073
010		010	074		074
011		011	075		075
012		012	076		076
013		013	077		077
014		014	078		078
015		015	079		079
016		016	080		080
017		017	081		081
018		018	082		082
019		019	083		083
020		020	084		084
021		021	085		085
022		022	086		086
023		023	087		087
024		024	088		088
025		025	089		089
026		026	090		090
027		027	091		091
028		028	092		092
029		029	093		093
030		030	094		094
031		031	095		095
032	Scene	032	096	Scene	096
033		033	097		097
034		034	098		098
035		035	099		099
036		036	100		100
037		037	101		101
038		038	102		102
039		039	103		103
040		040	104		104
041		041	105		105
042		042	106		106
043		043	107		107
044		044	108		108
045		045	109		109
046		046	110		110
047		047	111		111
048		048	112		112
049		049	113		113
050		050	114		114
051		051	115		115
052		052	116		116
053		053	117		117
054		054	118		118
055		055	119		119
056		056	120		120
057		057	121		121
058		058	122		122
059		059	123		123
060		060	124		124
061		061	125		125
062		062	126		126
063		063	127		127
064		064	128		128

## □ Preset Bank/Ch# 2

Program Change#	Scene/Effect	Preset#	Program Change#	Scene/Effect	Preset#
001		129	065		193
002		130	066		194
003		131	067		195
004		132	068		196
005		133	069		197
006		134	070		198
007		135	071		199
008		136	072		200
009		137	073		201
010		138	074		202
011		139	075		203
012		140	076		204
013		141	077		205
014		142	078		206
015		143	079		207
016		144	080		208
017		145	081		209
018		146	082		210
019		147	083		211
020		148	084		212
021		149	085		213
022		150	086		214
023		151	087		215
024		152	088		216
025		153	089		217
026		154	090		218
027		155	091		219
028		156	092		220
029		157	093		221
030		158	094		222
031		159	095		223
032	Scene	160	096	Scene	224
033		161	097		225
034		162	098		226
035		163	099		227
036		164	100		228
037		165	101		229
038		166	102		230
039		167	103		231
040		168	104		232
041		169	105		233
042		170	106		234
043		171	107		235
044		172	108		236
045		173	109		237
046		174	110		238
047		175	111		239
048		176	112		240
049		177	113		241
050		178	114		242
051		179	115		243
052		180	116		244
053		181	117		245
054		182	118		246
055		183	119		247
056		184	120		248
057		185	121		249
058		186	122		250
059		187	123		251
060		188	124		252
061		189	125		253
062		190	126		254
063		191	127		255
064		192	128		256

❑ Preset Bank/Ch# 3

Program Change#	Scene/Effect	Preset#	Program Change#	Scene/Effect	Preset#
001		257	065		321
002		258	066		322
003		259	067		323
004		260	068		324
005		261	069		325
006		262	070		326
007		263	071		327
008		264	072		328
009		265	073		329
010		266	074		330
011		267	075		331
012		268	076		332
013		269	077		333
014		270	078		334
015		271	079		335
016		272	080		336
017		273	081		337
018		274	082		338
019		275	083		339
020		276	084		340
021		277	085		341
022		278	086		342
023		279	087		343
024		280	088		344
025		281	089		345
026		282	090		346
027		283	091		347
028		284	092		348
029		285	093		349
030		286	094		350
031		287	095		351
032	Scene	288	096	Scene	352
033		289	097		353
034		290	098		354
035		291	099		355
036		292	100		356
037		293	101		357
038		294	102		358
039		295	103		359
040		296	104		360
041		297	105		361
042		298	106		362
043		299	107		363
044		300	108		364
045		301	109		365
046		302	110		366
047		303	111		367
048		304	112		368
049		305	113		369
050		306	114		370
051		307	115		371
052		308	116		372
053		309	117		373
054		310	118		374
055		311	119		375
056		312	120		376
057		313	121		377
058		314	122		378
059		315	123		379
060		316	124		380
061		317	125		381
062		318	126		382
063		319	127		383
064		320	128		384

❑ Preset Bank/Ch# 4

Program Change#	Scene/Effect	Preset#	Program Change#	Scene/Effect	Preset#
001		385	065		449
002		386	066		450
003		387	067		451
004		388	068		452
005		389	069		453
006		390	070		454
007		391	071		455
008		392	072		456
009		393	073		457
010		394	074		458
011		395	075		459
012		396	076		460
013		397	077		461
014		398	078		462
015		399	079		463
016		400	080		464
017		401	081		465
018		402	082		466
019		403	083		467
020		404	084		468
021		405	085		469
022		406	086		470
023		407	087		471
024		408	088		472
025		409	089		473
026		410	090		474
027		411	091	Scene	475
028		412	092		476
029		413	093		477
030		414	094		478
031		415	095		479
032	Scene	416	096		480
033		417	097		481
034		418	098		482
035		419	099		483
036		420	100		484
037		421	101		485
038		422	102		486
039		423	103		487
040		424	104		488
041		425	105		489
042		426	106		490
043		427	107		491
044		428	108		492
045		429	109		493
046		430	110		494
047		431	111		495
048		432	112		496
049		433	113		497
050		434	114		498
051		435	115		499
052		436	116		500
053		437	117		000
054		438	118		
055		439	119		
056		440	120		
057		441	121		
058		442	122		
059		443	123	No Assign	
060		444	124		
061		445	125		
062		446	126		
063		447	127		
064		448	128		

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

**❑ Preset Bank/Ch# 5**

Program Change#	Scene/Effect	Preset#
001	No Assign	
002		
003		
:		
128		

**❑ Preset Bank/Ch# 6**

Program Change#	Scene/Effect	Preset#
001	No Assign	
002		
003		
:		
128		

**❑ Preset Bank/Ch# 7**

Program Change#	Scene/Effect	Preset#
001	No Assign	
002		
003		
:		
128		

**❑ Preset Bank/Ch# 8**

Program Change#	Scene/Effect	Preset#
001	No Assign	
002		
003		
:		
128		

**❑ Preset Bank/Ch# 9**

Program Change#	Scene/Effect	Preset#
001	Effect1	001
002		002
003		003
:		:
128		128

**❑ Preset Bank/Ch# 10**

Program Change#	Scene/Effect	Preset#
001	Effect2	001
002		002
003		003
:		:
128		128

**❑ Preset Bank/Ch# 11**

Program Change#	Scene/Effect	Preset#
001	Effect3	001
002		002
003		003
:		:
128		128

**❑ Preset Bank/Ch# 12**

Program Change#	Scene/Effect	Preset#
001	Effect4	001
002		002
003		003
:		:
128		128

**❑ Preset Bank/Ch# 13**

Program Change#	Scene/Effect	Preset#
001	Effect5	001
002		002
003		003
:		:
128		128

**❑ Preset Bank/Ch# 14**

Program Change#	Scene/Effect	Preset#
001	Effect6	001
002		002
003		003
:		:
128		128

**❑ Preset Bank/Ch# 15**

Program Change#	Scene/Effect	Preset#
001	Effect7	001
002		002
003		003
:		:
128		128

**❑ Preset Bank/Ch# 16**

Program Change#	Scene/Effect	Preset#
001	Effect8	001
002		002
003		003
:		:
128		128

□ Bank/Ch# \_

Program Change#	Scene/Effect	User#
001		
002		
003		
004		
005		
006		
007		
008		
009		
010		
011		
012		
013		
014		
015		
016		
017		
018		
019		
020		
021		
022		
023		
024		
025		
026		
027		
028		
029		
030		
031		
032		
033		
034		
035		
036		
037		
038		
039		
040		
041		
042		
043		

Program Change#	Scene/Effect	User#
044		
045		
046		
047		
048		
049		
050		
051		
052		
053		
054		
055		
056		
057		
058		
059		
060		
061		
062		
063		
064		
065		
066		
067		
068		
069		
070		
071		
072		
073		
074		
075		
076		
077		
078		
079		
080		
081		
082		
083		
084		
085		
086		

Program Change#	Scene/Effect	User#
087		
088		
089		
090		
091		
092		
093		
094		
095		
096		
097		
098		
099		
100		
101		
102		
103		
104		
105		
106		
107		
108		
109		
110		
111		
112		
113		
114		
115		
116		
117		
118		
119		
120		
121		
122		
123		
124		
125		
126		
127		
128		

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

## Parameters that can be assigned to control changes

MODE	PARAMETER 1	PARAMETER 2
NO ASSIGN	—	—
FADER H	INPUT	CH 1-CH48 STIN1L-STIN4R FXRTN1L-FXRTN4R
	OUTPUT	MIX 1-MIX24 MATRIX 1-MATRIX 8 STEREO AL-STEREO BR
FADER L	INPUT	CH 1-CH48 STIN1L-STIN4R FXRTN1L-FXRTN4R
	OUTPUT	MIX 1-MIX24 MATRIX 1-MATRIX 8 STEREO AL-STEREO BR
CH ON	INPUT	CH 1-CH48 STIN1L-STIN4R FXRTN1L-FXRTN4R
	OUTPUT	MIX 1-MIX24 MATRIX 1-MATRIX 8 STEREO AL-STEREO BR
PHASE	INPUT	CH 1-CH48 STIN1L-STIN4R FXRTN1L-FXRTN4R
INSERT	INPUT	CH 1-CH48 STIN1L-STIN4R
	OUTPUT	MIX 1-MIX24 MATRIX 1-MATRIX 8 STEREO AL-STEREO BR
DIRECT OUT	ON	CH 1-CH48 STIN1L-STIN4R FXRTN1L-FXRTN4R
PAN/BALANCE	INPUT	CH 1-CH48 STIN1L-STIN4R FXRTN1L-FXRTN4R
BALANCE	OUTPUT	MIX 1-MIX24 MATRIX 1-MATRIX 8 STEREO AL-STEREO BR
TO STEREO	ON	CH 1-CH48 STIN1L-STIN4R FXRTN1L-FXRTN4R
LCR	ON	CH 1-CH48 STIN1L-STIN4R FXRTN1L-FXRTN4R
	CSR	MIX 1-MIX24
MIX SEND	PRE POINT	CH 1-CH48 STIN1L-STIN4R FXRTN1L-FXRTN4R
	MIX 1 ON- MIX24 ON	
	MIX 1 PRE/POST- MIX24 PRE/POST	
	MIX 1 LEVEL H- MIX24 LEVEL H	
	MIX 1 LEVEL L- MIX24 LEVEL L	
	MIX 1/ 2 PAN- MIX23/24 PAN	
	FOLLOW PAN VARI	
	FOLLOW PAN FIXED	
	POST POINT	MIX 1-MIX24
MIX TO STEREO	POINT	MIX 1-MIX24
	ON	
	PAN	
MIX TO MATRIX	MATRIX 1 POINT- MATRIX 8 POINT	MIX 1-MIX24
	MATRIX 1 ON- MATRIX 8 ON	
	MATRIX 1 LEVEL H- MATRIX 8 LEVEL H	
	MATRIX 1 LEVEL L- MATRIX 8 LEVEL L	
	MATRIX 1/2 PAN- MATRIX 7/8 PAN	

MODE	PARAMETER 1	PARAMETER 2
ST TO MATRIX	MATRIX 1 POINT- MATRIX 8 POINT	STEREO AL-STEREO BR
	MATRIX 1 ON- MATRIX 8 ON	
	MATRIX 1 LEVEL H- MATRIX 8 LEVEL H	
	MATRIX 1 LEVEL L- MATRIX 8 LEVEL L	
IN DELAY	MATRIX 1/2 PAN- MATRIX 7/8 PAN	CH 1-CH48 STIN1L-STIN4R
	ON	
	TIME HIGH	
	TIME MID	
OUT DELAY	TIME LOW	MIX 1-MIX24 MATRIX 1-MATRIX 8 STEREO AL-STEREO BR
	ON	
	TIME HIGH	
	TIME MID	
INPUT EQ	TIME LOW	CH 1-CH48 STIN1L-STIN4R FXRTN1L-FXRTN4R
	ON	
	LOW Q	
	LOW FREQ	
	LOW GAIN	
	LOW MID Q	
	LOW MID FREQ	
	LOW MID GAIN	
	HIGH MID Q	
	HIGH MID FREQ	
	HIGH MID GAIN	
	HIGH Q	
	HIGH FREQ	
	HIGH GAIN	
LPF ON		
LOW TYPE		
HIGH TYPE		
INPUT ATT	INPUT	CH 1-CH48 STIN1L-STIN4R FXRTN1L-FXRTN4R
INPUT HPF	ON	CH 1-CH48 STIN1L-STIN4R FXRTN1L-FXRTN4R
	FREQ	

MODE	PARAMETER 1	PARAMETER 2
OUTPUT EQ	ON	MIX 1–MIX24 MATRIX 1–MATRIX 8 STEREO AL–STEREO BR
	L LOW BYPASS	
	L LOW Q	
	L LOW FREQ	
	L LOW GAIN	
	L LOW MID BYPASS	
	L LOW MID Q	
	L LOW MID FREQ	
	L LOW MID GAIN	
	L HIGH MID BYPASS	
	L HIGH MID Q	
	L HIGH MID FREQ	
	L HIGH MID GAIN	
	L HIGH BYPASS	
	L HIGH Q	
	L HIGH FREQ	
	L HIGH GAIN	
	U LOW BYPASS	MIX 1–MIX24 STEREO AL–STEREO BR
	U LOW Q	
	U LOW FREQ	
	U LOW GAIN	
	U LOW MID BYPASS	
	U LOW MID Q	
	U LOW MID FREQ	
	U LOW MID GAIN	
	U HIGH MID BYPASS	
	U HIGH MID Q	
	U HIGH MID FREQ	
	U HIGH MID GAIN	
	U HIGH BYPASS	
	U HIGH Q	
	U HIGH FREQ	
U HIGH GAIN		
L LOW TYPE	MIX 1–MIX24 MATRIX 1–MATRIX 8 STEREO AL–STEREO BR	
L HIGH TYPE	MIX 1–MIX24 STEREO AL–STEREO BR	
U LOW TYPE	MIX 1–MIX24 STEREO AL–STEREO BR	
U HIGH TYPE	MIX 1–MIX24 MATRIX 1–MATRIX 8 STEREO AL–STEREO BR	
L LOW HPF ON	MIX 1–MIX24 MATRIX 1–MATRIX 8 STEREO AL–STEREO BR	
L HIGH HPF ON	MIX 1–MIX24 STEREO AL–STEREO BR	
U LOW HPF ON	MIX 1–MIX24 STEREO AL–STEREO BR	
U HIGH HPF ON	MIX 1–MIX24 STEREO AL–STEREO BR	
INPUT GATE	ON	CH 1–CH48 STIN1L–STIN4R
	ATTACK	
	THRESHOLD	
	RANGE	
	HOLD H	
	HOLD L	
	DECAY H	
	DECAY L	
INPUT COMP	ON	CH 1–CH48 STIN1L–STIN4R
	ATTACK	
	THRESHOLD	
	RELEASE H	
	RELEASE L	
	RATIO	
	GAIN	
	KNEE/WIDTH	

MODE	PARAMETER 1	PARAMETER 2
OUTPUT COMP	ON	MIX 1–MIX24 MATRIX 1–MATRIX 8 STEREO AL–STEREO BR
	ATTACK	
	THRESHOLD	
	RELEASE H	
	RELEASE L	
	RATIO	
	GAIN	
	KNEE/WIDTH	
	SURROUND	
LFE L		
DIVERGENCE F		
DIVERGENCE R		CH 1–CH48 STIN1L–STIN4R FXRTN1L–FXRTN4R ALT SEL CH
LEFT–RIGHT PAN		
FRONT–REAR PAN		
EFFECT	BYPASS	EFFECT 1–EFFECT 8
	MIX BALANCE	
	PARAM 1 H– PARAM32 L	
GEQ	ON	GEQ 1–GEQ12
	GAIN 1–GAIN31	
DCA	ON	DCA 1–DCA 8
	FADER H	
	FADER L	
MUTE MASTER	ON	MASTER 1–MASTER 8
RECALL SAFE	ON	CH 1–CH48 STIN1L–STIN4R FXRTN1L–FXRTN4R MIX 1–MIX24 MATRIX 1–MATRIX 8 STEREO AL–STEREO BR EFFECT 1–EFFECT 8 GEQ 1–GEQ12 DCA 1–DCA 8 MUTE MASTER
CUE DELAY	ON	L R
	TIME HIGH	
	TIME MID	
	TIME LOW	
MONITOR DELAY	ON	L R C
	TIME HIGH	
	TIME MID	
	TIME LOW	

Information shown  
in the display

Function  
menu

Global  
functions

Output  
functions

Input  
functions

Appendices

# Control change parameter assignments

## PRESET CHANNEL 1

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	FADER H	INPUT	CH 1
2			CH 2
3			CH 3
4			CH 4
5			CH 5
6			CH 6
7			CH 7
8			CH 8
9			CH 9
10			CH10
11			CH11
12			CH12
13			CH13
14			CH14
15			CH15
16			CH16
17			CH17
18			CH18
19			CH19
20			CH20
21			CH21
22			CH22
23			CH23
24			CH24
25	OUTPUT		MIX 1
26			MIX 2
27			MIX 3
28			MIX 4
29	NO ASSIGN	—	
30	FADER H	OUTPUT	STEREO AL
31			STEREO BL
33	FADER L	INPUT	CH 1
34			CH 2
35			CH 3
36			CH 4
37			CH 5
38			CH 6
39			CH 7
40			CH 8
41			CH 9
42			CH10
43			CH11
44			CH12
45			CH13
46			CH14
47			CH15
48			CH16
49			CH17
50			CH18
51			CH19
52			CH20
53			CH21
54			CH22
55			CH23
56			CH24
57	OUTPUT		MIX 1
58			MIX 2
59			MIX 3
60			MIX 4
61	NO ASSIGN	—	
62	FADER L	OUTPUT	STEREO AL
63			STEREO BL

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	CH ON	INPUT	CH 1
65			CH 2
66			CH 3
67			CH 4
68			CH 5
69			CH 6
70			CH 7
71			CH 8
72			CH 9
73			CH10
74			CH11
75			CH12
76			CH13
77			CH14
78			CH15
79			CH16
80			CH17
81			CH18
82			CH19
83			CH20
84			CH21
85			CH22
86			CH23
87			CH24
88	NO ASSIGN	—	
89	PAN/BALANCE	INPUT	CH 1
90			CH 2
91			CH 3
92			CH 4
93			CH 5
94			CH 6
95			CH 7
102			CH 8
103			CH 9
104			CH10
105			CH11
106			CH12
107	CH13		
108	CH14		
109	CH15		
110	CH16		
111	CH17		
112	CH18		
113	CH19		
114	CH20		
115	CH21		
116	CH22		
117	CH23		
118	CH24		
119	NO ASSIGN	—	

PRESET CHANNEL2

Control Change#	MODE	PARAMETER 1	PARAMETER 2	
1	FADER H	INPUT	CH25	
2			CH26	
3			CH27	
4			CH28	
5			CH29	
6			CH30	
7			CH31	
8			CH32	
9			CH33	
10			CH34	
11			CH35	
12			CH36	
13			CH37	
14			CH38	
15			CH39	
16			CH40	
17			CH41	
18			CH42	
19			CH43	
20			CH44	
21			CH45	
22			CH46	
23			CH47	
24			CH48	
25		OUTPUT	MIX 5	
26			MIX 6	
27			MIX 7	
28			MIX 8	
29	NO ASSIGN	—		
30	CH ON	OUTPUT	STEREO AL	
31			STEREO BL	
33	FADER L	INPUT	CH25	
34			CH26	
35			CH27	
36			CH28	
37			CH29	
38			CH30	
39			CH31	
40			CH32	
41			CH33	
42			CH34	
43			CH35	
44			CH36	
45			CH37	
46			CH38	
47			CH39	
48			CH40	
49			CH41	
50			CH42	
51			CH43	
52			CH44	
53			CH45	
54			CH46	
55			CH47	
56			CH48	
57		OUTPUT	MIX 5	
58			MIX 6	
59			MIX 7	
60			MIX 8	
61		NO ASSIGN	—	
62		BALANCE	OUTPUT	STEREO AL
63				STEREO BL

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	CH ON	INPUT	CH25
65			CH26
66			CH27
67			CH28
68			CH29
69			CH30
70			CH31
71			CH32
72			CH33
73			CH34
74			CH35
75			CH36
76			CH37
77			CH38
78			CH39
79			CH40
80			CH41
81			CH42
82			CH43
83			CH44
84			CH45
85			CH46
86			CH47
87			CH48
88	NO ASSIGN	—	
89	PAN/BALANCE	INPUT	CH25
90			CH26
91			CH27
92			CH28
93			CH29
94			CH30
95			CH31
102			CH32
103			CH33
104			CH34
105			CH35
106	CH36		
107	CH37		
108	CH38		
109	CH39		
110	CH40		
111	CH41		
112	CH42		
113	CH43		
114	CH44		
115	CH45		
116	CH46		
117	CH47		
118	CH48		
119	NO ASSIGN	—	

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

**PRESET CHANNEL3**

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	INPUT EQ	LOW GAIN	CH 1
2			CH 2
3			CH 3
4			CH 4
5			CH 5
6			CH 6
7			CH 7
8			CH 8
9			CH 9
10			CH10
11			CH11
12			CH12
13			CH13
14			CH14
15			CH15
16			CH16
17			CH17
18			CH18
19			CH19
20			CH20
21			CH21
22			CH22
23			CH23
24			CH24
25	FADER H	OUTPUT	MIX 9
26			MIX10
27			MIX11
28			MIX12
29	NO ASSIGN	—	
30	BALANCE	OUTPUT	MIX 1
31			MIX 3
33	NO ASSIGN	—	
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57	FADER L	OUTPUT	MIX 9
58			MIX10
59			MIX11
60			MIX12
61	NO ASSIGN	—	
62	BALANCE	OUTPUT	MIX 5
63			MIX 7

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	INPUT EQ	LOW FREQ	CH 1
65			CH 2
66			CH 3
67			CH 4
68			CH 5
69			CH 6
70			CH 7
71			CH 8
72			CH 9
73			CH10
74			CH11
75			CH12
76			CH13
77			CH14
78			CH15
79			CH16
80			CH17
81			CH18
82			CH19
83			CH20
84			CH21
85			CH22
86			CH23
87			CH24
88	NO ASSIGN	—	
89	INPUT EQ	LOW Q	CH 1
90			CH 2
91			CH 3
92			CH 4
93			CH 5
94			CH 6
95			CH 7
102			CH 8
103			CH 9
104			CH10
105			CH11
106			CH12
107			CH13
108			CH14
109			CH15
110			CH16
111			CH17
112			CH18
113			CH19
114			CH20
115			CH21
116			CH22
117			CH23
118			CH24
119	NO ASSIGN	—	

PRESET CHANNEL4

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	INPUT EQ	LOW GAIN	CH25
2			CH26
3			CH27
4			CH28
5			CH29
6			CH30
7			CH31
8			CH32
9			CH33
10			CH34
11			CH35
12			CH36
13			CH37
14			CH38
15			CH39
16			CH40
17			CH41
18			CH42
19			CH43
20			CH44
21			CH45
22			CH46
23			CH47
24			CH48
25	FADER H	OUTPUT	MIX13
26			MIX14
27			MIX15
28			MIX16
29	NO ASSIGN	—	
30	BALANCE	OUTPUT	MIX 9
31			MIX11
33	NO ASSIGN	—	
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57	FADER L	OUTPUT	MIX13
58			MIX14
59			MIX15
60			MIX16
61	NO ASSIGN	—	
62	BALANCE	OUTPUT	MIX13
63			MIX15

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	INPUT EQ	LOW FREQ	CH25
65			CH26
66			CH27
67			CH28
68			CH29
69			CH30
70			CH31
71			CH32
72			CH33
73			CH34
74			CH35
75			CH36
76			CH37
77			CH38
78			CH39
79			CH40
80			CH41
81			CH42
82			CH43
83			CH44
84			CH45
85			CH46
86			CH47
87			CH48
88	NO ASSIGN	—	
89	INPUT EQ	LOW Q	CH25
90			CH26
91			CH27
92			CH28
93			CH29
94			CH30
95			CH31
102			CH32
103			CH33
104			CH34
105			CH35
106	CH36		
107	CH37		
108	CH38		
109	CH39		
110	CH40		
111	CH41		
112	CH42		
113	CH43		
114	CH44		
115	CH45		
116	CH46		
117	CH47		
118	CH48		
119	NO ASSIGN	—	

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

**PRESET CHANNELS**

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	INPUT EQ	LOW MID GAIN	CH 1
2			CH 2
3			CH 3
4			CH 4
5			CH 5
6			CH 6
7			CH 7
8			CH 8
9			CH 9
10			CH10
11			CH11
12			CH12
13			CH13
14			CH14
15			CH15
16			CH16
17			CH17
18			CH18
19			CH19
20			CH20
21			CH21
22			CH22
23			CH23
24			CH24
25	CH ON	OUTPUT	MIX 1
26			MIX 2
27			MIX 3
28			MIX 4
29	NO ASSIGN	—	
30	CH ON	OUTPUT	MIX17
31			MIX18
33	NO ASSIGN	—	
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57	CH ON	OUTPUT	MIX 5
58			MIX 6
59			MIX 7
60			MIX 8
61	NO ASSIGN	—	
62	CH ON	OUTPUT	MIX19
63			MIX20

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	INPUT EQ	LOW MID FREQ	CH 1
65			CH 2
66			CH 3
67			CH 4
68			CH 5
69			CH 6
70			CH 7
71			CH 8
72			CH 9
73			CH10
74			CH11
75			CH12
76			CH13
77			CH14
78			CH15
79			CH16
80			CH17
81			CH18
82			CH19
83			CH20
84			CH21
85			CH22
86			CH23
87			CH24
88	NO ASSIGN	—	
89	INPUT EQ	LOW MID Q	CH 1
90			CH 2
91			CH 3
92			CH 4
93			CH 5
94			CH 6
95			CH 7
102			CH 8
103			CH 9
104			CH10
105			CH11
106			CH12
107			CH13
108			CH14
109			CH15
110			CH16
111			CH17
112			CH18
113			CH19
114			CH20
115			CH21
116			CH22
117			CH23
118			CH24
119	NO ASSIGN	—	

PRESET CHANNEL6

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	INPUT EQ	LOW MID GAIN	CH25
2			CH26
3			CH27
4			CH28
5			CH29
6			CH30
7			CH31
8			CH32
9			CH33
10			CH34
11			CH35
12			CH36
13			CH37
14			CH38
15			CH39
16			CH40
17			CH41
18			CH42
19			CH43
20			CH44
21			CH45
22			CH46
23			CH47
24			CH48
25	CH ON	OUTPUT	MIX 9
26			MIX10
27			MIX11
28			MIX12
29	NO ASSIGN	—	
30	CH ON	OUTPUT	MIX21
31			MIX22
33	NO ASSIGN	—	
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57	CH ON	OUTPUT	MIX13
58			MIX14
59			MIX15
60			MIX16
61	NO ASSIGN	—	
62	CH ON	OUTPUT	MIX23
63			MIX24

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	INPUT EQ	LOW MID FREQ	CH25
65			CH26
66			CH27
67			CH28
68			CH29
69			CH30
70			CH31
71			CH32
72			CH33
73			CH34
74			CH35
75			CH36
76			CH37
77			CH38
78			CH39
79			CH40
80			CH41
81			CH42
82			CH43
83			CH44
84			CH45
85			CH46
86			CH47
87			CH48
88	NO ASSIGN	—	
89	INPUT EQ	LOW MID Q	CH25
90			CH26
91			CH27
92			CH28
93			CH29
94			CH30
95			CH31
102			CH32
103			CH33
104			CH34
105			CH35
106			CH36
107			CH37
108			CH38
109			CH39
110			CH40
111			CH41
112			CH42
113	CH43		
114	CH44		
115	CH45		
116	CH46		
117	CH47		
118	CH48		
119	NO ASSIGN	—	

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

**PRESET CHANNEL7**

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	INPUT EQ	HIGH MID GAIN	CH 1
2			CH 2
3			CH 3
4			CH 4
5			CH 5
6			CH 6
7			CH 7
8			CH 8
9			CH 9
10			CH10
11			CH11
12			CH12
13			CH13
14			CH14
15			CH15
16			CH16
17			CH17
18			CH18
19			CH19
20			CH20
21			CH21
22			CH22
23			CH23
24			CH24
25	FADER H	OUTPUT	MIX17
26			MIX18
27			MIX19
28			MIX20
29	NO ASSIGN	—	
30	BALANCE	OUTPUT	MIX17
31			MIX19
33	NO ASSIGN	—	
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57	FADER L	OUTPUT	MIX17
58			MIX18
59			MIX19
60			MIX20
61	NO ASSIGN	—	
62	BALANCE	OUTPUT	MIX21
63			MIX23

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	INPUT EQ	HIGH MID FREQ	CH 1
65			CH 2
66			CH 3
67			CH 4
68			CH 5
69			CH 6
70			CH 7
71			CH 8
72			CH 9
73			CH10
74			CH11
75			CH12
76			CH13
77			CH14
78			CH15
79			CH16
80			CH17
81			CH18
82			CH19
83			CH20
84			CH21
85			CH22
86			CH23
87			CH24
88	NO ASSIGN	—	
89	INPUT EQ	HIGH MID Q	CH 1
90			CH 2
91			CH 3
92			CH 4
93			CH 5
94			CH 6
95			CH 7
102			CH 8
103			CH 9
104			CH10
105			CH11
106			CH12
107			CH13
108			CH14
109			CH15
110			CH16
111			CH17
112			CH18
113			CH19
114			CH20
115			CH21
116			CH22
117			CH23
118			CH24
119	NO ASSIGN	—	

PRESET CHANNEL8

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	INPUT EQ	HIGH MID GAIN	CH25
2			CH26
3			CH27
4			CH28
5			CH29
6			CH30
7			CH31
8			CH32
9			CH33
10			CH34
11			CH35
12			CH36
13			CH37
14			CH38
15			CH39
16			CH40
17			CH41
18			CH42
19			CH43
20			CH44
21			CH45
22			CH46
23			CH47
24			CH48
25	FADER H	OUTPUT	MIX21
26			MIX22
27			MIX23
28			MIX24
29	NO ASSIGN	—	
30	BALANCE	OUTPUT	MATRIX 1
31			MATRIX 3
33	NO ASSIGN	—	
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57	FADER L	OUTPUT	MIX21
58			MIX22
59			MIX23
60			MIX24
61	NO ASSIGN	—	
62	BALANCE	OUTPUT	MATRIX 5
63			MATRIX 7

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	INPUT EQ	HIGH MID FREQ	CH25
65			CH26
66			CH27
67			CH28
68			CH29
69			CH30
70			CH31
71			CH32
72			CH33
73			CH34
74			CH35
75			CH36
76			CH37
77			CH38
78			CH39
79			CH40
80			CH41
81			CH42
82			CH43
83			CH44
84			CH45
85			CH46
86			CH47
87			CH48
88	NO ASSIGN	—	
89	INPUT EQ	HIGH MID Q	CH25
90			CH26
91			CH27
92			CH28
93			CH29
94			CH30
95			CH31
102			CH32
103			CH33
104			CH34
105			CH35
106			CH36
107			CH37
108			CH38
109			CH39
110			CH40
111			CH41
112			CH42
113			CH43
114			CH44
115			CH45
116			CH46
117			CH47
118			CH48
119	NO ASSIGN	—	

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

**PRESET CHANNEL9**

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	INPUT EQ	HIGH GAIN	CH 1
2			CH 2
3			CH 3
4			CH 4
5			CH 5
6			CH 6
7			CH 7
8			CH 8
9			CH 9
10			CH10
11			CH11
12			CH12
13			CH13
14			CH14
15			CH15
16			CH16
17			CH17
18			CH18
19			CH19
20			CH20
21			CH21
22			CH22
23			CH23
24			CH24
25	FADER H	OUTPUT	MATRIX 1
26			MATRIX 2
27			MATRIX 3
28			MATRIX 4
29	NO ASSIGN	—	
30	CH ON	OUTPUT	MATRIX 1
31			MATRIX 2
33	NO ASSIGN	—	
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57	FADER L	OUTPUT	MATRIX 1
58			MATRIX 2
59			MATRIX 3
60			MATRIX 4
61	NO ASSIGN	—	
62	CH ON	OUTPUT	MATRIX 3
63			MATRIX 4

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	INPUT EQ	HIGH FREQ	CH 1
65			CH 2
66			CH 3
67			CH 4
68			CH 5
69			CH 6
70			CH 7
71			CH 8
72			CH 9
73			CH10
74			CH11
75			CH12
76			CH13
77			CH14
78			CH15
79			CH16
80			CH17
81			CH18
82			CH19
83			CH20
84			CH21
85			CH22
86			CH23
87			CH24
88	NO ASSIGN	—	
89	INPUT EQ	HIGH Q	CH 1
90			CH 2
91			CH 3
92			CH 4
93			CH 5
94			CH 6
95			CH 7
102			CH 8
103			CH 9
104			CH10
105			CH11
106			CH12
107			CH13
108			CH14
109			CH15
110			CH16
111	CH17		
112	CH18		
113	CH19		
114	CH20		
115	CH21		
116	CH22		
117	CH23		
118	CH24		
119	NO ASSIGN	—	

PRESET CHANNEL10

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	INPUT EQ	HIGH GAIN	CH25
2			CH26
3			CH27
4			CH28
5			CH29
6			CH30
7			CH31
8			CH32
9			CH33
10			CH34
11			CH35
12			CH36
13			CH37
14			CH38
15			CH39
16			CH40
17			CH41
18			CH42
19			CH43
20			CH44
21			CH45
22			CH46
23			CH47
24			CH48
25	FADER H	OUTPUT	MATRIX 5
26			MATRIX 6
27			MATRIX 7
28			MATRIX 8
29	NO ASSIGN	—	
30	CH ON	OUTPUT	MATRIX 5
31			MATRIX 6
33	NO ASSIGN	—	
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57	FADER L	OUTPUT	MATRIX 5
58			MATRIX 6
59			MATRIX 7
60			MATRIX 8
61	NO ASSIGN	—	
62	CH ON	OUTPUT	MATRIX 7
63			MATRIX 8

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	INPUT EQ	HIGH FREQ	CH25
65			CH26
66			CH27
67			CH28
68			CH29
69			CH30
70			CH31
71			CH32
72			CH33
73			CH34
74			CH35
75			CH36
76			CH37
77			CH38
78			CH39
79			CH40
80			CH41
81			CH42
82			CH43
83			CH44
84			CH45
85			CH46
86			CH47
87			CH48
88	NO ASSIGN	—	
89	INPUT EQ	HIGH Q	CH25
90			CH26
91			CH27
92			CH28
93			CH29
94			CH30
95			CH31
102			CH32
103			CH33
104			CH34
105			CH35
106			CH36
107			CH37
108			CH38
109			CH39
110			CH40
111			CH41
112			CH42
113			CH43
114			CH44
115			CH45
116			CH46
117			CH47
118			CH48
119	NO ASSIGN	—	

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

**PRESET CHANNEL11**

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	INPUT ATT	INPUT	CH 1
2			CH 2
3			CH 3
4			CH 4
5			CH 5
6			CH 6
7			CH 7
8			CH 8
9			CH 9
10			CH10
11			CH11
12			CH12
13			CH13
14			CH14
15			CH15
16			CH16
17			CH17
18			CH18
19			CH19
20			CH20
21			CH21
22			CH22
23			CH23
24			CH24
25	INPUT HPF	FREQ	CH 1
26			CH 2
27			CH 3
28			CH 4
29	NO ASSIGN	—	
30	INPUT HPF	FREQ	CH 5
31			CH 6
33	NO ASSIGN	—	
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57	INPUT HPF	FREQ	CH 7
58			CH 8
59			CH 9
60			CH10
61	NO ASSIGN	—	
62	INPUT HPF	FREQ	CH11
63			CH12

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	INPUT HPF	ON	CH 1
65			CH 2
66			CH 3
67			CH 4
68			CH 5
69			CH 6
70			CH 7
71			CH 8
72			CH 9
73			CH10
74			CH11
75			CH12
76			CH13
77			CH14
78			CH15
79			CH16
80			CH17
81			CH18
82			CH19
83			CH20
84			CH21
85			CH22
86			CH23
87			CH24
88	NO ASSIGN	—	
89	INPUT EQ	LPF ON	CH 1
90			CH 2
91			CH 3
92			CH 4
93			CH 5
94			CH 6
95			CH 7
102			CH 8
103			CH 9
104			CH10
105			CH11
106			CH12
107			CH13
108			CH14
109			CH15
110			CH16
111	CH17		
112	CH18		
113	CH19		
114	CH20		
115	CH21		
116	CH22		
117	CH23		
118	CH24		
119	NO ASSIGN	—	

PRESET CHANNEL12

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	INPUT ATT	INPUT	CH25
2			CH26
3			CH27
4			CH28
5			CH29
6			CH30
7			CH31
8			CH32
9			CH33
10			CH34
11			CH35
12			CH36
13			CH37
14			CH38
15			CH39
16			CH40
17			CH41
18			CH42
19			CH43
20			CH44
21			CH45
22			CH46
23			CH47
24			CH48
25	INPUT HPF	FREQ	CH13
26			CH14
27			CH15
28			CH16
29	NO ASSIGN	—	
30	INPUT HPF	FREQ	CH17
31			CH18
33	NO ASSIGN	—	
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57	INPUT HPF	FREQ	CH19
58			CH20
59			CH21
60			CH22
61	NO ASSIGN	—	
62	INPUT HPF	FREQ	CH23
63			CH24

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	INPUT HPF	ON	CH25
65			CH26
66			CH27
67			CH28
68			CH29
69			CH30
70			CH31
71			CH32
72			CH33
73			CH34
74			CH35
75			CH36
76			CH37
77			CH38
78			CH39
79			CH40
80			CH41
81			CH42
82			CH43
83			CH44
84			CH45
85			CH46
86			CH47
87			CH48
88	NO ASSIGN	—	
89	INPUT EQ	LPF ON	CH25
90			CH26
91			CH27
92			CH28
93			CH29
94			CH30
95			CH31
102			CH32
103			CH33
104			CH34
105			CH35
106			CH36
107			CH37
108			CH38
109			CH39
110			CH40
111			CH41
112			CH42
113	CH43		
114	CH44		
115	CH45		
116	CH46		
117	CH47		
118	CH48		
119	NO ASSIGN	—	

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

**PRESET CHANNEL13**

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	SURROUND	LFE H	CH 1
2			CH 2
3			CH 3
4			CH 4
5			CH 5
6			CH 6
7			CH 7
8			CH 8
9			CH 9
10			CH10
11			CH11
12			CH12
13			CH13
14			CH14
15			CH15
16			CH16
17			CH17
18			CH18
19			CH19
20			CH20
21			CH21
22			CH22
23			CH23
24			CH24
25	INPUT HPF	FREQ	CH25
26			CH26
27			CH27
28			CH28
29	NO ASSIGN	—	
30	INPUT HPF	FREQ	CH29
31			CH30
33	SURROUND	LFE L	CH 1
34			CH 2
35			CH 3
36			CH 4
37			CH 5
38			CH 6
39			CH 7
40			CH 8
41			CH 9
42			CH10
43			CH11
44			CH12
45			CH13
46			CH14
47			CH15
48			CH16
49			CH17
50			CH18
51			CH19
52			CH20
53			CH21
54			CH22
55			CH23
56			CH24
57	INPUT HPF	FREQ	CH31
58			CH32
59			CH33
60			CH34
61	NO ASSIGN	—	
62	INPUT HPF	FREQ	CH35
63			CH36

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	SURROUND	DIVERGENCE F	CH 1
65			CH 2
66			CH 3
67			CH 4
68			CH 5
69			CH 6
70			CH 7
71			CH 8
72			CH 9
73			CH10
74			CH11
75			CH12
76			CH13
77			CH14
78			CH15
79			CH16
80			CH17
81			CH18
82			CH19
83			CH20
84			CH21
85			CH22
86			CH23
87			CH24
88	NO ASSIGN	—	
89	INPUT EQ	ON	CH 1
90			CH 2
91			CH 3
92			CH 4
93			CH 5
94			CH 6
95			CH 7
102			CH 8
103			CH 9
104			CH10
105	CH11		
106	CH12		
107	CH13		
108	CH14		
109	CH15		
110	CH16		
111	CH17		
112	CH18		
113	CH19		
114	CH20		
115	CH21		
116	CH22		
117	CH23		
118	CH24		
119	NO ASSIGN	—	

PRESET CHANNEL14

Control Change#	MODE	PARAMETER 1	PARAMETER 2		
1	SURROUND	LFE H	CH25		
2			CH26		
3			CH27		
4			CH28		
5			CH29		
6			CH30		
7			CH31		
8			CH32		
9			CH33		
10			CH34		
11			CH35		
12			CH36		
13			CH37		
14			CH38		
15			CH39		
16			CH40		
17			CH41		
18			CH42		
19			CH43		
20			CH44		
21			CH45		
22			CH46		
23			CH47		
24			CH48		
25	INPUT HPF	FREQ	CH37		
26			CH38		
27			CH39		
28			CH40		
29	NO ASSIGN	—			
30	INPUT HPF	FREQ	CH41		
31			CH42		
33	SURROUND	LFE L	CH25		
34			CH26		
35			CH27		
36			CH28		
37			CH29		
38			CH30		
39			CH31		
40			CH32		
41			CH33		
42			CH34		
43			CH35		
44			CH36		
45			CH37		
46			CH38		
47			CH39		
48			CH40		
49			CH41		
50			CH42		
51			CH43		
52			CH44		
53			CH45		
54			CH46		
55			CH47		
56			CH48		
57			INPUT HPF	FREQ	CH43
58					CH44
59					CH45
60					CH46
61			NO ASSIGN	—	
62			INPUT HPF	FREQ	CH47
63					CH48

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	SURROUND	DIVERGENCE F	CH25
65			CH26
66			CH27
67			CH28
68			CH29
69			CH30
70			CH31
71			CH32
72			CH33
73			CH34
74			CH35
75			CH36
76			CH37
77			CH38
78			CH39
79			CH40
80			CH41
81			CH42
82			CH43
83			CH44
84			CH45
85			CH46
86			CH47
87			CH48
88	NO ASSIGN	—	
89	INPUT EQ	ON	CH25
90			CH26
91			CH27
92			CH28
93			CH29
94			CH30
95			CH31
102			CH32
103			CH33
104			CH34
105			CH35
106	CH36		
107	CH37		
108	CH38		
109	CH39		
110	CH40		
111	CH41		
112	CH42		
113	CH43		
114	CH44		
115	CH45		
116	CH46		
117	CH47		
118	CH48		
119	NO ASSIGN	—	

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

**PRESET CHANNEL15**

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	SURROUND	LEFT-RIGHT PAN	CH 1
2			CH 2
3			CH 3
4			CH 4
5			CH 5
6			CH 6
7			CH 7
8			CH 8
9			CH 9
10			CH10
11			CH11
12			CH12
13			CH13
14			CH14
15			CH15
16			CH16
17			CH17
18			CH18
19			CH19
20			CH20
21			CH21
22			CH22
23			CH23
24			CH24
25	DCA	FADER H	DCA 1
26			DCA 2
27			DCA 3
28			DCA 4
29	NO ASSIGN	—	
30	MUTE MASTER	ON	MASTER 1
31			MASTER 2
33	SURROUND	FRONT-REAR PAN	CH 1
34			CH 2
35			CH 3
36			CH 4
37			CH 5
38			CH 6
39			CH 7
40			CH 8
41			CH 9
42			CH10
43			CH11
44			CH12
45			CH13
46			CH14
47			CH15
48			CH16
49			CH17
50			CH18
51			CH19
52			CH20
53			CH21
54			CH22
55			CH23
56			CH24
57	DCA	FADER L	DCA 1
58			DCA 2
59			DCA 3
60			DCA 4
61	NO ASSIGN	—	
62	MUTE MASTER	ON	MASTER 3
63			MASTER 4

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	NO ASSIGN	—	—
65			
66			
67			
68			
69			
70			
71			
72			
73			
74			
75			
76			
77			
78			
79			
80			
81			
82			
83			
84			
85			
86			
87			
88			
89			
90			
91			
92			
93			
94			
95			
102			
103			
104			
105			
106			
107			
108			
109			
110			
111			
112			
113			
114			
115			
116			
117			
118			
119			

PRESET CHANNEL16

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1	SURROUND	LEFT-RIGHT PAN	CH25
2			CH26
3			CH27
4			CH28
5			CH29
6			CH30
7			CH31
8			CH32
9			CH33
10			CH34
11			CH35
12			CH36
13			CH37
14			CH38
15			CH39
16			CH40
17			CH41
18			CH42
19			CH43
20			CH44
21			CH45
22			CH46
23			CH47
24			CH48
25	DCA	FADER H	DCA5
26			DCA6
27			DCA7
28			DCA8
29	NO ASSIGN	—	
30	MUTE MASTER	ON	MASTER5
31			MASTER6
33	SURROUND	FRONT-REAR PAN	CH25
34			CH26
35			CH27
36			CH28
37			CH29
38			CH30
39			CH31
40			CH32
41			CH33
42			CH34
43			CH35
44			CH36
45			CH37
46			CH38
47			CH39
48			CH40
49			CH41
50			CH42
51			CH43
52			CH44
53			CH45
54			CH46
55			CH47
56			CH48
57	DCA	FADER L	DCA 5
58			DCA 6
59			DCA 7
60			DCA 8
61	NO ASSIGN	—	
62	MUTE MASTER	ON	MASTER 7
63			MASTER 8

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64	NO ASSIGN	—	64
65			65
66			66
67			67
68			68
69			69
70			70
71			71
72			72
73			73
74			74
75			75
76			76
77			77
78			78
79			79
80			80
81			81
82			82
83	83		
84	84		
85	85		
86	86		
87	87		
88	88		
89	89		
90	90		
91	91		
92	92		
93	93		
94	94		
95	95		
102	102		
103	103		
104	104		
105	105		
106	106		
107	107		
108	108		
109	109		
110	110		
111	111		
112	112		
113	113		
114	114		
115	115		
116	116		
117	117		
118	118		
119	119		

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

CHANNEL \_

Control Change#	MODE	PARAMETER 1	PARAMETER 2
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57			
58			
59			
60			
61			
62			
63			

Control Change#	MODE	PARAMETER 1	PARAMETER 2
64			
65			
66			
67			
68			
69			
70			
71			
72			
73			
74			
75			
76			
77			
78			
79			
80			
81			
82			
83			
84			
85			
86			
87			
88			
89			
90			
91			
92			
93			
94			
95			
102			
103			
104			
105			
106			
107			
108			
109			
110			
111			
112			
113			
114			
115			
116			
117			
118			
119			

# NRPN parameter assignments

PARAMETER		FROM (HEX)	TO (HEX)
FADER	CHANNEL	0000	003F
	MIX1-20, MATRIX1-8, ST A LR	0060	007D
CH to Mix LEVEL	MIX9 SEND	007E	00BD
	MIX10 SEND	00DE	011D
	MIX11 SEND	013E	017D
	MIX12 SEND	019E	01DD
	MIX13 SEND	01FE	023D
	MIX14 SEND	025E	029D
	MIX15 SEND	02BE	02FD
	MIX16 SEND	031E	035D
	MIX17 SEND	037E	03BD
	MIX18 SEND	03DE	041D
	MIX19 SEND	043E	047D
MIX20 SEND	049E	04DD	
MIX1-20, MATRIX1-8, ST A LR to Matrix LEVEL	MATRIX1 SEND	04FE	0513
	MATRIX2 SEND	0514	0529
	MATRIX3 SEND	052A	053F
	MATRIX4 SEND	0540	0555
	MATRIX5 SEND	0556	056B
	MATRIX6 SEND	056C	0581
	MATRIX7 SEND	0582	0597
	MATRIX8 SEND	0598	05AD
MIX1-8 to ST LEVEL	MIX TO ST	05AE	05B5
ON	CHANNEL	05B6	05F5
	MIX1-20, MATRIX1-8, ST A LR	0616	0633
CH to Mix ON	MIX9 SEND	0634	0673
	MIX10 SEND	0694	06D3
	MIX11 SEND	06F4	0733
	MIX12 SEND	0754	0793
	MIX13 SEND	07B4	07F3
	MIX14 SEND	0814	0853
	MIX15 SEND	0874	08B3
	MIX16 SEND	08D4	0913
	MIX17 SEND	0934	0973
	MIX18 SEND	0994	09D3
	MIX19 SEND	09F4	0A33
MIX20 SEND	0A54	0A93	
MIX1-20, MATRIX1-8, ST A LR to Matrix LEVEL	MATRIX1 SEND	0AB4	0AC9
	MATRIX2 SEND	0ACA	0AC9
	MATRIX3 SEND	0AE0	0ADF
	MATRIX4 SEND	0AF6	0AF5
	MATRIX5 SEND	0B0C	0B0B
	MATRIX6 SEND	0B22	0B21
	MATRIX7 SEND	0B38	0B37
	MATRIX8 SEND	0B4E	0B4D
MIX1-8 to ST ON	MIX TO ST	0B64	0B6B
PHASE	CHANNEL	0B6C	0BAB
INSERT ON	CHANNEL	0BCC	0C03
	MIX1-20, MATRIX1-8, ST A LR	0C2C	0C49
CH to Mix PRE/ POST	MIX9 SEND	0C4A	0C89
	MIX10 SEND	0CAA	0CE9
	MIX11 SEND	0D0A	0D49
	MIX12 SEND	0D6A	0DA9
	MIX13 SEND	0DCA	0E09
	MIX14 SEND	0E2A	0E69
	MIX15 SEND	0E8A	0EC9
	MIX16 SEND	0EEA	0F29
	MIX17 SEND	0F4A	0F89
	MIX18 SEND	0FAA	0FE9
	MIX19 SEND	100A	1049
MIX20 SEND	106A	10A9	
INPUT DELAY	ON	10CA	1101
	TIME HIGH	112A	1161
	TIME LOW	118A	11C1

PARAMETER		FROM (HEX)	TO (HEX)
MIX1-20, MATRIX1-8, ST A LR OUTPUT DELAY	ON	12AA	12C7
	TIME HIGH	12C8	12E5
	TIME LOW	12E6	1303
EQ CH & MIX1-20, MATRIX1-8, ST A LR OUTPUT(LOWER) *1	ON	1304	1381
	Q LOW	1382	13FF
	F LOW	1400	147D
	G LOW	147E	14FB
	Q LO-MID	14FC	1579
	F LO-MID	157A	15F7
	G LO-MID	15F8	1675
	Q HI-MID	1676	16F3
	F HI-MID	16F4	1771
	G HI-MID	1772	17EF
	Q HIGH	17F0	186D
	F HIGH	186E	18EB
	G HIGH	18EC	1969
	ATT	196A	19A9
HPF ON	19E8	1A65	
LPF ON	1A66	1AE3	
GATE	ON	1AE4	1B1B
	ATTACK	1B44	1B7B
	THRESH	1BA4	1BDB
	RANGE	1C04	1C3B
	HOLD	1C64	1C9B
	DECAY	1CC4	1CFB
COMP CH & MIX1-20, MATRIX1-8, ST A LR OUTPUT *1	ON	1D24	1DA1
	ATTACK	1DA2	1E1F
	THRESH	1E20	1E9D
	RELEASE	1E9E	1F1B
	RATIO	1F1C	1F99
	GAIN	1F9A	2017
KNEE	2018	2095	
PAN	CHANNEL	2096	20D5
CH to MIX PAN	MIX9-10	20F6	2135
	MIX11-12	2156	2195
	MIX13-14	21B6	21F5
	MIX15-16	2216	2255
	MIX17-18	2276	22B5
MIX1-20, ST A LR to Matrix PAN	MIX19-20	22D6	2315
	MATRIX1,2	2336	234B
	MATRIX3,4	234C	2361
	MATRIX5,6	2362	2377
MATRIX7,8	2378	238D	
MIX1-8 to ST PAN	MIX TO ST	238E	2395
BALANCE	MIX1-20, MATRIX1-8, ST A LR	2396	23B3
SURROUND	LFE	23B4	23F3
	DIV (F)	2414	2453
	LR	2474	24B3
	FR	24D4	2513

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

PARAMETER	FROM (HEX)	TO (HEX)
EFFECT 1-8	BYPASS	26B4 26BB
	MIX	26BC 26C3
	PARAM1	26C4 26CB
	PARAM2	26CC 26D3
	PARAM3	26D4 26DB
	PARAM4	26DC 26E3
	PARAM5	26E4 26EB
	PARAM6	26EC 26F3
	PARAM7	26F4 26FB
	PARAM8	26FC 2703
	PARAM9	2704 270B
	PARAM10	270C 2713
	PARAM11	2714 271B
	PARAM12	271C 2723
	PARAM13	2724 272B
	PARAM14	272C 2733
	PARAM15	2734 273B
	PARAM16	273C 2743
	PARAM17	2744 274B
	PARAM18	274C 2753
	PARAM19	2754 275B
	PARAM20	275C 2763
	PARAM21	2764 276B
	PARAM22	276C 2773
	PARAM23	2774 277B
	PARAM24	277C 2783
	PARAM25	2784 278B
	PARAM26	278C 2793
	PARAM27	2794 279B
	PARAM28	279C 27A3
	PARAM29	27A4 27AB
	PARAM30	27AC 27B3
PARAM31	27B4 27BB	
PARAM32	27BC 27C3	
GEQ 1-6	ON	27C4 27C9
	GAIN1	27CA 27CF
	GAIN2	27D0 27D5
	GAIN3	27D6 27DB
	GAIN4	27DC 27E1
	GAIN5	27E2 27E7
	GAIN6	27E8 27ED
	GAIN7	27EE 27F3
	GAIN8	27F4 27F9
	GAIN9	27FA 27FF
	GAIN10	2800 2805
	GAIN11	2806 280B
	GAIN12	280C 2811
	GAIN13	2812 2817
	GAIN14	2818 281D
	GAIN15	281E 2823
	GAIN16	2824 2829
	GAIN17	282A 282F
	GAIN18	2830 2835
	GAIN19	2836 283B
	GAIN20	283C 2841
	GAIN21	2842 2847
	GAIN22	2848 284D
	GAIN23	284E 2853
	GAIN24	2854 2859
	GAIN25	285A 285F
	GAIN26	2860 2865
	GAIN27	2866 286B
	GAIN28	286C 2871
	GAIN29	2872 2877
	GAIN30	2878 287D
GAIN31	287E 2883	
SURROUND	DIV R	2884 28C3
FADER	MIX21-24,ST B LR	28E4 28E9

PARAMETER	FROM (HEX)	TO (HEX)
CH to Mix LEVEL	MIX1 SEND	28EA 2929
	MIX2 SEND	292A 2969
	MIX3 SEND	296A 29A9
	MIX4 SEND	29AA 29E9
	MIX5 SEND	29EA 2A29
	MIX6 SEND	2A2A 2A69
	MIX7 SEND	2A6A 2AA9
	MIX8 SEND	2AAA 2AE9
	MIX21 SEND	2AEA 2B29
	MIX22 SEND	2B2A 2B69
	MIX23 SEND	2B6A 2BA9
	MIX24 SEND	2BAA 2BE9
MIX21-24, ST B LR to Matrix LEVEL	MATRIX1 SEND	2BEA 2BEF
	MATRIX2 SEND	2BF0 2BF5
	MATRIX3 SEND	2BF6 2BFB
	MATRIX4 SEND	2BFC 2C01
	MATRIX5 SEND	2C02 2C07
	MATRIX6 SEND	2C08 2C0D
	MATRIX7 SEND	2C0E 2C13
	MATRIX8 SEND	2C14 2C19
MIX21-24 to ST LEVEL	MIX TO ST	2C1A 2C29
ON	MIX21-24,ST B LR	2C2A 2C2F
CH to Mix ON	MIX1 SEND	2C30 2C6F
	MIX2 SEND	2C70 2CAF
	MIX3 SEND	2CB0 2CEF
	MIX4 SEND	2CF0 2D2F
	MIX5 SEND	2D30 2D6F
	MIX6 SEND	2D70 2DAF
	MIX7 SEND	2DB0 2DEF
	MIX8 SEND	2DF0 2E2F
	MIX21 SEND	2E30 2E6F
	MIX22 SEND	2E70 2EAF
	MIX23 SEND	2EB0 2EEF
	MIX24 SEND	2EF0 2F2F
	MATRIX SEND	2F30 2F35
	MIX TO ST	2F36 2F45
INSERT ON	MIX21-24,ST B LR	2F46 2F4B
CH to Mix PRE/ POST	MIX1 SEND	2F4C 2F8B
	MIX2 SEND	2F8C 2FCB
	MIX3 SEND	2FCC 300B
	MIX4 SEND	300C 304B
	MIX5 SEND	304C 308B
	MIX6 SEND	308C 30CB
	MIX7 SEND	30CC 310B
	MIX8 SEND	310C 314B
	MIX21 SEND	314C 318B
	MIX22 SEND	318C 31CB
	MIX23 SEND	31CC 320B
	MIX24 SEND	320C 324B
MIX1-20, ST B LR OUTPUT DELAY	ON	324C 3251
	TIME HIGH	3252 3257
	TIME LOW	3258 325D
EQ MIX21-24, ST A LR OUT-PUT(LOWER)	ON	325E 3263
	Q LOW	3264 3269
	F LOW	326A 326F
	G LOW	3270 3275
	Q LO-MID	3276 327B
	F LO-MID	327C 3281
	G LO-MID	3282 3287
	Q HI-MID	3288 328D
	F HI-MID	328E 3293
	G HI-MID	3294 3299
	Q HIGH	329A 329F
	F HIGH	32A0 32A5
	G HIGH	32A6 32AB
	HPF ON	32AC 32B1
LPF ON	32B2 32B7	

PARAMETER		FROM (HEX)	TO (HEX)
EQ OUTPUT (HIGHER)	E Q	32B8	32D3
	E F	32D4	32EF
	E G	32F0	330B
	F Q	330C	3327
	F F	3328	3343
	F G	3344	335F
	G Q	3360	337B
	G F	337C	3397
	G G	3398	33B3
	H Q	33B4	33CF
	H F	33D0	33EB
	H G	33EC	3407
		E HPF ON/OFF	3408
	H LPF ON/OFF	3424	343F
INPUT EQ	LOW TYPE(P/S/F)	3440	347F
INPUT EQ	HIGH TYPE(P/S/F)	3480	34BF
OUTPUT EQ	A TYPE(P/S/F)	34C0	34E3
	D TYPE(P/S/F)	34E4	3507
	E TYPE(P/S/F)	3508	3523
	H TYPE(P/S/F)	3524	353F
OUTPUT EQ	A BYPASS	3540	3563
	B BYPASS	3564	3587
	C BYPASS	3588	35AB
	D BYPASS	35AC	35CF
	E BYPASS	35D0	35EB
	F BYPASS	35EC	3607
	G BYPASS	3608	3623
	H BYPASS	3624	363F
IN HPF	F	3640	367F
COMP MIX21-24, ST A LR OUTPUT	ON	3680	3685
	ATTACK	3686	368B
	THRESH	368C	3691
	RELEASE	3692	3697
	RATIO	3698	369D
	GAIN	369E	36A3
	KNEE	36A4	36A9
PAN	MIX1-2	36AA	36E9
CH to MIX PAN	MIX3-4	36EA	3729
	MIX5-6	372A	3769
	MIX7-8	376A	37A9
	MIX21-22	37AA	37E9
	MIX23-24	37EA	3829
MIX21-24, ST B LR to Matrix PAN	MATRIX1,2	382A	382F
	MATRIX3,4	3830	3835
	MATRIX5,6	3836	383B
	MATRIX7,8	383C	3841
MIX9-24 to ST PAN	MIX TO ST	3842	3851

PARAMETER		FROM (HEX)	TO (HEX)
GEQ7-12	ON	3852	3857
	GAIN1	3858	385D
	GAIN2	385E	3863
	GAIN3	3864	3869
	GAIN4	386A	386F
	GAIN5	3870	3875
	GAIN6	3876	387B
	GAIN7	387C	3881
	GAIN8	3882	3887
	GAIN9	3888	388D
	GAIN10	388E	3893
	GAIN11	3894	3899
	GAIN12	389A	389F
	GAIN13	38A0	38A5
	GAIN14	38A6	38AB
	GAIN15	38AC	38B1
	GAIN16	38B2	38B7
	GAIN17	38B8	38BD
	GAIN18	38BE	38C3
	GAIN19	38C4	38C9
	GAIN20	38CA	38CF
	GAIN21	38D0	38D5
	GAIN22	38D6	38DB
	GAIN23	38DC	38E1
	GAIN24	38E2	38E7
	GAIN25	38E8	38ED
	GAIN26	38EE	38F3
	GAIN27	38F4	38F9
	GAIN28	38FA	38FF
	GAIN29	3900	3905
	GAIN30	3906	390B
GAIN31	390C	3911	
LCR IN, MIX	ON/OFF	3912	3969
	CSR	396A	39C1
DIRECT OUT	ON/OFF	39C2	39F9
CH TO STEREO	ON/OFF	3A02	3A41
DCA	ON/OFF	3A42	3A49
	LEVEL	3A4E	3A55
MUTE MASTER	ON/OFF	3A5A	3A61
RECALL SAFE	ON/OFF	3A66	3A6E
HA	GAIN1	3B06	3B14
	GAIN2	3B16	3B24
	GAIN3	3B26	3B34
	GAIN4	3B36	3B44
	GAIN5	3B46	3B54
	GAIN6	3B56	3B64
	GAIN7	3B66	3B74
	GAIN8	3B76	3B84
	+48v 1	3B86	3B94
	+48v 2	3B96	3BA4
	+48v 3	3BA6	3BB4
	+48v 4	3BB6	3BC4
	+48v 5	3BC6	3BD4
	+48v 6	3BD6	3BE4
	+48v 7	3BE6	3BF4
	+48v 8	3BF6	3C04
	HPF1	3C06	3C14
	HPF2	3C16	3C24
	HPF3	3C26	3C34
	HPF4	3C36	3C44
	HPF5	3C46	3C54
	HPF6	3C56	3C64
	HPF7	3C66	3C74
	HPF8	3C76	3C84

\*1. For EQ or COMP parameters that include INPUT CH and OUTPUT, the OUTPUT is assigned starting at 96 (60h) after the first number. Thus, the numbers from immediately after INPUT CH until immediately before OUTPUT are unassigned.

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

# Channel Library List

This table lists the parameters that are saved in the channel library for INPUT/ST IN channels, MIX channels, MATRIX channels, and STEREO A/B channels.

INPUT/ST IN	MIX	MATRIX	STEREO A/B
LCR On/Off			
LCR Center-Side Ratio			
Fade Time On/Off			
Fade Time Start Offset			
Fade Time Fading Time			
Insert In On/Off			
Insert Point			
Direct Out On/Off			
Direct Out Point			
Phase			
On/Off			
To Stereo Pan			
Master Balance			
Level	Master Level		
Attenuator			
GATE On/Off			
GATE Key In Filter On			
GATE Filter Type			
GATE Filter Freq.			
GATE Filter Q			
GATE Type			
GATE Attack			
GATE Range			
GATE Hold			
GATE Decay			
GATE Threshold			
COMP LINK 1-8	COMP LINK A-H		
COMP On/Off			
COMP Key In Type			
COMP Attack			
COMP Release			
COMP Ratio			
COMP OutGain			
COMP Knee/Width			
COMP Threshold			
EQ LINK 1-8	EQ LINK A-F	EQ LINK G,H	EQ LINK A-F
HPF On/Off	EQ HPF On/Off x2	EQ HPF On/Off	EQ HPF On/Off x2
HPF Freq			
EQ Type 1,2			
EQ On/Off			
EQ Filter Type x2	EQ Filter Type x4	EQ Filter Type x2	EQ Filter Type x4
EQ LPF On/Off	EQ LPF On/Off x2	EQ LPF On/Off	EQ LPF On/Off x2
EQ Q x4	EQ Q x8	EQ Q x4	EQ Q x8
EQ Freq x4	EQ Freq x8	EQ Freq x4	EQ Freq x8
EQ Gain x4	EQ Gain x8	EQ Gain x4	EQ Gain x8
	EQ Bypass x8	EQ Bypass x4	EQ Bypass x8
Delay On/Off			
Delay Time			
Surround LFE			
Surround Div.			
Surround Div.Rear			
Surround LR Pan			
Surround FR Pan			
Surround Div.Link			

INPUT/ST IN	MIX	MATRIX	STEREO A/B
Mute Group 1-8 On/Off			
DCA Group 1-8 On/Off	DCA Group 7,8 On/Off	DCA Group 7,8 On/Off	DCA Group 7,8 On/Off
To Stereo On/Off			
	To Stereo Point		
Mix Send Pre Point	Mix Send Post Point		
Mix Send Follow Pan Vari			
Mix Send Follow Pan Fixed			
Mix Send 1-24 On/Off			
Mix Send 1-24 Pre/Post			
Mix Send 1-24 Level			
Mix Send 1-24 Pan			
	To Matrix On/Off		To Matrix On/Off
	To Matrix Point		To Matrix Point
	To Matrix 1-8 Level		To Matrix 1-8 Level
	To Matrix 1-8 Pan		To Matrix 1-8 Pan
Selective Recall On			
Selective Recall Parameter			

# Channel parameter behavior when paired

This table lists the behavior of channel parameters when INPUT/ST IN channels, MIX channels, or MATRIX channels are paired.

## Parameters that are copied when pairing is enabled

INPUT/ST IN	MIX	MATRIX
LCR On/Off		
LCR Center-Side Ratio		
Fade Time On/Off		
Fade Time Start Offset		
Fade Time Fading Time		
Insert In On/Off		
Insert Point		
Direct Out On/Off		
Direct Out Point		
On/Off		
Level	Master Level	
GATE On/Off		
GATE Key In Source		
GATE Key In Filter On		
GATE Filter Type		
GATE Filter Freq.		
GATE Filter Q		
GATE Type		
GATE Attack		
GATE Range		
GATE Hold		
GATE Decay		
GATE Threshold		
COMP LINK 1-8	COMP LINK A-H	
COMP On/Off		
COMP Key In Source		
COMP Key In Type		
COMP Attack		
COMP Release		
COMP Ratio		
COMP OutGain		
COMP Knee/Width		
COMP Threshold		
EQ LINK 1-8	EQ LINK A-F	EQ LINK G,H
HPF On/Off	EQ HPF On/Off x2	EQ HPF On/Off
HPF Freq		
EQ Type 1,2		
EQ On/Off		
EQ Filter Type x2	EQ Filter Type x4	EQ Filter Type x2
EQ LPF On/Off	EQ LPF On/Off x2	EQ LPF On/Off
EQ Q x4	EQ Q x8	EQ Q x4
EQ Freq x4	EQ Freq x8	EQ Freq x4
EQ Gain x4	EQ Gain x8	EQ Gain x4
	EQ Bypass x8	EQ Bypass x4
Delay On/Off		
Surround LFE		
Surround Div.		
Surround Div.Rear		
Surround Div.Link		
Mute Group 1-8 On/Off		
DCA Group 1-8 On/Off	DCA Group 7,8 On/Off	
To Stereo On/Off		
	To Stereo Point	
Mix Send Pre Point	Mix Send Post Point	
Mix Send Follow Pan Vari		

INPUT/ST IN	MIX	MATRIX
Mix Send Follow Pan Fixed		
Mix Send 1-24 On/Off		
Mix Send 1-24 Pre/Post		
Mix Send 1-24 Level		
	To Matrix On/Off	
	To Matrix Point	
Selective Recall On		
Selective Recall Parameter		
Recall Safe On		
Recall Safe Parameter		
Mute Safe On		
Tracking On/Off		
Tracking Level		
Solo Safe On/Off		
Cue/Solo On/Off		
CH COPY CH SELECT		
GLOBAL PASTE CH SELECT		

## Parameters that are turned on when pairing is enabled

INPUT/ST IN	MIX	MATRIX
Attenuator Gang		
Gate Stereo Link		
Comp Stereo Link		
Delay Gang		

## Parameters that are not modified when pairing is enabled (reset if RESET BOTH is selected)

INPUT/ST IN	MIX	MATRIX
Phase		
To Stereo Pan		
Master Balance		
Attenuator		
Delay Time		
Surround LR Pan		
Surround FR Pan		
Mix Send 1-24 Pan		
	To Matrix 1-8 Level	
	To Matrix 1-8 Pan	
Input Pan Mode		
Surround Link On/Off		
Surround Link Pattern		
M-S Encode On/Off		
M-S Encode S-Gain		

## Parameters that are not modified when pairing is enabled (not reset even if RESET BOTH is selected)

INPUT/ST IN	MIX	MATRIX
	Mix Type (VARI, FIX, SURR)	
	TB On/Off	
	OSC On/Off	
	MONITOR DEFINE On/Off	

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

# MIDI Data Format

This section explains the format of the data that the PM5D is able to understand, send, and receive.

In addition to the messages described here, you can use the MIDI REMOTE function or the MIDI EVENT settings of the SCENE function to transmit any type of command.

## 1 CHANNEL MESSAGE

### 1.1 NOTE OFF (8n)

#### Reception

These messages are echoed to MIDI OUT if [OTHER ECHO] is ON. They are received if [Rx CH] matches, and used to control effects.

```
STATUS 1000nnnn 8n Note off message
DATA 0nnnnnnn nn Note number
0vvvvvvv vv Velocity(ignored)
```

### 1.2 NOTE ON (9n)

#### Reception

These messages are echoed to MIDI OUT if [OTHER ECHO] is ON. They are received if [Rx CH] matches, and used to control effects.

```
STATUS 1001nnnn 9n Note on message
DATA 0nnnnnnn nn Note number
0vvvvvvv vv Velocity (1-127:on, 0:off)
```

### 1.3 CONTROL CHANGE (Bn)

Two types of control change can be transmitted and received; [NRPN] (Non-Registered Parameter Numbers) and freely-assigned [TABLE] (16CH x 110) messages. Select either [TABLE] or [NRPN].

#### Reception

These messages are echoed to MIDI OUT if [Control Change ECHO] is ON. If [TABLE MULTI] is selected, these messages are received when [Control Change Rx] is ON, and will control parameters according to the settings of the [Control assign table]. If [TABLE SINGLE] is selected, these messages are received when [Control Change Rx] is ON and [Rx CH] matches, and will control parameters according to the settings of the [Control assign table]. For the parameters that can be assigned, refer to p.312.

If [NRPN] is selected, these messages are received when [Control Change Rx] is ON and the [Rx CH] matches; the four messages NRPN control number (62h, 63h) and DATA ENTRY control number (06h, 26h) are used to control the specified parameter.

#### Transmission

If [TABLE MULTI] is selected, and if [Control Change Tx] is ON when you operate a parameter that is assigned in the [Control assign table], these messages will be transmitted. If [TABLE SINGLE] is selected, and if [Control Change Tx] is ON when you operate a parameter that is assigned in the [Control assign table], these messages are transmitted on the [Tx CH] channel. For the parameters that can be assigned, refer to p.312.

If [NRPN] is selected, and if [Control Change Tx] is ON when you operate a specified parameter, the four messages NRPN control number (62h, 63h) and DATA ENTRY control number (06h, 26h) are transmitted on the [Tx CH] channel.

Control Change messages are not used for transmission to PM5D Editor because there is no guarantee that the contents of the assignment tables will match. (Parameter Change messages are always used.)

Control Change numbers 0 and 32 are for selecting banks.

```
STATUS 1011nnnn Bn Control change
DATA 00 Control number (00)
0vvvvvvv vv Control Value (0-127)

STATUS 1011nnnn Bn Control change
DATA 20 Control number (32)
0vvvvvvv vv Control Value (0-127)
```

#### If [TABLE] is selected

```
STATUS 1011nnnn Bn Control change
DATA 0nnnnnnn nn Control number (1-31,33-95,102-119) *
0vvvvvvv vv Control Value (0-127)
```

\* Numbers 0, 32, and 96–101 cannot be used.

#### Equation for converting a Control Value to parameter data

```
paramSteps = paramMax - paramMin + 1;
add = paramWidth / paramSteps;
mod = paramWidth - add * paramSteps;
curValue = parm * add + mod / 2;
```

#### (1) If the assigned parameter has fewer than 128 steps

paramWidth = 128; rxValue = Control value;

#### (2) If the assigned parameter has 128 or more but less than 16,384 steps

paramWidth = 16384;

(2-1) When High and Low data is received  
 $rxValue = Control\ value(High) * 128 + Control\ value(Low);$

(2-2) When Low data is received  
 $rxValue = (curValue \& 16256) + Control\ value(Low);$

(2-3) When High data is received  
 $rxValue = Control\ value(High) * 128 + (curValue \& 127);$

#### (3) If the assigned parameter has 16,384 or more but less than 2,097,152 steps

paramWidth = 2097152;

(3-1) When High, Middle, and Low data is received  
 $rxValue = Control\ value(High) * 16384 + Control\ value(Middle) * 128 + Control\ value(Low);$

(3-2) When only Low data is received  
 $rxValue = (curValue \& 2097024) + Control\ value(Low);$

(3-3) When only Middle data is received  
 $rxValue = (curValue \& 2080895) + Control\ value(Middle) * 128;$

(3-4) When only High data is received  
 $rxValue = (curValue \& 16383) + Control\ value(High) * 16384;$

(3-5) When only Middle and Low data is received  
 $rxValue = (curValue \& 2080768) + Control\ value(Middle) * 128 + Control\ value(Low);$

(3-6) When only High and Low data is received  
 $rxValue = (curValue \& 16256) + Control\ value(High) * 16384 + Control\ value(Low);$

(3-7) When only High and Middle data is received  
 $rxValue = (curValue \& 127) + Control\ value(High) * 16384 + Control\ value(Middle) * 128;$

if ( rxValue > paramWidth)  
 rxValue = paramWidth;  
 param = ( rxValue - mod / 2 ) / add;

#### If [NRPN] is selected

```
STATUS 1011nnnn Bn Control change
DATA 01100010 62 NRPN LSB
0vvvvvvv vv Parameter number LSB

STATUS 1011nnnn Bn Control change *
DATA 01100011 63 NRPN MSB
0vvvvvvv vv Parameter number MSB

STATUS 1011nnnn Bn Control change *
DATA 00000110 06 Data entry MSB
0vvvvvvv vv Parameter data MSB

STATUS 1011nnnn Bn Control change *
DATA 00100110 26 Data entry LSB
0vvvvvvv vv Parameter data LSB
```

\* The STATUS byte of the second and subsequent messages need not be added during transmission. Reception must occur correctly whether or not the status byte is omitted.

## 1.4 PROGRAM CHANGE (Cn)

### Reception

If [Program Change ECHO] is ON, bank select messages will also be echoed from MIDI OUT.  
If SINGLE CH is selected, these messages are received if [Program Change RX] is ON and the [Rx CH] matches. However if [OMNI] is ON, these messages are received regardless of the channel. When these messages are received, scene memories are recalled according to the settings of the [Program Change Table].

### Transmission

If [Program Change] is ON, these messages are transmitted according to the [Program Change Table] settings when a scene memory is recalled.  
If SINGLE CH is selected, these messages are transmitted on the [Tx CH] channel.  
If the recalled scene has been assigned to more than one program number, the lowest-numbered program number for each MIDI channel will be transmitted. Program Change messages are not used for transmission to PM5D Editor because there is no guarantee that the contents of the assignment tables will match. (Parameter Change messages are always used.)  
You can choose either MULTI MIDI CH or SINGLE CH.

### If SINGLE is selected

You can choose the RX CH, OMNI CH, and TX CH.  
You can choose whether a bank select message will be added.  
A bank of up to 16 can be specified.

### If MULTI is selected

The RX and TX channels will be the same.  
The assignment table will use the settings for each MIDI channel. Bank select messages will not be added.  
You can make settings for up to sixteen MIDI channels.

STATUS 1100nnnn Cn Program change  
DATA 0nnnnnnn nn Program number (0-127)

## 2 SYSTEM REALTIME MESSAGE

### 2.1 TIMING CLOCK (F8)

#### Reception

This message is used to control effects. This message is transmitted twenty-four times per quarter note.  
Echoing of this message depends on the OTHER item in the ECHO settings.

STATUS 11111000 F8 Timing clock

### 2.2 ACTIVE SENSING (FE)

#### Reception

Once this message has been received, MIDI communication will be initialized (e.g., Running Status will be cleared) if no message is received for an interval of 400 ms.  
This message is not subject to echoing.

STATUS 11111110 FE Active sensing

### 2.3 SYSTEM RESET (FF)

#### Reception

When this message is received, MIDI communication will be initialized (e.g., Running Status will be cleared).  
This message is not subject to echoing.

STATUS 11111111 FF System reset

## 3 System Exclusive Message

### 3.1 Real Time System Exclusive

Command	rx/tx	function
F0 7F dd 06 ... F7 MMC COMMAND	tx	MMC command
F0 7F dd 01 ... F7 MIDI TIME CODE	rx	Full message

### 3.2 Bulk Dump

This message is used to send or receive the contents of various memories stored within the PM5D.

The basic format is as follows.

Command	rx/tx	function
F0 43 0n 3E BB BB 0F D0 D1 D2 ... EE F7 BULK DUMP DATA	rx/tx	BULK DUMP DATA
F0 43 2n 3E 0F D0 D1 D2 ... EE F7 BULK DUMP REQUEST	rx	BULK DUMP REQUEST

The PM5D uses the following data types for a bulk dump.

Data name (D0)	Data Number (D1,2)	tx/rx	function
'M'	0-500 512 (current data)	tx/rx	Scene Memory & Request
'S'	512 (current data)	tx/rx	Setup Memory & Request (current setup)
'R'	0-99 512 (current data)	tx/rx	Input patch library & Request
'O'	0-99 512 (current data)	tx/rx	Output patch library & Request
'H'	1-199 512- (channel current data)	tx/rx	Input Channel library & Request
'h'	1-199 768- (channel current data)	tx/rx	Output Channel library & Request
'G'	1-199 512- (channel current data)	tx/rx	Gate library & Request
'Y'	1-199 512- (channel current data)	tx/rx	Compressor library & Request
'Q'	1-199 512- (channel current data)	tx/rx	Input Equalizer library & Request
'q'	1-199 768 - (channel current data)	tx/rx	Output Equalizer library & Request
'F'	1-199 512- (GEQ 1-12 current data)	tx/rx	GEQ Equalizer library & Request
'E'	1-199 512- (Effect 1-8 current data)	tx/rx	Effect library & Request
'W'	1-199 512 (current data)	tx/rx	HA library & Request
'P'	512 (current data)	tx/rx	Program change table & Request
'C'	512 (current data)	tx/rx	Control change table & Request
'N'	512 (current data)	tx/rx	Plug-in Effect Card Data & Request
'A'	512 (current data)	tx/rx	Event List & Request

The unique header (Model ID) identifies whether the device is a PM5D. To calculate the check sum, add the bytes starting with the byte after BYTE COUNT (LOW) and ending with the byte before CHECK SUM, take the binary complement, and set bit 7 to 0.  
CHECK SUM = (-sum)&0x7F

Bulk Dumps can be received at any time, and can be transmitted at any time when a Bulk Dump Request is received.

A Bulk Dump is transmitted on the [Rx CH] channel in response to a Bulk Dump Request.

In the data portion, seven words of 8-bit data are converted into eight words of 7-bit data.

#### [Conversion from actual data to bulk data]

```
d[0..6]: actual data
b[0..7]: bulk data
b[0] = 0;
for( I=0; I<7; I++){
    if( d[I]&0x80){
        b[0] |= 1<<(6-I);
    }
    b[I+1] = d[I]&0x7F;
}
}
```



### 4.3.2 Function names

FUNCTION NAME	
Store	"LibStr_"
Recall	"LibRcl_"
Store -Unknown Factor- *1	"LibUnStr"

\*1 This indicates that the library data has been updated due to an external cause (such as LOAD).

### 4.3.3 Module names

MODULE NAME	
Scene	"SCENE_"
Input Patch	"INPATCH_"
Output Patch	"OUTPATCH"
Input Channel	"INCHNNL_"
Output Channel	"OUTCHNNL"
Input EQ	"INEQ_"
Output EQ	"OUTEQ_"
Gate	"GATE_"
Comp	"COMP_"
GEQ	"GEQ_"
Effect	"EFFECT_"
HA	"HA_"

Function		Number	Channel	tx/rx
"LibStr_"	SCENE	1- 500	*5	tx/rx
	INPATCH	1- 99	*5	tx/rx
	OUTPATCH LIB	1- 99	*5	tx/rx
	INPUT CHANNEL LIB	1- 199	*1	tx/rx
	OUTPUT CHANNEL LIB	1- 199	*2 *3 *4	tx/rx
	INPUT EQ LIB	41- 199	*1	tx/rx
	OUTPUT EQ LIB	4- 199	*2 *3 *4	tx/rx
	GATE LIB	5- 199	*1	tx/rx
	COMP LIB	37- 199	*1 *2 *3 *4	tx/rx
	GEQ LIB	1- 199	*6	tx/rx
	EFFECT LIB	48- 199	*7	tx/rx
"LibUnStr"	HA LIB	1- 199	*5	tx/rx
	SCENE	1- 500		tx/rx
	INPATCH	1- 99		tx/rx
	OUTPATCH LIB	1- 99		tx/rx
	INPUT CHANNEL LIB	1- 199		tx/rx
	OUTPUT CHANNEL LIB	1- 199		tx/rx
	INPUT EQ LIB	41- 199		tx/rx
	OUTPUT EQ LIB	4- 199		tx/rx
	GATE LIB	5- 199		tx/rx
	COMP LIB	37- 199		tx/rx
	GEQ LIB	1- 199		tx/rx
"LibRcl_"	EFFECT LIB	48- 199		tx/rx
	HA LIB	1- 199		tx/rx
	SCENE	0- 500	*5	tx/rx
	INPATCH	0- 99	*5	Tx/rx
	OUTPATCH LIB	0- 99	*5	Tx/rx
	INPUT CHANNEL LIB	0- 199	*1	Tx/rx
	OUTPUT CHANNEL LIB	0- 199	*2 *3 *4	Tx/rx
	INPUT EQ LIB	1- 199	*1	tx/rx
	OUTPUT EQ LIB	1- 199	*2 *3 *4	tx/rx
	GATE LIB	1- 199	*1	tx/rx
	COMP LIB	1- 199	*1 *2 *3 *4	tx/rx
GEQ LIB	0- 199	*6	tx/rx	
EFFECT LIB	1- 199	*7	tx/rx	
HA LIB	0- 199	*5	tx/rx	

\*1 0: CH1-47:CH48, 48:STIN1L-55:STIN4R, 56:FXRTN 1L-63: FXRTN 4R,

\*2 256: MIX1-279:MIX24,

\*3 512: MATRIX1-519: MATRIX8,

\*4 1024: STEREO1L-1027: STEREO2R

\*5 Use 512 if the recall-destination or store-source data is single

\*6 0: GEQ1-11: GEQ12

\*7 0: Effect1-7: Effect8

## 4.4 Function Call – Library Edit – (Parameter change)

### 4.4.1 Format

#### Reception

This message is received if [Parameter change RX] is ON and [Rx CH] matches the Device number included in the SUB STATUS.

This message is echoed if [Parameter change ECHO] is ON.

When the message is received, the specified memory/library will be edited.

#### Transmission

In response to a request, a Parameter Change message is transmitted on the [Rx CH].

If [Parameter change ECHO] is ON, the message is transmitted without change.

STATUS	11110000	F0	System exclusive message
ID No.	01000011	43	Manufacture's ID number (YAMAHA)
SUB STATUS	0001nnnn	1n	n=0-15 (Device number=MIDI Channel)
GROUP ID	00111110	3E	Digital mixer
MODEL ID	00001111	0F	PM5D
DATA	00000000	00	OTHER DATA
CATEGORY			
FUNCTION NAME	01001100	"L"	(ASCII CODE) See 4.4.2

01101001 "i" (ASCII CODE)

01100010 "b" (ASCII CODE)

0fffffff ff (ASCII CODE)

MODULE NAME 0mmmmmmmm mm (ASCII CODE) See 4.4.3

0mmmmmmmm mm (ASCII CODE)

DATA 0mmmmmmmm mh number -source start High

0mmmmmmmm ml number -source start Low

0mmmmmmmm mh number -source end High

0mmmmmmmm ml number -source end Low

0mmmmmmmm mh number -destination start High

0mmmmmmmm ml number -destination to start Low

EOX 11110111 F7 End of exclusive

### 4.4.2 Function names

FUNCTION NAME	
Copy	"LibCpy_"
Paste	"LibPst_"
Clear	"LibClr_"
Cut	"LibCut_"
Insert	"LibIns_"

### 4.4.3 Module names

MODULE NAME	
Scene	"SCENE_"

## 4.5 Function Call – Library Attribute –

### 4.5.1 Title (Parameter change) format

#### Reception

This message is received if [Parameter change RX] is ON and [Rx CH] matches the Device number included in the SUB STATUS.

This message is echoed if [Parameter change ECHO] is ON.

When the message is received, the title of the specified memory/library will be edited.

#### Transmission

In response to a request, a Parameter Change message is transmitted on the [Rx CH].

If [Parameter change ECHO] is ON, the message is transmitted without change.

STATUS	11110000	F0	System exclusive message
ID No.	01000011	43	Manufacture's ID number (YAMAHA)
SUB STATUS	0001nnnn	1n	n=0-15 (Device number=MIDI Channel)
GROUP ID	00111110	3E	Digital mixer

```

MODEL ID 00001111 0F PMSD
DATA 00000000 00 OTHER DATA
CATEGORY
FUNCTION 01001100 "L" (ASCII CODE)
NAME
    01101001 "i" (ASCII CODE)
    01100010 "b" (ASCII CODE)
    01010100 "T" (ASCII CODE)
    01101001 "i" (ASCII CODE)
    01110100 "t" (ASCII CODE)
    01101100 "l" (ASCII CODE)
    01011111 "_" (ASCII CODE)
MODULE NAME 0mmmmmmmm mm (ASCII CODE) See 4.5.3
    0mmmmmmmm mm (ASCII CODE)
    0mmmmmmmm mm (ASCII CODE)
DATA 0mmmmmmmm mh number High
    0mmmmmmmm ml number Low
    0ddddddd dd title 1
    0ddddddd dd title x
EOX 11110111 F7 End of exclusive
    
```

**4.5.2 Title (Parameter request) format**

**Reception**

When this is received, a parameter change is transmitted with [Rx CH] as the device number.

```

STATUS 11110000 F0 System exclusive message
ID No. 01000011 43 Manufacture's ID number (YAMAHA)
SUB STATUS 0011nnnn 3n n=0-15 (Device number=MIDI Channel)
GROUP ID 00111110 3E Digital mixer
MODEL ID 00001111 0F PMSD
DATA 00000000 00 OTHER DATA
CATEGORY
FUNCTION 01001100 "L" (ASCII CODE)
NAME
    01101001 "i" (ASCII CODE)
    01100010 "b" (ASCII CODE)
    01010100 "T" (ASCII CODE)
    01101001 "i" (ASCII CODE)
    01110100 "t" (ASCII CODE)
    01101100 "l" (ASCII CODE)
    01011111 "_" (ASCII CODE)
MODULE NAME 0mmmmmmmm mm (ASCII CODE) See 4.5.3
    0mmmmmmmm mm (ASCII CODE)
    0mmmmmmmm mm (ASCII CODE)
DATA 0mmmmmmmm mh number High
    0mmmmmmmm ml number Low
EOX 11110111 F7 End of exclusive
    
```

**4.5.3 Title module names**

MODULE NAME		number	size
SCENE LIB	"SCENE__"	0-500,512 (0: response only)	16
INPATCH LIB	"INPATCH_"	0-99 (0: response only)	16
OUTPATCH LIB	"OUTPATCH"	0-99 (0: response only)	16
INPUT CHANNEL LIB	"INCHNNL_"	0-199 (0-1: response only)	16
OUTPUT CHANNEL LIB	"OUTCHNNL"	0-199 (0-1: response only)	16
INPUT EQ LIB	"INEQ__"	1-199 (1-40: response only)	16
OUTPUT EQ LIB	"OUTEQ_"	1-199 (1-3: response only)	16
GATE LIB	"GATE__"	1-199 (1-4: response only)	16
COMP LIB	"COMP__"	1-199 (1-36: response only)	16
GEQ LIB	"GEQ__"	1-199 (1-52: response only)	16
EFFECT LIB	"EFFECT_"	0-199 (0: response only)	16
HA LIB	"HA__"	0-199 (0: response only)	16

**4.5.4 Protect (Parameter change) format**

```

STATUS 11110000 F0 System exclusive message
ID No. 01000011 43 Manufacture's ID number (YAMAHA)
SUB STATUS 0001nnnn 1n n=0-15 (Device number=MIDI Channel)
GROUP ID 00111110 3E Digital mixer
MODEL ID 00001111 0F PMSD
DATA 00000000 00 OTHER DATA
CATEGORY
FUNCTION 01001100 "L" (ASCII CODE)
NAME
    01101001 "i" (ASCII CODE)
    01100010 "b" (ASCII CODE)
    01010000 "p" (ASCII CODE)
    01110010 "x" (ASCII CODE)
    01110100 "t" (ASCII CODE)
    01100011 "c" (ASCII CODE)
    01011111 "_" (ASCII CODE)
MODULE NAME 0mmmmmmmm mm (ASCII CODE) See 4.5.6
    0mmmmmmmm mm (ASCII CODE)
    0mmmmmmmm mm (ASCII CODE)
DATA 0mmmmmmmm mh number High
    0mmmmmmmm ml number Low
    0ddddddd dd data (unprotected:0, protected:1, read only:2)
EOX 11110111 F7 End of exclusive
    
```

**4.5.5 Protect (Parameter request) format**

**Reception**

When this is received, a parameter change is transmitted with [Rx CH] as the device number.

```

STATUS 11110000 F0 System exclusive message
ID No. 01000011 43 Manufacture's ID number (YAMAHA)
SUB STATUS 0011nnnn 3n n=0-15 (Device number=MIDI Channel)
GROUP ID 00111110 3E Digital mixer
MODEL ID 00001111 0F PMSD
DATA 00000000 00 OTHER DATA
CATEGORY
FUNCTION 01001100 "L" (ASCII CODE)
NAME
    01101001 "i" (ASCII CODE)
    01100010 "b" (ASCII CODE)
    01010000 "p" (ASCII CODE)
    01110010 "x" (ASCII CODE)
    01110100 "t" (ASCII CODE)
    01100011 "c" (ASCII CODE)
    01011111 "_" (ASCII CODE)
MODULE NAME 0mmmmmmmm mm (ASCII CODE) See 4.5.6
    0mmmmmmmm mm (ASCII CODE)
    0mmmmmmmm mm (ASCII CODE)
DATA 0mmmmmmmm mh number High
    0mmmmmmmm ml number Low
EOX 11110111 F7 End of exclusive
    
```



#### 4.6.2 Effect module names

MODULE NAME		channel
Freeze Play button	"FRZPLAY_"	0:Effect1 - 7:Effect8
Freeze Record button	"FRZREC_"	0:Effect1 - 7:Effect8

Nothing will happen if the Effect Type is different.

### 4.7 Level Meter Data – Parameter change –

#### 4.7.1 Format (Parameter change)

Once a Level Meter Request is received to enable transmission, the specified meter data will be transmitted at 50 msec intervals for a duration of ten seconds. If you want meter data to be transmitted continuously, you must transmit a Request at intervals of no longer than ten seconds.

##### Reception

This message is echoed if [Parameter change ECHO] is ON.

##### Transmission

Once transmission is enabled by a Request, the meter data specified in the Address will be transmitted on the [Rx CH] channel at a specific interval for a specific duration. (The transmission interval and the duration of transmission will differ between models of device.)

Transmission is disabled when the power is cycled, or when PORT settings are changed.

If [Parameter change ECHO] is ON, the message is transmitted without change.

```

STATUS      11110000  F0  System exclusive message
ID No.      01000011  43  Manufacture's ID number (YAMAHA)
SUB STATUS  0001nnnn  1n  n=0-15 (Device number=MIDI Channel)
GROUP ID    00111110  3E  Digital mixer
MODEL ID    00001111  0F  PM5D
DATA        00100001  21  REMOTE LEVEL METER
CATEGORY
DATA        0mmmmmmmm  mm  ADDRESS UL (See 4.7.3)
            0mmmmmmmm  mm  ADDRESS LU
            0mmmmmmmm  mm  ADDRESS LL
            0ddddd dd  Data1 H (See 4.7.5) *1
            0ddddd dd  Data1 L
            :
EOX         11110111  F7  End of exclusive

```

\*1 Two types of meter data are provided; data that uses the decay value of the DSP as-is, and data that is converted via a table according to the number of segments in the meter display.

#### 4.7.2 Format (Parameter request)

##### Reception

This message is received if [Parameter change RX] is ON and [Rx CH] matches the Device number included in the SUB STATUS. This message is echoed if [Parameter change ECHO] is ON.

When this is received, the meter data specified in the Address is transmitted on the [Rx CH] channel at a specific interval for a specific duration.

If this is received with an Address UL = 0x7F, transmission of all meter data will stop (will be disabled) immediately.

##### Transmission

If [Parameter change ECHO] is ON, the message is transmitted without change.

```

STATUS      11110000  F0  System exclusive message
ID No.      01000011  43  Manufacture's ID number (YAMAHA)
SUB STATUS  0011nnnn  3n  n=0-15 (Device number=MIDI Channel)
GROUP ID    00111110  3E  Digital mixer
MODEL ID    00001111  0F  PM5D
DATA        00100001  21  REMOTE LEVEL METER
CATEGORY
DATA        0mmmmmmmm  mm  ADDRESS UL (See 4.7.3)
            0mmmmmmmm  mm  ADDRESS LU
            0mmmmmmmm  mm  ADDRESS LL
            0ccccccc  ch  Request Ch Total Number H
            0ccccccc  cl  Request Ch Total Number L
EOX         11110111  F7  End of exclusive

```

### 4.8 Time Counter Data – Time Code –

#### 4.8.1 Format (Parameter change)

When transmission is enabled by receiving a Remote Time Counter request, Time Counter data is transmitted at 50 ms intervals for a duration of ten seconds. If you want counter data to be transmitted continuously, you must transmit a Request at intervals of no longer than ten seconds.

##### Reception

This message is echoed if [Parameter change ECHO] is ON.

##### Transmission

When transmission is enabled by a request, Time Counter data is transmitted for a specific duration.

Transmission is disabled when the power is cycled, or when PORT settings are changed.

If [Parameter change ECHO] is ON, the message is transmitted without change.

```

STATUS      11110000  F0  System exclusive message
ID No.      01000011  43  Manufacture's ID number (YAMAHA)
SUB STATUS  0001nnnn  1n  n=0-15 (Device number=MIDI Channel)
GROUP ID    00111110  3E  Digital mixer
MODEL ID    00001111  0F  PM5D
DATA        00101011  2b  Time Counter TC
CATEGORY
DATA        0ddddd dd  Hour
            0ddddd dd  Minute
            0ddddd dd  Second
            0ddddd dd  Frame
EOX         11110111  F7  End of exclusive

```

#### 4.8.2 Format (Parameter request)

##### Reception

This message is received if [Parameter change RX] is ON and [Rx CH] matches the Device number included in the SUB STATUS. This message is echoed if [Parameter change ECHO] is ON.

When this message is received, Time Counter data is transmitted on the [Rx CH] channel for a specific duration.

If a message is received with 0x7F as the second byte of the Address, data transmission will be stopped (disabled) immediately.

##### Transmission

If [Parameter change ECHO] is ON, the message is transmitted without change.

```

STATUS      11110000  F0  System exclusive message
ID No.      01000011  43  Manufacture's ID number (YAMAHA)
SUB STATUS  0011nnnn  3n  n=0-15 (Device number=MIDI Channel)
GROUP ID    00111110  3E  Digital mixer
MODEL ID    00001111  0F  PM5D
DATA        00101011  2b  Time Counter TC
CATEGORY
DATA        0ddddd dd  0: Request transmission
            0x7F: Request stop transmission
EOX         11110111  F7  End of exclusive

```

# Warning Messages

These are messages displayed in the lower part of the screen. They will disappear after a certain duration has elapsed.

Message	Meaning
#xxx of Scene is Empty!	No data has been stored in the scene you attempted to recall, or the data has been damaged so that it cannot be recalled.
#xxx of Scene is Read Only!	You attempted to overwrite (store) a read-only scene.
#xxx of Scene is Protected!	You attempted to overwrite (store) a protected scene.
Cannot Undo!	You pressed the SCENE MEMORY [UNDO] key when Undo was not available.
Cannot Assign!	You clicked an unavailable (grayed-out) grid in the patch screen, or pressed an invalid key on the panel (e.g., a DCA/MUTE assign key that is unavailable due to the selected channel).
Cannot Drop!	You attempted to drop a EQ/compressor/gate/EQ/effect mini-graph onto a location of a different type.
Pair Made.	You used a panel operation to assign channel pairing.
Pair Broken.	You used a panel operation to cancel channel pairing.
EFFECT CUE: Turned Off.	CUE was defeated because you switched to another screen from the EQ PARAM or EFFECT ASSIGN screen, or because you switched the selected effect.
KEY IN CUE: Turned Off.	KEY IN CUE was defeated because you switched from the GATE PRM/COMP PRM screen to a different screen.
Overwrite Existing Event.	In the EVENT LIST screen you input an event at the same time as a previously-input event, so the existing event was overwritten.
Event List Full! Last Event cancelled.	In the EVENT LIST screen, the event list is full; the last event in the event list was pushed out and deleted when you added a new event.
Interval from Previous Event is Too Short!	The event you are attempting to input in the EVENT LIST screen is too close to an existing event earlier than that location, so it is possible that it may not be recalled at the time you intend.
TIME CODE: Frame Jump!	The time code that was input in the EVENT LIST screen has experienced a frame jump or is running backward.
TIME CODE: Frame Mismatch!	The incoming time code has a frame rate that is different than the time code specified in the EVENT LIST screen.
MIDI: Data Framing Error!	Invalid signals are being input to the MIDI IN connector.
MIDI: Data Overrun!	Invalid signals are being input to the MIDI IN connector.
MIDI: Rx Buffer Full!	Too much data is being received at the MIDI IN connector.
MIDI: Tx Buffer Full!	Too much data is being sent from the MIDI OUT connector.
USB: Data Framing Error!	Invalid signals are being input from the USB connector input port.
USB: Data Overrun!	Invalid signals are being input from the USB connector input port.
USB: Rx Buffer Full!	Too much data is being received at the USB connector input port.
USB: Tx Buffer Full!	Too much data is being sent from the USB connector output port.
SLOT x: Data Framing Error!	Invalid signals are being input from the SLOT x input port.
SLOT x: Data Overrun!	Invalid signals are being input from the SLOT x input port.
SLOT x: Rx Buffer Full!	Too much data is being received at the SLOT x input port.
SLOT x: Tx Buffer Full!	Too much data is being sent from the SLOT x output port.
RS422: Data Framing Error!	Invalid signals are being received at the HA REMOTE connector or RS422 REMOTE connector.
RS422: Data Overrun!	Invalid signals are being received at the HA REMOTE connector or RS422 REMOTE connector.
RS422: Rx Buffer Full!	Too much data is being received at the HA REMOTE connector or RS422 REMOTE connector.
RS422: Tx Buffer Full!	Too much data is being transmitted from the HA REMOTE connector or RS422 REMOTE connector.
CASCADE: Data Framing Error!	Invalid signals are being input to the CASCADE IN/OUT connector.
CASCADE: Data Overrun!	Invalid signals are being input to the CASCADE IN/OUT connector.
CASCADE: Rx Buffer Full!	Too much data is being received at the CASCADE IN/OUT connector.
CASCADE: Tx Buffer Full!	Too much data is being transmitted from the CASCADE IN/OUT connector.
DME Control: Data Framing Error!	Invalid signals are being input during communication with the DME.
DME Control: Data Overrun!	Invalid signals are being input during communication with the DME.
DME Control: Rx Buffer Full!	Too much data is being received during communication with the DME.
DME Control: Tx Buffer Full!	Too much data is being transmitted during communication with the DME.
Wrong Word Clock!	The PM5D cannot synchronize because the source selected by MASTER CLOCK SELECT in the WORD CLOCK screen is not appropriate.
Sync Error! [xxxx]	The xxxx signal is not synchronized with the PM5D.
xxxx No Signal Present!	The xxxx signal is not being input.
Data Type Conflict! Canceled.	You attempted to execute a library recall or channel copy operation on a different type of channel.
HA Type Conflict! Data Ignored.	You attempted to recall a HA library of a different model (PM5D model or PM5D-RH model).
Conflicting GPI OUT Cancelled.	The parameter you assigned to the FADER START function or to a User Defined key is the same as an existing GPI OUT assignment, so the GPI OUT assignment was cancelled.
Conflicting USER DEFINED KEY Cancelled.	The parameter you assigned to GPI OUT is the same as an existing User Defined key assignment, so the User Defined key assignment was cancelled.
Conflicting FADER START Cancelled.	The parameter you assigned to GPI OUT is the same as an existing FADER START function, so the FADER START assignment was cancelled.
Wrong Password!	The system password or console password you input was incorrect.
System Password Changed.	The system password has been changed.
Console Password Changed.	The console password has been changed.

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

Message	Meaning
Parameter Locked.	Parameter Lock has been enabled.
Parameter Unlocked.	Parameter Lock has been defeated.
This Parameter is Locked.	The parameter you attempted to control is locked.
Channel Copied.	The selected channel settings were copied to the memory buffer.
Channel Pasted.	The channel settings in the memory buffer were pasted to the selected channel.
Nothing to Paste!	Paste cannot be performed because there is no data in the memory buffer.
Cannot Paste to Different Channel Type.	Paste cannot be performed because you are attempting to paste channel settings of a different type.
No Card in Slot!	No memory card is inserted in the MEMORY CARD slot.
File Already Exist!	The memory card already contain a file/directory with the same name as the one you are attempting to save, rename, or create.
Saving Aborted.	Saving to memory card was aborted.
Loading Aborted.	Loading from memory card was aborted.
No Controllable Gain.	You attempted to operate a gain knob that is currently disabled on the panel.
Tap Operation Ignored.	Tap operation was ignored because the TAP TEMPO button is not displayed in the screen.
Cascade Unit Disconnected.	The connection with a cascade-connected external device was broken.
Additional Cascade Unit Detected.	A cascade-connected external device was newly detected.
Incorrect Cascade Connection!	The connection is not appropriate for the cascade settings.
Couldn't Store Scene on Slave Console!	The cascade-connected slave console was unable to store the scene because the scene was protected on the slave console, or for some other reason.
Couldn't Edit Scene on Slave Console!	The cascade-connected slave console was unable to edit the scene because the scene was protected on the slave console, or for some other reason.
DME Disconnected.	The connection with an external DME was broken.
No Response from External HA.	No response from an external AD8HR or AD824.
Processing Aborted.	A process was aborted.

## Error Messages

These are messages displayed as popup windows in the center of the screen. After noting the content of the message, click the OK button in the screen to close the popup window.

Message	Meaning
Cannot Store!	Failed to store a scene memory or library.
Cannot Recall!	Failed to recall a scene memory or library.
Memory Card Full!	You attempted to save a file that was larger than the available capacity of the memory card.
File Not Found!	The file/directory does not exist on the memory card.
Couldn't Read File.	Failed to read the file from the memory card.
Couldn't Write File.	Failed to write the file to the memory card.
Couldn't Delete File.	Failed to delete the memory card file.
Couldn't Open File.	Failed to open the file from the memory card.
Couldn't Close File.	Failed to close the file on the memory card.
Unsupported File Format!	The file you attempted to load from the memory card is of an unsupported format.
No Files to Upload!	Internal memory does not contain files to upload.
Low Battery!	The backup battery voltage is low.
Power Supply has Malfunctioned!	A problem has occurred with the PW800W power supply connected to the PM5D. Please contact your Yamaha dealer.
Total Slot Power Capability Exceeded!	The I/O cards installed in the slots exceed the rated power capacity.

# Troubleshooting

Power does not turn on, panel LEDs and the LCD display do not light	<ul style="list-style-type: none"> <li>○ Are the PMSD and PW800W correctly connected by the special power cable?</li> <li>○ Is the PW800W's POWER switch turned on?</li> <li>○ In the UTILITY function PREFERENCE 2 screen, could the LED brightness have been turned down? (➔ p.188)</li> <li>○ If the power still does not turn on, contact your Yamaha dealer.</li> </ul>
Sound is not input	<ul style="list-style-type: none"> <li>○ Is the optional I/O card installed correctly? (➔ p.30)</li> <li>○ Is a signal being input from the external device?</li> <li>○ Is the input port patched to an input channel? (➔ p.66)</li> <li>○ Is the GAIN of the internal head amp or external head amp set to an appropriate level? (➔ p.36, 206)</li> <li>○ Is the EQ attenuator raised? (➔ p.260)</li> <li>○ Could insert be turned on even though it has not been specified correctly? (➔ p.70)</li> <li>○ Is the [ON] key indicator of the input channel lit?</li> <li>○ Is the fader of the input channel raised?</li> <li>○ In SOLO mode, could the [CUE] key be on for a channel that has no signal? (➔ p.96)</li> <li>○ Is the DCA fader assigned to that channel raised? Could MUTE be turned on? (➔ p.75)</li> </ul>
Sound is not output	<ul style="list-style-type: none"> <li>○ Is the optional I/O card installed correctly? (➔ p.30)</li> <li>○ Is the [ON] key indicator of the STEREO A/B channel lit?</li> <li>○ Is an output port patched to the output channel? (➔ p.67)</li> <li>○ Could LCR be on, and the CSR value be set to 1.0? (➔ p.242)</li> </ul>
Sound is not output from headphones or the MONITOR OUT jacks	<ul style="list-style-type: none"> <li>○ Is the MONITOR section [PHONES] knob or [LEVEL] knob set to an appropriate volume?</li> </ul>
Sound is not loud enough	<ul style="list-style-type: none"> <li>○ Is the GAIN of the internal head amp or external head amp set to an appropriate level? (➔ p.36, 206)</li> <li>○ Is the fader of the input channel raised?</li> <li>○ Could the EQ gain be set to an extremely low setting? (➔ p.65)</li> <li>○ Could the GATE/COMP threshold or ratio be set to an extreme setting? (➔ p.63, 64)</li> <li>○ Is the EQ attenuator raised? (➔ p.260)</li> <li>○ Is the fader of the output channel raised?</li> <li>○ Try using the various screens of the METER function to check the levels. (➔ p.209, 210)</li> <li>○ Is the DCA fader assigned to that channel raised?</li> </ul>
Sound is distorted	<ul style="list-style-type: none"> <li>○ Is the word clock set correctly? (➔ p.31)</li> <li>○ Is the GAIN of the internal head amp or external head amp set to an appropriate level? (➔ p.36, 206)</li> <li>○ Could the fader of the input channel be raised too high?</li> <li>○ Could the fader of the STEREO A/B channel be raised too high?</li> <li>○ Could the EQ gain be set to an extremely high setting? (➔ p.65)</li> </ul>
Sound is output even though it is not patched to an output channel	<ul style="list-style-type: none"> <li>○ Could you have assigned an input channel to direct out? (➔ p.72)</li> <li>○ Could you have assigned an output channel as the insert out? (➔ p.70)</li> </ul>
Paired channels are not heard in stereo	<ul style="list-style-type: none"> <li>○ Are the pan mode setting and pan value correct? (➔ p.45)</li> </ul>
The volume of a specific channel rises and falls	<ul style="list-style-type: none"> <li>○ Could GATE/COMP be set to ducking? (➔ p.63, 64)</li> </ul>
Operating a fader does not control the level as you expect	<ul style="list-style-type: none"> <li>○ Have you used the layer keys ([CH 1-24]/[CH 25-48] keys or [ST IN 1-4]/[FX RTN 1-4] keys) to select the appropriate layer?</li> <li>○ Is the FADER [FLIP] key turned off?</li> </ul>
Only the sound of a specific channel is heard from the MONITOR OUT or PHONES jack	<ul style="list-style-type: none"> <li>○ Could a [CUE] key be on?</li> </ul>
Noise occurs from an externally connected recorder or other device	<ul style="list-style-type: none"> <li>○ Is the word clock set correctly? (➔ p.31)</li> <li>○ Could the input signal be unsynchronized?</li> <li>○ Is the dither setting appropriate? (➔ p.207)</li> <li>○ Could oscillator or talkback be turned on? (➔ p.98, 99)</li> </ul>
High frequency range is attenuated	<ul style="list-style-type: none"> <li>○ Could emphasis be applied? This problem will occur if the input signal status does not match the emphasis data. (➔ p.200, 215)</li> <li>○ Could EQ be applied? (➔ p.65)</li> </ul>
An input signal is being input, but there's no monitor output	<ul style="list-style-type: none"> <li>○ Could the CUE INTERRUPTION button be on? If this button is on, the cue/solo signal will also be output from the MONITOR OUT jacks while the Cue/Solo function is active. (➔ p.217)</li> </ul>
Some channels are always heard even in SOLO mode	<ul style="list-style-type: none"> <li>○ Could those channels be set to SOLO SAFE? (➔ p.219, 219)</li> </ul>
Not enough headroom, especially when EQ boost is applied	<ul style="list-style-type: none"> <li>○ Use the EQ attenuator function to lower the level. (➔ p.260)</li> </ul>
Sound recorded via a 2TR OUT DIGITAL jack or a digital I/O card is gritty	<ul style="list-style-type: none"> <li>○ Check that the dither function matches the word length of the recording device. (➔ p.207)</li> </ul>
Signal is delayed	<ul style="list-style-type: none"> <li>○ Check whether the delay setting for each channel is set correctly. (➔ p.58)</li> </ul>
Turning a MIX encoder does not change the send level to the MIX bus	<ul style="list-style-type: none"> <li>○ Is the [MIX SEND] key turned on?</li> <li>○ Is the MIX [ON] key turned on?</li> <li>○ Is the MIX bus set to VARI type? (➔ p.201)</li> <li>○ If the send point is set to POST, could the fader have been lowered?</li> </ul>
Can't save scene memory or library data	<ul style="list-style-type: none"> <li>○ Are you attempting to save the data to a read-only scene/library or a protected scene? (➔ p.159)</li> </ul>
Can't save to a memory card	<ul style="list-style-type: none"> <li>○ Is the memory card protected?</li> <li>○ Does the memory card have enough free capacity to save the data?</li> <li>○ When formatting a memory card, format it in FAT16 format.</li> </ul>
Can't transmit/receive MIDI data	<ul style="list-style-type: none"> <li>○ Is the MIDI PORT selected correctly? (➔ p.113, 115, 117)</li> <li>○ Are the mode and channel selected correctly on the transmitting and receiving devices? (➔ p.113, 115)</li> <li>○ Has an event been assigned for the program change? (➔ p.113)</li> </ul>
The [ON] keys or [SEL] keys select the wrong channels	<ul style="list-style-type: none"> <li>○ Have you used the layer keys ([CH 1-24]/[CH 25-48] keys or [ST IN 1-4]/[FX RTN 1-4] keys) to select the appropriate layer?</li> </ul>

Information shown in the display

Function menu

Global functions

Output functions

Input functions

Appendices

You paired input channels, but the signal phase is incorrect	○ Set the paired input channels to the same phase setting. Even when channels are paired, the phase settings are not linked. (➔ p.45)
When you recall a scene, some channels/parameters are not updated	○ Could those channels/parameters be set to Recall Safe or Selective Recall? (➔ p.84, 86)
You turn on a CUE button in the EFFECT PARAM screen, but it is automatically defeated	○ This is defeated automatically when you switch screens in the display. (➔ p.152)
Can't make boost settings with the GEQ	○ In the GEQ PARAM screen, could LIMIT be set to -24 dB? (➔ p.111)
When you recall a scene, it takes a certain amount of time for the faders to stop	○ Could you have specified a fade time? (➔ p.87)
The panel LEDs or LCD display are too dark / too bright	○ In the UTILITY function PREFERENCE 2 screen, use the BRIGHTNESS setting to adjust the brightness. (➔ p.188)

## General Specifications

Sampling Frequency	Internal: 44.1 kHz, 48 kHz, 88.2 kHz, 96 kHz External: 44.1 kHz (-10%) to 48 kHz (+6%) 88.2 kHz (-10%) to 96 kHz (+6%)
Signal Delay	PM5D: Less than 2.3 ms INPUT to STEREO A,B (@Fs = 48 kHz) Less than 1.15 ms INPUT to STEREO A,B (@Fs = 96 kHz) PM5D-RH: Less than 2.5 ms INPUT to STEREO A,B (@Fs = 48 kHz) Less than 1.25 ms INPUT to STEREO A,B (@Fs = 96 kHz)
Fader	100mm motorized x38
Fader Resolution	+10 to -138, -∞ dB (1024 steps/100 mm)
Maximum Voltage Gain	PM5D: 84 dB INPUT1-48 to Each Output PM5D-RH: 86 dB INPUT1-48 to Each Output
Crosstalk (@1kHz)	-80 dB Adjacent Input Channels (INPUT1-48)
Dimensions	1551 x 950 x 283 mm (W x D x H)
Net Weight	PM5D: 98 kg PM5D-RH: 97 kg
Power Requirements	PM5D: 480W, DC 24V, 20A (Use PW800W Only) PM5D-RH: 528W, DC 24V, 22A (Use PW800W Only)
Operation free-air Temperature Range	+10 °C to +35 °C
Storage Temperature Range	-20 °C to +60 °C
Included Accessories	Owner's Manual Gooseneck Lamps x 3 Power Supply PW800W Connection Cable Studio Manager CD-ROM Studio Manager Installation Guide
Optional Accessories	mini YGDAL cards Power Supply PW800W Power Supply Link Cable PSL120

## □ Analog Input (1-48)

<b>Connector</b>	XLR-3-31 Type (Balanced) x48
<b>Phantom Power</b>	PM5D: +48V DC is supplied to Input by individual mechanical switch PM5D-RH: +48V DC is supplied to Input by individual software control
<b>Pad Switch</b>	PM5D: 0/26 dB attenuation
<b>Gain Control</b>	PM5D: 44 dB detented -60 dB to -16 dB (PAD=OFF), -34 to +10 dB (PAD=ON) PM5D-RH: 72 dB by software control -62 dB to 10 dB (1 dB step)
<b>Peak Indicator</b>	Red LED is lit when post HA level reaches 3 dB below clipping
<b>Signal Indicator</b>	Green LED is lit when post HA level reaches 14 dB below nominal
<b>Insert (Pre AD converter)</b>	PM5D: Out, In (TRS Balanced)
<b>Insert Switch</b>	PM5D: On/Off
<b>AD Converter</b>	24bit linear, 128 times oversampling

## □ Analog Input (ST IN1-4 [L,R])

<b>Connector</b>	XLR-3-31 Type (Balanced) x8
<b>Phantom Power</b>	PM5D-RH: +48V DC is supplied to Input by individual software control
<b>Gain Control</b>	PM5D: 44 dB detented -34 dB to +10 dB PM5D-RH: 72 dB by software control -62 dB to +10 dB (1 dB step)
<b>Peak Indicator</b>	Red LED is lit when post HA level reaches 3 dB below clipping
<b>Signal Indicator</b>	Green LED is lit when post HA level reaches 14 dB below nominal
<b>AD Converter</b>	24bit linear, 128 times oversampling

## □ Analog Input (2TR IN ANALOG1,2 [L,R])

<b>Connector</b>	XLR-3-31 Type (Balanced) x4
<b>Gain Switch</b>	+24 dBu (default) / +18 dBu
<b>AD Converter</b>	24bit linear, 128 times oversampling

## □ Digital Input (2TR IN DIGITAL1-3)

<b>Connector</b>	AES/EBU XLR-3-31 Type (Balanced) x2 (DIGITAL IN 1,2) SPDIF RCA PIN (DIGITAL IN 3)
<b>Sampling Rate Converter</b>	On/Off by software control (1:3 and 3:1 maximum input to output sample rate ratio)

## □ Talkback Input

<b>Connector</b>	XLR-3-31 Type (Balanced)
<b>Phantom Power</b>	+48V DC is supplied by software control
<b>Gain</b>	50 dB fixed (pre level control)
<b>AD Converter</b>	24bit linear, 128 times oversampling
<b>Talkback Select</b>	TALKBACK IN and selected INPUT1-48 can be used simultaneously

## □ Oscillator

<b>Level</b>	0 to -96dB (1dB step)
<b>On/Off</b>	Dedicated switch and software control
<b>Waveform</b>	MODE: Sine Wave 1ch, Sine Wave 2ch, Pink Noise, Burst Noise Sine Waveform: 100Hz, 1kHz, 10kHz
<b>Routing</b>	MIX1-24, MATRIX1-8, STEREO A,B (L,R)

## □ STEREO A,B [L,R], MIX1-24, MATRIX1-8

<b>Connector</b>	XLR-3-32 Type (Balanced)
<b>DA Converter</b>	24bit linear, 128 times oversampling

## □ MONITOR OUT [L,C,R], CUE OUT

<b>Connector</b>	XLR-3-32 Type (Balanced)
<b>DA Converter</b>	24bit linear, 128 times oversampling
<b>Level Control</b>	Analog potentiometer

## □ PHONES (x2)

<b>Connector</b>	TRS
<b>Level Control</b>	Analog potentiometer

## □ Digital Output (2TR OUT DIGITAL1-3)

<b>Connector</b>	AES/EBU XLR-3-32 Type (Balanced) x2 (DIGITAL OUT 1,2) SPDIF RCA PIN (DIGITAL OUT 3)
<b>Sampling Rate Converter</b>	On/Off by software control (1:3 and 3:1 maximum input to output sample rate ratio)

# Input/output characteristics

## □ Analog Input Characteristics (PM5D)

Input Terminals	PAD	GAIN	Actual Load Impedance	For Use With Nominal	GAIN SW *4	Input Level			Connector
						Sensitivity *1	Nominal	Max. Before Clip	
INPUT 1-48	0	-60dB	3kΩ	50-600Ω Mics & 600Ω Lines	—	-80 dBu (0.0775 mV)	-60 dBu (0.775 mV)	-40 dBu (7.75 mV)	XLR-3-31 Type (Balanced)*2
		-16dB				-36 dBu (12.3 mV)	-16 dBu (1.23 mV)	+4 dBu (1.23 V)	
	26	-10 dBu (245 mV)				+10 dBu (2.45 V)	+30 dBu (24.51 V)		
ST IN1-4 [L,R]	—	-34dB	4kΩ	600Ω Lines	—	-54 dBu (1.55 mV)	-34 dBu (15.5 mV)	-14 dBu (155 mV)	XLR-3-31 Type (Balanced)*2
		10dB				-10 dBu (245 mV)	+10 dBu (2.54 V)	+30 dBu (24.51 V)	
INSERT IN 1-48	—	—	10kΩ	600Ω Lines	—	-16 dBu (123 mV)	+4 dBu (1.23 V)	+24 dBu (12.28 V)	Phone Jack (TRS) (Balanced)*3
2TR IN ANALOG 1,2 [L,R]	—	—	10kΩ	600Ω Lines	+24 dB (default)	-6 dBu (388 mV)	+4 dBu (1.23 V)	+24 dBu (12.28 V)	XLR-3-31 Type (Balanced)*2
					+18 dB	-12 dBu (195 mV)	-2 dBu (0.616 V)	+18 dBu (6.16 V)	
TALKBACK	—	—	3kΩ	50-600Ω Mics & 600Ω Lines	—	-60 dBu (0.775 mV)	-50 dBu (2.45 mV)	-30 dBu (24.5 mV)	XLR-3-31 Type (Balanced)*2

## □ Analog Input Characteristics (PM5D-RH)

Input Terminals	GAIN	Actual Load Impedance	For Use With Nominal	GAIN SW *4	Input Level			Connector
					Sensitivity *1	Nominal	Max. Before Clip	
INPUT 1-48	-62dB	3kΩ	50-600Ω Mics & 600Ω Lines	—	-82 dBu (61.6 μV)	-62 dBu (0.616 mV)	-42 dBu (6.16 mV)	XLR-3-31 Type (Balanced)*2
	+10dB				-10 dBu (245 mV)	+10 dBu (2.45 V)	+30 dBu (24.5 V)	
ST IN1-4 [L,R]	-62dB	3kΩ	50-600Ω Mics & 600Ω Lines	—	-82dBu (61.6 μV)	-62 dBu (0.616 mV)	-42 dBu (6.16 mV)	XLR-3-31 Type (Balanced)*2
	+10dB				-10 dBu (245 mV)	+10 dBu (2.45 V)	+30 dBu (24.5 V)	
2TR IN ANALOG 1,2 [L,R]	—	10kΩ	600Ω Lines	+24 dB (default)	-6 dBu (388 mV)	+4 dBu (1.23 V)	+24 dBu (12.28 V)	XLR-3-31 Type (Balanced)*2
				+18 dB	-12 dBu (195 mV)	-2 dBu (0.616 V)	+18 dBu (6.16 V)	
TALKBACK	—	3kΩ	50-600Ω Mics & 600Ω Lines	—	-60 dBu (0.775 mV)	-50 dBu (2.45 mV)	-30 dBu (24.5 mV)	XLR-3-31 Type (Balanced)*2

\*1. Sensitivity is the lowest level that will produce an output of +4 dBu (1.23 V) or the nominal output level when the unit is set to maximum gain. (All faders and level controls are maximum position.)

\*2. XLR-3-31 type connectors are balanced. (1=GND, 2=HOT, 3=COLD)

\*3. Phone jacks are balanced. (Tip=HOT, Ring=COLD, Sleeve=GND )

\*4. There are switches inside the body to preset the maximum input level.

\* In these specifications, 0 dBu = 0.775 Vrms.

\* All input AD converters are 24bit linear, 128 times (@48 kHz) oversampling.

\* PM5D: +48V DC (phantom power) is supplied to INPUT (1-48) XLR type connectors via each individual switch, and TALKBACK XLR type connectors via software switch.

PM5D-RH: +48V DC (phantom power) is supplied to INPUT (1-48) and TALKBACK XLR type connectors via master mechanical switch and each individual software switch.

## □ Analog Output Characteristics

Output Terminals	Actual Source Impedance	For Use With Nominal	GAIN SW <sup>*4</sup>	Output Level		Connector
				Nominal	Max. Before Clip	
STEREO A,B [L,R]	150Ω	600Ω Lines	+24 dB (default)	+4 dBu (1.23 V)	+24 dBu (12.28 V)	XLR-3-32 Type (Balanced) <sup>*1</sup>
			+18 dB	-2 dBu (616 mV)	+18 dBu (6.16 V)	
MONITOR OUT [L,R,C]	150Ω	600Ω Lines	+24 dB (default)	+4 dBu (1.23 V)	+24 dBu (12.28 V)	XLR-3-32 Type (Balanced) <sup>*1</sup>
			+18 dB	-2 dBu (616 mV)	+18 dBu (6.16 V)	
CUE OUT [L,R]	150Ω	600Ω Lines	+24 dB (default)	+4 dBu (1.23 V)	+24 dBu (12.28 V)	XLR-3-32 Type (Balanced) <sup>*1</sup>
			+18 dB	-2 dBu (616 mV)	+18 dBu (6.16 V)	
MATRIX OUT 1-8	150Ω	600Ω Lines	+24 dB (default)	+4 dBu (1.23 V)	+24 dBu (12.28 V)	XLR-3-32 Type (Balanced) <sup>*1</sup>
			+18 dB	-2 dBu (616 mV)	+18 dBu (6.16 V)	
MIX OUT 1-24	150Ω	600Ω Lines	+24 dB (default)	+4 dBu (1.23 V)	+24 dBu (12.28 V)	XLR-3-32 Type (Balanced) <sup>*1</sup>
			+18 dB	-2 dBu (616 mV)	+18 dBu (6.16 V)	
INSERT OUT 1-48	150Ω	10kΩ Lines	—	+4 dBu (1.23 V)	+24 dBu (12.28 V)	Phone Jack (TRS) (Balanced) <sup>*2 *5</sup>
PHONES (x 2)	15Ω	8Ω Phones	—	75 mW <sup>*6</sup>	150 mW	Stereo Phone Jack
		40Ω Phones	—	65 mW <sup>*6</sup>	150 mW	(TRS) (Unbalanced) <sup>*3</sup>

\*1. XLR-3-32 type connectors are balanced. (1=GND, 2=HOT, 3=COLD)

\*2. Phone jacks are balanced. (Tip=HOT, Ring=COLD, Sleeve=GND)

\*3. PHONES stereo phone jacks are unbalanced. (Tip=LEFT, Ring=RIGHT, Sleeve=GND)

\*4. There are switches inside the body to preset the maximum output level.

\*5. INSERT OUTs are only provided for PM5D.

\*6. The position of the level control is 10 dB lowered from Max.

\* In these specifications, 0 dBu = 0.775 Vrms.

\* All output DA converters are 24bit, 128 times (@48 kHz) oversampling.

## □ Digital Input Characteristics

Terminal	Format	Data Length	Level	Connector	
2TR IN DIGITAL	1 AES/EBU	AES/EBU	24bit	RS422	XLR-3-31 Type (Balanced) <sup>*1</sup>
	2 AES/EBU	AES/EBU	24bit	RS422	XLR-3-31 Type (Balanced) <sup>*1</sup>
	3 COAXIAL	IEC-60958	24bit	0.5Vpp/75Ω	RCA Pin Jack
CASCADE IN	—	—	RS422	D-Sub Half Pitch Connector 68P (Female)	

\*1. XLR-3-31 type connectors are balanced. (1=GND, 2=HOT, 3=COLD)

## □ Digital Output Characteristics

Terminal	Format	Data Length	Level	Connector	
2TR OUT DIGITAL	1 AES/EBU	AES/EBU <sup>*1</sup> Professional Use	24bit <sup>*3</sup>	RS422	XLR-3-32 Type (Balanced) <sup>*4</sup>
	2 AES/EBU	AES/EBU <sup>*1</sup> Professional Use	24bit <sup>*3</sup>	RS422	XLR-3-32 Type (Balanced) <sup>*4</sup>
	3 COAXIAL	IEC-60958 <sup>*2</sup> Consumer Use	24bit <sup>*3</sup>	0.5Vpp/75Ω	RCA Pin Jack
CASCADE OUT	—	—	RS422	D-Sub Half Pitch Connector 68P (Female)	

\*1. The channel status of 2TR OUT DIGITAL 1,2 is described on page 350.

\*2. The channel status of 2TR OUT DIGITAL 3 is described on page 350.

\*3. Dither: word length 16/20/24 bit

\*4. XLR-3-32 type connectors are balanced. (1=GND, 2=HOT, 3=COLD)

• Channel Status of 2TR OUT DIGITAL 1,2

byte	bit	field name	fixed/variable	data	description
0	0	Block Format	fixed	1	professional use
	1	Mode		0	audio
	2-4	Emphasis		0x4	off
	5	Fs Lock		0	lock
	6-7	Sampling Frequency	variable	0x0	others
		0x3		32kHz	
		0x2		44.1kHz	
		0x1		48kHz	
1	0-3	Channel Mode	fixed	0x1	2ch mode
	4-7	Users Bit Management		0x0	—
2	0-2	Use of AUX	fixed	0x1	24bits Audio Data
	3-7	Source		0x00	—
3	0-7	Multi Channel	fixed	0x00	—
4	0-1	Digital Audio Reference Signal	fixed	0x0	—
	2	—		0	
	3-6	Sampling Frequency	variable	0x0	others
				0x5	88.2kHz
				0x4	96kHz
7	Sampling Frequency Scan Flag	fixed	0	—	

• Channel Status of 2TR OUT DIGITAL 3

byte	bit	field name	fixed/variable	data	description
0	0	Block Format	fixed	0	consumer use
	1	Mode			audio
	2	Copy		1	enabled
	3	Emphasis		0	off
	4	—			—
	5				
	6				
	7				
1	0-7		Category Code	fixed	
2	0-3	Source Number	fixed	0x0	
	4-7	Channel Number			
3	0-3	Sampling Frequency	variable	0xC	32kHz
				0x0	44.1kHz
				0x4	48kHz
				0x8	—
				0x1	88.2kHz
				0x5	96kHz
	4-5	Fs Accuracy	fixed	0x0	Level II
6	—	0		—	
7					
4	0	Maximum Audio Sample word length	fixed	1	24bits
	1-3	Sample Word Length	fixed	0x5	24bits
4-7	Original Sampling Frequency	variable	0x3	32kHz	
			0xF	44.1kHz	
			0xB	48kHz	
			0x0	—	
			0xE	88.2kHz	
			0xA	96kHz	

## Control I/O Characteristics

Terminal		Format	Level	Connector	
TO HOST	USB	USB 1.1	—	B Type USB Connector	
MIDI	IN	MIDI		—	DIN Connector 5P
	THRU				
	OUT				
TIME CODE IN	SMPTE	SMPTE	0.3Vpp(Min)/10.0Vpp(Max), 10kΩ	XLR-3-31 Type (Balanced)*1	
WORD CLOCK	IN	—	TTL/75Ω (ON/OFF)	BNC Connector	
	OUT		TTL/75Ω		
GPI		—	RS422	D-Sub Connector 25P (Female)*3	
HA REMOTE				D-Sub Connector 9P (Male)	
RS422 REMOTE				D-Sub Connector 9P (Female)	
KEYBOARD		PS/2	—	DIN Connector 6P	
MOUSE					
LAMP 1,2,3		—	2.5V - 11.5V	XLR-4-31 Type*2	
MEMORY CARD			—	—	PCMCIA (Compact Flash)

\*1. XLR-3-31 type connectors are balanced. (1/Sleeve=GND, 2/Tip=HOT, 3/Ring=COLD)

\*2. 4pin=HOT, 3pin=COLD, Lamp rating 5 W, Voltage control by variable volume

\*3. Inputs: 4 channels, Outputs: 12 channels

Input Pin: AD Converter (7bit, 128steps, Voltage Detection Range: 0-5V, Maximum Rating: 5V)

Output Pin: Open Collector (Vmax=12V, Imax/pin=75 mA, GPO1-8: Total Imax=300 mA, GPO9-12: Total Imax=300 mA)

Power Pin: Power Supply (Vp=5V, Imax/2 pin=500 mA)

## SLOT 1-4 Characteristics

Card Name	Function	Input	Output	The Number Of Usable Cards
MY8-AT	ADAT	8 IN	8 OUT	4
MY8-TD	TASCAM			
MY8-AE	AES/EBU			
MY4-AD	ANALOG IN	4 IN	—	
MY8-AD		8 IN		
MY4-DA	ANALOG OUT	—	4 OUT	
MY8-AD24	ANALOG IN	8 IN	—	
MY8-AD96				
MY8-DA96	ANALOG OUT	—	8 OUT	
MY8-AE96S	AES/EBU	8 IN		
MY8-AE96				
MY16-AT	ADAT	16 IN	16 OUT	
MY16-AE	AES/EBU			
MY16-TD	TASCAM			
MY16-C	CobraNet™	16 IN	16 OUT	

Information shown  
in the display

Function  
menu

Global  
functions

Output  
functions

Input  
functions

Appendices

## Electrical characteristics

All faders are nominal when measured. Output impedance of signal generator:150ohms

- **Frequency Response** Fs= 44.1 kHz or 48 kHz @20 Hz–20 kHz, referenced to the nominal output level @1 kHz  
Fs= 88.2 kHz or 96 kHz @20 Hz–40 kHz, referenced to the nominal output level @1 kHz

Input	Output	RL	Conditions	Min.	Typ.	Max.	Unit
INPUT 1-48	STEREO A,B	600Ω	PM5D: GAIN: Max., PAD: Off PM5D-RH: GAIN: Max.	-1.5	0.0	0.5	dB
	MIX OUT						
	MATRIX OUT						
	MONITOR OUT						
	CUE OUT	8Ω		-3.0			
2TR IN ANALOG 1,2	STEREO A,B	600Ω		-1.5			
	MONITOR OUT						

- **Gain Error** @1 kHz

Input	Output	RL	Conditions	Min.	Typ.	Max.	Unit
INPUT 1-48	STEREO A,B	600Ω	PM5D: Input Level : -60 dBu, GAIN: Max., PAD: Off PM5D-RH: Input Level : -62 dBu, GAIN: Max.	2.0	4.0	6.0	dBu
			PM5D: Input Level : +10 dBu, GAIN: Min., PAD: On PM5D-RH: Input Level : +10 dBu, GAIN: Min.				
2TR IN ANALOG 1,2	STEREO A,B	600Ω	Input Level: +4 dBu	2.0	4.0	6.0	
Internal OSC	STEREO A,B	600Ω	Full Scale Output	23.5	24.0	24.5	dBu
	MIX OUT						
	MATRIX OUT						
	MONITOR OUT						
	CUE OUT	8Ω	Full Scale Output, MONITOR Level Control: Max.				
PHONES	8Ω	-30 dBFs, PHONES Level Control: Max.	-0.5	0	0.5		

- **Total Harmonic Distortion** Fs= 44.1 kHz or 48 kHz

Input	Output	RL	Conditions	Min.	Typ.	Max.	Unit
INPUT 1-48	STEREO A,B	600Ω	PM5D: +4 dBu @20 Hz–20 kHz, GAIN: Max., PAD: Off PM5D-RH: +4 dBu @20 Hz–20 kHz, GAIN: Max.			0.1	%
			PM5D: +4 dBu @20 Hz–20 kHz, GAIN: Min., PAD: On PM5D-RH: +4 dBu @20 Hz–20 kHz, GAIN: Min.			0.05	
2TR IN ANALOG 1,2	STEREO A,B	600Ω	+4 dBu @20 Hz–20 kHz			0.05	
Internal OSC	STEREO A,B	600Ω	Full Scale Output @1 kHz			0.02	%
	MIX OUT						
	MATRIX OUT						
	MONITOR OUT						
	CUE OUT	8Ω	Full Scale Output @1 kHz, MONITOR Level Control : Max.				
PHONES	8Ω	Full Scale Output @1 kHz, CUE Level Control: Max.					
		8Ω	Full Scale Output @1 kHz, PHONES Level Control: Max.			0.2	

\* Total Harmonic Distortion is measured with a 18 dB/octave filter @80 kHz

- **Total Harmonic Distortion** Fs=88.2 kHz or 96 kHz

Input	Output	RL	Conditions	Min.	Typ.	Max.	Unit
INPUT 1-48	STEREO A,B	600Ω	PM5D: +4 dBu @20 Hz–40 kHz, GAIN: Max., PAD: Off PM5D-RH: +4 dBu @20 Hz–40 kHz, GAIN: Max.			0.1	%
			PM5D: +4 dBu @20 Hz–40 kHz, GAIN: Min., PAD: On PM5D-RH: +4 dBu @20 Hz–40 kHz, GAIN: Min.			0.05	
2TR IN ANALOG 1,2	STEREO A,B	600Ω	+4 dBu @20 Hz–40 kHz			0.05	
Internal OSC	STEREO A,B	600Ω	Full Scale Output @1 kHz			0.02	%
	MIX OUT						
	MATRIX OUT						
	MONITOR OUT						
	CUE OUT	8Ω	Full Scale Output @1 kHz, MONITOR Level Control : Max.				
PHONES	8Ω	Full Scale Output @1 kHz, CUE Level Control: Max.					
		8Ω	Full Scale Output @1 kHz, PHONES Level Control: Max.			0.2	

\* Total Harmonic Distortion is measured with a 18 dB/octave filter @80 kHz

## □ Hum & Noise

EIN= Equivalent Input Noise

Input	Output	RL	Conditions	Min.	Typ.	Max.	Unit
INPUT 1-48	STEREO A,B	600Ω	Master fader at nominal level and one INPUT fader at nominal level. PM5D: Rs= 150Ω, GAIN: Max., PAD: Off		-128 EIN		dBu
			PM5D-RH: Rs= 150Ω, GAIN: Max.		-64		
Master fader at nominal level and one INPUT fader at nominal level. PM5D: Rs= 150Ω, GAIN: Min., PAD: On			-81	-76			
PM5D-RH: Rs= 150Ω, GAIN: Min.							
All INPUT			Master fader at nominal level and all INPUT1-48 faders at nominal level. PM5D: Rs= 150Ω, GAIN: Min., PAD: On			-64	
			PM5D-RH: Rs= 150Ω, GAIN: Min.				
2TR IN ANALOG 1,2	STEREO A,B	600Ω	Master fader at nominal level. Rs= 150Ω		-81	-76	
—	STEREO A,B	600Ω	Residual Output Noise, ST Master Off				-86
	MIX OUT		Residual Output Noise, MIX Master Off				
	MATRIX OUT		Residual Output Noise, MATRIX Master Off				
	MONITOR OUT		Residual Output Noise, MONITOR Level Control Min.				
	CUE OUT		Residual Output Noise, CUE Level Control Min.				
	PHONES	8Ω	Residual Output Noise, PHONES Level Control Min.				

\* Hum & Noise is measured with a 6 dB/octave filter @12.7 kHz; equivalent to a 20 kHz filter with infinite dB/octave attenuation.

## □ Dynamic Range

Input	Output	RL	Conditions	Min.	Typ.	Max.	Unit
INPUT 1-48	STEREO A,B	600Ω	PM5D: AD + DA, GAIN: Min., PAD: On Fs= 44.1/48 kHz		108		dB
			PM5D-RH: AD + DA, GAIN: Min. Fs= 88.2/96 kHz		106		
—	STEREO A,B	600Ω	DA Converter		110		dB
	MIX OUT						
	MATRIX OUT						
	MONITOR OUT						
	CUE OUT						

\* Dynamic range is measured with a 6 dB/octave filter @12.7 kHz; equivalent to a 20 kHz filter with infinite dB/octave attenuation.

## □ Input Indicator Level

Input	Output	Condition	Min.	Typ.	Max.	Unit
INPUT 1-48	INSERT OUT	PEAK Red LED: ON	19	21	23	dBu
		SIGNAL Green LED: ON	-12	-10	-8	
PEAK Red LED: ON		19	21	23		
SIGNAL Green LED: ON		-12	-10	-8		
ST IN 1-4						

## □ Sampling Frequency

Parameter	Conditions	Min.	Typ.	Max.	Unit	
External Clock	Frequency Range	Normal Rate	39.69		50.88	kHz
		Double Rate	79.39		101.76	
Internal Clock	Frequency	Word Clock : Int 44.1kHz		44.1		kHz
		Word Clock : Int 48kHz		48		
		Word Clock : Int 88.2kHz		88.2		
		Word Clock : Int 96kHz		96		
	Accuracy	Word Clock : Int 44.1kHz			50	ppm
		Word Clock : Int 48kHz				
		Word Clock : Int 88.2kHz				
		Word Clock : Int 96kHz				
	Jitter	Word Clock : Int 44.1kHz			5	ns
		Word Clock : Int 48kHz				
Word Clock : Int 88.2kHz						
Word Clock : Int 96kHz						

## Other Functions

### Libraries

Name	Number	Total
Scene Memory	Preset 1 + User 500	501
Input Patch Library	Preset 1 + User 99	100
Output Patch Library	Preset 1 + User 99	100
Input Channel Library	Preset 1 + User 199	200
Output Channel Library	Preset 1 + User 199	200
Input EQ Library	Preset 40 + User 159	199
Output EQ Library	Preset 3 + User 196	199
GATE Library	Preset 4 + User 195	199
COMP Library	Preset 36 + User 163	199
Effect Library	Preset 54 + User 145	199
GEQ Library	Preset 1 + User 199	200
HA Library	Preset 1 + User 199	200

### Input Function

Function	Parameter
Phase	Normal/Reverse
MS Decode	On, S-Gain
Attenuator	-96 to +24 dB
HPF	Slope= 12 dB/Oct
	Frequency= 20 Hz to 600 Hz
4Band Equalizer	Frequency= 20 Hz to 20 kHz
	Gain= -18 dB to +18 dB
	Q= 0.10 to 10.0
	Low Shelving (Low Band)
	High Shelving, LPF (High Band)
	Type I/Type II
Insert	Insert Point: Pre EQ/Post EQ/Pre Delay/Post Fader
Direct Out	Direct Out Point: Pre HPF/Pre EQ/Pre Fader/Post On
Noise Gate	Type: Gate/Ducking
	Threshold= -54 dB to 0 dB
	Attack= 0 msec to 120 msec
	Hold= 0.02 msec to 1.96 sec
	Decay= 5 msec to 42.3 sec
	Range= -70 dB to 0 dB
	Key In: Self Pre EQ/Self Post EQ/Mix21-24/ Ch1-STIN4R (8ch block)
	Key In Filter: HPF/LPF/BPF
Compressor	Type: Comp/Expander/Compannder H/ Compannder S
	Threshold= -54 dB to 0 dB
	Ratio= 1:1 to ∞:1
	Attack= 0 msec to 120 msec
	Release= 5 msec to 42.3 sec
	Gain= 0 dB to +18 dB
	Knee= Hard to 5 (soft)
Input Delay	Time= 0.0 msec to 1000 msec
Fader	Level: 1024 steps, ∞, -138 dB to +10 dB
On	On/Off
DCA Group	8 Groups
Mute Group	8 Groups
Mix Send	24 sends
	Fix/Variable can be set each two mixes
	Mix Send Point: Pre EQ/Pre Fader/Post On/Post TO ST
	Level: 1024 steps, ∞, -138 dB to +10 dB
LCR Pan	CSR= 0% to 100%
Surround Pan	3-1, 5.1, 6.1 panning support


### Output Function

Function	Parameter
8Band Equalizer (Matrix: 4band)	Frequency= 20 Hz to 20 kHz
	Gain= -18 dB to +18 dB
	Q= 0.10 to 10.0
	Low Shelving (Low Band)
	High Shelving, LPF (High Band)
	Type I/Type II
Insert	Insert Point: Pre EQ/Post EQ/Pre Fader/Post On
Compressor	Type: Comp/Expander/Compannder H/Com- pannder S
	Threshold= -54 dB to 0 dB
	Ratio= 1:1 to ∞:1
	Attack= 0 msec to 120 msec
	Release= 5 msec to 42.3 sec
	Gain= 0 dB to +18 dB
	Knee= Hard to 5 (soft)
Input Delay	Time = 0.0 msec to 1000 msec
Fader	Level: 1024 steps, ∞, -138 dB to +10 dB
On	On/Off
DCA Group	2 Groups
Mute Group	8 Groups
Mix to Matrix Stereo to Matrix	Matrix Send Point: Pre Fader/Post Fader/Post On Level: 1024 steps, ∞, -138 dB to +10 dB
Output Port Att	0 dB to -9 dB

### Processor

Function	Parameter
GEQ	31 bands x 12 systems
Effects	Stereo In/Stereo Out multi effector x 8 systems

# Pin Assignment




## □ CASCADE IN

Pin	Signal	Pin	Signal
1	GND	35	GND
2	Input 1-2(+)	36	Input 1-2(-)
3	Input 3-4(+)	37	Input 3-4(-)
4	Input 5-6(+)	38	Input 5-6(-)
5	Input 7-8(+)	39	Input 7-8(-)
6	Input 9-10(+)	40	Input 9-10(-)
7	Input 11-12(+)	41	Input 11-12(-)
8	Input 13-14(+)	42	Input 13-14(-)
9	Input 15-16(+)	43	Input 15-16(-)
10	DTR In(+)	44	DTR In(-)
11	RTS Out(+)	45	RTS Out(-)
12	GND	46	GND
13	Word Clock In(+)	47	Word Clock In(-)
14	Word Clock Out(+)	48	Word Clock Out(-)
15	Control In(+)	49	Control In(-)
16	Control Out(+)	50	Control Out(-)
17	GND	51	ID6 In
18	GND	52	ID6 Out
19	Input 17-18(+)	53	Input 17-18(-)
20	Input 19-20(+)	54	Input 19-20(-)
21	Input 21-22(+)	55	Input 21-22(-)
22	Input 23-24(+)	56	Input 23-24(-)
23	Input 25-26(+)	57	Input 25-26(-)
24	Input 27-28(+)	58	Input 27-28(-)
25	Input 29-30(+)	59	Input 29-30(-)
26	Input 31-32(+)	60	Input 31-32(-)
27	ID0 In	61	ID1 In
28	ID2 In	62	ID3 In
29	ID4 In	63	ID5 In
30	ID0 Out	64	ID1 Out
31	ID2 Out	65	ID3 Out
32	ID4 Out	66	ID5 Out
33	MSB In	67	2Ch/Line In
34	FG	68	FG


## □ CASCADE OUT

Pin	Signal	Pin	Signal
1	GND	35	GND
2	Output 1-2(+)	36	Output 1-2(-)
3	Output 3-4(+)	37	Output 3-4(-)
4	Output 5-6(+)	38	Output 5-6(-)
5	Output 7-8(+)	39	Output 7-8(-)
6	Output 9-10(+)	40	Output 9-10(-)
7	Output 11-12(+)	41	Output 11-12(-)
8	Output 13-14(+)	42	Output 13-14(-)
9	Output 15-16(+)	43	Output 15-16(-)
10	DTR Out(+)	44	DTR Out(-)
11	RTS In(+)	45	RTS In(-)
12	GND	46	GND
13	Word Clock Out(+)	47	Word Clock Out(-)
14	Word Clock In(+)	48	Word Clock In(-)
15	Control Out(+)	49	Control Out(-)
16	Control In(+)	50	Control In(-)
17	GND	51	ID6 Out
18	GND	52	ID6 In
19	Output 17-18(+)	53	Output 17-18(-)
20	Output 19-20(+)	54	Output 19-20(-)
21	Output 21-22(+)	55	Output 21-22(-)
22	Output 23-24(+)	56	Output 23-24(-)
23	Output 25-26(+)	57	Output 25-26(-)
24	Output 27-28(+)	58	Output 27-28(-)
25	Output 29-30(+)	59	Output 29-30(-)
26	Output 31-32(+)	60	Output 31-32(-)
27	ID0 Out	61	ID1 Out
28	ID2 Out	62	ID3 Out
29	ID4 Out	63	ID5 Out
30	ID0 In	64	ID1 In
31	ID2 In	65	ID3 In
32	ID4 In	66	ID5 in
33	MSB Out	67	2Ch/Line Out
34	FG	68	FG



## □ HA REMOTE

Pin	Signal Name	Pin	Signal Name
1	GND	6	RX+
2	RX-	7	RTS
3	TX-	8	CTS
4	TX+	9	GND
5	N.C		



## □ RS422 REMOTE

Pin	Signal Name	Pin	Signal Name
1	GND	6	GND
2	RX-	7	RX+
3	TX+	8	TX-
4	GND	9	GND
5	N.C		

Information shown  
in the display



Function  
menu

Global  
functions

Output  
functions

Input  
functions

Appendices



**GPI**

Pin	Signal Name	Pin	Signal Name
1	GPO1	14	GPO2
2	GPO3	15	GPO4
3	GPO5	16	GPO6
4	GPO7	17	GPO8
5	GND	18	GND
6	GND	19	GND
7	GND	20	GND
8	GND	21	+5V
9	+5V	22	GPI1
10	GPI2	23	GPI3
11	GPI4	24	GPO9
12	GPO10	25	GPO11
13	GPO12		


**DC POWER INPUT**

Pin	Signal Name	Pin	Signal Name
1	+24V	13	GND
2	+24V	14	GND
3	+24V	15	GND
4	+24V	16	GND
5	+24V	17	GND
6	+24V	18	GND
7	+24V	19	CAUTION(+)
8	+24V	20	CAUTION(-)
9	+24V	21	DETECT A
10	GND	22	DETECT B
11	GND	23	DETECT GND
12	GND	⊕	Frame GND


\* For information on maximum permissible current, refer to the page 351.

## Dimensions

**PM5D**



**PM5D-RH**



Unit: mm

\* Specifications and descriptions in this owner's manual are for information purposes only. Yamaha Corp. reserves the right to change or modify products or specifications at any time without prior notice. Since specifications, equipment or options may not be the same in every locale, please check with your Yamaha dealer.

European models

Purchaser/User Information specified in EN55103-1 and EN55103-2.

Conforms to Environments: E1, E2, E3 and E4

Function...	Transmitted	Recognized	Remarks
Basic Default Channel Changed	1-16 1-16	1-16 1-16	Memorized
Mode Default Messages Altered	X X *****	1, 3 X X	Memorized
Note Number :True Voice	X *****	0-127 X	
Velocity Note On Note Off	X X	0 0	Effect Control
After Key's Touch Ch's	X X	X X	
Pitch Bend	X	X	
Control Change 0,32 6,38 98,99 1-31,33-98, 102-119	0 0 0 0	0 0 0 0	Bank Select Data Entry NRPN LSB,MSB Assignable Cntrl
Prog Change :True#	0 0-127 *****	0 0-127 0-500	Assignable
System Exclusive	0 *1	0 *1	
System Common :Song Pos :Song Sel :Tune	X X X	X X X	
System Real Time :Clock :Commands	X X	0 X	Effect Control
Aux Messages :All Sound Off :Reset All Cntrls :Local ON/OFF :All Notes OFF :Active Sense :Reset	X X X X X X	X X X X 0 0	
Notes	*1: Bulk Dump/Request, Parameter Change/Request, and MMC. For MIDI remote and event, all messages can be transmitted. MTC quarter frame message is recognized.		

Mode 1: OMNI ON, POLY  
Mode 3: OMNI OFF, POLY

Mode 2: OMNI ON, MONO  
Mode 4: OMNI OFF, MONO

0: Yes  
X: No

# Index

## Symbols

∅ .....	59
∅/ATT 1-48 .....	262
∅/ATT STIN/FXRTN.....	262

## Numerics

2TR I/O.....	215
--------------	-----

## A

Accessing a screen .....	23
AD IN section .....	35
Add-On Effects .....	109
Adjusting the input gain (PM5D-RH) .....	148
Adjusting the output gain .....	148
ADVANCED mode .....	193, 196
Analog audio connections .....	27
Analog output connections.....	28
Appendices.....	290
Assign	
ASSIGN MODE section.....	73
Assigning a name.....	26
Assigning MIDI messages .....	117
GEQ ASSIGN .....	157
ATTENUATION.....	59
AUTO CAPTURE.....	162
Auto Store function.....	83

## B

BASIC mode .....	192, 196
Basic operation.....	19
BLANK SKIP.....	160
Block Diagram .....	<b>End of Manual</b>
Boxes .....	19
BPM .....	153
BUSY indicator .....	150
Buttons .....	19, 25

## C

Calibrating the GPI IN ports.....	125
Calibration .....	147
Cascade .....	204
BI-DIRECTION .....	203
Cascade connections.....	143
CASCADE IN PORT SELECT	202
Cascade master.....	143
CASCADE MODE .....	203
CASCADE OUT PORT	
SOURCE SELECT ....	203
Cascade slave.....	144
Source when cascade connected	
.....	202
CASCADE FROM .....	205
CASCADE/Fs.....	149
CH 1-12 .....	267
CH 1-24 .....	258, 270

CH 1-24 layer.....	37
CH 13-24 .....	267
CH 25-36 .....	267
CH 25-48 .....	270
CH 25-48 layer .....	37
CH 37-48 .....	267
CH COPY .....	249, 289
CH to MIX.....	104, 274
CH VIEW .....	245, 286
Channel Library List.....	334
Channel parameter behavior when	
paired .....	335
CHANNEL SELECT.....	58
Channel strip.....	37, 39, 53
INPUT channel .....	37
ST IN/FX RTN channel .....	39
STEREO A/B channel .....	53
Channel structure.....	12
Character palette .....	19
COMP LIBRARY .....	63, 232, 269
COMP LINK ASSIGN....	77, 237, 273
COMP PARAM.....	229, 266
Compressor.....	60, 102
Operations .....	63
Compressor Library List .....	292
Compressor Link.....	77
Connecting to a computer .....	146
Connections .....	27
Analog audio connections.....	27
Analog output connections.....	28
Digital input/output connections	
.....	29
Console Lock.....	142
Control change parameter assign-	
ments.....	314
Control changes .....	115
CSV EXPORT mode.....	193
CSV IMPORT mode .....	197
Cue .....	91
Cue function .....	96
CUE mode .....	94
CUE section .....	91, 94
Cue/Solo functions.....	94
Solo function .....	96
CUE FUNCTION.....	218
CUE/SOLO .....	217
CUE FUNCTION.....	218
INPUT SOLO SAFE .....	219
OUTPUT SOLO SAFE .....	219
SOLO ON/OFF .....	217
Cursor.....	19, 23

## D

Daisy-chain connections.....	31
Data Entry.....	20
DCA.....	73
DCA CUE indicator .....	150
DCA GROUP ASSIGN.....	234, 271
DCA Groups .....	73, 74

DELAY.....	58
Digital input/output connections...	29
Dimensions .....	356
DIMM indicator.....	150
DIRECT OUT PATCH.....	72, 253
DIRECT RECALL.....	151
DIRECT RECALL ASSIGN.....	161
Direct Recall function .....	83
Directly outputting.....	72
DISPLAY ACCESS .....	20, 23
DISPLAY ACCESS section.....	151
Distribution box.....	31
DITHER.....	207
Divergence .....	136
DME CONTROL .....	182
Drag and drop .....	22
Dynamics Parameters .....	294

## E

Effect Library	
Program Change Table .....	308
Effects .....	103
Add-On Effects.....	109
Basic operations.....	106
Editing .....	106
EFFECT ASSIGN.....	154
EFFECT CUE indicator .....	150
EFFECT functions .....	152
EFFECT LIBRARY.....	155
Effect Library List .....	297
EFFECT PARAM	
.....	104, 105, 106, 152
Effects Parameters .....	298
Freeze effect.....	109
Inserting into a channel .....	105
Recalling.....	106
Storing .....	107
Tap Tempo function.....	108
Using via a MIX bus .....	104
Effects and tempo synchronization	
.....	307
Electrical characteristics .....	352
Encoder function.....	41
Encoder mode .....	150
EQ (Equalizer) .....	61, 261
Operations .....	65
EQ Library List .....	290
EQ Link.....	77
EQ LINK ASSIGN .....	77, 236, 272
EQ PARAM.....	225, 260
EQ STIN/FXRTN .....	261
Error Messages .....	344
EVENT indicator.....	150
EVENT LIST .....	161
AUTO CAPTURE .....	162
DISABLE.....	149, 161
ENABLE.....	149, 161
EVENT RECALL .....	162
EVENT TRIGGER.....	162

MOVE DOWN .....	163
MOVE UP .....	162
Events .....	113, 115
Exchanging the fader and encoder functions .....	41
EXTERNAL CUE indicator .....	150
External user interface .....	21

## F

Fade function .....	87
FADE TIME .....	87, 167
FADER ASSIGN .....	197
Fader Assign function .....	139
Fader calibration .....	147
FADER FLIP/ENCODER MODE section .....	40
FADER MODE .....	150, 151
FADER MODE section .....	139
FADER START .....	179
FADER VIEW .....	249, 288
Faders .....	19, 25
FADING indicator .....	150
Features .....	10
FIX ASSIGN VIEW .....	282
FIXED type MIX bus .....	44
FRAME RATE .....	163
Freeze effect .....	109
Front panel .....	18
Function Name .....	149
Function parameters .....	150
FX RTN channels 1–4 .....	34
FX RTN layer .....	39, 151

## G

Gain .....	59
Adjusting .....	148
Gain reduction .....	102
Gate .....	102
Operations .....	64
GATE LIBRARY .....	64, 268
GATE Library List .....	291
GATE PARAM .....	264
GEQ .....	
GEQ ASSIGN .....	157
GEQ function .....	156
GEQ LIBRARY .....	158
GEQ PARAM .....	110, 156
Global .....	20, 151, 152
EFFECT functions .....	152
GEQ function .....	156
METER function .....	209
MIDI REMOTE function .....	171
MON/CUE function .....	212
SCENE function .....	159
SYS/W.CLOCK function .....	199
UTILITY function .....	186
GLOBAL PASTE .....	89, 170
Global Paste function .....	89
GPI .....	177
Calibrating .....	125
General Purpose Interface .....	123
GPI IN .....	123

GPI IN MONITOR .....	178
GPI indicator .....	150
GPI OUT .....	126, 178
TALLY .....	127, 179
USER DEFINED KEYS .....	127
Graphic EQ .....	110
Patching .....	110
Group .....	57
Cue and Solo .....	95
Grouping .....	73
ASSIGN MODE section .....	73
DCA .....	73

## H

HA (Head Amp) .....	36, 206
HA indicator .....	150
HA LIBRARY .....	208, 225, 260
HORIZONTAL PAIR .....	45, 200
HPF (High Pass Filter) .....	61
Operations .....	65

## I

I/O card .....	29
Indicator .....	150
Initializing .....	147
Input .....	20, 151, 252
$\emptyset$ /ATT 1–48 .....	262
$\emptyset$ /ATT STIN/FXRTN .....	262
$\emptyset$ /EQ function .....	260
CH 1–12 .....	267
CH 1–24 .....	258, 270
CH 13–24 .....	267
CH 25–36 .....	267
CH 25–48 .....	270
CH 37–48 .....	267
CH COPY .....	289
CH LIBRARY .....	289
CH to MIX .....	274
CH VIEW .....	286
COMP LIBRARY .....	269
COMP LINK ASSIGN .....	273
COMP PARAM .....	266
DCA GROUP ASSIGN .....	271
DCA/GROUP function .....	271
DELAY function .....	270
DIRECT OUT PATCH .....	253
EQ .....	261
EQ LIBRARY .....	263
EQ LINK ASSIGN .....	272
EQ PARAM .....	260
EQ STIN/FXRTN .....	261
FADER VIEW .....	288
FIX ASSIGN VIEW .....	282
GATE LIBRARY .....	268
GATE PARAM .....	264
GATE/COMP function .....	264
HA LIBRARY .....	260
HA/INSERT function .....	258
INSERT .....	259
INSERT PATCH .....	254
INSERT STIN .....	259
INSERT/DIRECT OUT POINT .....	256
NAME .....	257
INPUT SOLO SAFE .....	219
LCR .....	283

M/S .....	285
MIX SEND VIEW .....	280
MUTE GROUP ASSIGN .....	272
NAME .....	257
PAN/ROUTING function .....	274
PATCH .....	252
PATCH function .....	252
PATCH LIBRARY .....	257
SIGNAL FLOW .....	287
ST IN .....	267, 270
STIN/FXRTN .....	258
SURR PARAM .....	283
SURR VIEW .....	285
VIEW function .....	286
Input a character .....	26
Assigning a name .....	26
INPUT CH layer .....	151
Input channel .....	12, 33, 258, 267, 270
AD IN section .....	35
Channel strip .....	37, 39
FADER FLIP/ENCODER MODE section .....	40
FX RTN channels 1–4 .....	34
Input channels 1–48 .....	33
ST IN channels 1–4 .....	33
INPUT CUE indicator .....	150
INPUT DCA/GROUP function ...	271
COMP LINK ASSIGN .....	273
DCA GROUP ASSIGN .....	271
EQ LINK ASSIGN .....	272
MUTE GROUP ASSIGN .....	272
INPUT DELAY function .....	270
Input Gain Reduction .....	211
INPUT GATE/COMP function ...	264
COMP LIBRARY .....	269
COMP PARAM .....	266
GATE LIBRARY .....	268
GATE PARAM .....	264
Input channel .....	267
ST IN .....	267
INPUT GR .....	102, 211
INPUT HA/INSERT function .....	258
CH 1–24 .....	258
HA LIBRARY .....	260
Input channel .....	258
INSERT .....	259
STIN/FXRTN .....	258
INPUT METER .....	209
INPUT $\emptyset$ /EQ function .....	260
$\emptyset$ /ATT 1–48 .....	262
$\emptyset$ /ATT STIN/FXRTN .....	262
EQ .....	261
EQ PARAM .....	260
EQ STIN/FXRTN .....	261
INPUT EQ LIBRARY .....	263
Input patch .....	66
INPUT PATCH function .....	252
DIRECT OUT PATCH .....	253
INPUT PATCH LIBRARY .....	257
INSERT PATCH .....	254
INSERT/DIRECT OUT POINT .....	256
NAME .....	257
INPUT SOLO SAFE .....	219

- INPUT VIEW function ..... 286  
 CH COPY ..... 289  
 CH VIEW ..... 286  
 FADER VIEW ..... 288  
 INPUT CH LIBRARY ..... 289  
 SIGNAL FLOW ..... 287
- Input/output characteristics ..... 348
- INSERT ..... 259  
 INSERT IN MIX 1-24 ..... 224  
 INSERT PATCH ..... 70, 221, 254  
 INSERT POINT ..... 222  
 INSERT STIN ..... 259  
 INSERT/DIRECT OUT POINT  
 ..... 70, 72, 105, 256
- Inserting  
 External device ..... 69  
 Internal effect into a channel... 105
- Insert-out and insert-in  
 Patching ..... 70
- Internal memory  
 Initializing ..... 147
- K**
- KEY IN CUE indicator ..... 150
- Keyboard ..... 21
- Knobs ..... 19, 25
- L**
- LATCH ..... 176
- Layer ..... 37, 39  
 [CH 1-24]/[CH 25-48] keys ..... 37  
 [ST IN 1-4]/[FX RTN 1-4] keys 39  
 INPUT CH ..... 151  
 ST IN/FX RTN ..... 151
- LCR ..... 242, 283
- LCR [B] indicator ..... 150
- LCR indicator ..... 150
- LEARN ..... 176
- Level Diagram ..... **End of Manual**
- LFE ..... 136
- Library  
 COMP LIBRARY ..... 269  
 EFFECT LIBRARY ..... 155  
 GATE LIBRARY ..... 268  
 GEQ LIBRARY ..... 158  
 HA LIBRARY ..... 225, 260  
 INPUT CH LIBRARY ..... 289  
 INPUT EQ LIBRARY ..... 263  
 INPUT PATCH LIBRARY ..... 257  
 OUTPUT CH LIBRARY ..... 251  
 OUTPUT PATCH LIBRARY.. 223
- Linking ..... 73  
 ASSIGN MODE section ..... 73  
 Compressor Link ..... 77  
 EQ Link ..... 77
- LOAD ..... 195  
 ADVANCED mode ..... 196  
 BASIC mode ..... 196  
 CSV IMPORT mode ..... 197
- Loading ..... 130
- M**
- M/S ..... 285
- Manual organize ..... 13
- MATRIX channels 1-8 ..... 48
- MATRIX section ..... 55
- MATRIX/ST function ..... 238  
 LCR ..... 242  
 MATRIX/ST ROUTING ..... 238  
 MIX to MATRIX VIEW ..... 240  
 SURR SETUP ..... 244
- MATRIX/STEREO ..... 227, 231, 233
- Memory cards ..... 128
- METER function ..... 209  
 INPUT GR ..... 211  
 INPUT METER ..... 209  
 OUTPUT GR ..... 211  
 OUTPUT METER ..... 210
- Meter section ..... 100, 150
- Meters ..... 100  
 Metering point ..... 101
- MIDI ..... 113  
 Assigning MIDI messages ..... 117  
 MIDI events ..... 122  
 MIDI remote channels ..... 121
- MIDI CTRL CHANGE ..... 115, 174
- MIDI Data Format ..... 336
- MIDI EVENT ..... 159
- MIDI Implementation Chart ..... 357
- MIDI indicator ..... 150
- MIDI PGM CHANGE ..... 113, 173
- MIDI REMOTE ..... 117, 175
- MIDI REMOTE function ..... 171  
 DME CONTROL ..... 182  
 FADER START ..... 179  
 GPI ..... 177  
 LATCH ..... 176  
 LEARN ..... 176  
 MMC ..... 180, 181  
 RS422 ..... 180, 181  
 TALLY ..... 179  
 TRANSPORT ..... 181
- MIDI SETUP ..... 171
- mini-YGDAI I/O cards ..... 29
- MIX 1-24 ..... 227, 231, 233
- MIX channel output signals ..... 52
- MIX channels 1-24 ..... 47
- MIX section ..... 49, 150
- MIX SEND VIEW ..... 280
- MIX to MATRIX VIEW ..... 240
- MIXER SETUP ..... 45, 200  
 PAIR MODE ..... 200
- MMC ..... 180, 181
- MON/CUE function ..... 212  
 2TR I/O ..... 215  
 CUE/SOLO ..... 217  
 MONITOR ..... 216  
 OSCILLATOR ..... 213  
 TALKBACK ..... 212
- Monitor ..... 91, 93, 216  
 CUE mode ..... 94  
 SOLO mode ..... 94
- MONITOR sections ..... 91
- Mouse ..... 21
- MOVE DOWN ..... 163
- MOVE UP ..... 162
- MUTE GROUP ASSIGN ..... 235, 272
- Mute Groups ..... 73, 75
- MUTE MASTER ..... 151
- N**
- NAME ..... 257
- NEXT SCENE/NEXT EVENT ..... 149
- NOISE GATE ..... 59
- NRPN parameter assignments ..... 331
- O**
- OFFSET TIME ..... 163
- Operating section ..... 10
- Option card ..... 30  
 types of I/O card ..... 29
- OSC indicator ..... 150
- OSCILLATOR ..... 97, 99, 213
- Output ..... 20, 151, 220  
 CH COPY ..... 249  
 CH LIBRARY ..... 251  
 CH VIEW ..... 245  
 COMP function ..... 229  
 COMP LIBRARY ..... 232  
 COMP LINK ASSIGN ..... 237  
 COMP PARAM ..... 229  
 DCA GROUP ASSIGN ..... 234  
 DCA/GROUP function ..... 234  
 DELAY function ..... 233  
 EQ function ..... 225  
 EQ LIBRARY ..... 228  
 EQ LINK ASSIGN ..... 236  
 EQ PARAM ..... 225  
 FADER VIEW ..... 249  
 HA LIBRARY ..... 225  
 INSERT function ..... 224  
 INSERT IN MATRIX/STE-  
 REO/MONITOR ..... 224  
 INSERT IN MIX 1-24 ..... 224  
 INSERT PATCH ..... 221  
 INSERT POINT ..... 222  
 LCR ..... 242  
 MATRIX/ST function ..... 238  
 MATRIX/ST ROUTING ..... 238  
 MATRIX/STEREO  
 ..... 227, 231, 233  
 MIX 1-24 ..... 227, 231, 233  
 MIX to MATRIX VIEW ..... 240  
 MUTE GROUP ASSIGN ..... 235  
 PATCH ..... 220  
 PATCH function ..... 220  
 PATCH LIBRARY ..... 223  
 SIGNAL FLOW ..... 247  
 SURR SETUP ..... 244  
 VIEW function ..... 245
- Output channel ..... 12, 47  
 Channel strip ..... 53  
 MATRIX channels 1-8 ..... 48  
 MATRIX section ..... 55  
 MIX channels 1-24 ..... 47  
 MIX section ..... 49  
 STEREO A/B channels ..... 47

OUTPUT COMP function .....	229
COMP LIBRARY .....	232
COMP PARAM .....	229
MATRIX/STEREO .....	231
MIX 1-24 .....	231
OUTPUT CUE indicator.....	150
OUTPUT DCA/GROUP function .....	234
.....	234
COMP LINK ASSIGN.....	237
DCA GROUP ASSIGN.....	234
EQ LINK ASSIGN.....	236
MUTE GROUP ASSIGN.....	235
OUTPUT DELAY function .....	233
OUTPUT EQ function .....	225
EQ PARAM .....	225
MATRIX/STEREO .....	227
MIX 1-24 .....	227
OUTPUT EQ LIBRARY .....	228
Output Gain Reduction.....	211
OUTPUT GR.....	102, 211
OUTPUT INSERT function .....	224
HA LIBRARY .....	225
INSERT IN MIX 1-24.....	224
OUTPUT METER.....	210
Output patch .....	67
OUTPUT PATCH function.....	220
INSERT PATCH .....	221
INSERT POINT .....	222
OUTPUT PATCH LIBRARY..	223
OUTPUT PORT ATT .....	207
Output signals from MATRIX .....	56
channels .....	56
OUTPUT SOLO SAFE .....	219
OUTPUT VIEW function .....	245
CH COPY .....	249
CH VIEW .....	245
FADER VIEW .....	249
OUTPUT CH LIBRARY.....	251
SIGNAL FLOW.....	247
Overview of the PM5D.....	10

## P

PAIR MODE.....	45, 200
Pairing .....	
Enabling/disabling.....	45
Pairing MIX channels.....	51
PAN/ROUTING function .....	274
CH to MIX.....	274
FIX ASSIGN VIEW .....	282
LCR .....	283
M/S.....	285
MIX SEND VIEW .....	280
SURR PARAM.....	283
SURR VIEW .....	285
Panels .....	14
Parameter Lock .....	142
Parameters that can be assigned to .....	
control changes.....	312
PASTE MODE .....	89
Patch.....	66
Patching .....	
Insert-out and insert-in .....	70
Pattern .....	136
Phantom power .....	36

Phase.....	59
Pin Assignment .....	355
PM5D, PM5D-RH model.....	11
Pointer .....	19
PREFERENCE 1/2.....	186
PRESENT TIME .....	149
PREVIEW indicator .....	82
PREVIEW mode .....	82
Program changes.....	113

## R

Rear panel .....	16
RECALL SAFE .....	86, 166
Recall Safe function .....	86
Reference section.....	149
Remote control .....	113
Control changes .....	115
MIDI.....	113
MIDI Remote.....	117
MIDI remote channels.....	121
Program changes.....	113
Restoring to the default state.....	32
RS422.....	180, 181
RS422 indicator.....	150

## S

SAVE .....	128, 192
ADVANCED mode .....	193
BASIC mode .....	192
CSV EXPORT mode.....	193
Scene.....	79, 159
Restoring to the default state.....	32
Scene memory.....	79, 149
Auto Store function.....	83
Basic operation.....	81
BLANK SKIP.....	160
DIRECT RECALL ASSIGN.....	161
Direct Recall function.....	83
EVENT LIST .....	161
Fade function .....	87
FADE TIME.....	167
GLOBAL PASTE .....	170
Global Paste function .....	89
GPI OUT CONTROL.....	160
MIDI EVENT.....	159
PREVIEW mode .....	82
Program Change Table.....	308
RECALL SAFE.....	166
Recall Safe function .....	86
Recalling .....	82
REMOTE TRANSPORT.....	160
SCENE.....	159
SCENE FUNCTION.....	160
SCENE function .....	159
SCENE MEMORY section.....	80
SELECTIVE RECALL .....	164
Selective Recall function .....	84
Storing .....	81
TRACKING RECALL.....	169
Tracking Recall function.....	88
Scroll.....	24
Scroll bar.....	20
SECURITY .....	198

Security functions.....	141
Console Lock.....	142
Parameter Lock .....	142
Selected channel .....	57, 150
Editing parameters .....	62
SELECTED CHANNEL section .....	57
Selecting the word clock master .....	31
SELECTIVE RECALL .....	84, 164
Selective Recall function .....	84
Sending signals .....	
from the MATRIX section to .....	
output jacks .....	55
from the STEREO A/B chan- .....	
nels to MATRIX buses .....	54
from the STEREO A/B chan- .....	
nels to output jacks .....	54
to a MIX bus .....	43
to MATRIX buses.....	50
to the STEREO bus.....	42, 51
Setup.....	27
Word clock.....	31
Shown in the display.....	149
SIGNAL FLOW .....	247, 287
Signals sent .....	
to a VARI type MIX bus.....	52
to MATRIX buses.....	56
Solo function.....	96
SOLO indicator .....	150
SOLO mode .....	94
SOLO ON/OFF .....	217
Specifications .....	346
ST IN .....	267, 270
ST IN channels 1-4.....	33
ST IN layer .....	39, 151
START OFFSET button.....	168
START TIME .....	163
STEREO.....	60
STEREO A/B channels.....	47
STEREO B.....	201
STIN/FXRTN.....	258
Surround .....	
SURR PARAM .....	283
SURR SETUP .....	244
SURR VIEW.....	285
Surround mode.....	132, 133, 201
Surround pan.....	132, 201
Divergence .....	136
LFE .....	136
Notes.....	137
Pattern .....	136
Surround buses .....	133
Synchronization .....	12
SYS/W.CLOCK function .....	199
CASCADE.....	204
DITHER.....	207
HA (Head Amp).....	206
HA LIBRARY .....	208
MIXER SETUP .....	200
OUTPUT PORT ATT.....	207
WORD CLOCK .....	199

**T**

- Tabs ..... 19, 150
- TALKBACK ..... 97, 98, 212
- TALKBACK/OSCILLATOR sections  
..... 97
- TALLY ..... 179
- TAP TEMPO
  - BPM..... 153
- Tap Tempo function ..... 108
- Tapping ..... 22
- TB indicator ..... 150
- TIME CODE ..... 149, 163
- TIME CODE SETUP ..... 163
- Top panel..... 14
- TRACKING indicator ..... 150
- TRACKING RECALL..... 88, 169
- Tracking Recall function..... 88
- TRANSPORT ..... 181
- Troubleshooting..... 345

**U**

- USB
  - USB TO HOST connector ..... 146
- USE AS CENTER BUS ..... 201, 216
- USE AS STEREO BUS ..... 201, 216
- USER DEFINE ..... 189
- USER DEFINED KEY BANK..... 151
- USER DEFINED KEYS..... 138, 179
- USER DEFINED section..... 138
- User interface ..... 19
- Using an internal effect via a MIX
  - bus ..... 104
- UTILITY function ..... 186
  - FADER ASSIGN ..... 197
  - LOAD ..... 195
  - PREFERENCE 1/2..... 186
  - SAVE ..... 192
  - SECURITY ..... 198
  - USER DEFINE ..... 189


**V**

- VARI type MIX bus ..... 44
- VERTICAL PAIR ..... 45, 200


**W**

- Warning Messages..... 343
- Word clock ..... 12, 31, 199

# PM5D/PM5D-RH Block Diagram




# PM5D Level Diagram



[0dBu = 0.775Vrms]  
 [0dBFS = Full Scale]

# PM5D-RH Level Diagram



[0dBu = 0.775Vrms]  
 [0dBFS = Full Scale]

For details of products, please contact your nearest Yamaha representative or the authorized distributor listed below.

Pour plus de détails sur les produits, veuillez-vous adresser à Yamaha ou au distributeur le plus proche de vous figurant dans la liste suivante.

Die Einzelheiten zu Produkten sind bei Ihrer unten aufgeführten Niederlassung und bei Yamaha Vertragshändlern in den jeweiligen Bestimmungsländern erhältlich.

Para detalles sobre productos, contacte su tienda Yamaha más cercana o el distribuidor autorizado que se lista debajo.

## NORTH AMERICA

### CANADA

**Yamaha Canada Music Ltd.**  
135 Milner Avenue, Scarborough, Ontario,  
M1S 3R1, Canada  
Tel: 416-298-1311

### U.S.A.

**Yamaha Corporation of America**  
6600 Orangethorpe Ave., Buena Park, Calif. 90620,  
U.S.A.  
Tel: 714-522-9011

## CENTRAL & SOUTH AMERICA

### MEXICO

**Yamaha de México S.A. de C.V.**  
Calz. Javier Rojo Gómez #1149,  
Col. Guadalupe del Moral  
C.P. 09300, México, D.F., México  
Tel: 55-5804-0600

### BRAZIL

**Yamaha Musical do Brasil Ltda.**  
Av. Reboucas 2636-Pinheiros CEP: 05402-400  
Sao Paulo-SP, Brasil  
Tel: 011-3085-1377

### ARGENTINA

**Yamaha Music Latin America, S.A.**  
**Sucursal de Argentina**  
Viamonte 1145 Piso2-B 1053,  
Buenos Aires, Argentina  
Tel: 1-4371-7021

### PANAMA AND OTHER LATIN AMERICAN COUNTRIES/ CARIBBEAN COUNTRIES

**Yamaha Music Latin America, S.A.**  
Torre Banco General, Piso 7, Urbanización Marbella,  
Calle 47 y Aquilino de la Guardia,  
Ciudad de Panamá, Panamá  
Tel: +507-269-5311

## EUROPE

### THE UNITED KINGDOM

**Yamaha-Kemble Music (U.K.) Ltd.**  
Sherbourne Drive, Tilbrook, Milton Keynes,  
MK7 8BL, England  
Tel: 01908-366700

### GERMANY

**Yamaha Music Central Europe GmbH**  
Siemensstraße 22-34, 25462 Rellingen, Germany  
Tel: 04101-3030

### SWITZERLAND/LIECHTENSTEIN

**Yamaha Music Central Europe GmbH,**  
**Branch Switzerland**  
Seefeldstrasse 94, 8008 Zürich, Switzerland  
Tel: 01-383 3990

### AUSTRIA

**Yamaha Music Central Europe GmbH,**  
**Branch Austria**  
Schleiergasse 20, A-1100 Wien, Austria  
Tel: 01-60203900

### THE NETHERLANDS

**Yamaha Music Central Europe,**  
**Branch Nederland**  
Clarissenhof 5-b, 4133 AB Vianen, The Netherlands  
Tel: 0347-358 040

## BELGIUM/LUXEMBOURG

**Yamaha Music Central Europe GmbH,**  
**Branch Belgium**  
Rue de Geneve (Genevastraat) 10, 1140 - Brussels,  
Belgium  
Tel: 02-726 6032

## FRANCE

**Yamaha Musique France**  
BP 70-77312 Marne-la-Vallée Cedex 2, France  
Tel: 01-64-61-4000

## ITALY

**Yamaha Musica Italia S.P.A.**  
**Combo Division**  
Viale Italia 88, 20020 Lainate (Milano), Italy  
Tel: 02-935-771

## SPAIN/PORTUGAL

**Yamaha-Hazen Música, S.A.**  
Ctra. de la Coruna km. 17, 200, 28230  
Las Rozas (Madrid), Spain  
Tel: 91-639-8888

## SWEDEN

**Yamaha Scandinavia AB**  
J. A. Wettergrens Gata 1  
Box 30053  
S-400 43 Göteborg, Sweden  
Tel: 031 89 34 00

## DENMARK

**YS Copenhagen Liaison Office**  
Generatorvej 8B  
DK-2730 Herlev, Denmark  
Tel: 44 92 49 00

## NORWAY

**Norsk filial av Yamaha Scandinavia AB**  
Grini Næringspark 1  
N-1345 Østerås, Norway  
Tel: 67 16 77 70

## OTHER EUROPEAN COUNTRIES

**Yamaha Music Central Europe GmbH**  
Siemensstraße 22-34, 25462 Rellingen, Germany  
Tel: +49-4101-3030

## AFRICA

**Yamaha Corporation,**  
**Asia-Pacific Music Marketing Group**  
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650  
Tel: +81-53-460-2313

## MIDDLE EAST

### TURKEY/CYPRUS

**Yamaha Music Central Europe GmbH**  
Siemensstraße 22-34, 25462 Rellingen, Germany  
Tel: 04101-3030

### OTHER COUNTRIES

**Yamaha Music Gulf FZE**  
LB21-128 Jebel Ali Freezone  
P.O.Box 17328, Dubai, U.A.E.  
Tel: +971-4-881-5868

## ASIA

### THE PEOPLE'S REPUBLIC OF CHINA

**Yamaha Music & Electronics (China) Co.,Ltd.**  
25/F., United Plaza, 1468 Nanjing Road (West),  
Jingan, Shanghai, China  
Tel: 021-6247-2211

### INDONESIA

**PT. Yamaha Music Indonesia (Distributor)**  
**PT. Nusantik**  
Gedung Yamaha Music Center, Jalan Jend. Gatot  
Subroto Kav. 4, Jakarta 12930, Indonesia  
Tel: 21-520-2577

### KOREA

**Yamaha Music Korea Ltd.**  
Tong-Yang Securities Bldg. 16F 23-8 Yoido-dong,  
Youngdungpo-ku, Seoul, Korea  
Tel: 02-3770-0660

### MALAYSIA

**Yamaha Music Malaysia, Sdn., Bhd.**  
Lot 8, Jalan Perbandaran, 47301 Kelana Jaya,  
Petaling Jaya, Selangor, Malaysia  
Tel: 3-78030900

### SINGAPORE

**Yamaha Music Asia Pte., Ltd.**  
#03-11 A-Z Building  
140 Paya Lebor Road, Singapore 409015  
Tel: 747-4374

### TAIWAN

**Yamaha KHS Music Co., Ltd.**  
3F, #6, Sec.2, Nan Jing E. Rd. Taipei.  
Taiwan 104, R.O.C.  
Tel: 02-2511-8688

### THAILAND

**Siam Music Yamaha Co., Ltd.**  
891/1 Siam Motors Building, 15-16 floor  
Rama 1 road, Wangmai, Pathumwan  
Bangkok 10330, Thailand  
Tel: 02-215-2626

### OTHER ASIAN COUNTRIES

**Yamaha Corporation,**  
**Asia-Pacific Music Marketing Group**  
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650  
Tel: +81-53-460-2317

## OCEANIA

### AUSTRALIA

**Yamaha Music Australia Pty. Ltd.**  
Level 1, 99 Queensbridge Street, Southbank,  
Victoria 3006, Australia  
Tel: 3-9693-5111

### COUNTRIES AND TRUST TERRITORIES IN PACIFIC OCEAN

**Yamaha Corporation,**  
**Asia-Pacific Music Marketing Group**  
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650  
Tel: +81-53-460-2313

**HEAD OFFICE** Yamaha Corporation, Pro Audio & Digital Musical Instrument Division  
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650  
Tel: +81-53-460-2441



Yamaha Manual Library  
<http://www2.yamaha.co.jp/manual/english/>